



### EDI MODEL 2010ECL CONFLICT MONITOR

#### PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



- NOTES:
- CARD IS PROVIDED WITH ALL DIODE JUMPERS IN PLACE. REMOVAL OF ANY JUMPER ALLOWS ITS CHANNELS TO RUN CONCURRENTLY.
  - MAKE SURE JUMPERS SEL1-SEL5 ARE PRESENT ON THE MONITOR BOARD.

#### NOTES

- TO PREVENT "FLASH-CONFLICT" PROBLEMS, INSERT RED FLASH PROGRAM BLOCKS FOR ALL UNUSED VEHICLE LOAD SWITCHES IN THE OUTPUT FILE. THE INSTALLER SHALL VERIFY THAT SIGNAL HEADS FLASH IN ACCORDANCE WITH THE SIGNAL PLANS.
- ENSURE THAT RED ENABLE IS ACTIVE AT ALL TIMES DURING NORMAL OPERATION. TO PREVENT RED FAILURES ON UNUSED MONITOR CHANNELS, TIE UNUSED RED MONITOR INPUTS 3,5,7, 9,10,11,12,13,14,15 & 16 TO LOAD SWITCH AC+ PER THE CABINET MANUFACTURER'S INSTRUCTIONS.
- PROGRAM CONTROLLER TO START UP IN PHASES 2 AND 6 GREEN.
- ENABLE SIMULTANEOUS GAP-OUT FEATURE, ON CONTROLLER UNIT, FOR ALL PHASES.
- PROGRAM PHASES 4 AND 8, ON CONTROLLER UNIT, FOR DUAL ENTRY.

#### FIELD CONNECTION HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S2P	S3	S4	S4P	S5	S6	S6P	S7	S8	S8P	S9	S10	S11	S12	S13	S14
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	61	21,22	NU	NU	41,42	NU	NU	61,62	NU	NU	81,82	NU	NU	NU	NU	NU	NU	NU
GREEN		130			103			136			109							
YELLOW		129			102			135			108							
RED	*	128			101			134			107							
RED ARROW																		
YELLOW ARROW	126																	
GREEN ARROW	127																	

NU = NOT USED  
 \* DENOTES INSTALL LOAD RESISTOR. SEE LOAD RESISTOR INSTALLATION DETAIL THIS PAGE.

#### EQUIPMENT INFORMATION

CONTROLLER.....CONTRACTOR SUPPLIED 2070L  
 CABINET .....CONTRACTOR SUPPLIED 332  
 SOFTWARE .....ECONOLITE OASIS  
 CABINET MOUNT.....BASE  
 OUTPUT FILE POSITIONS..18 (12-STD, 6-AUX)  
 LOAD SWITCHES USED.....S1,S2,S4,S6,S8  
 PHASES USED.....1,2,4,6,8  
 OVERLAPS.....NONE

#### BACK-UP PROTECTION PROGRAMMING DETAIL

(program controller as shown below)


- FROM MAIN MENU PRESS '2' (PHASE CONTROL), THEN '1' (PHASE CONTROL FUNCTIONS). SCROLL TO THE BOTTOM OF THE MENU AND ENABLE DYNAMIC/BACKUP CONTROL FUNCTION 1.
- FROM PHASE CONTROL FUNCTIONS MENU PRESS '2' (DYNAMIC/BACKUP CONTROL FUNCTIONS).

DYNAMIC/BACKUP CONTROL FUNCTION #01  
 OVERLAPS: ABCDEFGHIJKLMNPO  
 IF OVERLAPS ARE ACTIVE:  
 OR PHASES: 12345678910111213141516  
 IF PHASES ARE ON: X  
 OMIT PHASES : X  
 CALL PHASES : X

BACKUP PROTECTION PROGRAMMING COMPLETE

#### INPUT FILE POSITION LAYOUT

(front view)




EX. : 1A, 2A, ETC. = LOOP NO.'S  
 FS = FLASH SENSE  
 ST = STOP TIME


#### INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
1A	TB2-5,6	I2U	39	1	2	1	Y	Y			10
2A	TB4-1,2	I4U	47	9	22	2	Y	Y			
4A	TB6-1,2	I7U	65	27	34	4	Y	Y			10
4B	TB6-3,4	I7L	78	40	44	4	Y	Y			15
6A	TB3-9,10	J3U	64	26	36	6	Y	Y			
8A	TB7-1,2	J7U	66	28	38	8	Y	Y			10

INPUT FILE POSITION LEGEND: J2L



#### LOAD RESISTOR INSTALLATION DETAIL



NOTE: THE PURPOSE OF THIS RESISTOR IS TO LOAD THE CHANNEL RED MONITOR INPUT IN ORDER FOR THE SIGNAL SEQUENCE MONITOR TO USE THE FULL SIGNAL SEQUENCE MONITORING CAPABILITY ON CHANNELS THAT DO NOT USE THE RED DISPLAY IN THE FIELD.

#### SIGNAL UPGRADE: PHASE II TEMPORARY DESIGN 1

ELECTRICAL AND PROGRAMMING DETAILS FOR: Prepared in the Office of:  122 N. McDowell St., Raleigh, NC 27603	SR 1141 (BINGHAM RD.)/ HOPE MILLS BYPASS AT SR 1107 (FISHER RD.)/GAS STATION	SEAL 
	DIVISION 6 CUMBERLAND COUNTY HOPE MILLS PLAN DATE: OCTOBER 2003 REVIEWED BY: T. Vajda PREPARED BY: WILLIAM HAIRSTON REVIEWED BY:	REVISIONS INIT. DATE