	COM MAIN MENU SELECT CONFIGURATION CONTROLLER SEQ PHASE IN USE/PED LOAD SW ASSIGN PORT 1 (SDLC) PRESS KEYS 1.	ON SUBMENU 5. COMMUNICATIONS 6. ENABLE LOGGING 7. DISPLAY/ACCESS 8. LOGIC PROCESSOR	<u>TE ASC/</u> (program
	CONFIGURATIO CONTROLLER SEQ PHASE IN USE/PED LOAD SW ASSIGN PORT 1 (SDLC) PRESS KEYS 1.	ON SUBMENU 5. COMMUNICATIONS 6. ENABLE LOGGING 7. DISPLAY/ACCESS 8. LOGIC PROCESSOR	
2 3 4	<ul> <li>PHASE IN USE/PED</li> <li>LOAD SW ASSIGN</li> <li>PORT 1 (SDLC)</li> <li>PRESS KEYS 1.</li> </ul>	6. ENABLE LOGGING 7. DISPLAY/ACCESS 8. LOGIC PROCESSOR	_
		.8 TO SELECT	
	• • • • =		
	CAUT	ION!	
ιc		ash before attempting	
This	s programming and tha card must match exac	MMU programming data. at of the MMU programming tly. If they do not, the placed into Flash.	
rom Main Menu select 2 (CON)		From Controller Sub select 2	
MAIN	MENU	CONTROLLER	SUBMENU
1. CONFIGURATION	6. DETECTORS	1. TIMING PLANS	5. START
CONTROLLER	<ul><li>7. STATUS DISPLAY</li><li>8. UTILITIES</li></ul>	3. VEHICLE OVERLAPS	6. OPTIC 7. PRE-1
• PREEMPTOR/TSP	9. DIAGNOSTICS	4. GUAR MIN TIME	8. PHASE
TIME BASE			
PRESS KEYS 1	9 TO SELECT	PRESS KEYS 1.	8 TO SELEC
	PEDESTRIAN SI		





