
LOGICAL I/O PROCESSOR PROGRAMMING DETAIL


TO PRODUCE SPECIAL FYA-PPLT SIGNAL SEQUENCE

(program controller as shown below)

- 1. From Main Menu press '2' (PHASE CONTROL), then '1' (PHASE CONTROL FUNCTIONS). Scroll to the bottom of the menu and Enable ACT Logic Commands 1, 2, 3 and 4.
- 2. From Main Menu press '6' (OUTPUTS), then '3' (LOGICAL I/O PROCESSOR).




LOGIC I/O PROCESSOR PROGRAMMING COMPLETE




OVERLAP PROGRAMMING DETAIL

(program controller as shown below)

From Main Menu press '8' (OVERLAPS), then '1' (VEHICLE OVERLAP SETTINGS).





PAGE 1: VEHICLE OVERLAP 'E' SETTINGS PHASE: 12345678910111213141516 VEH OVL PARENTS: X VEH OVL NOT VEH: VEH OVL NOT PED: X VEH OVL GRN EXT: STARTUP COLOR: _ RED _ YELLOW _ GREEN FLASH COLORS: _ RED _ YELLOW _ GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N) FLASH YELLOW IN CONTROLLER FLASH?N GREEN EXTENSION (0-255 SEC)0 YELLOW CLEAR (0=PARENT,3-25.5 SEC)0.0 RED CLEAR (0=PARENT,0.1-25.5 SEC)0.0 OUTPUT AS PHASE # (0=NONE, 1-16)3

OVERLAP PROGRAMMING COMPLETE

DYNAMIC BACK-UP CONTROL PROGRAMMING

(program controller as shown below)


- 1. From Main Menu press '2' (Phase Control), then '1' (Phase Control Functions). Scroll to the bottom of the menu and enable Dynamic/Backup Control Function 1.
- 2. From Phase Control Functions Menu press '2' (Dynamic/Backup Control Functions).

DYNAMIC/BACKUP CONTROL FUNCTION #01 OVERLAPS: | ABCDEFGHIJKLMNOP IF OVERLAPS ARE ACTIVE ; PHASES: 12345678910111213141516 IF PHASES ARE ON! OMIT PHASES ¦ X CALL PHASES

BACKUP PROTECTION PROGRAMMING COMPLETE

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 09-0735 DESIGNED: May 2015 SEALED: 07/01/2015 REVISED: N/A

Electrical Detail - Sheet 2 of 2



NC 8 (Winston Road) I-85 Bus./US 29 SB-US 64-70 WB Ramp

Division 9		Davidso	n County	Lexington
PLAN DATE:	June		REVIEWED BY:	Lexington
PREPARED BY: C	Stri	ckland	REVIEWED BY:	

REVISIONS

INIT. DATE

SEAL

SIG. INVENTORY NO. 09-0735