EMERGENCY VEHICLE PREEMPTION PROGRAMMING DETAIL


(program controller as shown below)

From Main Menu press 'A' (Preemption), then '1' (Standard Preemptions). Press 'NEXT' to advance to Preemption #2.

| PREEMPTION #2 SETTINGS (NEXT:1-10) INTERVAL/TIMING CLEAR/DWELL PHASES GRN YEL RED 1234567891011121314151 1 255 4.0 1.7 X X 2 0 0.0 0.0 3 0 0.0 0.0 4 0 0.0 0.0 5 1 0.0 0.0 X X | 6 |
|--|--------|
| S 1 0.0 1.X X EXIT CALLS . . OPTIONS PRIORITY (Y/N TO SELECT) | 0 0 |

* Denotes timing to be determined in field.

USING PREEMPT CONTROL BOX



| El |
|------|
| ELEC |
| |