OVERLAP PROGRAMMING DETAIL

(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS), THEN '1' (VEHICLE OVERLAP SETTINGS).

PAGE 1: VEHICLE OVERLAP 'A' SETTINGS
PHASE: | 12345678910111213141516
VEH OVL PARENTS: | XX
VEH OVL NOT VEH: |
VEH OVL NOT PED: |
VEH OVL GRN EXT: |
STARTUP COLOR: _ RED _ YELLOW _ GREEN
FLASH COLORS: _ RED _ YELLOW X GREEN

SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC).......
YELLOW CLEAR (0=PARENT,3-25.5 SEC).....
OUTPUT AS PHASE # (0=NONE, 1-16)....

PRESS '+'

PAGE 1: VEHICLE OVERLAP 'B' SETTINGS
PHASE: | 12345678910111213141516

VEH OVL PARENTS: | XX

VEH OVL NOT VEH: |
VEH OVL NOT PED: |
VEH OVL GRN EXT: |
STARTUP COLOR: _ RED _ YELLOW _ GREEN
FLASH COLORS: _ RED _ YELLOW X GREEN

SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...N
GREEN EXTENSION (0-255 SEC)......0
YELLOW CLEAR (0=PARENT,3-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)...0

PRESS '+'

PAGE 1: VEHICLE OVERLAP 'C' SETTINGS
PHASE: | 12345678910111213141516
VEH OVL PARENTS: | XX
VEH OVL NOT VEH: |
VEH OVL NOT PED: |
VEH OVL GRN EXT: |
STARTUP COLOR: _ RED _ YELLOW _ GREEN
FLASH COLORS: _ RED _ YELLOW X GREEN

SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC).......
YELLOW CLEAR (0=PARENT, 3-25.5 SEC)......
OUTPUT AS PHASE # (0=NONE, 1-16)....

PRESS '+'

PAGE 1: VEHICLE OVERLAP 'D' SETTINGS
PHASE: |12345678910111213141516
VEH OVL PARENTS: |X X
VEH OVL NOT VEH: |
VEH OVL NOT PED: |
VEH OVL GRN EXT: |
STARTUP COLOR: _ RED _ YELLOW _ GREEN
FLASH COLORS: _ RED _ YELLOW X GREEN

SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...N
GREEN EXTENSION (0-255 SEC)..........0
YELLOW CLEAR (0=PARENT, 3-25.5 SEC).........0
RED CLEAR (0=PARENT, 0.1-25.5 SEC)...........0

OVERLAP PROGRAMMING COMPLETE

OUTPUT AS PHASE # (0=NONE, 1-16)....0

LOGICAL I/O PROCESSOR PROGRAMMING

TO DISABLE SPECIAL FYA-PPLT SIGNAL SEQUENCE

(program controller as shown below)

1. FROM MAIN MENU PRESS '2' (PHASE CONTROL), THEN '1' (PHASE CONTROL FUNCTIONS). SCROLL TO THE BOTTOM OF THE MENU AND DISABLE ACT LOGIC COMMANDS 1, 2, 3, 4, 5, 6, 7, 8, and 9.

FLASHER CIRCUIT MODIFICATION DETAIL

IN ORDER TO INSURE THAT SIGNALS FLASH CONCURRENTLY ON THE SAME APPROACH, MAKE THE FOLLOWING FLASHER CIRCUIT CHANGES:


- 1. ON REAR OF PDA REMOVE WIRE FROM TERM, T2-4 AND TERMINATE ON T2-2.
- 2. ON REAR OF PDA REMOVE WIRE FROM TERM. T2-5 AND TERMINATE ON T2-3.
- 3. REMOVE FLASHER UNIT 2.

THE CHANGES LISTED ABOVE TIES ALL PHASES AND OVERLAPS TO FLASHER UNIT 1.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: Ø3-Ø6Ø5 DESIGNED: June 2Ø14 SEALED: December 19, 2Ø14 REVISED:

Signal Upgrade - Final Design (Electrical Detail Sheet 2 of 2)

REVISIONS



SR 1175 (Kerr Avenue) at Randall Parkway

Division 03 New Hanover County Wilmington
PLAN DATE: June 2014 REVIEWED BY: LM Moon
PREPARED BY:AM Encarnacion REVIEWED BY: MB Toth

TE Docusigned by:

12/

Melissa B. Toth

ATKINS 1616 EAST MILLBROOK ROAD, SUITE 310 RALEIGH, NORTH CAROLINA 27609 (919) 876-6888 NCBEES #F-0326