



### EDI MODEL 2018ECLip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



**NOTES:**

1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
3. Ensure that Red Enable is active at all times during normal operation.
4. Integrate monitor with Ethernet network in cabinet.

### NOTES

1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
2. Return controller to Factory Defaults before programming per this electrical detail.
3. Program controller to start up in phase 2 Green and 6 Green.
4. The cabinet and controller are part of the Fayetteville Signal System.

### EQUIPMENT INFORMATION

CONTROLLER.....2070  
 CABINET.....332 W/AUX  
 SOFTWARE.....ECONOLITE ASC/3-2070  
 CABINET MOUNT.....BASE  
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE  
 LOAD SWITCHES USED.....S1,S2,S5,S7,S8,S11  
 PHASES USED.....1,2,4,5,6,8  
 OVERLAP A.....NOT USED  
 OVERLAP B.....NOT USED  
 OVERLAP C.....NOT USED  
 OVERLAP D.....NOT USED

### SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	11	21,22	NU	NU	41,42	NU	51	61,62	NU	NU	81,82	NU	NU	NU	NU	NU	NU	NU
RED		128			101			134			107							
YELLOW		129			102			135			108							
GREEN		130			103			136			109							
RED ARROW	125							131										
YELLOW ARROW	126							132										
GREEN ARROW	127							133										

NU = Not Used


★ See pictorial of head wiring in detail below.

### DETECTOR NOTES

1. For all loops install a video detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.
2. Remove "Wired Inputs" from rear of input file to prevent unwanted calls to Phases 2 and 6.

### INPUT FILE POSITION LAYOUT

(front view)




EX.: 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE  
ST = STOP TIME

### SIGNAL WIRING DETAIL


(wire signal heads as shown)



THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0592T3  
 DESIGNED: March 2018  
 SEALED: 03-29-2018  
 REVISED: N/A

### LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown)



### Temporary Design 3 - TMP Phase III Electrical Detail

<p>Stantec Consulting Services Inc.                  801 Jones Franklin Road-Suite 300                  Raleigh, NC 27606                  Tel. (919) 851-6866                  Fax. (919) 851-7024                  www.stantec.com                  License No. F-0672</p>	ELECTRICAL AND PROGRAMMING DETAILS FOR: Prepared in the Offices of: 	US 401 (Raeford Road) at Revere Street/ Time Warner Cable Driveway Division 6 Cumberland County Fayetteville	SEAL 
	PLAN DATE: March 2018 PREPARED BY: G B Spell www.stantec.com License No. F-0672	REVIEWED BY: L Overn REVIEWED BY:	REVISIONS INIT. DATE