

DocuSign Envelope ID: EDEA80FB-80A3-45F4-B6C8-CD80310DC6C8

DYNAMIC BACK-UP CONTROL PROGRAMMING	
(program controller as shown below)	
<ol> <li>From Main Menu press '2' (Phase Control), then '1' (Phase Control Functions). Scroll to the bottom of the menu and enable Dynamic/Backup Control Function 1.</li> </ol>	FROM MAIN MENU PRESS '8' '1' (VEHICLE OVERLAP SETT
2. From Phase Control Functions Menu press '2' (Dynamic/Backup Control Functions). DYNAMIC/BACKUP CONTROL FUNCTION #01 OVERLAPS: ABCDEFGHIJKLMNOP IF OVERLAPS ARE ACTIVE ; OR PHASES: 12345678910111213141516 IF PHASES ARE ON ; X OMIT PHASES ; X CALL PHASES ; X CALL PHASES ;	PAGE 1: VEHICLE OVERLAP 'A' SE PHASE:  1234567891011' VEH OVL PARENTS:   X VEH OVL NOT VEH:   VEH OVL NOT PED:   VEH OVL GRN EXT:   STARTUP COLOR: _ RED _ YELLOW FLASH COLORS: _ RED _ YELLOW SELECT VEHICLE OVERLAP OPTIONS: FLASH YELLOW IN CONTROLLER FLAS GREEN EXTENSION (0-255 SEC) YELLOW CLEAR (0=PARENT,3-25.5 SE OUTPUT AS PHASE # (0=NONE, 1-16 PRES PAGE 1: VEHICLE OVERLAP 'B' SE PHASE:  1234567891011' VEH OVL PARENTS:   XX VEH OVL NOT VEH:   VEH OVL NOT VEH:   VEH OVL NOT PED:   VEH OVL GRN EXT:   STARTUP COLOR: _ RED _ YELLOW FLASH COLORS: _ RED _ YELLOW SELECT VEHICLE OVERLAP OPTIONS:
	FLASH YELLOW IN CONTROLLER FLAS GREEN EXTENSION (0-255 SEC) YELLOW CLEAR (0=PARENT,3-25.5 SE OUTPUT AS PHASE # (0=NONE, 1-16 PRE
	<u></u>
	IN ORE SAME A
	1. ON REAR OF 2. ON REAR OF 3. REMOVE FLA
	THE CHANGES L
OUTPUT REFERENCE SCHEDULEUSE TO INTERPRET LOGIC PROCESSOROUTPUT 42 = Overlap C RedOUTPUT 43 = Overlap C YellowOUTPUT 44 = Overlap C GreenOUTPUT 47 = Overlap B RedOUTPUT 48 = Overlap B YellowOUTPUT 49 = Overlap B Green	
	E 1 ELEC
	Prepared by
	URS Corporation – North Carolina 1600 Perimeter Park Drive Morrisville, North Carolina 27560 TELEPHONE (919) 461-1100 FAX (919) 461-1415 NC LICENSE # C-2243 750 M

