


LOGICAL I/O PROCESSOR PROGRAMMING D

TO PRODUCE SPECIAL FYA-PPLT SIGNAL S

(program controller as shown below)

- 1. FROM MAIN MENU PRESS '2' (PHASE CONTROL), THEN '1' (PH CONTROL FUNCTIONS). SCROLL TO THE BOTTOM OF THE MENU ENABLE ACT LOGIC COMMANDS 1, 2 AND 3.
- 2. FROM MAIN MENU PRESS '6' (OUTPUTS), THEN '3' (LOGICAL PROCESSOR).





<u>DETAIL</u> EQUENCE	<u>OVERLAP</u> (program
HASE	FROM MAIN MENU PRESS '8' (OVERLAPS) '1' (VEHICLE OVERLAP SETTINGS).
Ι/Ο	PAGE 1: VEHICLE OVERLAP 'A' SETTINGS PHASE: 12345678910111213141516 VEH OVL PARENTS: X VEH OVL NOT VEH: VEH OVL NOT PED: VEH OVL GRN EXT: STARTUP COLOR: _ RED _ YELLOW _ GREEN FLASH COLORS: _ RED _ YELLOW X GREEN
E: LOGIC FOR PHASE 3 RED CLEAR WHEN TRANSITIONING FROM PHASE 3	SELECT VEHICLE OVERLAP OPTIONS: (Y/N) FLASH YELLOW IN CONTROLLER FLASH?Y GREEN EXTENSION (0-255 SEC)0 YELLOW CLEAR (0=PARENT,3-25.5 SEC)0.0 RED CLEAR (0=PARENT,0.1-25.5 SEC)0.0 OUTPUT AS PHASE # (0=NONE, 1-16)0 PRESS '+'
TO PHASE 4 (HEAD 31).	PAGE 1: VEHICLE OVERLAP 'B' SETTINGS PHASE: 12345678910111213141516 VEH OVL PARENTS: XX VEH OVL NOT VEH: VEH OVL NOT VEH: VEH OVL NOT PED: VEH OVL GRN EXT: VEH OVL GRN EXT: VEH OVL GREEN
: LOGIC FOR SWITCHING FLASHING YELLOW ARROW "OFF"	<pre>FLASH COLORS: _ RED _ YELLOW X GREEN SELECT VEHICLE OVERLAP OPTIONS: (Y/N) FLASH YELLOW IN CONTROLLER FLASH?N GREEN EXTENSION (0-255 SEC)00 YELLOW CLEAR (0=PARENT,3-25.5 SEC)0.0 RED CLEAR (0=PARENT,0.1-25.5 SEC)0.0 OUTPUT AS PHASE # (0=NONE, 1-16)0</pre>
DURING PHASE 3 (HEAD 31).	PRESS '+' TWICE
: LOGIC FOR YELLOW ARROW CLEARANCE	FLASHER CIF
FROM PHASE 3 (HEAD 31).	IN ORDER TO INSURE Same approach, make
	1. ON REAR OF PDA - REMOVE 2. ON REAR OF PDA - REMOVE 3. REMOVE FLASHER UNIT 2.
	THE CHANGES LISTED ABOVE TI
RATION	Fina Elec ELECTRIC
ng only during user's manual	Prepared by TCRSS URS Corporation – North Carolina 1600 Perimeter Park Drive Morrisville, North Carolina 27560 TELEPHONE (919) 461-1100 FAX (919) 461-1415 NC LICENSE * C-2243 750 N.Gree

