



SCHOOL FLASHER (23)
(wire flasher as shown below)



SCHOOL FLASHER (63)
(wire flasher as shown below)



IMPORTANT

1. Ensure that the white keyed plug located behind rear panel of output file labeled 2PY-4PY-6PY-8PY is disconnected. This will disconnect conflict monitor wires from field signal terminals 114 and 105 shown on flasher wiring detail above.
2. To activate school zone flasher operation as indicated on the signal plan, program outputs 33 and 35 as shown on this sheet.
3. Operational times and dates are determined by the DTE. See this sheet for the scheduling programming detail.

EVENT #1 SCHEDULING (AM)
SCHOOL FLASHER PROGRAMMING DETAIL
(program controller as shown below)

FROM MAIN MENU PRESS 'B' (SCHEDULING).

```

SCHEDULED EVENT #1      NOT ASSIGNED*
START DATE (MM/DD).....**/**
END DATE (MM/DD).....**/**
START TIME (HH:MM).....**/**
STOP TIME (HH:MM).....**/**
DOW   1SUN MON TUE WED THR FRI SAT
ENABLED 1  X  X  X  X  X  X
EVENT GROUPS 12345678910111213141516
ASSIGNED

DELETE EVENT WHEN COMPLETED?.....N
CONTINUOUS EVENT?.....N
INVERT EVENT?.....N
SELECT 1 EVENT TYPE:
EVENT GROUP (1-16).....
PLAN (65=FLSH,66=FREE).. OFFSET#...
PLAN PRIORITY: LOW.. MED.. HIGH..
CHANGE PHASE SEQUENCE PAGE (1-12)...
CHANGE PHASE TIMING PAGE (1-4)...
CHANGE PHASE CONTROL PAGE (1-4)...
CHANGE OVERLAP CONTROL PAGE (1-4)...
CHANGE INPUT PAGE (1-4)...
CHANGE OUTPUT PAGE (1-4)...
SET OUTPUT ON (1-64).....33
SET OUTPUT OFF (1-64).....
SET INPUT ON (1-64).....
SET INPUT OFF (1-64).....
ENABLE FAILURES LOG?.....
ENABLE EVENTS LOG?.....
ENABLE DATA ENTRIES LOG?.....
ENABLE COORDINATION PLANS LOG?.....
ENABLE SPECIAL FUNCTIONS LOG?.....
ENABLE SPLIT MONITOR LOG?.....
ENABLE DETECTOR DATA LOG?.....
ENABLE DETECTOR (1-64).....
ENABLE DETECTOR DIAGNOSTICS (1-64)...
ENABLE DET STRETCH / DELAY (1-64)...
ENABLE DET STOP BAR MODE (1-64)...
SET LOGIC FLAG ON (1-16).....
SET LOGIC FLAG OFF (1-64).....
OVERRIDE PHASE CONTROL FUNCTIONS?...
    
```

EVENT #2 SCHEDULING (PM)
SCHOOL FLASHER PROGRAMMING DETAIL
(program controller as shown below)

FROM MAIN MENU PRESS 'B' (SCHEDULING).

```

SCHEDULED EVENT #2      NOT ASSIGNED*
START DATE (MM/DD).....**/**
END DATE (MM/DD).....**/**
START TIME (HH:MM).....**/**
STOP TIME (HH:MM).....**/**
DOW   1SUN MON TUE WED THR FRI SAT
ENABLED 1  X  X  X  X  X  X
EVENT GROUPS 12345678910111213141516
ASSIGNED

DELETE EVENT WHEN COMPLETED?.....N
CONTINUOUS EVENT?.....N
INVERT EVENT?.....N
SELECT 1 EVENT TYPE:
EVENT GROUP (1-16).....
PLAN (65=FLSH,66=FREE).. OFFSET#...
PLAN PRIORITY: LOW.. MED.. HIGH..
CHANGE PHASE SEQUENCE PAGE (1-12)...
CHANGE PHASE TIMING PAGE (1-4)...
CHANGE PHASE CONTROL PAGE (1-4)...
CHANGE OVERLAP CONTROL PAGE (1-4)...
CHANGE INPUT PAGE (1-4)...
CHANGE OUTPUT PAGE (1-4)...
SET OUTPUT ON (1-64).....33
SET OUTPUT OFF (1-64).....
SET INPUT ON (1-64).....
SET INPUT OFF (1-64).....
ENABLE FAILURES LOG?.....
ENABLE EVENTS LOG?.....
ENABLE DATA ENTRIES LOG?.....
ENABLE COORDINATION PLANS LOG?.....
ENABLE SPECIAL FUNCTIONS LOG?.....
ENABLE SPLIT MONITOR LOG?.....
ENABLE DETECTOR DATA LOG?.....
ENABLE DETECTOR (1-64).....
ENABLE DETECTOR DIAGNOSTICS (1-64)...
ENABLE DET STRETCH / DELAY (1-64)...
ENABLE DET STOP BAR MODE (1-64)...
SET LOGIC FLAG ON (1-16).....
SET LOGIC FLAG OFF (1-64).....
OVERRIDE PHASE CONTROL FUNCTIONS?...
    
```

* AFTER PROGRAMMING, THIS SPACE WILL READ 'OUTPUT OVERRIDE'.
/ TIMES AND DATES DETERMINED BY THE DTE.

SCHOOL FLASHER
OUTPUT ASSIGNMENT PROGRAMMING DETAIL
(program controller as shown below)

1. FROM MAIN MENU PRESS '6' (OUTPUTS), THEN '1' (OUTPUT ASSIGNMENTS).
2. WITH CURSOR IN "OUTPUT ASSIGNMENT #" FIELD, USE '+' KEY TO FIND THE OUTPUT ASSIGNMENT NUMBER 33, AS SHOWN BELOW.
3. PROGRAM CONTROLLER AS SHOWN:

```

PAGE:1 C1 PIN:35 NOT ENABLED
OUTPUT ASSIGNMENT #.....33
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...1.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...50
MODE (0=SOLID, 1=FLASH)...1
SELECT ASSIGNMENT:
NOT ENABLED.....Y
VEHICLE PHASE.....
PEDESTRIAN PHASE.....
VEHICLE OVERLAP.....
PEDESTRIAN OVERLAP.....
WATCHDOG.....
DETECTOR RESET.....
ADVANCE BEACON.....
OUT OF PHASE FLASHER.....
CONTROLLER FLASH.....
RUN FREE.....
RESERVED.....
PREEMPT.....
SOFT PREEMPT.....
ANY PREEMPT.....
COORDINATION PLAN.....
PHASE CHECK.....
PHASE ON.....
PHASE NEXT.....
    
```

PRESS '+' KEY FOR OUTPUT ASSIGNMENT 35 (C1 PIN 37)

```

PAGE:1 C1 PIN:37 NOT ENABLED
OUTPUT ASSIGNMENT #.....35
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID, 1=FLASH)...0
SELECT ASSIGNMENT:
NOT ENABLED.....Y
VEHICLE PHASE.....
PEDESTRIAN PHASE.....
VEHICLE OVERLAP.....
PEDESTRIAN OVERLAP.....
WATCHDOG.....
DETECTOR RESET.....
ADVANCE BEACON.....
OUT OF PHASE FLASHER.....
CONTROLLER FLASH.....
RUN FREE.....
RESERVED.....
PREEMPT.....
SOFT PREEMPT.....
ANY PREEMPT.....
COORDINATION PLAN.....
PHASE CHECK.....
PHASE ON.....
PHASE NEXT.....
    
```

```

PAGE:1 C1:37 NOT ENABLED
SELECT OUTPUT ASSIGNMENT (1-64).....33
    
```

DISPLAY WILL NOW SHOW THE SPECIFIED OUTPUT ASSIGNED AS "OUT OF PHASE FLASHER" AS SHOWN BELOW:

```

PAGE:1 C1 PIN:37 OUT OF PHASE FLASHER
OUTPUT ASSIGNMENT #.....35
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID, 1=FLASH)...0
SELECT ASSIGNMENT:
NOT ENABLED.....
VEHICLE PHASE.....
PEDESTRIAN PHASE.....
VEHICLE OVERLAP.....
PEDESTRIAN OVERLAP.....
WATCHDOG.....
DETECTOR RESET.....
ADVANCE BEACON.....
OUT OF PHASE FLASHER.....Y
CONTROLLER FLASH.....
RUN FREE.....
RESERVED.....
PREEMPT.....
SOFT PREEMPT.....
ANY PREEMPT.....
COORDINATION PLAN.....
OFFSET.....
PHASE CHECK.....
PHASE ON.....
PHASE NEXT.....
    
```

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 01-0526
DESIGNED: August 2018
SEALED: 11/20/2018
REVISED:

Electrical Detail - Sheet 3 of 3

Electrical and Programming Details For: SR 1217 (Ocean Bay Boulevard) at Veteran's Drive

Prepared In the Offices of: [Logo] 750 N. Greenfield Pkwy, Garner, NC 27529

Division 1 Dare County Kill Devil Hills
PLAN DATE: November 2018 REVIEWED BY: T. Joyce
PREPARED BY: C. Strickland REVIEWED BY:

REVISIONS INIT. DATE

DocuSigned by: D. Todd Joyce 11/20/2018
SIC. INVENTORY NO. 01-0526

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SEAL: [Signature Seal] SEAL 031001 ENGINEER D. TODD JOYCE

20-Nov-2018 11:55 S:\ITS\ASST\ITS_157_0-SIGNAL\work\hgr\output\sig_Mgmt\strickland\0026_sml_e_xxx.dgn