MAXTIME OVERLAP PROGRAMMING DETAIL FOR DEFAULT PHASING

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

Overlap Plan 1

1	2
FYA 4 - Section	Normal
2	1,8
1	4
4	4
0	0
0.0	0.0
0.0	0.0
	2 1 - 0 0.0

MAXTIME OVERLAP PROGRAMMING DETAIL FOR ALTERNATE PHASING

Front Panel

Main Menu > Controller > Overlap > Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

In the table view of the web interface, right click on "Overlap" in the top left corner of the table. Copy the entire contents of Overlap Plan 1. Paste Overlap Plan 1 into Overlap Plan 2. Modify Overlap Plan 2 as shown below and save changes.

Overlap Plan 2

Overlap	1	2	
Туре	FYA 4 - Section	Normal	
Included Phases	<u> </u>	1,8	NOTICE INCLUDED PHA
Modifier Phases	1	<u>-</u>	
Modifier Overlaps	<u> </u>	<u> </u>	
Trail Green	0	0	
Trail Yellow	0.0	0.0	
Trail Red	0.0	0.0	
		_	-

FLASHER CIRCUIT MODIFICATION DETAIL

IN ORDER TO INSURE THAT SIGNALS FLASH CONCURRENTLY ON THE SAME APPROACH, MAKE THE FOLLOWING FLASHER CIRCUIT CHANGES:

- 1. ON REAR OF PDA REMOVE WIRE FROM TERM. T2-4 AND TERMINATE ON T2-2.
- 2. ON REAR OF PDA REMOVE WIRE FROM TERM. T2-5 AND TERMINATE ON T2-3.
- 3. REMOVE FLASHER UNIT 2.

THE CHANGES LISTED ABOVE TIES ALL PHASES AND OVERLAPS TO FLASHER UNIT 1.

MAXTIME ALTERNATE PHASING ACTIVATION DETAIL

To run alternate phasing, select a Pattern that is programmed to run Overlap Plan 2 and Detector Plan 2. A Pattern can be selected through the scheduler or manually by changing the Operational Mode.

PHASING	OVERLAP PLAN	VEH DET PLAN
ACTIVE PLAN REQUIRED TO RUN DEFAULT PHASING	1	1
ACTIVE PLAN REQUIRED TO RUN ALTERNATE PHASING	2	2

ALTERNATE PHASING CHANGE SUMMARY

THE FOLLOWING IS A SUMMARY OF WHAT TAKES PLACE WHEN OVERLAP PLAN 2 AND VEHICLE DETECTOR PLAN 2 ACTIVATE TO CALL THE "ALTERNATE PHASING":

OVERLAP PLAN 2: Modifies overlap included phases

for head 11 to run protected turns only.

VEH DET PLAN 2: Disables phase 6 call on loop 1A

and reduces delay time for phase 1 call on loop 1A to 0 seconds.

MAXTIME DETECTOR PROGRAMMING DETAIL FOR ALTERNATE PHASING LOOP 1A

Front Panel

Main Menu >Controller >Detector >Veh Det Plans

Web Interface

Home >Controller >Detector Configuration >Vehicle Detectors

In the table view of web interface right click on "Detector" in the top left corner of the table. Copy the entire contents of Detector Plan 1. Paste Detector Plan 1 into Detector Plan 2. Modify Detector Plan 2 as shown below and save changes.

Plan 2

Detector	Call Phase	Delay
1	1	0
29	0	3

MAXTIME ALTERNATE PHASING PATTERN PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Coordination >Patterns

Web Interface

Home >Controller >Coordination >Patterns

Pattern Parameters

attern arametere				
Pattern	Veh Det Plan	Overlap Plan		
*	2	2		

*The Pattern number(s) are to be determined by the Division and/or City Traffic Engineer.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 09-0511T3 DESIGNED: February 2024 SEALED: February 12, 2024 REVISED:

Signal Upgrade - Temporary Design 3 (TMP Phase III) Electrical Detail- Sheet 2 of 2

Electrical and Programming Details For: Prepared for the Offices of:

RKK

NC License No. F-0112

8601 Six Forks Road Suite 700 | Raleigh, North Carolina 27615-296

Engineers | Construction Managers | Planners | Scientists

Responsive People | Creative Solutions

US 158 (Reidsville Rd.) NC 74 Westbound Ramps

Forsyth County Winston-Salem PLAN DATE: February 2024 REVIEWED BY: DT Sears PREPARED BY: WP Erickson-Jones REVIEWED BY: REVISIONS

056142 Porter Jones

SIG. INVENTORY NO. 09-0511T3

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

| Sig. 18.2