	MAXTIME OVERLAP PROGRAMMING DETAIL FOR DEFAULT PHASING				
	Front Panel Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings				
	Web Interface Home >Controller >Overlap Configuration >Overlaps				
	Overlap Plan 1				
	Overlap 4				
	TypeFYA 4 - SectionIncluded Phases2Modifier Phases7				
	Modifier Overlaps - Trail Green 0				
	Trail Yellow0.0Trail Red0.0				
MAXTIME OVERLAP PROGRAMMING DETAIL FOR ALTERNATE PHASING					
Front Panel Main Menu >Controller >Overlap >Overlap Parameters/Overlap 1					
	In the table view of the web interface, right click on "Overlap" in the top left corner of the table. Copy the entire contents of Overlap Plan 1. Paste Overlap Plan 1 into Overlap Plan 2. Modify Overlap Plan 2 as shown below and save changes.				
	Overlap Plan 2				
	Overlap 4				
	Type FYA 4 - Section Included Phases - Modifier Phases 7				
	Modifier Overlaps - Trail Green 0				
	Trail Yellow0.0Trail Red0.0				
UÍ	MAXTIME ALTERNATE PHASING PATTERN PROGRAMMING DETAIL				
dp•XXXXX					
-dsn_XXX	Front Panel Main Menu >Controller >Coordination >Patterns				
eT5_sig_	Web Interface				
966060*9	Home >Controller >Coordination >Patterns				
sign*Signal:	Pattern Parameters Pattern Veh Det Plan Overlap Plan * 2 2				
raffic#Signals#Design#Signals#090996eT5_sig_dsn_XXXXXXX.dgn nes	* The Pattern number(s) are to be determined by the Division and/or City Traffic Engineer.				
aff. Ies					

12 *T

MAXTIME ALTERNATE PHASING ACTIVATION DETAIL

To run alternate phasing, select a Pattern that is programmed to run Overlap Plan 2 and Detector Plan 2. A Pattern can be selected through the scheduler or manually by changing the Operational Mode.

PHASING

ACTIVE PLAN REQUIRED TO RUN DEFAULT PHASING ACTIVE PLAN REQUIRED TO RUN ALTERNATE PHASING

RKK

8601 Six Forks Road Suite 700 | Raleigh, North Carolina 27615-2965 NC License No. F-0112

Engineers | Construction Managers | Planners | Scientists

Responsive People | Creative Solutions

P: (919) 878-9560

www.rkk.com

	ALTERNATE PHASING CH
OVERLAP PLAN 2	IS A SUMMARY OF WHAT AND VEHICLE DETECTOF TERNATE PHASING":
OVERLAP PLAN 2:	Modifies overlap included for head 71 to run protecte
VEH DET PLAN 2:	Reduces delay time for pha call on loop 7A to 0 second

MAXTIME DETECTOR PROGRAMMING DETAIL FOR ALTERNATE PHASING LOOPS 7A

Front Panel Main Menu >Controller >Detector >Veh Det Plans

Web Interface Home >Controller >Detector Configuration >Vehicle Detectors

In the table view of web interface right click on "Detector" in the top left corner of the table. Copy the entire contents of Detector Plan 1. Paste Detector Plan 1 into Detector Plan 2. Modify Detector Plan 2 as shown below and save changes.

	Plan 2		
	Detector	Call Phase	Delay
7A	21	7	0

PROJECT REFERENCE NO.	SHEET NO.
R-2577A	Sig. 26.2

OVERLAP PLAN	VEH DET PLAN
1	1
2	2

HANGE SUMMARY

T TAKES PLACE WHEN OR PLAN 2 ACTIVATE

l phases ed turns only.

iase 7

