


EDI MODEL 2018ECLip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



REMOVE JUMPERS AS SHOWN

NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- Ensure that Red Enable is active at all times during normal operation.
- Integrate monitor with Ethernet network in cabinet.

NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Enable Simultaneous Gap-Out for all phases.
- Program phases 2 and 6 for volume density operation.
- Program controller to start up in phase 2 Green and 6 Green.
- The cabinet and controller are part of the Fayetteville Signal System.

EQUIPMENT INFORMATION

CONTROLLER.....2070E
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S4,S5,S6,S7,S8,S10,S11
 PHASES USED.....1,2,3,4,5,6,7,8,4 PED
 OVERLAPS.....NOT USED

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
EMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	11	21,22	NU	22	31	41,42	P41, P42	42	51	61,62	NU	71	81,82	NU	NU	NU	NU	NU
RED		128				101				134			107					
YELLOW		129				102				135			108					
GREEN		130				103				136			109					
RED ARROW	125				116					131			122					
YELLOW ARROW	126			117	117			132	132				123					
GREEN ARROW	127			118	118			133	133				124					
Hand icon										104								
Walking person icon										106								

NU = Not Used

COUNTDOWN PEDESTRIAN SIGNAL OPERATION

Countdown Ped Signals are required to display timing only during Ped Clearance Interval. Consult Ped Signal Module user's manual for instructions on selecting this feature.

INPUT FILE POSITION LAYOUT

(front view)

FILE U	1	2	3	4	5	6	7	8	9	10	11	12	13	14
U	∅ 1	∅ 2	∅ 3	∅ 4	∅ 5	∅ 6	∅ 7	∅ 8	∅ 9	∅ 10	∅ 11	∅ 12	∅ 13	∅ 14
L	1A	2A	3A	4A	5A	6A	7A	8A	9A	10A	11A	12A	13A	14A
U	∅ 1	∅ 2	∅ 3	∅ 4	∅ 5	∅ 6	∅ 7	∅ 8	∅ 9	∅ 10	∅ 11	∅ 12	∅ 13	∅ 14
L	5A	5B	6A	7A	8A	8B	9A	9B	10A	10B	11A	11B	12A	12B

EX.: 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
 ST = STOP TIME


INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND TIME	DELAY TIME	DETECTOR TYPE
1A	TB2-1,2	I1U	56	1	1	YES			S
2A	TB2-5,6	I2U	39	2	2	YES			N
2B	TB2-7,8	I2L	43	12	2	YES			N
3A	TB4-5,6	I5U	58	3	3	YES			S
4A	TB4-9,10	I6U	41	4	4	YES			S
5A	TB3-1,2	J1U	55	5	5	YES			S
5B	TB3-5,6	J2U	40	6	5	YES		15	S
6A	TB3-9,10	J3U	64	36	6	YES			N
7A	TB5-5,6	J5U	57	7	7	YES			S
8A	TB5-9,10	J6U	42	8	8	YES		10	S
8B	TB5-11,12	J6L	46	18	8	YES		10	S
PED PUSH BUTTONS									
P41,P42	TB8-5,6	I12L	69	PED 4	4 PED				

NOTE:

INSTALL DC ISOLATOR IN INPUT FILE SLOT 112.

INPUT FILE POSITION LEGEND: J2L



THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0341
 DESIGNED: April 2016
 SEALED: 8-23-16
 REVISED: N/A

Electrical Detail

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

Prepared In the Offices of:
 Transporatio Mobility and Safety Solutions
 NORTH CAROLINA PROFESSIONAL ENGINEER
 KEITH M. MINS

750 N. Greenfield Pkwy, Garner, NC 27529

SR 1600 (McArthur Road) at SR 1615 (Rosehill Rd/Stacy Weaver Rd)
 Division 6 Cumberland County Fayetteville
 PLAN DATE: August 2016 REVIEWED BY: BAS
 PREPARED BY: James Peterson REVIEWED BY:

REVISIONS INIT. DATE

8/31/2016
 DATE

SIG. INVENTORY NO. 06-0341