

### EMERGENCY VEHICLE PREEMPTION PROGRAMMING DETAIL

(program controller as shown below)

From Main Menu press 'A' (Preemption), then '1' (Standard Preemptions). Press 'NEXT' to advance to Preemption #2.

| PREEMPTION #2   | SETTINGS (NEXT:1-10)    |
|-----------------|-------------------------|
| INTERVAL/TIMING | CLEAR/DWELL PHASES      |
| GRN YEL RED     | 12345678910111213141516 |
| 1 255 0.0 0.0   | X X                     |
| 2 0 0.0 0.0     |                         |
| 3 0 0.0 0.0     |                         |
| 4 0 0.0 0.0     |                         |
| 5 1 0.0 0.0     | X X                     |


  

| EXIT CALLS                               | OPTIONS          |
|--|------------------|
| PRIORITY (Y/N TO SELECT) .....           | MED              |
| DELAY TIMER (0-255 SEC) .....            | *                |
| MIN GREEN BEFORE PRE (0= DEFAULT)...     | 1                |
| PED CLEAR BEFORE PRE (0= DEFAULT)...     | 10               |
| YELLOW CLEAR BEFORE PRE (0= DEFAULT)...  | 0.0              |
| RED CLEAR BEFORE PRE (0= DEFAULT)...     | 0.0              |
| DWELL MIN TIMER (0-255 SEC) .....        | *                |
| DWELL MAX TIMER (0=OFF,1-255MIN) .....   | 0                |
| DWELL HOLD-OVER TIMER (0-255) .....      | 0                |
| LATCH CALL? .....                        | Y                |
| LINK TO NEXT PREEMPT? .....              | N                |
| ENABLE BACKUP PROTECTION? .....          | Y                |
| HOLD CLEAR 1 PHASES DURING DELAY? .....  | N                |
| FAST GREEN FLASH DWELL PHASES? .....     | N                |
| PED CLEARANCE THROUGH YELLOW? .....      | Y                |
| INHIBIT OVERLAP GREEN EXTENSION? .....   | N                |
| SERVICE DURING SOFTWARE FLASH? .....     | N                |
| REST IN RED DURING DWELL INTERVAL? ..... | N                |
| FLASH DWELL INTERVAL? .....              | N                |
| ALLOW PEDS IN DWELL INTERVAL? .....      | N                |
| RE-TIME DWELL INTERVAL? .....            | Y                |
| OVERLAPS:                                | ABCDEFGHIJKLMNQP |
| DWELL INT FLASH YELLOW                   |                  |
| OMIT OVERLAPS:                           |                  |

\* Denotes timing to be determined in field.

### EV Preemption Control Box Wiring Detail


(wire as shown below)



### NOTES


- Relay K1 is shown in the energized (Preempt not active) normal operation state.
- Relay 'K1' is an enclosed DPDT general purpose relay with a 120VAC coil, 10A contacts, and octal-style plug.
- Relay SSR1 is a SPST (normally open) Solid State Relay with AC input and AC (25 amp) output.
- AC Isolator Card shall activate preemption upon removal of AC+ from the input (as shown above). To accomplish this, set invert dip switch on AC Isolator Card.
- IMPORTANT!! Terminal TB9-12 (on input panel) shall be connected to AC neutral (jumper may have to be added).

### FRONT VIEW



### PREEMPT 2 AC ISOLATOR (MODEL 252) OUTPUT PROGRAMMING DETAIL

(set DIP switches as shown below)



NOTE: IF ANOTHER MANUFACTURER TYPE OF AC ISOLATOR IS USED, OUTPUT PROGRAMMING IS LIKELY NOT TO EQUATE TO THAT SHOWN ABOVE.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 14-0740  
 DESIGNED: January 2016  
 SEALED: 11-09-16  
 REVISED: N/A

Electrical Detail - Sheet 3 of 3

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

|  |  |  |          |
|--|--|--|----------|
| ELECTRICAL AND PROGRAMMING DETAILS FOR:<br>Prepared In the Offices of:<br><br>750 N. Greenfield Pkwy, Garner, NC 27529 | US 25 (Hendersonville Road) at SR 1358 (Fanning Bridge Road)           |  | SEAL<br> |
|  | Division 14<br>PLAN DATE: November 2016<br>PREPARED BY: James Peterson | Henderson County<br>REVIEWED BY: BAS<br>REVIEWED BY: |          |

10-14016-2016\_08.rvt  
 S:\1125351\15\Sig\mol\work\hgr\oups\sig Mol\Peter.som\140740\_1.smc.ele\_xxxx.dgn  
 J.peterson