

LOGIC I/O PROCESSOR PROGRAMMING COMPLETE

OUTPUT REFERENCE SCHEDULE

OUTPUT 50 = Overlap A Red OUTPUT 51 = Overlap A Yellow OUTPUT 52 = Overlap A Green

EMERGENCY VEHICLE PREEMPTION PROGRAMMING DETAIL

(program controller as shown below)

From Main Menu press 'A' (Preemption), then '1' (Standard Preemptions). Press 'NEXT' to advance to Preemption #3, 4 and 5.


PREEMPTION #3 SETTINGS (NEXT:1-10) INTERVAL/TIMING CLEAR/DWELL PHASES GRN YEL RED 12345678910111213141516 1 255 0.0 0.0 X X 2 0 0.0 0.0 3 0 0.0 0.0 4 0 0.0 0.0 5 0 0.0 0.0
EXIT CALLS ' OPTIONS PRIORITY (Y/N TO SELECT)MED DELAY TIMER (O-255 SEC)O MIN GREEN BEFORE PRE (O= DEFAULT)1 PED CLEAR BEFORE PRE (O= DEFAULT)0 YELLOW CLEAR BEFORE PRE (O= DEFAULT)0 O CLEAR BEFORE PRE (O= DEFAULT)0 DWELL MIN TIMER (O-255 SEC)10 DWELL MAX TIMER (O-255 SEC)0 DWELL HOLD-OVER TIMER (O-255)0 LATCH CALL? N LINK TO NEXT PREEMPT?N ENABLE BACKUP PROTECTION?N HOLD CLEAR 1 PHASES DURING DELAY?N FAST GREEN FLASH DWELL PHASES?N PED CLEARANCE THROUGH YELLOW?N INHIBIT OVERLAP GREEN EXTENSION?N SERVICE DURING SOFTWARE FLASH?N REST IN RED DURING DWELL INTERVAL?N ALLOW PEDS IN DWELL INTERVAL?N RE-TIME DWELL INTERVAL?N OVERLAPS: ABCDEFGHIJKLMNOP DWELL INT FLASH YELLOW OMIT OVERLAPS:

PREEMPTION INTERVAL/TIMIN GRN YEL RED 1 255 0.0 0. 2 0 0.0 0. 3 0 0.0 0. 4 0 0.0 0. 5 0 0.0 0.	G CLEA 123456 O X O O O O	INGS (NEXT:1 R/DWELL PHAS 789101112131
EXIT CALLS O PRIORITY (Y/N DELAY TIMER (O MIN GREEN BEFO PED CLEAR BEFO YELLOW CLEAR B RED CLEAR BEFO DWELL MIN TIME DWELL MAX TIME DWELL HOLD-OVE LATCH CALL? LINK TO NEXT P ENABLE BACKUP	IPTIONSTO SELECT-255 SEC)RE PRE (ORE PRE PRERE PRE (OR (O-255R (O-255P (O-255S (O-255P (O-255S (O-255P (O-255R (O-	= DEFAULT) = DEFAULT) (O= DEFAULT = DEFAULT) SEC) 1-255MIN) 0-255) N? NG DELAY?. PHASES? ELLOW? FLASH? L INTERVAL?
DWELL INT FLAS OMIT OVERLAPS		PRESS

Program extend time an optical detector unit for 5.0 seconds.

OVERLAP PROGRAMMING DETAIL (program controller as shown below)	
FROM MAIN MENU PRESS '8' (OVERLAPS), THEN '1' (VEHICLE OVERLAP SETTINGS).	
PAGE 1: VEHICLE OVERLAP 'A' SETTINGS PHASE: 12345678910111213141516 VEH OVL PARENTS: XX VEH OVL NOT VEH: VEH OVL NOT PED: VEH OVL GRN EXT: STARTUP COLOR: _ RED _ YELLOW _ GREEN FLASH COLORS: _ RED _ YELLOW X GREEN SELECT VEHICLE OVERLAP OPTIONS: (Y/N) FLASH YELLOW IN CONTROLLER FLASH?Y GREEN EXTENSION (0-255 SEC)0 YELLOW CLEAR (0=PARENT, 3-25.5 SEC)0.0	NOTICE GREEN FLASH
RED CLEAR (O=PARENT,0.1-25.5 SEC)0.0 OUTPUT AS PHASE # (O=NONE, 1-16)0	EL

OVERLAP PROGRAMMING COMPLETE



ATKINS 1616 EAST MILLBROOK ROAD, SUITE 160 RALEIGH, NORTH CAROLINA 27609 (919) 876-6888 NCBEES #F-0326

SIG. INVENTORY NO. 04-0429