


### EDI MODEL 2010ECL-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



- NOTES:
- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
  - Make sure jumpers SEL2-SEL5 are present on the monitor board.
- = DENOTES POSITION OF SWITCH

### NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Ensure that Red Enable is active at all times during normal operation. To prevent Red Failures on unused monitor channels, tie unused red monitor inputs 1,3, 5,7,10,12,13,14,15 & 16 to load switch AC+ per the cabinet manufacturer's instructions.
- Program phases 4 and 8 for Dual Entry.
- Enable Simultaneous Gap-Out for all Phases.
- Program phases 2 and 6 for Variable Initial and Gap Reduction.
- Program phases 2 and 6 for Startup In Green.
- Program phases 2 and 6 for Yellow Flash.
- The cabinet and controller are part of the NC 115 (Mecklenburg Hwy.) Closed Loop System.

### SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S2P	S3	S4	S4P	S5	S6	S6P	S7	S8	S8P	S9	S10	S11	S12	S13	S14
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	61	65	22,23	**	NU	41, 42,43	NU	NU	61,62	NU	NU	81,82	NU	63,64	NU	21*	NU	NU
RED	125	128			101			134			107		A121					
YELLOW	126	129			102			135			108		A122					
GREEN	127	130			103			136			109							
RED ARROW																		A114
YELLOW ARROW	126																	A115
FLASHING YELLOW ARROW																		A116
GREEN ARROW	127																	


NU = Not Used 8" Flashing Yellow A123  
 \*\* See Lamp Notes (Sheet 2 of 3)  
 \* See pictorial of head wiring in detail below.

### EQUIPMENT INFORMATION

CONTROLLER.....2070L  
 CABINET .....332 W/ AUX  
 SOFTWARE .....ECONOLITE OASIS  
 CABINET MOUNT.....BASE  
 OUTPUT FILE POSITIONS..18 (12-STD, 6-AUX)  
 LOAD SWITCHES USED.....S1,S2,S2P,S4,S6,S8,S9,S12  
 PHASES USED.....1\*,2,4,6,8  
 OVERLAP A.....2+4+6+8  
 OVERLAP B.....NOT USED  
 OVERLAP C.....6  
 OVERLAP D.....NOT USED

\* PHASE USED DURING PREEMPTION ONLY  
 ^ DENOTES S2P IS USED ONLY FOR FIRE HOUSE PREEMPT PILOT LAMP CONTROL.

### FYA SIGNAL WIRING DETAIL



### INPUT FILE POSITION LAYOUT

(front view)

FILE "I"	1	2	3	4	5	6	7	8	9	10	11	12	13	14
U	∅ 2	2A	∅ 2	∅ 2	∅ 2	∅ 4	∅ 4	∅ 4	∅ 4	∅ 4	∅ 4	∅ 4	∅ 4	∅ 4
L	∅ 2	2B	∅ 2	∅ 2	∅ 2	∅ 4	∅ 4	∅ 4	∅ 4	∅ 4	∅ 4	∅ 4	∅ 4	∅ 4
U	∅ 6	6A	∅ 6	∅ 6	∅ 6	∅ 8	∅ 8	∅ 8	∅ 8	∅ 8	∅ 8	∅ 8	∅ 8	∅ 8
L	NOT USED	6A	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED

EX.: 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE  
 ST = STOP TIME  
 PRE2 = PREEMPTOR 2 (EV)

### OVERLAP PROGRAMMING DETAIL

(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS), THEN '1' (VEHICLE OVERLAP SETTINGS).

```

PAGE 1: VEHICLE OVERLAP 'A' SETTINGS
PHASE: :12345678910111213141516
VEH OVL PARENTS: : X X X X
VEH OVL NOT VEH: :
VEH OVL NOT PED: :
VEH OVL GRN EXT: :
STARTUP COLOR: - RED - YELLOW - GREEN
FLASH COLORS: - RED - YELLOW X GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC)...0.0
YELLOW CLEAR (0=PARENT,3-25.5 SEC)...0.0
RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)...0
    
```

← NOTICE GREEN FLASH

PRESS '+' TWICE


```

PAGE 1: VEHICLE OVERLAP 'C' SETTINGS
PHASE: :12345678910111213141516
VEH OVL PARENTS: : X
VEH OVL NOT VEH: :
VEH OVL NOT PED: :
VEH OVL GRN EXT: :
STARTUP COLOR: - RED - YELLOW - GREEN
FLASH COLORS: - RED - YELLOW X GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC)...0.0
YELLOW CLEAR (0=PARENT,3-25.5 SEC)...0.0
RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)...0
    
```

← NOTICE GREEN FLASH

### INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
2A	TB2-5,6	I2U	39	1	2	2	Y	Y			
2B	TB2-7,8	I2L	43	5	12	2	Y	Y	Y		3
4A	TB6-1,2	I7U	65	27	34	4	Y	Y		1.0	
4B	TB4-9,10	I6U	41	3	4	4	Y	Y			3
4C	TB4-11,12	I6L	45	7	14	4	Y	Y			15
6A	TB3-5,6	J2U	40	2	6	6	Y	Y			
8A	TB5-9,10	J6U	42	4	8	8	Y	Y			5



### PREEMPT ONLY PHASE OMIT NOTE

(program controller as shown below)

From Main Menu press '2' (Phase Control). Then '1' (Phase Control Functions). Program Phase 1 for 'Omit Phase' and Phases 2, 4, 6 and 8 for 'Startup Calls'. This is to prevent Phase 1 from being served when not in Preempt.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 12-1717  
 DESIGNED: January 2018  
 SEALED: 2/27/2018  
 REVISED:

Electrical Detail - Sheet 1 of 3

<p>750 N. Greenfield Pkwy, Garner, NC 27529</p>	<p>NC 115 (Mecklenburg Hwy.) at SR 1102 (Langtree Rd.) / SR 2948 (Hobbs Lane)</p> <p>Division 12 Iredell County Mooresville</p> <p>PLAN DATE: February 2018 REVIEWED BY: T. Joyce</p> <p>PREPARED BY: C. Strickland REVIEWED BY:</p>	<p>SEAL</p> <p>PROFESSIONAL ENGINEER</p> <p>SEAL 031001</p> <p>ENGINEER</p> <p>TODD JOYCE</p> <p>3/1/2018</p> <p>SIG. INVENTORY NO. 12-1717</p>
---	--	---

28 FEB 2018 07:42 S:\ITS\ASIS\ITS\_Sig\edi\work\hgr\oups\sig\_Maps\Strickland\2117\_Sm.ele.xxx.dgn