ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL

(program controller as shown)

- 1. From Main Menu select 2. CONTROLLER
- 2. From CONTROLLER Submenu select | 2. VEHICLE OVERLAPS

OVERLAP A

Select TMG VEH OVLP [A] and 'OTHER/ECONOLITE'

TMG VEH OVLP...[A] TYPE: OTHER/ECONOLITE PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6 LAG GRN 0.0 YEL 0.0 RED 0.0 ADV GRN 0.0 Toggle Twice

OVERLAP C


Select TMG VEH OVLP [C] and 'PPLT FYA'

TMG VEH OVLP...[C] TYPE: PPLT FYA PROTECTED LEFT TURN.... PHASE 5 OPPOSING THROUGH..... PHASE 6 FLASHING ARROW OUTPUT....CH15 ISOLATE DELAY START OF: FYA..O.O CLEARANCE..O.O ACTION PLAN SF BIT DISABLE..... 0

END PROGRAMMING

PEDESTRIAN PUSH BUTTON WIRING DETAIL

(wire push buttons as shown)



ECONOLITE ASC/3-2070 SPECIAL MMU PROGRAMMING

PROJECT REFERENCE NO.

I-5700

Sig. 6.2

(program controller as shown)

1. From Main Menu select | 1. CONFIGURATION

2. From CONFIGURATION Submenu select | 4. PORT 1 (SDLC)

3. From PORT 1 (SDLC) Submenu select 2. MMU PROGRAM

CAUTION!

Set intersection to Flash before attempting to enter or change any MMU programming data.

This programming and that of the MMU programming card must match exactly. If they do not, the intersection will be placed into Flash.

MMU PROGRAM [MANUAL CH 6 5 4 3 2 1 0 9 8 7 6 5 4 3 2 1 2 . X . X . X . X . . X X . . 4 X . X . X . . . 5 . X . X . . . X . . . 6 . X . X . X . X . . 7 8 . . . X . X . 9 . X . X . X . 11 . X . X . 12 13 . X . 14 . . 15 .

END PROGRAMMING

COUNTDOWN PEDESTRIAN SIGNAL OPERATION

Countdown Ped Signals are required to display timing only during Ped Clearance Interval. Consult Ped Signal Module user's manual for instructions on selecting this feature.

> THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 05-2088 DESIGNED: February 2019 SEALED: 7/24/2019 REVISED: N/A

