

ECONOLITE ASC/3-2070 EMERGENCY VEHICLE PREEMPT PROGRAMMING DETAIL

(program controller as shown)

- 1. From Main Menu select **4. PREEMPTOR/TSP**
- 2. From PREEMPTOR/TSP/SCP Submenu select **1. PREEMPT PLAN 1-10**

Place cursor in [] next to Preempt Plan and press 3. Then press the right cursor arrow and toggle the controller to YES. Next cursor down. This will select Emergency Vehicle Preempt #3.

```

PREEMPT PLAN [ 3]  ENABLE....YES
VEH/PED 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
OVERLAP A B C D E F G H I J K L M N O P
TRKCLR V . . . . .
TRKCLR O . . . . .
ENA TRL . . . . .
DWEL VEH X . . . . X . . . . .
DWEL PED . . . . .
DWEL OLP . . . . .
CYC VEH . . . . .
CYC PED . . . . .
CYC OLP . . . . .
EXIT PH . . . X . . . X . . . . .
EXIT CAL . . . . .
SP FUNC . . . . .

ENABLE... YESIPMT OVRIDE..INTERLOCK. NO
DET LOCK... XIDELAY.. OINHIBIT... 0
OVERRIDE FL. .IDURATION OICLR-GRN... NO
TERM OLP. NOIPC>NO NOITERM PH NO
PED DARK.. NOITC RESRV NOIDWELL FL OFF
LINK PMT....OIX FLCOLR REDIEXIT OPT. OFF
X TMG PLN...OIRE-SERV.. OIFLT TYPE.HARD
FREE DUR PMTIR1 NOIR2 NOIR3 NOIR4 NO
--TIMING----WALKIPED CLIMN GRI YELI RED
ENTRANCE TM. 255I 255I 1125.5125.5
-----MIN GRIEXT GRIMX GRI YELI RED
TRACK CLEAR 0I 0I 0125.5125.5
-----MIN DLIPMTEXTIMX TMI YELI RED
DWL/CYC-EXIT 12I 2.0I 120125.5125.5
PMT ACTIVE OUT..ON PMT ACT DWELL...NO
OTHER - PRI PMT.OFF NON-PRI PMT....OFF
INH EXT TIME... 0.0 PED PR RETURN...OFF
PRIORITY RETURN.OFF QUEUE DELAY.... OFF
COND DELAY.....OFF

PHASES 1 2 3 4 5 6 7 8
PR RTN% 0 0 0 0 0 0 0 0
PHASES 9 10 11 12 13 14 15 16
PR RTN% 0 0 0 0 0 0 0 0

```

Place cursor in [] next to Preempt Plan and press 4. Then press the right cursor arrow and toggle the controller to YES. Next cursor down. This will select Emergency Vehicle Preempt #4.

```

PREEMPT PLAN [ 4]  ENABLE....YES
VEH/PED 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
OVERLAP A B C D E F G H I J K L M N O P
TRKCLR V . . . . .
TRKCLR O . . . . .
ENA TRL . . . . .
DWEL VEH . X . . . X . . . . .
DWEL PED . . . . .
DWEL OLP . . . . .
CYC VEH . . . . .
CYC PED . . . . .
CYC OLP . . . . .
EXIT PH . . . X . . . X . . . . .
EXIT CAL . . . . .
SP FUNC . . . . .

ENABLE... YESIPMT OVRIDE..INTERLOCK. NO
DET LOCK... XIDELAY.. OINHIBIT... 0
OVERRIDE FL. .IDURATION OICLR-GRN... NO
TERM OLP. NOIPC>YEL NOITERM PH NO
PED DARK.. NOITC RESRV NOIDWELL FL OFF
LINK PMT....OIX FLCOLR REDIEXIT OPT. OFF
X TMG PLN...OIRE-SERV.. OIFLT TYPE.HARD
FREE DUR PMTIR1 NOIR2 NOIR3 NOIR4 NO
--TIMING----WALKIPED CLIMN GRI YELI RED
ENTRANCE TM. 255I 255I 1125.5125.5
-----MIN GRIEXT GRIMX GRI YELI RED
TRACK CLEAR 0I 0I 0125.5125.5
-----MIN DLIPMTEXTIMX TMI YELI RED
DWL/CYC-EXIT 12I 2.0I 120125.5125.5
PMT ACTIVE OUT..ON PMT ACT DWELL...NO
OTHER - PRI PMT.OFF NON-PRI PMT....OFF
INH EXT TIME... 0.0 PED PR RETURN...OFF
PRIORITY RETURN.OFF QUEUE DELAY.... OFF
COND DELAY.....OFF

PHASES 1 2 3 4 5 6 7 8
PR RTN% 0 0 0 0 0 0 0 0
PHASES 9 10 11 12 13 14 15 16
PR RTN% 0 0 0 0 0 0 0 0

```

Place cursor in [] next to Preempt Plan and press 5. Then press the right cursor arrow and toggle the controller to YES. Next cursor down. This will select Emergency Vehicle Preempt #5.

```

PREEMPT PLAN [ 5]  ENABLE....YES
VEH/PED 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
OVERLAP A B C D E F G H I J K L M N O P
TRKCLR V . . . . .
TRKCLR O . . . . .
ENA TRL . . . . .
DWEL VEH . . X . . . . X . . . . .
DWEL PED . . . . .
DWEL OLP .F1 .F1 . . . . .
CYC VEH . . . . .
CYC PED . . . . .
CYC OLP . . . . .
EXIT PH . X . . . X . . . . .
EXIT CAL . . . . .
SP FUNC . . . . .

ENABLE... YESIPMT OVRIDE..INTERLOCK. NO
DET LOCK... XIDELAY.. OINHIBIT... 0
OVERRIDE FL. .IDURATION OICLR-GRN... NO
TERM OLP. NOIPC>YEL NOITERM PH NO
PED DARK.. NOITC RESRV NOIDWELL FL OFF
LINK PMT....OIX FLCOLR REDIEXIT OPT. OFF
X TMG PLN...OIRE-SERV.. OIFLT TYPE.HARD
FREE DUR PMTIR1 NOIR2 NOIR3 NOIR4 NO
--TIMING----WALKIPED CLIMN GRI YELI RED
ENTRANCE TM. 255I 255I 1125.5125.5
-----MIN GRIEXT GRIMX GRI YELI RED
TRACK CLEAR 0I 0I 0125.5125.5
-----MIN DLIPMTEXTIMX TMI YELI RED
DWL/CYC-EXIT 7I 2.0I 120125.5125.5
PMT ACTIVE OUT..ON PMT ACT DWELL...NO
OTHER - PRI PMT.OFF NON-PRI PMT....OFF
INH EXT TIME... 0.0 PED PR RETURN...OFF
PRIORITY RETURN.OFF QUEUE DELAY.... OFF
COND DELAY.....OFF

PHASES 1 2 3 4 5 6 7 8
PR RTN% 0 0 0 0 0 0 0 0
PHASES 9 10 11 12 13 14 15 16
PR RTN% 0 0 0 0 0 0 0 0

```

Place cursor in [] next to Preempt Plan and press 6. Then press the right cursor arrow and toggle the controller to YES. Next cursor down. This will select Emergency Vehicle Preempt #6.

```

PREEMPT PLAN [ 6]  ENABLE....YES
VEH/PED 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
OVERLAP A B C D E F G H I J K L M N O P
TRKCLR V . . . . .
TRKCLR O . . . . .
ENA TRL . . . . .
DWEL VEH . . . X . . . X . . . . .
DWEL PED . . . . .
DWEL OLP .F1 .F1 . . . . .
CYC VEH . . . . .
CYC PED . . . . .
CYC OLP . . . . .
EXIT PH . X . . . X . . . . .
EXIT CAL . . . . .
SP FUNC . . . . .

ENABLE... YESIPMT OVRIDE..INTERLOCK. NO
DET LOCK... XIDELAY.. OINHIBIT... 0
OVERRIDE FL. .IDURATION OICLR-GRN... NO
TERM OLP. NOIPC>YEL NOITERM PH NO
PED DARK.. NOITC RESRV NOIDWELL FL OFF
LINK PMT....OIX FLCOLR REDIEXIT OPT. OFF
X TMG PLN...OIRE-SERV.. OIFLT TYPE.HARD
FREE DUR PMTIR1 NOIR2 NOIR3 NOIR4 NO
--TIMING----WALKIPED CLIMN GRI YELI RED
ENTRANCE TM. 255I 255I 1125.5125.5
-----MIN GRIEXT GRIMX GRI YELI RED
TRACK CLEAR 0I 0I 0125.5125.5
-----MIN DLIPMTEXTIMX TMI YELI RED
DWL/CYC-EXIT 7I 2.0I 120125.5125.5
PMT ACTIVE OUT..ON PMT ACT DWELL...NO
OTHER - PRI PMT.OFF NON-PRI PMT....OFF
INH EXT TIME... 0.0 PED PR RETURN...OFF
PRIORITY RETURN.OFF QUEUE DELAY.... OFF
COND DELAY.....OFF


PHASES 1 2 3 4 5 6 7 8
PR RTN% 0 0 0 0 0 0 0 0
PHASES 9 10 11 12 13 14 15 16
PR RTN% 0 0 0 0 0 0 0 0

```

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 01-0013 DESIGNED: MARCH 2018 SEALED: 08/21/2018 REVISED: N/A

Electrical Detail - Sheet 3 of 4

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED



US 17 (Hughes Blvd.) at SR 1309 (W. Main St.) / W. Main St.

Division 1 Pasquotank County Elizabeth City

PLAN DATE: March 2018 REVIEWED BY: AJ Davis

PREPARED BY: DJ White REVIEWED BY: LM Moon

REVISIONS	INIT.	DATE




20-SEP-2018 10:49 R:\415942\451\001\415942.dgn AT CAR-LMCDM-W7

EDI MODEL 2018ECLIP-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)





REMOVE DIODE JUMPERS 1-5, 1-6, 1-15, 2-5, 2-6, 2-13, 2-15, 3-7, 3-8, 3-16, 4-7, 4-8, 4-14, 4-16, 5-13, 6-13, 6-15, 7-14, 8-14, 8-16, 13-15 AND 14-16.



REMOVE JUMPERS AS SHOWN

NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- Ensure that Red Enable is active at all times during normal operation.
- Integrate monitor with Ethernet network in cabinet.



■ = DENOTES POSITION OF SWITCH

NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Program controller to start up in phase 2 WALK and 6 WALK.
- The cabinet and controller are part of the Elizabeth City Signal System.
- Ensure Delayed Green times shown in the Timing Chart on the signal design plan are accounted for to facilitate leading pedestrian interval.

EQUIPMENT INFORMATION

CONTROLLER.....2070LX
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S3,S4,S5,S6,S7,S8,S9,
 S10,S11,S12
 PHASES USED.....1,2,3,4,5,6,7,8,2PED,4PED,
 6PED,8PED
 OVERLAPS.....NONE

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	11	21,22	P21, P22	31	41,42	P41, P42	51	61,62	P61, P62	71	81,82	P81, P82	NU	NU	NU	NU	NU	NU
RED		128			101			134			107							
YELLOW		129			102			135			108							
GREEN		130			103			136			109							
RED ARROW	125				116			131			122							
YELLOW ARROW	126				117			132			123							
GREEN ARROW	127				118			133			124							
Hand icon					113			104			119							110
Walking person icon					115			106			121							112

NU = Not Used


ECONOLITE ASC/3-2070 PREEMPT FILTERING PROGRAMMING DETAIL

(program controller as shown)

- From Main Menu select **4. PREEMPTOR/TSP**
- From PREEMPT/TSP/SCP Submenu select **2. ENABLE PREEMPT FILTERING & TSP/SCP**

INPUT	1	2	3	4	5	6	7	8	9	10
ENABLE PREEMPT FILTERING & TSP/SCP	SOLID	SOLID	SOLID	SOLID	SOLID	SOLID	SOLID	SOLID	SOLID	SOLID
FILTERED	BYPASSED	BYPASSED	BYPASSED	BYPASSED	BYPASSED	BYPASSED	BYPASSED	BYPASSED	BYPASSED	BYPASSED
PULSING	BYPASSED	BYPASSED	BYPASSED	BYPASSED	BYPASSED	BYPASSED	BYPASSED	BYPASSED	BYPASSED	BYPASSED

INPUT FILE POSITION LAYOUT (front view)



EX.: 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
ST = STOP TIME
PRE = PREEMPT


INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND TIME	DELAY TIME	ADDED INITIAL	DETECTOR TYPE
1A	TB2-1,2	I1U	56	1	1	YES		3		S
2A	TB2-5,6	I2U	39	2	2	YES				S
2B	TB2-7,8	I2L	43	12	2	YES				S
3A	TB4-5,6	I5U	58	3	3	YES		3		S
4A	TB4-9,10	I6U	41	4	4	NO	3,4			N
4B	TB4-11,12	I6L	45	14	4	NO	3,4			N
4C	TB6-1,2	I7U	65	34	4	YES				G
4D	TB6-3,4	I7L	78	44	4	YES		10		G
* S1	TB6-9,10	I9U	60	11	SYS	NO				N
* S2	TB6-11,12	I9L	62	13	SYS	NO				N
5A	TB3-1,2	J1U	55	5	5	YES		3		S
6A	TB3-5,6	J2U	40	6	6	YES				S
6B	TB3-7,8	J2L	44	16	6	YES				S
7A	TB5-5,6	J5U	57	7	7	YES		3		S
8A	TB5-9,10	J6U	42	8	8	NO	3,4			N
8B	TB5-11,12	J6L	46	18	8	NO	3,4			N
8C	TB7-1,2	J7U	66	38	8	YES				G
8D	TB7-3,4	J7L	79	48	8	YES		10		G
* S3	TB7-9,10	J9U	59	15	SYS	NO				N
* S4	TB7-11,12	J9L	61	17	SYS	NO				N
PED PUSH BUTTONS										
P21,P22	TB8-4,6	I12U	67	PED 2	2	PED				
P41,P42	TB8-5,6	I12L	69	PED 4	4	PED				
P61,P62	TB8-7,9	I13U	68	PED 6	6	PED				
P81,P82	TB8-8,9	I13L	70	PED 8	8	PED				

NOTE: INSTALL DC ISOLATORS IN INPUT FILE SLOTS 112 AND 113.

* System detector only. Remove any assigned vehicle phase.

INPUT FILE POSITION LEGEND: J2L



** OPTICAL PREEMPTION SYSTEM

- Install an optical preemption system for emergency vehicle preemption. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the preemption schemes shown on the Signal Design Plans.
- Ensure that the Optical Preemption System is fully compatible with equipment manufactured in accordance with the specification of the type 2070 controller.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 01-0014
 DESIGNED: September 2018
 SEALED: 09/21/2018
 REVISED: N/A

Signal Upgrade - Electrical Detail - Sheet 1 of 2

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

PLANS PREPARED BY:

RUMMEL, KLEPPER & KAHL, LLP
 900 RIDGEFIELD DRIVE SUITE 350
 RALEIGH, NORTH CAROLINA 27609-3960
 NC LICENSE NO. F-0112 • (919) 878-9560

ELECTRICAL AND PROGRAMMING DETAILS FOR:

Prepared for the Offices of:
 North Carolina Professional Engineer
 JAMES O. DEATON
 License No. 07438

US 17 Business (Ehringhaus St.)
 at
 NC 344 (Halstead Boulevard)

Division 1 Pasquotank County Elizabeth City
 PLAN DATE: September 2018 REVIEWED BY: J O Deaton
 PREPARED BY: M W Yalch REVIEWED BY:

REVISIONS	INIT.	DATE

DocuSigned by:
 James O. Deaton
 9/21/2018
 DATE
 SIG. INVENTORY NO. 01-0014

ECONOLITE ASC/3-2070 EMERGENCY VEHICLE PREEMPT PROGRAMMING DETAIL

(program controller as shown)

- 1. From Main Menu select 4. PREEMPTOR/TSP
2. From PREEMPTOR/TSP/SCP Submenu select 1. PREEMPT PLAN 1-10

Place cursor in [] next to Preempt Plan and press 3. Then press the right cursor arrow and toggle the controller to YES. Next cursor down. This will select Emergency Vehicle Preempt #3.

Place cursor in [] next to Preempt Plan and press 4. Then press the right cursor arrow and toggle the controller to YES. Next cursor down. This will select Emergency Vehicle Preempt #4.

Place cursor in [] next to Preempt Plan and press 5. Then press the right cursor arrow and toggle the controller to YES. Next cursor down. This will select Emergency Vehicle Preempt #5.

Place cursor in [] next to Preempt Plan and press 6. Then press the right cursor arrow and toggle the controller to YES. Next cursor down. This will select Emergency Vehicle Preempt #6.

Table with columns: PREEMPT PLAN [3], ENABLE....YES, VEH/PED, OVERLAP, TRKCLR, ENA TRL, DWEL VEH, DWEL PED, DWEL OLP, CYC VEH, CYC PED, CYC OLP, EXIT PH, EXIT CAL, SP FUNC.

Table with columns: ENABLE... YES, IPMT, OVRIDE, INTERLOCK, NO DET LOCK, XIDELAY, OINHIBIT, OVERIDE FL, IDURATION, OICLR-GRN, TERM OLP, NOIPC>YEL, YESITERM PH, PED DARK, NOITC RESRV, NOIDWELL FL, LINK PMT, OIX FLCOLR, REDIEEXIT OPT, X TMG PLN, OIRE-SERV, OIFLT TYPE, HARD FREE DUR, PMTIR1, NOIR2, NOIR3, NOIR4, --TIMING, WALKIPED, CLIMN, GRI, YELI, RED ENTRANCE TM, 255I, 255I, 255I, 255I, 25.5I, 25.5I, -----MIN, GRIEXT, GRIMX, GRI, YELI, RED TRACK CLEAR, 0I, 0I, 0I, 25.5I, 25.5I, -----MIN, DLIPMTEXTIMX, TMI, YELI, RED DWL/CYC-EXIT, 0I, 2.0I, 120I, 25.5I, 25.5I, PMT ACTIVE OUT, ON, PMT ACT DWELL, NO, OTHER - PRI, PMT.OFF, NON-PRI, PMT, OFF, INH EXT TIME, 0.0, PED PR RETURN, OFF, PRIORITY RETURN.OFF, QUEUE DELAY, OFF, COND DELAY, OFF, PHASES, PR RTN%, PHASES, PR RTN%.

Table with columns: PREEMPT PLAN [4], ENABLE....YES, VEH/PED, OVERLAP, TRKCLR, ENA TRL, DWEL VEH, DWEL PED, DWEL OLP, CYC VEH, CYC PED, CYC OLP, EXIT PH, EXIT CAL, SP FUNC.

Table with columns: ENABLE... YES, IPMT, OVRIDE, INTERLOCK, NO DET LOCK, XIDELAY, OINHIBIT, OVERIDE FL, IDURATION, OICLR-GRN, TERM OLP, NOIPC>YEL, YESITERM PH, PED DARK, NOITC RESRV, NOIDWELL FL, LINK PMT, OIX FLCOLR, REDIEEXIT OPT, X TMG PLN, OIRE-SERV, OIFLT TYPE, HARD FREE DUR, PMTIR1, NOIR2, NOIR3, NOIR4, --TIMING, WALKIPED, CLIMN, GRI, YELI, RED ENTRANCE TM, 255I, 255I, 255I, 255I, 25.5I, 25.5I, -----MIN, GRIEXT, GRIMX, GRI, YELI, RED TRACK CLEAR, 0I, 0I, 0I, 25.5I, 25.5I, -----MIN, DLIPMTEXTIMX, TMI, YELI, RED DWL/CYC-EXIT, 0I, 2.0I, 120I, 25.5I, 25.5I, PMT ACTIVE OUT, ON, PMT ACT DWELL, NO, OTHER - PRI, PMT.OFF, NON-PRI, PMT, OFF, INH EXT TIME, 0.0, PED PR RETURN, OFF, PRIORITY RETURN.OFF, QUEUE DELAY, OFF, COND DELAY, OFF, PHASES, PR RTN%, PHASES, PR RTN%.

Table with columns: PREEMPT PLAN [5], ENABLE....YES, VEH/PED, OVERLAP, TRKCLR, ENA TRL, DWEL VEH, DWEL PED, DWEL OLP, CYC VEH, CYC PED, CYC OLP, EXIT PH, EXIT CAL, SP FUNC.

Table with columns: ENABLE... YES, IPMT, OVRIDE, INTERLOCK, NO DET LOCK, XIDELAY, OINHIBIT, OVERIDE FL, IDURATION, OICLR-GRN, TERM OLP, NOIPC>YEL, YESITERM PH, PED DARK, NOITC RESRV, NOIDWELL FL, LINK PMT, OIX FLCOLR, REDIEEXIT OPT, X TMG PLN, OIRE-SERV, OIFLT TYPE, HARD FREE DUR, PMTIR1, NOIR2, NOIR3, NOIR4, --TIMING, WALKIPED, CLIMN, GRI, YELI, RED ENTRANCE TM, 255I, 255I, 255I, 255I, 25.5I, 25.5I, -----MIN, GRIEXT, GRIMX, GRI, YELI, RED TRACK CLEAR, 0I, 0I, 0I, 25.5I, 25.5I, -----MIN, DLIPMTEXTIMX, TMI, YELI, RED DWL/CYC-EXIT, 0I, 2.0I, 120I, 25.5I, 25.5I, PMT ACTIVE OUT, ON, PMT ACT DWELL, NO, OTHER - PRI, PMT.OFF, NON-PRI, PMT, OFF, INH EXT TIME, 0.0, PED PR RETURN, OFF, PRIORITY RETURN.OFF, QUEUE DELAY, OFF, COND DELAY, OFF, PHASES, PR RTN%, PHASES, PR RTN%.

Table with columns: PREEMPT PLAN [6], ENABLE....YES, VEH/PED, OVERLAP, TRKCLR, ENA TRL, DWEL VEH, DWEL PED, DWEL OLP, CYC VEH, CYC PED, CYC OLP, EXIT PH, EXIT CAL, SP FUNC.

Table with columns: ENABLE... YES, IPMT, OVRIDE, INTERLOCK, NO DET LOCK, XIDELAY, OINHIBIT, OVERIDE FL, IDURATION, OICLR-GRN, TERM OLP, NOIPC>YEL, YESITERM PH, PED DARK, NOITC RESRV, NOIDWELL FL, LINK PMT, OIX FLCOLR, REDIEEXIT OPT, X TMG PLN, OIRE-SERV, OIFLT TYPE, HARD FREE DUR, PMTIR1, NOIR2, NOIR3, NOIR4, --TIMING, WALKIPED, CLIMN, GRI, YELI, RED ENTRANCE TM, 255I, 255I, 255I, 255I, 25.5I, 25.5I, -----MIN, GRIEXT, GRIMX, GRI, YELI, RED TRACK CLEAR, 0I, 0I, 0I, 25.5I, 25.5I, -----MIN, DLIPMTEXTIMX, TMI, YELI, RED DWL/CYC-EXIT, 0I, 2.0I, 120I, 25.5I, 25.5I, PMT ACTIVE OUT, ON, PMT ACT DWELL, NO, OTHER - PRI, PMT.OFF, NON-PRI, PMT, OFF, INH EXT TIME, 0.0, PED PR RETURN, OFF, PRIORITY RETURN.OFF, QUEUE DELAY, OFF, COND DELAY, OFF, PHASES, PR RTN%, PHASES, PR RTN%.

PROGRAM EXTEND TIME ON OPTICAL DETECTOR UNITS FOR 2.0 SEC.

COUNTDOWN PEDESTRIAN SIGNAL OPERATION

Countdown Ped Signals are required to display timing only during Ped Clearance Interval. Consult Ped Signal Module user's manual for instructions on selecting this feature.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 01-0014 DESIGNED: September 2018 SEALED: 09/21/2018 REVISED: N/A

PLANS PREPARED BY: RK&K RUMMEL, KLEPPER & KAHL, LLP 900 RIDGEFIELD DRIVE SUITE 350 RALEIGH, NORTH CAROLINA 27609-3960 NC LICENSE NO. F-0112 • (919) 878-9560


ELECTRICAL AND PROGRAMMING DETAILS FOR: Prepared for the Offices of: [Seal of Pasquotank County]

US 17 Business (Ehringhaus St.) at NC 344 (Halstead Boulevard) Division 1 Pasquotank County Elizabeth City PLAN DATE: September 2018 REVIEWED BY: J O Deaton PREPARED BY: M W Yalch REVIEWED BY: [Signature]

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED [Seal of James O. Deaton, Engineer]

9/21/2018 R:\Projects\Signal\Signal\Drawings\Detail\01-0014e-05-200.dgn dsccar5


PHASING DIAGRAM



PHASING DIAGRAM DETECTION LEGEND

- DETECTED MOVEMENT
- UNDETECTED MOVEMENT (OVERLAP)
- UNSIGNALIZED MOVEMENT
- PEDESTRIAN MOVEMENT


EV PREEMPT PHASES



SIGNAL FACE	PHASE											
	01+5	01+6	02+5	02+6	03+7	03+8	04+7	04+8	EVP 3	EVP 4	EVP 5	EVP 6
11	←	←	←	←	←	←	←	←	←	←	←	←
21,22	R	R	G	G	R	R	R	R	G	R	R	R
31,32	←	←	←	←	←	←	←	←	←	←	←	←
41,42	R	R	R	R	R	G	G	R	R	R	G	R
51	←	←	←	←	←	←	←	←	←	←	←	←
61,62	R	G	R	G	R	R	R	R	G	R	R	R
71	←	←	←	←	←	←	←	←	←	←	←	←
81	R	R	R	R	R	G	G	R	R	G	R	R
82	R	R	R	R	R	G	R	G	R	G	R	R

SIGNAL FACE I.D.

All Heads L.E.D.




ASC/3 DETECTOR INSTALLATION CHART												
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PROGRAMMING							
					PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE	SYSTEM LOOP	NEW CARD
1A	6X60	0	2-4-2	-	1	Yes	-	3	-	S	-	X
1B	6X40	0	2-4-2	-	1	Yes	-	15	-	S	-	X
2A	6X6	300	EXIST	-	2	Yes	1.6	-	-	S	-	X
2B	6X6	300	EXIST	-	2	Yes	1.6	-	-	S	-	X
2C, 2D	6X6	90	EXIST	-	2	Yes	-	-	-	S	-	X
3A	6X40	0	2-4-2	-	3	Yes	-	3	-	S	-	X
3B	6X40	0	2-4-2	-	3	Yes	-	-	-	S	-	X
4A	6X60	0	2-4-2	-	4	Yes	-	-	-	S	-	X
4B	6X60	0	2-4-2	-	4	Yes	-	10	-	S	-	X
5A	6X60	0	2-4-2	-	5	Yes	-	3	-	S	-	X
6A	6X6	300	EXIST	-	6	Yes	1.6	-	-	S	-	X
6B	6X6	300	EXIST	-	6	Yes	1.6	-	-	S	-	X
6C, 6D	6X6	96	EXIST	-	6	Yes	-	-	-	S	-	X
7A	6X60	0	2-4-2	-	7	Yes	-	-	-	S	-	X
8A	6X40	0	2-4-2	-	8	Yes	-	-	-	S	-	X
8B	6X40	0	2-4-2	-	8	Yes	-	-	-	S	-	X
S22	6X6	+235	EXIST	-	-	-	-	-	-	N	X	X
S23	6X6	+235	EXIST	-	-	-	-	-	-	N	X	X
S24	6X6	+200	EXIST	-	-	-	-	-	-	N	X	X
S25	6X6	+200	EXIST	-	-	-	-	-	-	N	X	X
S26	6X6	+265	EXIST	-	-	-	-	-	-	N	X	X
S27	6X6	+265	EXIST	-	-	-	-	-	-	N	X	X

8 Phase Fully Actuated w/ EV Preemption (Elizabeth City Signal System)

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 1 and/or phase 5 may be lagged.
- Phase 3 and/or phase 7 may be lagged.
- Set all detector units to presence mode.
- In the event of loop replacement, refer to the current ITS and Signals Design Manual and submit a Plan of Record to the Signal Design Section.
- Locate new cabinet so as not to obstruct sight distance of vehicles turning right on red.
- Pavement markings are existing.
- Relocate emergency vehicle preemption equipment from existing cabinet to new cabinet.
- This intersection features an optical preemption system. Shown locations of optical detectors are conceptual only.
- Optical detector 10 calls EVP 3; Optical detector 20 calls EVP 4; Optical detector 30 calls EVP 5; Optical detector 40 calls EVP 6;
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.



LEGEND

- | | | | |
|--|--|--|--|
| | PROPOSED Traffic Signal Head | | EXISTING Traffic Signal Head |
| | PROPOSED Modified Signal Head | | EXISTING Modified Signal Head |
| | PROPOSED Pedestrian Signal Head | | EXISTING Pedestrian Signal Head |
| | PROPOSED Signal Pole with Guy | | EXISTING Signal Pole with Guy |
| | PROPOSED Signal Pole with Sidewalk Guy | | EXISTING Signal Pole with Sidewalk Guy |
| | PROPOSED Inductive Loop Detector | | EXISTING Inductive Loop Detector |
| | PROPOSED Controller & Cabinet | | EXISTING Controller & Cabinet |
| | PROPOSED Junction Box | | EXISTING Junction Box |
| | PROPOSED 2-in Underground Conduit | | EXISTING 2-in Underground Conduit |
| | PROPOSED Right of Way | | EXISTING Right of Way |
| | PROPOSED Directional Arrow | | EXISTING Directional Arrow |
| | PROPOSED Guardrail | | EXISTING Guardrail |
| | PROPOSED Fire Hydrant | | EXISTING Fire Hydrant |
| | PROPOSED Metal Strain Pole | | EXISTING Metal Strain Pole |
| | PROPOSED EVP Optical Detector | | EXISTING EVP Optical Detector |
| | PROPOSED "YIELD" Sign | | EXISTING "YIELD" Sign |

ASC/3 EV PREEMPT				
FUNCTION	PRE 3	PRE 4	PRE 5	PRE 6
Exit Phase(s)	2.6	2.6	2.6	2.6
Preempt Override	OFF	OFF	OFF	OFF
Delay Time	0	0	0	0
Ped Clear Through Yellow	N	N	N	N
Terminate Phases	N	N	N	N
Entrance Walk	255*	255*	255*	255*
Entrance Ped Clear	255*	255*	255*	255*
Entrance Min Green	1	1	1	1
Entrance Yellow Change	25.5*	25.5*	25.5*	25.5*
Entrance Red Clear	25.5*	25.5*	25.5*	25.5*
Minimum Dwell Time	12	12	7	7
Preempt Input Extension Time	2	2	2	2
Preempt Max Time	120	120	120	120
Exit Yellow Change	25.5*	25.5*	25.5*	25.5*
Exit Red Clear	25.5*	25.5*	25.5*	25.5*

* Allows normal phase times to be used.

ASC/3 TIMING CHART								
FEATURE	PHASE							
	1	2	3	4	5	6	7	8
Min Green *	7	12	7	7	7	12	7	7
Walk *	0	0	0	0	0	0	0	0
Ped Clear	0	0	0	0	0	0	0	0
Veh. Extension *	2.0	2.0	2.0	1.0	2.0	2.0	1.0	2.0
Max 1 *	30	60	25	40	20	60	15	40
Yellow	3.2	4.5	3.0	5.0	3.2	4.5	3.0	4.5
Red Clear	3.0	1.7	3.7	1.5	3.0	1.9	3.4	1.6
Actuations B4 Add *	-	-	-	-	-	-	-	-
Seconds /Actuation *	-	-	-	-	-	-	-	-
Max Initial *	-	-	-	-	-	-	-	-
Time Before Reduction *	-	-	-	-	-	-	-	-
Time To Reduce *	-	-	-	-	-	-	-	-
Minimum Gap	-	-	-	-	-	-	-	-
Locking Detector	-	X	-	-	-	X	-	-
Recall Position	-	VEH. RECALL	-	-	-	VEH. RECALL	-	-
Dual Entry	-	-	-	-	-	-	-	-
Simultaneous Gap	X	X	X	X	X	X	X	X

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

Signal Upgrade

Prepared for the Offices of:

 Department of Transportation
 State of North Carolina
 Signal Design Section

Plans Prepared By:

 DRMP, Inc.
 8000 Regency Parkway, Suite 175
 Cary, NC 27518
 NC License No. C-2213 (919) 650-1038

US 17 (S. Hughes Blvd.) at NC 344 (Halstead Blvd./ Halstead Blvd. Ext.)

Division 1 Pasquotank County Elizabeth City
 PLAN DATE: March 2018 REVIEWED BY: AJ Davis
 PREPARED BY: JA Le REVIEWED BY: LM Moon

REVISIONS: INIT. DATE

SCALE: 1"=50'


DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SEAL

 Lisa M. Moon
 8/21/2018
 DATE: _____
 SIG. INVENTORY NO. 01-0015

EDI MODEL 2018EClip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



- NOTES:
- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
 - Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
 - Ensure that Red Enable is active at all times during normal operation.
 - Integrate monitor with Ethernet network in cabinet.

NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Program controller to start up in phase 2 Green and 6 Green.
- The cabinet and controller are part of the Elizabeth City Signal System.

SIGNAL HEAD HOOK-UP CHART


LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	11	82	21,22	NU	31,32	41,42	NU	51	61,62	NU	71	81,82	NU	NU	NU	NU	NU	NU
RED		128			101			134			107							
YELLOW		129			102			135			108							
GREEN		130			103			136			109							
RED ARROW	125			116			131			122								
YELLOW ARROW	126	132		117			132			123								
GREEN ARROW	127	133		118			133			124								

NU = Not Used

EQUIPMENT INFORMATION

CONTROLLER.....2070LX
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S4,S5,S7,S8,S10,S11
 PHASES USED.....1,2,3,4,5,6,7,8
 OVERLAP "A".....NOT USED
 OVERLAP "B".....NOT USED
 OVERLAP "C".....NOT USED
 OVERLAP "D".....NOT USED

INPUT FILE POSITION LAYOUT (front view)




FS = FLASH SENSE
 ST = STOP TIME
 PRE = PREEMPT

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND TIME	DELAY TIME	ADDED INITIAL	DETECTOR TYPE
1A	TB2-5,6	I2U	39	2	1	YES		3		S
1B	TB2-7,8	I2L	43	12	1	YES		15		S
2A	TB2-9,10	I3U	63	32	2	YES	1.6			S
2B	TB2-11,12	I3L	76	42	2	YES	1.6			S
2C,2D	TB4-1,2	I4U	47	22	2	YES				S
3A	TB4-5,6	I5U	38	3	3	YES		3		S
3B	TB4-9,10	I6U	41	4	3	YES				S
4A	TB6-1,2	I7U	65	34	4	YES				S
4B	TB6-3,4	I6U	78	44	4	YES		10		S
*S22	TB6-9,10	I9U	60	11	SYS	NO				N
*S23	TB6-11,12	I9L	62	13	SYS	NO				N
5A	TB3-1,2	J1U	55	5	5	YES		3		S
6A	TB3-5,6	J2U	40	6	6	YES	1.6			S
6B	TB3-7,8	J2L	44	16	6	YES	1.6			S
6C,6D	TB3-9,10	J3U	64	36	6	YES				S
7A	TB5-5,6	J5U	57	7	7	YES				S
8A	TB5-9,10	J6U	42	8	8	YES				S
8B	TB5-11,12	J6L	46	18	8	YES				S
*S24	TB7-1,2	J7U	66	38	SYS	NO				N
*S25	TB7-3,4	J7L	79	48	SYS	NO				N
*S26	TB7-9,10	J9U	59	15	SYS	NO				N
*S27	TB7-11,12	J9L	61	17	SYS	NO				N


* System detector only. Remove any assigned vehicle phase.

INPUT FILE POSITION LEGEND: J2L



**OPTICAL PREEMPTION SYSTEM

- Install an optical preemption system for emergency vehicle preemption. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the preemption schemes shown on the Signal Design Plans.
- Ensure that the Optical Preemption System is fully compatible with equipment manufactured in accordance with the specification of the type 2070 controller.




* System detector only. Remove any assigned vehicle phase.

Electrical Detail - Sheet 1 of 2

Electrical and Programming Details For:

Prepared for the Offices of:



DRMP, Inc.
 8000 Regency Parkway, Suite 175
 Cary, NC 27519
 NC License No. C-2213 (919) 650-1038

US 17 (S. Hughes Blvd.)
 at
NC 344 (Halstead Blvd./
Halstead Blvd. Ext.)

Division 1 Pasquotank County Elizabeth City


PLAN DATE: March 2018 REVIEWED BY: AJ Davis

PREPARED BY: DJ White REVIEWED BY: LM Moon

REVISIONS INIT. DATE


DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SEAL



DocuSigned by:
Lisa M. Moon 9/20/2018
 DATE
 SIG. INVENTORY NO. 01-0015

PHASING DIAGRAM




PHASING DIAGRAM DETECTION LEGEND


- DETECTED MOVEMENT
- ◄ UNDETECTED MOVEMENT (OVERLAP)
- ◄ UNSIGNALIZED MOVEMENT
- ◄ PEDESTRIAN MOVEMENT

SIGNAL FACE	PHASE							
	Ø1+5	Ø1+6	Ø2+5	Ø2+6	Ø4+8	EVP 3	EVP 4	EVP 5
11	←	←	←	←	←	←	←	←
21, 22	R	R	G	G	R	R	G	R
41, 42	R	R	R	R	G	R	R	G
51	←	←	←	←	←	←	←	←
61, 62	R	G	R	G	R	G	R	R
81, 82	R	R	R	R	G	R	R	R

EV PREEMPT PHASES



SIGNAL FACE I.D.




ASC/3 DETECTOR INSTALLATION CHART											
DETECTOR					PROGRAMMING						
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE	SYSTEM LOOP NEW CARD
1A	6X40	0	2-4-2	-	1	Yes	-	15	-	S	- X
2A	6X6	300	EXIST	-	2	Yes	-	-	X	N	- X
2B	6X6	300	EXIST	-	2	Yes	-	-	X	N	- X
4A	6X40	+5	2-4-2	-	4	Yes	-	3	-	S	- X
4B	6X40	+5	2-4-2	-	4	Yes	-	10	-	S	- X
5A	6X40	+5	2-4-2	-	5	Yes	-	15	-	S	- X
6A	6X6	300	5	X	6	Yes	-	-	X	N	- X
6B	6X6	300	EXIST	-	6	Yes	-	-	X	N	- X
8A	6X40	+5	2-4-2	-	8	Yes	-	-	-	S	- X
8B	6X40	+5	2-4-2	-	8	Yes	-	10	-	S	- X
S1	6X6	+225	EXIST	-	-	No	-	-	-	N	X X
S2	6X6	+225	EXIST	-	-	No	-	-	-	N	X X
S3	6X6	+225	EXIST	-	-	No	-	-	-	N	X X
S4	6X6	+225	EXIST	-	-	No	-	-	-	N	X X

5 Phase Fully Actuated w/ EV Preemption (Elizabeth City Signal System)

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 1 and/or phase 5 may be lagged.
- Set all detector units to presence mode.
- Locate new cabinet so as not to obstruct sight distance of vehicles turning right on red
- Pavement markings are existing.
- This intersection features an optical preemption system. Shown location of optical detectors are conceptual only.
- Program pedestrian heads to countdown the flashing "Don't Walk" time only.
- Relocate existing optical detection equipment from existing cabinet to new cabinet.
- Optical detector 10 calls EVP 3; Optical detector 20 calls EVP 4; Optical detector 30 calls EVP 5; Optical detector 40 calls EVP 6.
- Raise spans to obtain 17' minimum clearance for signal head heights.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede this values.



PROPOSED		EXISTING	
○	Traffic Signal Head	●	N/A
◐	Modified Signal Head	◐	N/A
⊥	Sign	⊥	N/A
⊥	Pedestrian Signal Head With Push Button & Sign	⊥	N/A
○	Signal Pole with Guy	●	N/A
○	Signal Pole with Sidewalk Guy	●	N/A
⊠	Inductive Loop Detector	⊠	N/A
⊠	Controller & Cabinet	⊠	N/A
⊠	Junction Box	⊠	N/A
⊠	2-in Underground Conduit	⊠	N/A
→	Right of Way	→	N/A
→	Directional Arrow	→	N/A
○	Optical Detector	○	N/A

ASC/3 TIMING CHART

FEATURE	PHASE					
	1	2	4	5	6	8
Min Green *	7	12	7	7	12	7
Walk *	0	0	0	0	0	0
Ped Clear	0	0	0	0	0	0
Veh. Extension *	2.0	6.0	2.0	2.0	6.0	2.0
Max I *	30	90	30	30	90	30
Yellow	3.0	4.5	3.8	3.0	4.5	3.2
Red Clear	2.8	1.6	2.2	3.1	1.6	3.2
Actions B4 Add *	-	0	-	-	0	-
Seconds/Actuation *	-	1.5	-	-	1.5	-
Max Initial *	-	34	-	-	34	-
Time Before Reduction *	-	15	-	-	15	-
Time To Reduce *	-	45	-	-	45	-
Minimum Gap	-	3.0	-	-	3.0	-
Locking Detector	-	X	-	-	X	-
Recall Position	-	VEH. RECALL	-	-	VEH. RECALL	-
Dual Entry	-	-	X	-	-	X
Simultaneous Gap	X	X	X	X	X	X


* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

ASC/3 EV PREEMPT

FUNCTION	PRE 3	PRE 4	PRE 5
Exit Phase(s)	2,6	2,6	2,6
Preempt Override	OFF	OFF	OFF
Delay Time	0	0	0
Ped Clear Through Yellow	N	N	N
Terminate Phases	N	N	N
Entrance Walk	255*	255*	255*
Entrance Ped Clear	255*	255*	255*
Entrance Min Green	1	1	1
Entrance Yellow Change	25.5*	25.5*	25.5*
Entrance Red Clear	25.5*	25.5*	25.5*
Minimum Dwell Time	7	7	7
Preempt Input Extension Time	2	2	2
Preempt Max Time	120	120	120
Exit Yellow Change	25.5*	25.5*	25.5*
Exit Red Clear	25.5*	25.5*	25.5*

* Allows normal phase times to be used.

Signal Upgrade




US 17 (S. Hughes Blvd.) at SR 1308 (W. Church St.)	
Divison 1 Pasquotank County Elizabeth City	SEAL
PLAN DATE: February 2018	REVIEWED BY: AJ Davis
PREPARED BY: JA Le	REVIEWED BY: LM Moon
REVISIONS	INIT. DATE

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SCALE: 1"=50'	8/21/2018

EDI MODEL 2018EClip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



- NOTES:
- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
 - Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
 - Ensure that Red Enable is active at all times during normal operation.
 - Integrate monitor with Ethernet network in cabinet.

NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Program phases 4 and 8 for Dual Entry.
- Program controller to start up in phase 2 Green and 6 Green.
- The cabinet and controller are part of the Elizabeth City Signal System.

EQUIPMENT INFORMATION

CONTROLLER.....2070LX
 CABINET.....332 W/AUX
 SOFTWARE.....ECONDLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S5,S7,S8,S11,AUX S1,
 AUX S4
 PHASES USED.....1,2,4,5,6,8
 OVERLAP "A".....*
 OVERLAP "B".....NOT USED
 OVERLAP "C".....*
 OVERLAP "D".....NOT USED

* See overlap programming detail on sheet 2


SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6	
CNU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18	
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE	
SIGNAL HEAD NO.	1*	21,22	NU	NU	41,42	NU	51*	61,62	NU	NU	81,82	NU	11*	NU	NU	51*	NU	NU	
RED		128			101			134			107								
YELLOW	*	129			102		*	135			108								
GREEN		130			103			136			109								
RED ARROW													A121					A114	
YELLOW ARROW														A122					A115
FLASHING YELLOW ARROW														A123					A116
GREEN ARROW	127																		

NU = Not Used
 * Denotes install load resistor. See load resistor installation detail this sheet.
 ★ See pictorial of head wiring in detail this sheet.

INPUT FILE POSITION LAYOUT

(front view)




INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND TIME	DELAY TIME	ADDED INITIAL	DETECTOR TYPE
1A ¹	TB2-1,2	I1U	56	1	1	YES		15		S
	-	J4U	48	26	6	YES		3		S
	2A	TB2-5,6	I2U	39	2	YES			X	S
	2B	TB2-7,8	I2L	43	12	2	YES		X	S
4A	TB4-9,10	I6U	41	4	4	YES		3		S
	4B	TB4-11,12	I6L	45	14	4	YES	10		S
* S1	TB6-9,10	I9U	60	11	SYS	NO				N
* S2	TB6-11,12	I9L	62	13	SYS	NO				N
5A ²	TB3-1,2	J1U	55	5	5	YES		15		S
	-	I4U	47	22	2	YES		3		S
6A	TB3-5,6	J2U	40	6	6	YES			X	S
6B	TB3-7,8	J2L	44	16	6	YES			X	S
8A	TB5-9,10	J6U	42	8	8	YES				S
8B	TB5-11,12	J6L	46	18	8	YES		10		S
* S3	TB7-9,10	J9U	59	15	SYS	NO				N
* S4	TB7-11,12	J9L	61	17	SYS	NO				N

- Add jumper from I1-W to J4-W, on rear of input file.
 - Add jumper from I5-W to J8-W, on rear of input file.
- * System detector only. Remove any assigned vehicle phase.

FYA SIGNAL WIRING DETAIL

(wire signal heads as shown)




NOTE: See overlap programming instructions on sheet 2 of 3

LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown)

VALUE (ohms)	WATTAGE
1.5K - 1.9K	25W (min)
2.0K - 3.0K	10W (min)



**OPTICAL PREEMPTION SYSTEM

- Install an optical preemption system for emergency vehicle preemption. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the preemption schemes shown on the Signal Design Plans.
- Ensure that the Optical Preemption System is fully compatible with equipment manufactured in accordance with the specification of the type 2070 controller.



Electrical Detail - Sheet 1 of 3

Electrical and Programming Details For:

US 17 (S. Hughes Blvd.) at SR 1308 (W. Church St.)

Divison 1 Pasquotank County Elizabeth City

PLAN DATE: February 2018 REVIEWED BY: AJ Davis

PREPARED BY: DJ White REVIEWED BY: LM Moon

REVISIONS: INIT. DATE

DocuSigned by: Lisa M. Moon 9/20/2018

SIG. INVENTORY NO. 01-0016

ECONOLITE ASC/3-2070 EMERGENCY VEHICLE PREEMPT PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select 4. PREEMPTOR/TSP
2. From PREEMPTOR/TSP/SCP Submenu select 1. PREEMPT PLAN 1-10

Place cursor in [] next to Preempt Plan and press 3. Then press the right cursor arrow and toggle the controller to YES. Next cursor down. This will select Emergency Vehicle Preempt #3.

Place cursor in [] next to Preempt Plan and press 4. Then press the right cursor arrow and toggle the controller to YES. Next cursor down. This will select Emergency Vehicle Preempt #4.

Place cursor in [] next to Preempt Plan and press 5. Then press the right cursor arrow and toggle the controller to YES. Next cursor down. This will select Emergency Vehicle Preempt #5.

```

PREEMPT PLAN [ 3]  ENABLE....YES
VEH/PED 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
OVERLAP A B C D E F G H I J K L M N O P
TRKCLR V . . . . .
TRKCLR O . . . . .
ENA TRL . . . . .
DWEL VEH X . . . . X . . . . .
DWEL PED . . . . .
DWEL OLPF1 .F1 . . . . .
CYC VEH . . . . .
CYC PED . . . . .
CYC OLP . . . . .
EXIT PH . X . . . X . . . . .
EXIT CAL . . . . .
SP FUNC . . . . .
    
```

```

ENABLE... YESIPMT OVRIDE..IINTERLOCK. NO
DET LOCK... XIDELAY.. 0IINHIBIT... 0
OVERIDE FL. .IDURATION 0ICLR-GRN... NO
TERM OLP. NOIPC>YEL NOITERM PH NO
PED DARK.. NOITC RESRV NOIDWELL FL OFF
LINK PMT....0IX FLCOLR REDIEEXIT OPT. OFF
X TMG PLN...0IRE-SERV.. 0IFLT TYPE.HARD
FREE DUR PMTIR1 NOIR2 NOIR3 NOIR4 NO
--TIMING----WALKIPED CLIMN GRI YELI RED
ENTRANCE TM. 255I 255I 1I25.5I25.5
-----MIN GRIEXT GRIMX GRI YELI RED
TRACK CLEAR 0I 0I 0I25.5I25.5
-----MIN DLIPMTEXTIMX TMI YELI RED
DWL/CYC-EXIT 7I 2.0I 120I25.5I25.5
PMT ACTIVE OUT..ON PMT ACT DWELL...NO
OTHER - PRI PMT.OFF NON-PRI PMT....OFF
INH EXT TIME... 0.0 PED PR RETURN...OFF
PRIORITY RETURN.OFF QUEUE DELAY.... OFF
COND DELAY.....OFF
PHASES 1 2 3 4 5 6 7 8
PR RTN% 0 0 0 0 0 0 0 0
PHASES 9 10 11 12 13 14 15 16
PR RTN% 0 0 0 0 0 0 0 0
    
```

```

PREEMPT PLAN [ 4]  ENABLE....YES
VEH/PED 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
OVERLAP A B C D E F G H I J K L M N O P
TRKCLR V . . . . .
TRKCLR O . . . . .
ENA TRL . . . . .
DWEL VEH . X . . . X . . . . .
DWEL PED . . . . .
DWEL OLPF1 .F1 . . . . .
CYC VEH . . . . .
CYC PED . . . . .
CYC OLP . . . . .
EXIT PH . X . . . X . . . . .
EXIT CAL . . . . .
SP FUNC . . . . .
    
```

```

ENABLE... YESIPMT OVRIDE..IINTERLOCK. NO
DET LOCK... XIDELAY.. 0IINHIBIT... 0
OVERIDE FL. .IDURATION 0ICLR-GRN... NO
TERM OLP. NOIPC>YEL NOITERM PH NO
PED DARK.. NOITC RESRV NOIDWELL FL OFF
LINK PMT....0IX FLCOLR REDIEEXIT OPT. OFF
X TMG PLN...0IRE-SERV.. 0IFLT TYPE.HARD
FREE DUR PMTIR1 NOIR2 NOIR3 NOIR4 NO
--TIMING----WALKIPED CLIMN GRI YELI RED
ENTRANCE TM. 255I 255I 1I25.5I25.5
-----MIN GRIEXT GRIMX GRI YELI RED
TRACK CLEAR 0I 0I 0I25.5I25.5
-----MIN DLIPMTEXTIMX TMI YELI RED
DWL/CYC-EXIT 7I 2.0I 120I25.5I25.5
PMT ACTIVE OUT..ON PMT ACT DWELL...NO
OTHER - PRI PMT.OFF NON-PRI PMT....OFF
INH EXT TIME... 0.0 PED PR RETURN...OFF
PRIORITY RETURN.OFF QUEUE DELAY.... OFF
COND DELAY.....OFF
PHASES 1 2 3 4 5 6 7 8
PR RTN% 0 0 0 0 0 0 0 0
PHASES 9 10 11 12 13 14 15 16
PR RTN% 0 0 0 0 0 0 0 0
    
```

```

PREEMPT PLAN [ 5]  ENABLE....YES
VEH/PED 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
OVERLAP A B C D E F G H I J K L M N O P
TRKCLR V . . . . .
TRKCLR O . . . . .
ENA TRL . . . . .
DWEL VEH . . . X . . . X . . . . .
DWEL PED . . . . .
DWEL OLP . . . . .
CYC VEH . . . . .
CYC PED . . . . .
CYC OLP . . . . .
EXIT PH . X . . . X . . . . .
EXIT CAL . . . . .
SP FUNC . . . . .
    
```

```

ENABLE... YESIPMT OVRIDE..IINTERLOCK. NO
DET LOCK... XIDELAY.. 0IINHIBIT... 0
OVERIDE FL. .IDURATION 0ICLR-GRN... NO
TERM OLP. NOIPC>YEL NOITERM PH NO
PED DARK.. NOITC RESRV NOIDWELL FL OFF
LINK PMT....0IX FLCOLR REDIEEXIT OPT. OFF
X TMG PLN...0IRE-SERV.. 0IFLT TYPE.HARD
FREE DUR PMTIR1 NOIR2 NOIR3 NOIR4 NO
--TIMING----WALKIPED CLIMN GRI YELI RED
ENTRANCE TM. 255I 255I 1I25.5I25.5
-----MIN GRIEXT GRIMX GRI YELI RED
TRACK CLEAR 0I 0I 0I25.5I25.5
-----MIN DLIPMTEXTIMX TMI YELI RED
DWL/CYC-EXIT 7I 2.0I 120I25.5I25.5
PMT ACTIVE OUT..ON PMT ACT DWELL...NO
OTHER - PRI PMT.OFF NON-PRI PMT....OFF
INH EXT TIME... 0.0 PED PR RETURN...OFF
PRIORITY RETURN.OFF QUEUE DELAY.... OFF
COND DELAY.....OFF
PHASES 1 2 3 4 5 6 7 8
PR RTN% 0 0 0 0 0 0 0 0
PHASES 9 10 11 12 13 14 15 16
PR RTN% 0 0 0 0 0 0 0 0
    
```

ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select 2. CONTROLLER
2. From CONTROLLER Submenu select 2. VEHICLE OVERLAPS

OVERLAP A

Select TMG VEH OVLP [A] and 'PPLT FYA'

```

TMG VEH OVLP...[A] TYPE: ....PPLT FYA
PROTECTED LEFT TURN.... PHASE 1
OPPOSING THROUGH..... PHASE 2

FLASHING ARROW OUTPUT.....CH9 ISOLATE
DELAY START OF: FYA..0.0 CLEARANCE..0.0
ACTION PLAN SF BIT DISABLE..... 0
    
```

Toggle Twice

OVERLAP C

Select TMG VEH OVLP [C] and 'PPLT FYA'

```

TMG VEH OVLP...[C] TYPE: ....PPLT FYA
PROTECTED LEFT TURN.... PHASE 5
OPPOSING THROUGH..... PHASE 6

FLASHING ARROW OUTPUT.....CH11 ISOLATE
DELAY START OF: FYA..0.0 CLEARANCE..0.0
ACTION PLAN SF BIT DISABLE..... 0
    
```

END PROGRAMMING

THIS ELECTRICAL DETAIL IS FOR
 THE SIGNAL DESIGN: 01-0016
 DESIGNED: FEBRUARY 2018
 SEALED: 08/21/2018
 REVISED: N/A

Electrical Detail - Sheet 2 of 3

ELECTRICAL AND PROGRAMMING DETAILS FOR:

Prepared for the Offices of:



US 17 (S. Huhges Blvd.)
 at
 SR 1308 (W. Church St.)

Divison 1 Pasquotank County Elizabeth City

PLAN DATE: February 2018 REVIEWED BY: AJ Davis
 PREPARED BY: DJ White REVIEWED BY: LM Moon


REVISIONS	INIT.	DATE

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED



DocuSigned by:
 Lisa M. Moon 9/20/2018
 58CE68B083D0421 DATE
 SIG. INVENTORY NO. 01-0016

PHASING DIAGRAM



EV PREEMPT PHASES




TABLE OF OPERATION table with columns for SIGNAL FACE and PHASE (01+5 through F LASH).


ASC/3 DETECTOR INSTALLATION CHART table with columns for LOOP, SIZE, DISTANCE, TURNS, NEW LOOP, PHASE, CALLING, EXTEND TIME, DELAY TIME, USE ADDED INITIAL, TYPE, LOOP, SYSTEM, NEW CARD.

6 Phase Fully Actuated w/ EV Preemption (Elizabeth City Signal System)



NOTES

- List of 10 notes regarding signal timing, detector installation, and pavement markings.


PHASING DIAGRAM DETECTION LEGEND



SIGNAL FACE I.D.



LEGEND



ASC/3 TIMING CHART

ASC/3 TIMING CHART table with columns for FEATURE and PHASE (1 through 6, **10, OLG).

ASC/3 EV PREEMPT

ASC/3 EV PREEMPT table with columns for FUNCTION and PRE 3 through PRE 6.


Signal Upgrade

Project information block including DRMP logo, project name, dates, signatures, and seals.

24-SEP-2018 10:09 R:\415942\451\0401\451\0401-001-9-08232018.dgn

EDI MODEL 2018EClip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- Ensure that Red Enable is active at all times during normal operation.
- Integrate monitor with Ethernet network in cabinet.

NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Program controller to start up in phase 2 Green and 6 Green.
- The cabinet and controller are part of the Elizabeth City Signal System.

EQUIPMENT INFORMATION

CONTROLLER.....2070LX
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S4,S5,S7,S8,AUX S5
 PHASES USED.....1,2,3,4,5,6,**10
 OVERLAP "A".....NOT USED
 OVERLAP "B".....NOT USED
 OVERLAP "C".....NOT USED
 OVERLAP "D".....*
 OVERLAP "G".....*

* See overlap programming detail on sheet 2.
 ** Phase used for timing purposes only.


SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	DLG	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	DLC	OLD	SPARE
SIGNAL HEAD NO.	11	21,22,23	NU	31	32	41	42	NU	51	61,62	NU	NU	NU	NU	NU	NU	12,13	NU
RED		128		116	116	101	101			134								
YELLOW		129		117	117	102	102			135								
GREEN		130		118	118	103	103			136								
RED ARROW	125								131									A101
YELLOW ARROW	126								132									A102
FLASHING YELLOW ARROW																		A103
GREEN ARROW	127			118		103		133										

NU = Not Used

FYA SIGNAL WIRING DETAIL

(wire signal heads as shown)



12,13

INPUT FILE POSITION LAYOUT

(front view)

FILE "I"	1	2	3	4	5	6	7	8	9	10	11	12	13	14
U	∅ 1 1A	∅ 1 1B	∅ 2/SYS 2A/S1	∅ 2/SYS 2C/S3	∅ 3 3A	∅ 3 3B	∅ 4 4A	S -O- S	S -O- S	S -O- S	S -O- S	S -O- S	S -O- S	FS DC ISOLATOR ST
L	NOT USED	∅ 1 1C	∅ 2/SYS 2B/S2	NOT USED	NOT USED	NOT USED	NOT USED	←-∅Σm -O- Σ-	←-∅Σm -O- Σ-	←-∅Σm -O- Σ-	←-∅Σm -O- Σ-	←-∅Σm -O- Σ-	←-∅Σm -O- Σ-	DC ISOLATOR
U	∅ 5 5A	∅ 6/SYS 6A/S4	S -O- S	S -O- S	S -O- S	S -O- S	S -O- S	S -O- S	S -O- S	S -O- S	S -O- S	S -O- S	S -O- S	PRE 3 * Optical 4 Ch. Card PRE 4
L	NOT USED	∅ 6/SYS 6B/S5	←-∅Σm -O- Σ-	←-∅Σm -O- Σ-	←-∅Σm -O- Σ-	←-∅Σm -O- Σ-	←-∅Σm -O- Σ-	←-∅Σm -O- Σ-	←-∅Σm -O- Σ-	←-∅Σm -O- Σ-	←-∅Σm -O- Σ-	←-∅Σm -O- Σ-	←-∅Σm -O- Σ-	PRE 5 PRE 6


EX.: 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
 ST = STOP TIME
 PRE = PREEMPT

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND TIME	DELAY TIME	ADDED INITIAL	DETECTOR TYPE
1A	TB2-1,2	I1U	56	1	1	YES				S
1B	TB2-5,6	I2U	39	2	1	YES		15		S
1C	TB2-7,8	I2L	43	12	1	YES				S
2A/S1	TB2-9,10	I3U	63	32	2/SYS	YES			X	N
2B/S2	TB2-11,12	I3L	76	42	2/SYS	YES			X	N
2C/S3	TB4-1,2	I4U	47	22	2/SYS	YES			X	N
3A	TB4-5,6	I5U	58	3	3/10	YES				S
3B	TB4-9,10	I6U	41	4	3/10	YES		10		S
4A	TB6-1,2	I7U	65	34	4	YES				S
5A	TB3-1,2	J1U	55	5	5	YES		3		S
6A/S4	TB3-5,6	J2U	40	6	6/SYS	YES			X	N
6B/S5	TB3-7,8	J2L	44	16	6/SYS	YES			X	N

INPUT FILE POSITION LEGEND: J2L




** OPTICAL PREEMPTION SYSTEM

- Install an optical preemption system for emergency vehicle preemption. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the preemption schemes shown on the Signal Design Plans.
- Ensure that the Optical Preemption System is fully compatible with equipment manufactured in accordance with the specification of the type 2070 controller.

Electrical Detail - Sheet 1 of 4

ELECTRICAL AND PROGRAMMING DETAILS FOR:



US 17 (S. Hughes Blvd.) at US 17 Bus. (W. Ehringhaus St.) / SR 1145 (Oak Stump Rd.) / Shopping Center Entrance

Division 1 Pasquotank County Elizabeth City

PLAN DATE: June 2018 REVIEWED BY: AJ Davis

PREPARED BY: JA Le REVIEWED BY: LM Moon

REVISIONS	INIT.	DATE

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SEAL

PROFESSIONAL ENGINEER

SEAL 022516

LISA M. MOON

DocuSigned by: Lisa M. Moon 9/24/2018

SIG. INVENTORY NO. 01-0019

24-SEP-2018 10:19 R:\5942\51\001\DWG\18\EDM\18\01-0019-08232018a.dgn AT CAR-PLAN-DWG-W7

ECONOLITE ASC/3-2070 LOGIC PROCESSOR PROGRAMMING DETAIL FOR SIDE STREET PHASING

(program controller as shown)

1. From Main Menu select 1. CONFIGURATION
2. From CONFIGURATION Submenu select 8. LOGIC PROCESSOR
3. From LOGIC PROCESSOR Submenu select 2. LOGIC STATEMENTS

ENTER A "1" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#:  1 COPY FROM:  1 ACTIVE: M (T/F)
IF   VEH GREEN ON PH      3 IS ON

THEN LP SET LOGIC FLAG    1      ON

ELSE
    
```

PHASE 3 GREEN SETS
LOGIC FLAG 1 ON
(SIDE STREET BACKUP)

ENTER A "3" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#:  3 COPY FROM:  3 ACTIVE: M (T/F)
IF   VEH GREEN ON PH      2 IS ON

THEN LP SET LOGIC FLAG    1      OFF

ELSE
    
```

TURNS LOGIC FLAG 1
OFF TO ALLOW NORMAL
OPERATION

ENTER A "2" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#:  2 COPY FROM:  2 ACTIVE: M (T/F)
IF   LP FLAG                1 IS ON

THEN CTR OMIT PHASE        10     ON

ELSE
    
```

OMIT PHASE 10 SO
PHASE 3 MOVEMENTS
RUN ONCE PER CYCLE

4. From LOGIC PROCESSOR Submenu select 1. LOGIC STATEMENT CONTROL

ENABLE LOGIC PROCESSOR STATEMENTS 1, 2 & 3 BY POSITIONING THE CURSOR OVER THE FIELDS SHOWN BELOW AND USING THE TOGGLE KEY TO ENABLE THEM.

LOGIC STATEMENT CONTROL	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5
LP 1-15	E	E	E
LP 16-30
LP 31-45
LP 46-60
LP 61-75
LP 76-90

END PROGRAMMING

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 01-0019
DESIGNED: MARCH 2018
SEALED: 09/24/2018
REVISED: N/A

Electrical Detail - Sheet 3 of 4

ELECTRICAL AND PROGRAMMING DETAILS FOR:

Prepared for the Offices of:

Plans Prepared By:

DRMP, Inc.
8000 Regency Parkway, Suite 175
Cary, NC 27518
NC License No. LC-2215 (919) 650-1038

750 N. Greenfield Pkwy, Garner, NC 27529

US 17 (S. Hughes Blvd.) at US 17 Bus. (W. Ehringhaus St.)/ SR 1145 (Oak Stump Rd.)/ Shopping Center Entrance	
Division 1 Pasquotank County Elizabeth City	
PLAN DATE: March 2018	REVIEWED BY: AJ Davis
PREPARED BY: JA Le	REVIEWED BY: LM Moon
REVISIONS	INIT. DATE


DOCUMENT NOT CONSIDERED
FINAL UNLESS ALL
SIGNATURES COMPLETED

SEAL

DocuSigned by:
Lisa M. Moon 9/24/2018
SIC65880300421 DATE
SIG. INVENTORY NO. 01-0019

24-SEP-2018 10:19
R:\05942\51001\5\KOS\00\01\0019-08232018e.dgn
r:\lowton AT CAR-RALANTON-W7

PHASING DIAGRAM



PHASING DIAGRAM DETECTION LEGEND
 ● DETECTED MOVEMENT
 ◀ UNDETECTED MOVEMENT (OVERLAP)
 - - - UNSIGNALIZED MOVEMENT
 - - - PEDESTRIAN MOVEMENT

EV PREEMPT PHASES





TABLE OF OPERATION

SIGNAL FACE	PHASE							
	01+6	02+6	04	EVP 3	EVP 4	EVP 5	LEFT	RIGHT
11	←	←	←	←	←	←	←	←
21, 22	R	G	R	R	G	R	Y	
41, 42	←	←	←	←	←	←	←	←
61, 62	G	G	R	G	G	R	Y	

SIGNAL FACE I.D.




ASC/3 DETECTOR INSTALLATION CHART

LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PROGRAMMING							
					PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE	LOOP	NEW CARD
1A	6X40	+5	2-4-2	-	1	Yes	-	15	-	S	-	X
					6	Yes	-	3	-	G	-	X
2A/S1	6X6	300	EXIST	-	2	Yes	-	-	X	N	X	X
2B/S2	6X6	300	EXIST	-	2	Yes	-	-	X	N	X	X
4A	6X40	+5	2-4-2	-	4	Yes	-	3	-	S	-	X
4B	6X40	+5	2-4-2	-	4	Yes	-	-	-	S	-	X
6A/S3	6X6	300	EXIST	-	6	Yes	-	-	X	N	X	X
6B/S4	6X6	300	EXIST	-	6	Yes	-	-	X	N	X	X

3 Phase Fully Actuated w/ EV Preemption (Elizabeth City Signal System)

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Set all detector units to presence mode.
- Phase 1 may be logged.
- Locate new cabinet so as not to obstruct sight distance of vehicles turning right on red.
- Pavement markings are existing.
- This intersection features an optical preemption system. Shown locations of optical detectors are conceptual only.
- Optical detector 10 calls EVP 3: Optical detector 20 calls EVP 4: Optical detector 30 calls EVP 5:
- Install new pole directly adjacent to existing pole and raise signal spans to obtain 17' minimum clearance for signal head heights.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Remove existing "Left Turn Yield on Green" ball sign(s)-(R10-12).



ASC/3 TIMING CHART

FEATURE	PHASE			
	1	2	4	6
Min Green *	7	12	7	12
Walk *	0	0	0	0
Ped Clear	0	0	0	0
Veh. Extension *	2.0	6.0	2.0	6.0
Max 1 *	30	90	30	90
Yellow	3.0	4.5	3.0	4.5
Red Clear	1.8	1.8	3.6	1.8
Actuations B4 Add *	-	0	-	0
Seconds /Actuation *	-	1.5	-	1.5
Max Initial *	-	34	-	34
Time Before Reduction *	-	15	-	15
Time To Reduce *	-	30	-	30
Minimum Gap	-	3.0	-	3.0
Locking Detector	-	X	-	X
Recall Position	-	VEH RECALL	-	VEH RECALL
Dual Entry	-	-	-	-
Simultaneous Gap	X	X	X	X

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

ASC/3 EV PREEMPT

FUNCTION	PRE 3	PRE 4	PRE 5
Exit Phase(s)	2,6	4	2,6
Preempt Override	OFF	OFF	OFF
Delay Time	0	0	0
Ped Clear Through Yellow	N	N	N
Terminate Phases	N	N	N
Entrance Walk	255*	255*	255*
Entrance Ped Clear	255*	255*	255*
Entrance Min Green	1	1	1
Entrance Yellow Change	25.5*	25.5*	25.5*
Entrance Red Clear	25.5*	25.5*	25.5*
Minimum Dwell Time	12	12	7
Preempt Input Extension Time	2	2	2
Preempt Max Time	120	120	120
Exit Yellow Change	25.5*	25.5*	25.5*
Exit Red Clear	25.5*	25.5*	25.5*

* Allows normal phase times to be used.

LEGEND

PROPOSED	EXISTING
○ → Traffic Signal Head	● → N/A
○ → Modified Signal Head	○ → N/A
□ → Sign	□ → N/A
□ → Pedestrian Signal Head With Push Button & Sign	□ → N/A
□ → Signal Pole with Guy	□ → N/A
□ → Signal Pole with Sidewalk Guy	□ → N/A
□ → Inductive Loop Detector	□ → N/A
□ → Controller & Cabinet	□ → N/A
□ → Junction Box	□ → N/A
□ → 2-in Underground Conduit	□ → N/A
→ → Directional Arrow	→ → N/A
○ → Optical Detector	○ → N/A
Ⓐ → "YIELD" SIGN (R1-2)	Ⓐ → N/A
Ⓑ → "DOWNTOWN" Sign (D1-1)	Ⓑ → N/A

Signal Upgrade

Prepared For the Offices of:

US 17-US 158 (N. Hughes Blvd.) at US 158-NC 168 (W. Elizabeth St.)

Division 1 Pasquotank County Elizabeth City

PLAN DATE: March 2018 REVIEWED BY: AJ Davis

PREPARED BY: JA Le REVIEWED BY: LM Moon

REVISIONS: INIT. DATE

SCALE: 0 40' 1"=40'

DRMP, Inc. 8000 Regency Parkway, Suite 175 Cary, NC 27518 NC License No. C-2215 (919) 650-1038

Seal of the State of North Carolina Professional Engineer License No. 022516 Lisa M. Moon


DocuSigned by: Lisa M. Moon 8/22/2018

SIG. INVENTORY NO. 01-0020

22-AUG-2018 08:29 R:\05942\5\0001\5\0001\0001\0001-0020.dgn DWI:TB AT CAR-DWH:TE-LTW

EDI MODEL 2018EClip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



- NOTES:
- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
 - Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
 - Ensure that Red Enable is active at all times during normal operation.
 - Integrate monitor with Ethernet network in cabinet.

NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Program controller to start up in phase 2 Green and 6 Green.
- The cabinet and controller are part of the Elizabeth City Signal System.

EQUIPMENT INFORMATION

CONTROLLER.....2070LX
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S5,S8,AUX S1
 PHASES USED.....1,2,4,6
 OVERLAP "A".....*
 OVERLAP "B".....NOT USED
 OVERLAP "C".....NOT USED
 OVERLAP "D".....NOT USED


* See overlap programming detail on sheet 2

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CNU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	11*	21,22	NU	NU	41,42	NU	NU	61,62	NU	NU	NU	NU	11*	NU	NU	NU	NU	NU
RED		128						134										
YELLOW	*	129						135										
GREEN		130						136										
RED ARROW					101								A121					
YELLOW ARROW					102								A122					
FLASHING YELLOW ARROW													A123					
GREEN ARROW	127				103													

NU = Not Used
 * Denotes install load resistor. See load resistor installation detail this sheet.
 ★ See pictorial of head wiring in detail this sheet.

INPUT FILE POSITION LAYOUT (front view)




EX.: 1A, 2A, ETC. = LOOP NO.'S
 FS = FLASH SENSE
 ST = STOP TIME
 PRE = PREEMPT

INPUT FILE CONNECTION & PROGRAMMING CHART


LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND TIME	DELAY TIME	ADDED INITIAL	DETECTOR TYPE
1A ¹	TB2-1,2	I1U	56	1	1	YES		15		S
	-	J4U	48	26	6	YES		3		G
2A/S1	TB2-5,6	I2U	39	2	2/SYS	YES			X	N
2B/S2	TB2-7,8	I2L	43	12	2/SYS	YES			X	N
4A	TB4-9,10	I6U	41	4	4	YES		3		S
4B	TB4-11,12	I6L	45	14	4	YES				S
6A/S3	TB3-5,6	J2U	40	6	6/SYS	YES			X	N
6B/S4	TB3-7,8	J2L	44	16	6/SYS	YES			X	N

¹Add jumper from I1-W to J4-W, on rear of input file.



FYA SIGNAL WIRING DETAIL

(wire signal heads as shown)



LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown)

VALUE (ohms)	WATTAGE
1.5K - 1.9K	25W (min)
2.0K - 3.0K	10W (min)



**OPTICAL PREEMPTION SYSTEM

- Install an optical preemption system for emergency vehicle preemption. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the preemption schemes shown on the Signal Design Plans.
- Ensure that the Optical Preemption System is fully compatible with equipment manufactured in accordance with the specification of the type 2070 controller.



Electrical Detail - Sheet 1 of 2

ELECTRICAL AND PROGRAMMING DETAILS FOR: Prepared for the Offices of: 	US 17-US 158 (N. Hughes Blvd.) at US 158-NC 168 (W.Elizabeth St.) Division 1 Pasquotank County Elizabeth City		SEAL
	PLAN DATE: March 2018 PREPARED BY: DJ White	REVIEWED BY: AJ Davis REVIEWED BY: LM Moon	

ECONOLITE ASC/3-2070 EMERGENCY VEHICLE PREEMPT PROGRAMMING DETAIL

(program controller as shown)

- From Main Menu select **4. PREEMPTOR/TSP**
- From PREEMPTOR/TSP/SCP Submenu select **1. PREEMPT PLAN 1-10**

Place cursor in [] next to Preempt Plan and press 3. Then press the right cursor arrow and toggle the controller to YES. Next cursor down. This will select Emergency Vehicle Preempt #3.

Place cursor in [] next to Preempt Plan and press 4. Then press the right cursor arrow and toggle the controller to YES. Next cursor down. This will select Emergency Vehicle Preempt #4.

Place cursor in [] next to Preempt Plan and press 5. Then press the right cursor arrow and toggle the controller to YES. Next cursor down. This will select Emergency Vehicle Preempt #5.

```

PREEMPT PLAN [ 3 ]  ENABLE....YES
  VEH/PED 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
  OVERLAP A B C D E F G H I J K L M N O P
  TRKCLR V . . . . .
  TRKCLR O . . . . .
  ENA TRL . . . . .
  DWEL VEH X . . . . X . . . . .
  DWEL PED . . . . .
  DWEL OLPF1 . . . . .
  CYC VEH . . . . .
  CYC PED . . . . .
  CYC OLP . . . . .
  EXIT PH . X . . . X . . . . .
  EXIT CAL . . . . .
  SP FUNC . . . . .

```

```

ENABLE... YESIPMT OVRIDE.. IINTERLOCK. NO
DET LOCK... XIDELAY.. 0IINHIBIT... 0
OVERIDE FL. .IDURATION 0ICLR-GRN... NO
TERM OLP. NOIPC>YEL NOITERM PH NO
PED DARK.. NOITC RESRV NOIDWELL FL OFF
LINK PMT....0IX FLCOLR REDIEEXIT OPT. OFF
X TMG PLN...0IRE-SERV.. 0IFLT TYPE.HARD
FREE DUR PMTIR1 NOIR2 NOIR3 NOIR4 NO
--TIMING-----WALKIPED CLIMN GRI YELI RED
ENTRANCE TM. 255I 255I 1125.5I25.5
-----MIN GRIEXT GRIMX GRI YELI RED
TRACK CLEAR 0I 0I 0I25.5I25.5
-----MIN DLIPMTEXTIMX TMI YELI RED
DWL/CYC-EXIT 12I 2.0I 120I25.5I25.5
PMT ACTIVE OUT..ON PMT ACT DWELL...NO
OTHER - PRI PMT.OFF NON-PRI PMT.....OFF
INH EXT TIME... 0.0 PED PR RETURN...OFF
PRIORITY RETURN.OFF QUEUE DELAY.... OFF
COND DELAY.....OFF
PHASES 1 2 3 4 5 6 7 8
PR RTN% 0 0 0 0 0 0 0 0
PHASES 9 10 11 12 13 14 15 16
PR RTN% 0 0 0 0 0 0 0 0

```

```

PREEMPT PLAN [ 4 ]  ENABLE....YES
  VEH/PED 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
  OVERLAP A B C D E F G H I J K L M N O P
  TRKCLR V . . . . .
  TRKCLR O . . . . .
  ENA TRL . . . . .
  DWEL VEH . X . . . X . . . . .
  DWEL PED . . . . .
  DWEL OLPF1 . . . . .
  CYC VEH . . . . .
  CYC PED . . . . .
  CYC OLP . . . . .
  EXIT PH . . . X . . . . .
  EXIT CAL . . . . .
  SP FUNC . . . . .

```

```

ENABLE... YESIPMT OVRIDE.. IINTERLOCK. NO
DET LOCK... XIDELAY.. 0IINHIBIT... 0
OVERIDE FL. .IDURATION 0ICLR-GRN... NO
TERM OLP. NOIPC>YEL NOITERM PH NO
PED DARK.. NOITC RESRV NOIDWELL FL OFF
LINK PMT....0IX FLCOLR REDIEEXIT OPT. OFF
X TMG PLN...0IRE-SERV.. 0IFLT TYPE.HARD
FREE DUR PMTIR1 NOIR2 NOIR3 NOIR4 NO
--TIMING-----WALKIPED CLIMN GRI YELI RED
ENTRANCE TM. 255I 255I 1125.5I25.5
-----MIN GRIEXT GRIMX GRI YELI RED
TRACK CLEAR 0I 0I 0I25.5I25.5
-----MIN DLIPMTEXTIMX TMI YELI RED
DWL/CYC-EXIT 12I 2.0I 120I25.5I25.5
PMT ACTIVE OUT..ON PMT ACT DWELL...NO
OTHER - PRI PMT.OFF NON-PRI PMT.....OFF
INH EXT TIME... 0.0 PED PR RETURN...OFF
PRIORITY RETURN.OFF QUEUE DELAY.... OFF
COND DELAY.....OFF
PHASES 1 2 3 4 5 6 7 8
PR RTN% 0 0 0 0 0 0 0 0
PHASES 9 10 11 12 13 14 15 16
PR RTN% 0 0 0 0 0 0 0 0

```

```

PREEMPT PLAN [ 5 ]  ENABLE....YES
  VEH/PED 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
  OVERLAP A B C D E F G H I J K L M N O P
  TRKCLR V . . . . .
  TRKCLR O . . . . .
  ENA TRL . . . . .
  DWEL VEH . . . X . . . . .
  DWEL PED . . . . .
  DWEL OLP . . . . .
  CYC VEH . . . . .
  CYC PED . . . . .
  CYC OLP . . . . .
  EXIT PH . . . . .
  EXIT CAL . X . . . X . . . . .
  SP FUNC . . . . .

```

```

ENABLE... YESIPMT OVRIDE.. IINTERLOCK. NO
DET LOCK... XIDELAY.. 0IINHIBIT... 0
OVERIDE FL. .IDURATION 0ICLR-GRN... NO
TERM OLP. NOIPC>YEL NOITERM PH NO
PED DARK.. NOITC RESRV NOIDWELL FL OFF
LINK PMT....0IX FLCOLR REDIEEXIT OPT. OFF
X TMG PLN...0IRE-SERV.. 0IFLT TYPE.HARD
FREE DUR PMTIR1 NOIR2 NOIR3 NOIR4 NO
--TIMING-----WALKIPED CLIMN GRI YELI RED
ENTRANCE TM. 255I 255I 1125.5I25.5
-----MIN GRIEXT GRIMX GRI YELI RED
TRACK CLEAR 0I 0I 0I25.5I25.5
-----MIN DLIPMTEXTIMX TMI YELI RED
DWL/CYC-EXIT 7I 2.0I 120I25.5I25.5
PMT ACTIVE OUT..ON PMT ACT DWELL...NO
OTHER - PRI PMT.OFF NON-PRI PMT.....OFF
INH EXT TIME... 0.0 PED PR RETURN...OFF
PRIORITY RETURN.OFF QUEUE DELAY.... OFF
COND DELAY.....OFF
PHASES 1 2 3 4 5 6 7 8
PR RTN% 0 0 0 0 0 0 0 0
PHASES 9 10 11 12 13 14 15 16
PR RTN% 0 0 0 0 0 0 0 0

```

THIS ELECTRICAL DETAIL IS FOR
 THE SIGNAL DESIGN: 01-0020
 DESIGNED: MARCH 2018
 SEALED: 08/22/2018
 REVISED: N/A

ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL

(program controller as shown)

- From Main Menu select **2. CONTROLLER**
- From CONTROLLER Submenu select **2. VEHICLE OVERLAPS**

OVERLAP A

Select TMG VEH OVLP [A] and 'PPLT FYA'

```

TMG VEH OVLP...[A] TYPE: ....PPLT FYA
PROTECTED LEFT TURN.... PHASE 1
OPPOSING THROUGH..... PHASE 2
FLASHING ARROW OUTPUT.....CH9 ISOLATE
DELAY START OF: FYA..0.0 CLEARANCE..0.0
ACTION PLAN SF BIT DISABLE..... 0

```

END PROGRAMMING

ECONOLITE ASC/3-2070 PREEMPT FILTERING PROGRAMMING DETAIL





(program controller as shown)

- From Main Menu select **4. PREEMPTOR/TSP**
- From PREEMPT/TSP/SCP Submenu select **2. ENABLE PREEMPT FILTERING & TSP/SCP**

```


ENABLE PREEMPT FILTERING & TSP/SCP
FILTERED SOLID PULSING
INPUT 1 ...BYPASSED.. ...BYPASSED..
2 ...BYPASSED.. ...BYPASSED..
3 ...PREEMPT 3. ...BYPASSED..
4 ..PREEMPT 4. ...BYPASSED..
5 ..PREEMPT 5. ...BYPASSED..
6 ..PREEMPT 6. ...BYPASSED..
7 ...BYPASSED.. ...BYPASSED..
8 ...BYPASSED.. ...BYPASSED..
9 ...BYPASSED.. ...BYPASSED..
10 ...BYPASSED.. ...BYPASSED..

```

 <p>DRMP, Inc. 8000 Regency Parkway, Suite 175 Cary, NC 27518 NC License No. C-2215 (919) 650-1038</p>	<p>US 17-US 158 (N. Hughes Blvd.) at US 158-NC 168 (W.Elizabeth St.) Division 1 Pasquotank County Elizabeth City</p>		
	<p>Prepared for the Offices of: </p>	<p>PLAN DATE: March 2018 PREPARED BY: DJ White</p>	
<p>REVISIONS</p>		<p>INIT. DATE</p>	<p>DocuSigned by:  9/20/2018 DATE</p>

20-SEP-2018 18:51 R:\05942\51001\48051\0001\1\img\01-0020-0822018e.dgn Incon AT CAR-LMCDM-WT

PHASING DIAGRAM




PHASING DIAGRAM DETECTION LEGEND

- ←●→ DETECTED MOVEMENT
- ←○→ UNDETECTED MOVEMENT (OVERLAP)
- ←○→ UNSIGNALIZED MOVEMENT
- ←○→ PEDESTRIAN MOVEMENT

TABLE OF OPERATION

SIGNAL FACE	PHASE				
	Ø1+5	Ø1+6	Ø2+5	Ø2+6	FLUSH
11	←	←	←	←	←
21, 22	R	R	G	G	R
41, 42	R	R	R	R	G
51	←	←	←	←	←
61, 62	R	G	R	G	R
81, 82	R	R	R	R	G
P21, P22	DW	DW	W	W	DRK
P61, P62	DW	W	DW	W	DRK
P81, P82	DW	DW	DW	W	DRK

SIGNAL FACE I.D.




ASC/3 DETECTOR INSTALLATION CHART

LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PROGRAMMING							
					PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE	SYSTEM LOOP	NEW CARD
1A	6X40	0	2-4-2	X	1	Yes	-	15	-	S	-	X
2A	6X40	70	3	X	2	Yes	-	-	-	S	-	X
2B	6X40	70	3	X	2	Yes	-	-	-	S	-	X
4A	6X40	0	2-4-2	-	4	Yes	-	3	-	S	-	X
4B	6X40	0	2-4-2	-	4	Yes	-	10	-	S	-	X
5A	6X40	0	2-4-2	X	5	Yes	-	15	-	S	-	X
6A	6X6	70	3	X	6	Yes	-	-	-	S	-	X
6B	6X6	70	3	X	6	Yes	-	-	-	S	-	X
8A	6X40	0	2-4-2	-	8	Yes	-	3	-	S	-	X
8B	6X40	0	2-4-2	-	8	Yes	-	10	-	S	-	X
S1	6X6	+125	4	-	-	-	-	-	-	N	X	X
S2	6X6	+125	4	-	-	-	-	-	-	N	X	X

5 Phase Fully Actuated (Elizabeth City Signal System)

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Set all detector units to presence mode.
- Locate new cabinet so as not to obstruct sight distance of vehicles turning right on red.
- Omit "WALK" and flashing "DON'T WALK" with no pedestrian calls.
- Program pedestrian heads to countdown the flashing "Don't Walk" time only.
- Pedestrian pedestals are conceptual and shown for reference only. See sheets P1-P3 for pushbutton location details.
- Program phase 8 ped detector to call phase 4 and 8 ped.
- Phase 4 ped is dummy ped to enable phase 8 leading ped interval.
- Pavement markings are existing unless otherwise noted.
- Install new poles directly adjacent to existing poles and raise signal spans to obtain 17' minimum clearance for signal head heights.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.




Install new 50' pole to accommodate CCTV

ASC/3 TIMING CHART

FEATURE	PHASE						
	1	2	4	5	6	8	
Min Green *	7	10	7	7	10	7	
Delayed Green	-	-	7	-	-	7	
Walk *	0	7	0	0	7	7	
Ped Clear	0	10	0	0	9	18	
Veh. Extension *	2.0	3.0	2.0	2.0	3.0	2.0	
Max 1 *	25	60	25	25	60	25	
Yellow	3.0	3.8	3.2	3.0	3.8	3.2	
Red Clear	3.1	2.3	2.9	2.9	2.3	3.0	
Actuations B4 Add *	-	-	-	-	-	-	
Seconds / Actuation *	-	-	-	-	-	-	
Max Initial *	-	-	-	-	-	-	
Time Before Reduction *	-	-	-	-	-	-	
Time To Reduce *	-	-	-	-	-	-	
Minimum Gap	-	-	-	-	-	-	
Locking Detector	-	X	-	-	X	-	
Recall Position	-	VEH. RECALL	-	-	VEH. RECALL	-	
Dual Entry	-	-	X	-	-	X	
Simultaneous Gap	X	X	X	X	X	X	

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

PROPOSED STOP BAR & CROSSWALK LOCATIONS



LEGEND

PROPOSED	EXISTING
○→ Traffic Signal Head	●→ Traffic Signal Head
○→ Modified Signal Head	N/A
○→ Pedestrian Signal Head With Push Button & Sign	○→ Sign
○→ Type II Signal Pedestal	○→ Signal Pole with Guy
○→ Signal Pole with Sidewalk Guy	○→ Inductive Loop Detector
○→ Controller & Cabinet	○→ Junction Box
○→ 2-in Underground Conduit	○→ Right of Way
○→ Right of Way	○→ Directional Arrow
○→ Directional Arrow	○→ Fire Hydrant
○→ Fire Hydrant	○→ Truncated Dome
○→ Truncated Dome	

Signal Upgrade

Prepared for the Offices of:
 Transportation Mobility and Safety Division
 NORTH CAROLINA DEPARTMENT OF TRANSPORTATION
 Signal Design Section

750 N. Greenfield Pkwy, Garner, NC 27529
DRMP
 DRMP, Inc.
 8000 Regency Parkway, Suite 175
 Cary, NC 27518
 NC License No. C-2213 (919) 650-1038

US 17 Bus. (Ehringhaus St.) at Selden St.

Division 1 Pasquotank County Elizabeth City
 PLAN DATE: February 2018 REVIEWED BY: AJ Davis
 PREPARED BY: JA Le REVIEWED BY: LM Moon

REVISIONS: INIT. DATE

SCALE: 1" = 40'


DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SEAL
 NORTH CAROLINA PROFESSIONAL ENGINEER
 SEAL 022516
 J. M. MOON
 DocuSigned by: J. M. Moon 8/21/2018
 SIG. INVENTORY NO. 01-0022

EDI MODEL 2018ECLip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)

REMOVE DIODE JUMPERS 1-5, 1-6, 1-9, 1-11, 1-15, 2-5, 2-6, 2-9, 2-11, 2-13, 2-15, 4-8, 4-16, 5-9, 5-11, 5-13, 6-9, 6-11, 6-13, 6-15, 8-16, 9-11, 9-13, 9-15, 11-13, 11-15 and 13-15.



REMOVE JUMPERS AS SHOWN

NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- Ensure that Red Enable is active at all times during normal operation.
- Integrate monitor with Ethernet network in cabinet.

NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Program phases 4 and 8 for Dual Entry.
- Program controller to start up in phase 2 Walk and 6 Walk.
- The cabinet and controller are part of the Elizabeth City Signal System.
- Ensure Delayed Green times shown in the Timing Chart on the signal design plan are accounted for to facilitate leading pedestrian interval.

EQUIPMENT INFORMATION

CONTROLLER.....2070LX
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S3,S5,S7,S8,S9,S11,
 S12, AUX S1,AUX S4
 PHASES USED.....1,2,2PED,4,5,6,6PED,
 8,8PED
 OVERLAP "A".....*
 OVERLAP "B".....NOT USED
 OVERLAP "C".....*
 OVERLAP "D".....NOT USED
 * See overlap programming detail on sheet 2

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	11	21,22	P21, P22	NU	41,42	NU	51	61,62	P61, P62	NU	81,82	P81, P82	11	NU	NU	51	NU	NU
RED		128			101			134			107							
YELLOW	*	129			102		*	135			108							
GREEN		130			103			136			109							
RED ARROW													A121			A114		
YELLOW ARROW													A122			A115		
FLASHING YELLOW ARROW													A123			A116		
GREEN ARROW	127							133										
Hand				113					119				110					
Walker				115					121				112					


NU = Not Used

* Denotes install load resistor. See load resistor installation detail this sheet.

★ See pictorial of head wiring in detail this sheet.

FYA SIGNAL WIRING DETAIL

(wire signal heads as shown)



INPUT FILE POSITION LAYOUT

(front view)

FILE "I"	1	2	3	4	5	6	7	8	9	10	11	12	13	14
U	Ø 1	Ø 2	Ø 3	Ø 4	Ø 5	Ø 6	Ø 7	Ø 8	Ø 9	Ø 10	Ø 11	Ø 12	Ø 13	Ø 14
L	1A	2A	3A	4A	5A	6A	7A	8A	9A	10A	11A	12A	13A	14A
U	NOT USED	Ø 2	Ø 3	Ø 4	Ø 5	Ø 6	Ø 7	Ø 8	Ø 9	Ø 10	Ø 11	Ø 12	Ø 13	Ø 14
L	2B	3B	4B	5B	6B	7B	8B	9B	10B	11B	12B	13B	14B	


EX.: 1A, 2A, ETC. = LOOP NO.'S
 ⊗ Wired Input - Do not populate slot with detector card
 FS = FLASH SENSE
 ST = STOP TIME

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND TIME	DELAY TIME	ADDED INITIAL	DETECTOR TYPE
1A ¹	TB2-1,2	I1U	56	1	1	YES		15		S
2A	TB2-5,6	J4U	48	26	6	YES				S
2B	TB2-7,8	I2U	39	2	2	YES				S
4A	TB4-9,10	I6U	41	4	4	YES				S
4B	TB4-11,12	I6L	45	14	4	YES		10		S
* S1	TB6-9,10	I9U	60	11	SYS	NO				N
* S2	TB6-11,12	I9L	62	13	SYS	NO				N
5A ²	TB3-1,2	J1U	55	5	5	YES		15		S
6A	TB3-5,6	J2U	40	6	6	YES				S
6B	TB3-7,8	J2L	44	16	6	YES				S
8A	TB5-9,10	J6U	42	8	8	YES		3		S
8B	TB5-11,12	J6L	46	18	8	YES		10		S
PED PUSH BUTTONS										
P21,P22	TB8-4,6	I12U	67	PED 2	2 PED					
P61,P62	TB8-7,9	I13U	68	PED 6	6 PED					
P81,P82	TB8-8,9	I13L	70	PED 8	8 PED					

NOTE:
 INSTALL DC ISOLATORS IN INPUT FILE SLOTS 112 AND 113.


- Add jumper from I1-W to J4-W, on rear of input file.
 - Add jumper from J1-W to I4-W, on rear of input file.
- * System detector only. Remove any assigned vehicle phase.



LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown)

VALUE (ohms)	WATTAGE
1.5K - 1.9K	25W (min)
2.0K - 3.0K	10W (min)



COUNTDOWN PEDESTRIAN SIGNAL OPERATION

Countdown Ped Signals are required to display timing only during Ped Clearance Interval. Consult Ped Signal Module user's manual for instructions on selecting this feature.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 01-0022
 DESIGNED: FEBRUARY 2018
 SEALED: 08/21/2018
 REVISED: N/A

Electrical Detail - Sheet 1 of 2

DRMP Inc. 8000 Regency Parkway, Suite 175 Cary, NC 27518 NC License No. C-2215 (919) 650-1038

US 17 Bus. (Ehringhaus St.) at Selden St.
 Division 1 Pasquotank County Elizabeth City
 PLAN DATE: February 2018 REVIEWED BY: AJ Davis
 PREPARED BY: DJ White REVIEWED BY: LM Moon

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED


SEAL
 NORTH CAROLINA PROFESSIONAL ENGINEER
 SEAL 022516
 LISA M. MOON

DocuSigned by:
 Lisa M. Moon 9/20/2018
 DATE
 SIG. INVENTORY NO. 01-0022

EDI MODEL 2018EClip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)

REMOVE DIODE JUMPERS 2-5, 2-6, 2-9, 2-11, 2-12, 2-15, 4-12, 4-14, 5-9, 5-11, 5-12, 6-9, 6-11, 6-15, 9-11, 9-12, 9-15, 11-15 and 12-14.



REMOVE JUMPERS AS SHOWN

NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- Ensure that Red Enable is active at all times during normal operation.
- Integrate monitor with Ethernet network in cabinet.

NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Program controller to start up in phase 2 GREEN and 6 WALK.
- The cabinet and controller are part of the Elizabeth City Signal System.
- Ensure Delayed Green times shown in the Timing Chart on the signal design plan are accounted for to facilitate leading pedestrian interval.

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	NU	21,22	NU	NU	41,42	P41, P42	51	62,63	P61, P62	NU	NU	NU	61	NU	NU	51	43	NU
RED	128							134									A101	
YELLOW		129					*	135										
GREEN		130						136										
RED ARROW						101							A121				A114	
YELLOW ARROW						102							A122				A115	A102
FLASHING YELLOW ARROW													A123				A116	A103
GREEN ARROW						103		133										
							104		119									
							105		121									

NU = Not Used

* Denotes install load resistor. See load resistor installation detail this sheet.

★ See pictorial of head wiring in detail this sheet.

EQUIPMENT INFORMATION

CONTROLLER.....2070LX
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S2,S5,S6,S7,S8,S9,
 AUX S1,AUX S4,AUX S5
 PHASES USED.....2,4,4PED,5,6,6PED
 OVERLAP "A".....*
 OVERLAP "B".....NOT USED
 OVERLAP "C".....*
 OVERLAP "D".....*

* See overlap programming detail on sheet 2

INPUT FILE POSITION LAYOUT

(front view)

FILE "I"	FILE "J"	1	2	3	4	5	6	7	8	9	10	11	12	13	14
S	Ø 2	Ø 2	Ø 4	Ø 4	Ø 5	Ø 5	Ø 6	Ø 6	Ø 6	Ø 6	Ø 6	Ø 6	Ø 6	Ø 6	Ø 6
Ø 2	Ø 2	Ø 4	Ø 4	Ø 5	Ø 5	Ø 6	Ø 6	Ø 6	Ø 6	Ø 6	Ø 6	Ø 6	Ø 6	Ø 6	Ø 6
Ø 2	Ø 2	Ø 4	Ø 4	Ø 5	Ø 5	Ø 6	Ø 6	Ø 6	Ø 6	Ø 6	Ø 6	Ø 6	Ø 6	Ø 6	Ø 6
Ø 2	Ø 2	Ø 4	Ø 4	Ø 5	Ø 5	Ø 6	Ø 6	Ø 6	Ø 6	Ø 6	Ø 6	Ø 6	Ø 6	Ø 6	Ø 6

EX. : 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
 ST = STOP TIME

⊗ Wired Input - Do not populate slot with detector card


INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND TIME	DELAY TIME	ADDED INITIAL	DETECTOR TYPE
2A	TB2-5,6	I2U	39	2	2	YES				S
2B	TB2-7,8	I2L	43	12	2	YES				S
4A	TB4-9,10	I6U	41	4	4	YES		3		S
4B	TB4-11,12	I6L	45	14	4	YES				S
* S1	TB6-9,10	I9U	60	11	SYS	NO				N
* S2	TB6-11,12	I9L	62	13	SYS	NO				N
5A ¹	TB3-1,2	J1U	55	5	5	YES		15		S
		I4U	47	22	2	YES				S
5B	TB3-5,6	J2U	40	6	6	YES		15		S
6A	TB3-9,10	J3U	64	36	6	YES				S
6B	TB3-7,8	J3L	77	16	6	YES				S
PED PUSH BUTTONS										
P41,P42	TB8-5,6	I12L	69	PED 4	4 PED					
P61,P62	TB8-7,9	I13U	68	PED 6	6 PED					

INSTALL DC ISOLATORS IN INPUT FILE SLOTS 112 AND 113.


- ¹Add jumpers from J1-W to I4-W, on rear of input file.
 * System detector only. Remove any assigned vehicle phase.

INPUT FILE POSITION LEGEND: J2L



FYA SIGNAL WIRING DETAIL


(wire signal heads as shown)



LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown)

ACCEPTABLE VALUES	
VALUE (ohms)	WATTAGE
1.5K - 1.9K	25W (min)
2.0K - 3.0K	10W (min)



Electrical Detail - Sheet 1 of 2

Electrical AND PROGRAMMING DETAILS FOR:

Prepared for the Offices of:

Seal of the Department of Transportation

750 N. Greenfield Pkwy, Garner, NC 27529

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 01-0024
 DESIGNED: FEBRUARY 2018
 SEALED: 08/21/2018
 REVISED: N/A

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SEAL

NORTH CAROLINA PROFESSIONAL ENGINEER

SEAL 022516

LISA M. MOON

-DocuSigned by: Lisa M. Moon 9/20/2018

SIC: INVENTORY NO. 01-0024

ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select 2. CONTROLLER
2. From CONTROLLER Submenu select 2. VEHICLE OVERLAPS

OVERLAP A

Select TMG VEH OVLP [A] and 'OTHER/ECONOLITE'

```

TMG VEH OVLP...[A] TYPE:OTHER/ECONOLITE
 PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
 INCLUDED . X . . . . .
 PROTECT . . . . .
 PED PRTC . . . . .
 NOT OVLP . . . . .
 FLSH GRN . 1 . . . . .
 LAG X PH . . . . .
 LAG 2 PH . . . . .

 LAG GRN 0.0 YEL 0.0 RED 0.0 ADV GRN 0.0
    
```

Toggle Twice

OVERLAP C

Select TMG VEH OVLP [C] and 'PPLT FYA'

```

TMG VEH OVLP...[C] TYPE: . . . . .PPLT FYA
 PROTECTED LEFT TURN.... PHASE 5
 OPPOSING THROUGH..... PHASE 6

 FLASHING ARROW OUTPUT.....CH11 ISOLATE
 DELAY START OF: FYA..0.0 CLEARANCE..0.0
 ACTION PLAN SF BIT DISABLE..... 0
    
```

Toggle Once

OVERLAP D

Select TMG VEH OVLP [D] and 'OTHER/ECONOLITE'

```

TMG VEH OVLP...[D] TYPE:OTHER/ECONOLITE
 PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
 INCLUDED . . . X X . . . . .
 PROTECT . . . . .
 PED PRTC . . . . .
 NOT OVLP . . . . .
 FLSH GRN . . . 1 1 . . . . .
 LAG X PH . . . . .
 LAG 2 PH . . . . .

 LAG GRN 0.0 YEL 0.0 RED 0.0 ADV GRN 0.0
    
```

END PROGRAMMING

FLASHER CIRCUIT MODIFICATION DETAIL

IN ORDER TO INSURE THAT SIGNALS FLASH CONCURRENTLY ON THE SAME APPROACH, MAKE THE FOLLOWING FLASHER CIRCUIT CHANGES:

1. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-4 AND TERMINATE ON T2-2.
2. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-5 AND TERMINATE ON T2-3.
3. REMOVE FLASHER UNIT 2.

THE CHANGES LISTED ABOVE TIES ALL PHASES AND OVERLAPS TO FLASHER UNIT 1.

COUNTDOWN PEDESTRIAN SIGNAL OPERATION



Countdown Ped Signals are required to display timing only during Ped Clearance Interval. Consult Ped Signal Module user's manual for instructions on selecting this feature.

THIS ELECTRICAL DETAIL IS FOR
 THE SIGNAL DESIGN: 01-0024
 DESIGNED: FEBRUARY 2018
 SEALED: 08/21/2018
 REVISED: N/A


20-SEP-2018 18:51
 R:\415942\51\001\5\K05\00001\1\mg01-0024-08212018e.dgn
 Incon AT CAR-LMD\DW-M7

Electrical Detail - Sheet 2 of 2


DOCUMENT NOT CONSIDERED
FINAL UNLESS ALL
SIGNATURES COMPLETED



SR 1268 (Water St.)/ SR 1164 (Water St.) at SR 1268 (Ehringhaus St.) Division 1 Pasquotank County Elizabeth City	
PLAN DATE:	REVIEWED BY:
PREPARED BY:	REVIEWED BY:
REVISIONS	INIT. DATE



DocuSigned by:
 Lisa M. Moon 9/20/2018
 DATE
 SIG. INVENTORY NO. 01-0024



PHASING DIAGRAM DETECTION LEGEND

- DETECTED MOVEMENT
- UNDETECTED MOVEMENT (OVERLAP)
- - - UNSIGNALIZED MOVEMENT
- ← -- -- → PEDESTRIAN MOVEMENT

TABLE OF OPERATION

SIGNAL FACE	PHASE										
	01+6	02+6	03	04	EVP 3	EVP 4	EVP 5	PRE 7	FLASH		
11	←	→	←	→	←	→	←	→	←	→	
21	←	→	←	→	←	→	←	→	←	→	
22,23	←	→	←	→	←	→	←	→	←	→	
31	←	→	←	→	←	→	←	→	←	→	
32	←	→	←	→	←	→	←	→	←	→	
41	←	→	←	→	←	→	←	→	←	→	
42	←	→	←	→	←	→	←	→	←	→	
43, 44	←	→	←	→	←	→	←	→	←	→	
61, 62, 63	←	→	←	→	←	→	←	→	←	→	

ASC/3 DETECTOR INSTALLATION CHART

LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PROGRAMMING							
					PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE	SYSTEM LOOP	NEW CARD
1A	6X60	+5	2-4-2	-	1	Yes	-	15	-	S	-	X
1B	6X60	+5	2-4-2	-	6	Yes	-	3	-	G	-	X
1C	6X60	+5	2-4-2	-	1	Yes	-	15*	-	S	-	X
1D	6X6	180	EXIST	-	Pre7	-	-	5	-	N	-	X
2A	6X6	300	EXIST	-	2	Yes	-	-	-	X	N	-
2B	6X6	300	EXIST	-	2	Yes	-	-	-	X	N	-
2C	6X60	+5	2-4-2	-	2	Yes	-	3	-	S	-	X
3A	6X60	+5	2-4-2	-	3/10	Yes	-	-	-	S	-	X
4A	6X60	+5	2-4-2	-	4	Yes	-	3	-	S	-	X
4B	6X60	+5	2-4-2	-	4	Yes	-	-	-	S	-	X
6A	6X6	300	EXIST	-	6	Yes	-	-	-	X	N	-
6B	6X6	300	EXIST	-	6	Yes	-	-	-	X	N	-

* Disable Delay From 6:00a.m. to 7:00p.m.


4 Phase Fully Actuated W/ EV Preemption (Elizabeth City Signal System)

NOTES

1. Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
2. Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
3. Phase 1 and/or phase 5 may be lagged.
4. Set all detector units to presence mode.
5. Locate new cabinet so as not to obstruct sight distance of vehicles turning right on red.
6. Pavement markings are existing.
7. This intersection features an optical preemption system. Shown locations of optical detectors are conceptual only.
8. Relocate existing optical detection equipment from existing cabinet to new cabinet.
9. Optical detector 10 calls EVP3; Optical detector 20 calls EVP4; Optical detector 30 calls EVP5.
10. Install new poles directly adjacent to existing poles and raise signal spans to obtain 17' minimum clearance for signal head heights.
11. Loop 1D serves as queue backup detector. After 5 seconds of constant actuation, the detector unit places a call to the controller to preempt normal operation to clear out the storage lanes.
12. Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.

SIGNAL FACE I.D.

All Heads L.E.D.



ASC/3 BACKUP PREEMPT


FUNCTION	PRE 7
Exit Phase(s)	2,6
Preempt Override	OFF
Delay Time	0
Ped Clear Through Yellow	N
Terminate Phases	N
Entrance Walk	255*
Entrance Ped Clear	255*
Entrance Min Green	1
Entrance Yellow Change	25.5*
Entrance Red Clear	25.5*
Minimum Dwell Time	25
Exit Yellow Change	25.5*
Exit Red Clear	25.5*

* Time defaults to time used for phase during normal operation.

ASC/3 TIMING CHART

FEATURE	PHASE						
	1	2	3	4	6	**10	OLG
Min Green *	7	12	7	7	12	7	0.1
Walk *	0	0	0	0	0	0	
Ped Clear	0	0	0	0	0	0	
Veh. Extension *	1.0	6.0	1.0	1.0	6.0	1.0	
Max 1 *	30	90	15	30	90	15	
Yellow	3.0	4.5	3.8	3.8	4.5	3.8	3.8
Red Clear	3.5	2.0	2.3	2.0	2.0	2.3	2.3
Actuations B4 Add *	-	0	-	-	0	-	
Seconds / Actuation *	-	1.5	-	-	1.5	-	
Max Initial *	-	34	-	-	34	-	
Time Before Reduction *	-	15	-	-	15	-	
Time To Reduce *	-	30	-	-	30	-	
Minimum Gap	-	3.0	-	-	3.0	-	
Locking Detector	-	X	-	-	X	-	
Recall Position	-	VEH. RECALL	-	-	VEH. RECALL	-	
Dual Entry	-	-	-	-	-	-	
Simultaneous Gap	X	X	X	X	X	X	


* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should be lower than 4 seconds.
 ** Phase used for timing purposes only.



ASC/3 EV PREEMPT

FUNCTION	PRE 3	PRE 4	PRE 5
Exit Phase(s)	2,6	3	2,6
Preempt Override	OFF	OFF	ON
Delay Time	0	0	0
Ped Clear Through Yellow	N	N	N
Terminate Phases	N	N	N
Entrance Walk	255*	255*	255*
Entrance Ped Clear	255*	255*	255*
Entrance Min Green	1	1	1
Entrance Yellow Change	25.5*	25.5*	25.5*
Entrance Red Clear	25.5*	25.5*	25.5*
Minimum Dwell Time	12	12	7
Preempt Input Extension Time	2	2	2
Preempt Max Time	120	120	120
Exit Yellow Change	25.5*	25.5*	25.5*
Exit Red Clear	25.5*	25.5*	25.5*

* Allows normal phase times to be used.



Signal Upgrade

DRMP, Inc.
8000 Regency Parkway, Suite 175
Cary, NC 27519
NC License No. 6-2213 (919) 650-1038

Scale: 1" = 40'

US 17-158 (Hughes Boulevard) at US 17 Business (Road Street) / SR 1327 (Griggs Street)

Division 1 Pasquotank County Elizabeth City

PLAN DATE: March 2018 REVIEWED BY: AJ Davis

PREPARED BY: JA Le REVIEWED BY: LM Moon

Professional Engineer Seal for Lisa M. Moon, License No. 022516, State of North Carolina.


DocuSigned by: Lisa M. Moon 9/20/2018

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

EDI MODEL 2018EClip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)

REMOVE DIODE JUMPERS 1-6, 1-9, 1-10, 1-11, 2-6, 2-9, 2-11, 4-10, 6-9, 6-10, 6-11, 9-10, 9-11 and 10-11.



REMOVE JUMPERS AS SHOWN

NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- Ensure that Red Enable is active at all times during normal operation.
- Integrate monitor with Ethernet network in cabinet.

■ = DENOTES POSITION OF SWITCH

NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Program controller to start up in phase 2 Green and 6 Green.
- The cabinet and controller are part of the Elizabeth City Signal System.

EQUIPMENT INFORMATION

CONTROLLER.....2070LX
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S4,S5,S8,AUX S1,AUX S2,
 AUX S4
 PHASES USED.....1,2,3,4,6,**10
 OVERLAP "A".....*
 OVERLAP "B".....*
 OVERLAP "C".....*
 OVERLAP "D".....NOT USED
 OVERLAP "G".....*
 * See overlap programming detail on sheet 2
 ** Phase used for timing purposes only.

SIGNAL HEAD HOOK-UP CHART


LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	OLG	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	11	22,23	NU	31	32	41	42	NU	NU	61,62,63	NU	NU	11	43,44	NU	21	NU	NU
RED		128		116	116	101	101			134				A124				
YELLOW	*	129		117	117	102	102			135								
GREEN		130		118	118	103	103			136								
RED ARROW													A121			A114		
YELLOW ARROW													A122	A125		A115		
FLASHING YELLOW ARROW													A123			A116		
GREEN ARROW	127			118		103								A126				

NU = Not Used

* Denotes install load resistor. See load resistor installation detail this sheet.
 ★ See pictorial of head wiring in detail this sheet.

INPUT FILE POSITION LAYOUT

(front view)



EX.: 1A, 2A, ETC. = LOOP NO.'S
 * Wired Input - Do not populate slot with detector card


FS = FLASH SENSE
 ST = STOP TIME
 PRE = PREEMPT

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND TIME	DELAY TIME	ADDED INITIAL	DETECTOR TYPE
1A ¹	TB2-1,2	I1U	56	1	1	YES		15		S
	-	J4U	48	26	6	YES		3		G
1B	TB2-5,6	I2U	39	2 ★	1	YES				S
1C	TB2-7,8	I2L	43	12 ★	1	YES		5		S
1D	TB6-1,2	I7U	65	34 *	PRE1	NO				N
2A	TB2-9,10	I3U	63	32	2	YES			X	N
2B	TB2-11,12	I3L	76	42	2	YES			X	N
2C	TB4-1,2	I4U	47	22	2	YES		3		G
3A	TB4-5,6	I5U	58	3	3/10	YES				S
4A	TB4-9,10	I6U	41	4	4	YES		3		S
4B	TB4-11,12	I6L	45	14	4	YES				S
6A	TB3-5,6	J2U	40	6	6	YES			X	N
6B	TB3-7,8	J2L	44	16	6	YES			X	N

- ¹Add jumper from I1-W to J4-W, on rear of input file.
 * See Logic Processor programming detail on sheet 3 of 5 for Backup Preempt
 ★ See vehicle detector setup programming detail for delay on loops in the Action Plan Detail & Vehicle Detector Setup Programming on sheet 4 of 5.


INPUT FILE POSITION LEGEND: J2L



LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown)

ACCEPTABLE VALUES	
VALUE (ohms)	WATTAGE
1.5K - 1.9K	25W (min)
2.0K - 3.0K	10W (min)




** OPTICAL PREEMPTION SYSTEM

- Install an optical preemption system for emergency vehicle preemption. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the preemption schemes shown on the Signal Design Plans.
- Ensure that the Optical Preemption System is fully compatible with equipment manufactured in accordance with the specification of the type 2070 controller.

FYA SIGNAL WIRING DETAIL

(wire signal heads as shown)



11

21

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 01-0025
 DESIGNED: MARCH 2018
 SEALED: 09/20/2018
 REVISED: N/A

Electrical Detail - Sheet 1 of 5

Electrical and Programming Details For: US 17-158 (Hughes Boulevard) at US 17 Business (Road Street) / SR 1327 (Griggs Street) Division 1 Pasquotank County Elizabeth City

Plan Date: March 2018
 Prepared by: DJ White
 Reviewed by: AJ Davis
 Reviewed by: LM Moon

Revisions: _____ Init: _____ Date: _____

DRMP
 DRMP, Inc.
 8000 Regency Parkway, Suite 175
 Cary, NC 27519
 NC License No. C-2415 (019) 650-1038

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SEAL
 NORTH CAROLINA PROFESSIONAL ENGINEER
 SEAL 022516
 LISA M. MOON

DocuSigned by: Lisa M. Moon 9/20/2018
 DATE: _____
 SIG. INVENTORY NO. 01-0025

ECONOLITE ASC/3-2070 CONTROLLER SEQUENCE PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select 1. CONFIGURATION
2. From CONFIGURATION Submenu select 1. CONTROLLER SEQ
3. From CONTROLLER SEQUENCE Submenu select 1. PHASE RING SEQUENCE AND ASSIGNMENT

CONTROLLER SEQUENCE [1]																
SEQUENCE	COMMANDS	HW	ALT	SEQ	ENA.											NO.
	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16
BC-B	-	B	-	B	-	-	-	-	-	-	-	-	-	-	-	-
R1	-	1	2	3	4	10
R2	-	.	6
R3	-
R4	-

R1-R4=RING 1-4, DATA ENTRY, PHASES 1-16
BC=BARRIER CONTROL, VALUES: B,C
B=BARRIER MODE
C=COMPATIBILITY MODE

ECONOLITE ASC/3-2070 LOAD SWITCH ASSIGNMENT DETAIL

(program controller as shown)

To assign load switch S4 as DLE, program LD SWITCH 3 as OVLP '5' TYPE '0' as shown below.

1. From Main Menu select 1. CONFIGURATION
2. From CONFIGURATION Submenu select 3. LOAD SW ASSIGN

NOTICE OVLP 7
ASSIGNED TO
LD SWITCH 3 →

LD SWITCH ASSIGN									
	PHASE	DIMMING	---FLASH---						
	/OVLP	TYPE	R	Y	G	D	PWR	AUT	TGR
1	1	V	.	.	.	+	A	R	X
2	2	V	.	.	.	+	A	Y	.
3	7	0	.	.	.	+	A	R	X
4	4	V	.	.	.	+	A	R	.
5	5	V	.	.	.	-	A	R	.
6	6	V	.	.	.	-	A	Y	X
7	7	V	.	.	.	-	A	R	.
8	8	V	.	.	.	-	A	R	X
9	1	0	.	.	.	+	A	R	X
10	2	0	.	.	.	+	A	R	X
11	3	0	.	.	.	-	A	R	.
12	4	0	.	.	.	-	A	R	.
13	2	P	.	.	.	+	A	.	.
14	4	P	.	.	.	-	A	.	.
15	6	P	.	.	.	+	A	.	.
16	8	P	.	.	.	-	A	.	.

ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select 2. CONTROLLER
2. From CONTROLLER Submenu select 2. VEHICLE OVERLAPS

OVERLAP A

Select TMG VEH OVLP [A] and 'PPLT FYA'

TMG VEH OVLP...[A] TYPE:	PPLT FYA
PROTECTED LEFT TURN....	PHASE 1
OPPOSING THROUGH.....	PHASE 2
FLASHING ARROW OUTPUT....CH9 ISOLATE	
DELAY START DF: FYA..0.0 CLEARANCE..0.0	
ACTION PLAN SF BIT DISABLE..... 0	

OVERLAP B

Select TMG VEH OVLP [B] and 'NORMAL'

TMG VEH OVLP...[B] TYPE:	NORMAL
PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6	
INCLUDED X . . X	
LAG GRN 0.0 YEL 0.0 RED 0.0	

OVERLAP C

Select TMG VEH OVLP [C] and 'OTHER/ECONOLITE'

TMG VEH OVLP...[C] TYPE:	OTHER/ECONOLITE
PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6	
INCLUDED X	
PROTECT	
PED PRTC	
NOT OVLP	
FLSH GRN 1	
LAG X PH	
LAG 2 PH	
LAG GRN 0.0 YEL 0.0 RED 0.0 ADV GRN 0.0	

OVERLAP G

Select TMG VEH OVLP [G] and 'NORMAL'

TMG VEH OVLP...[G] TYPE:	NORMAL
PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6	
INCLUDED . . X X	
LAG GRN 0.1 YEL 3.8 RED 2.3	

END PROGRAMMING

ECONOLITE ASC/3-2070 VEHICLE DETECTOR SETUP PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select 6. DETECTORS
2. From DETECTOR Submenu select 2. VEHICLE DETECTOR SETUP

VEH DETECTOR [3]	VEH DET PLAN [1]
TYPE: S-STANDARD	
TS2 DETECTOR.....	X ECPI LOG..... NO
DET PH - 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6	3 3 . . X X
EXTEND TIME... 0.0 DELAY TIME... 0.0	
USE ADDED INITIAL . CROSS SWITCH PH.. 0	
LOCK IN..... NONE NTCIP VOL . OR OCC .	
PMT QUEUE DELAY. NO	

END PROGRAMMING

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 01-0025
DESIGNED: MARCH 2018
SEALED: 09/20/2018
REVISED: N/A

Electrical Detail - Sheet 2 of 5		DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED										
<p style="font-size: x-x-small;">ELECTRICAL AND PROGRAMMING DETAILS FOR:</p> <p style="text-align: center;">Prepared for the Offices of:</p> <p style="text-align: center;">DRMP DRMP, Inc. 8000 Regency Parkway, Suite 175 Cary, NC 27519 NC License No. C-2215 (019) 650-1038</p>	<p style="text-align: center;">US 17-158 (Hughes Boulevard) at US 17 Business (Road Street) / SR 1327 (Griggs Street)</p> <p style="text-align: center;">Division 1 Pasquotank County Elizabeth City</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td>PLAN DATE: March 2018</td> <td>REVIEWED BY: AJ Davis</td> </tr> <tr> <td>PREPARED BY: DJ White</td> <td>REVIEWED BY: LM Moon</td> </tr> </table> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>REVISIONS</th> <th>INIT.</th> <th>DATE</th> </tr> </thead> <tbody> <tr> <td> </td> <td> </td> <td> </td> </tr> </tbody> </table>	PLAN DATE: March 2018	REVIEWED BY: AJ Davis	PREPARED BY: DJ White	REVIEWED BY: LM Moon	REVISIONS	INIT.	DATE				<p>SEAL</p> <p>DocuSigned by: <i>Lisa M. Moon</i> 9/20/2018</p> <p style="font-size: x-x-small;">SIC INVENTORY NO. 01-0025</p>
PLAN DATE: March 2018	REVIEWED BY: AJ Davis											
PREPARED BY: DJ White	REVIEWED BY: LM Moon											
REVISIONS	INIT.	DATE										

20-SEP-2018 18:51 R:\415942\451\001\4485\gnw\1\1\gnw01-0025-08232018e.dgn Incon AT CAR-LMCDM-W7

ECONOLITE ASC/3-2070 BACKUP PREEMPT PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select 4. PREEMPTOR/TSP
2. From PREEMPTOR/TSP/SCP Submenu select 1. PREEMPT PLAN 1-10

Place cursor in [] next to Preempt Plan and press 7. Then press the right cursor arrow and toggle the controller to YES. Next cursor down. This will select Backup Preempt #7.

```

PREEMPT PLAN [ 7 ] ENABLE...YES
VEH/PED 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
OVERLAP A B C D E F G H I J K L M N O P
TRKCLR V . . . . .
TRKCLR O . . . . .
ENA TRL . . . . .
DWEL VEH X . . . . X . . . . .
DWEL PED . . . . .
DWEL OLPF1 XF1 . . . . .
CYC VEH . . . . .
CYC PED . . . . .
CYC OLP . . . . .
EXIT PH . X . . . X . . . . .
EXIT CAL . . . . .
SP FUNC . . . . .

ENABLE... YESIPMT OVRIDE..INTERLOCK. NO
DET LOCK... XIDELAY.. 0IINHIBIT... 0
OVERIDE FL. .IDURATION 0ICLR-GRN... NO
TERM OLP. NOIPC>YEL NOITERM PH NO
PED DARK.. NOITC RESRV NOIDWELL FL OFF
LINK PMT...0IX FLCOLR REDIXIT OPT. OFF
X TMG PLN...0IRE-SERV.. 0IFLT TYPE.HARD
FREE DUR PMTIR1 NOIR2 NOIR3 NOIR4 NO
--TIMING----WALKIPED CLIMN GRI YELI RED
ENTRANCE TM. 255I 255I 1125.5I25.5
-----MIN GRIEXT GRIMX GRI YELI RED
TRACK CLEAR 0I 0I 0I25.5I25.5
-----MIN DLIPMTEXTIMX TMI YELI RED
DWL/CYC-EXIT 25I 0I 25I25.5I25.5
PMT ACTIVE OUT..ON PMT ACT DWELL...NO
OTHER - PRI PMT.OFF NON-PRI PMT....OFF
INH EXT TIME... 0.0 PED PR RETURN...OFF
PRIORITY RETURN.OFF QUEUE DELAY.... OFF
COND DELAY.....OFF

PHASES 1 2 3 4 5 6 7 8
PR RTN% 0 0 0 0 0 0 0 0
PHASES 9 10 11 12 13 14 15 16
PR RTN% 0 0 0 0 0 0 0 0
    
```

ECONOLITE ASC/3-2070 LOGIC PROCESSOR PROGRAMMING DETAIL FOR SIDE STREET PHASING & FOR BACKUP PREEMPT

(program controller as shown)

1. From Main Menu select 1. CONFIGURATION
2. From CONFIGURATION Submenu select 8. LOGIC PROCESSOR
3. From LOGIC PROCESSOR Submenu select 2. LOGIC STATEMENTS

ENTER A "1" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 1 COPY FROM: 1 ACTIVE: M (T/F)
IF VEH GREEN ON PH 3 IS ON

THEN LP SET LOGIC FLAG 1 ON

ELSE
    
```

PHASE 3 GREEN SETS
LOGIC FLAG 1 ON
(SIDE STREET BACKUP)

ENTER A "2" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 2 COPY FROM: 2 ACTIVE: M (T/F)
IF LP FLAG 1 IS ON

THEN CTR OMIT PHASE 10 ON

ELSE
    
```

OMIT PHASE 10 SO
PHASE 3 MOVEMENTS
RUN ONCE PER CYCLE

ENTER A "3" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 3 COPY FROM: 3 ACTIVE: M (T/F)
IF VEH GREEN ON PH 2 IS ON

THEN LP SET LOGIC FLAG 1 OFF

ELSE
    
```

TURNS LOGIC FLAG 1
OFF TO ALLOW NORMAL
OPERATION

ENTER A "4" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 4 COPY FROM: 4 ACTIVE: M (T/F)
IF DET 34 IS ON

THEN LP DELAY FOR 5.0 SECONDS
PMT CALL PMT SEQ 7 ON

ELSE
    
```

END PROGRAMMING

4. From LOGIC PROCESSOR Submenu select 1. LOGIC STATEMENT CONTROL


ENABLE LOGIC PROCESSOR STATEMENTS 1, 2, 3 & 4 BY POSITIONING THE CURSOR OVER THE FIELDS SHOWN BELOW AND USING THE TOGGLE KEY TO ENABLE THEM.

```

LOGIC STATEMENT CONTROL
1 2 3 4 5 6 7 8 9 0 1 2 3 4 5
LP 1-15 E E E E . . . . .
LP 16-30 . . . . .
LP 31-45 . . . . .
LP 46-60 . . . . .
LP 61-75 . . . . .
LP 76-90 . . . . .
    
```

END PROGRAMMING

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 01-0025
DESIGNED: MARCH 2018
SEALED: 09/20/2018
REVISED: N/A



Electrical Detail - Sheet 3 of 5		DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED
ELECTRICAL AND PROGRAMMING DETAILS FOR:	US 17-158 (Hughes Boulevard) at US 17 Business (Road Street) / SR 1327 (Griggs Street) Division 1 Pasquotank County Elizabeth City	SEAL
Prepared for the Offices of:		
DRMP		
DRMP, Inc. 8000 Regency Parkway, Suite 175 Cary, NC 27519 NC License No. C-2218 (019) 650-1038		
750 N. Greenfield Pkwy, Garner, NC 27529		
PLAN DATE: March 2018 PREPARED BY: DJ White	REVIEWED BY: AJ Davis REVIEWED BY: LM Moon	SEAL Lisa M. Moon 9/20/2018 DATE SIG. INVENTORY NO. 01-0025

20-SEP-2018 18:51 R:\5942\51001\SHPS\gnw\1:1ng\01-0025-08232018e.dgn lmoon AT CAR-LMCDN1-WT

ECONOLITE ASC/3-2070 VEHICLE DETECTOR SETUP

PROGRAMMING DETAIL FOR LOOP 1B & 1C

(program controller as shown)

IMPORTANT!

Program detectors per the input file connection and programming chart shown on sheet 1 before proceeding.

- From Main Menu select **8. UTILITIES**
- From UTILITIES Submenu select **1. COPY/CLEAR**
- Copy from DETECTOR PLAN "1" to DETECTOR PLAN "2".

```

COPY / CLEAR UTILITY
FROM          TO
PHASE TIMING.... > PHASE TIMING....
TIMING PLAN.... > TIMING PLAN....
PH DET OPT PLAN. > PH DET OPT PLAN.
DETECTOR PLAN.. 1 > DETECTOR PLAN.. 2
TOGGLE TO SELECT A "FROM" AND A "TO"
THEN PRESS ENTER
    
```

- From Main Menu select **6. DETECTORS**
- From DETECTOR Submenu select **2. VEHICLE DETECTOR SETUP**
- Place cursor in VEH DET PLAN [] position and enter "2".
 - Place cursor in VEH DETECTOR [] position and enter "2".
 - Set delay time to "15".

```

VEH DETECTOR ["2"] VEH DET PLAN [ 2]
TYPE: S-STANDARD
TS2 DETECTOR..... X ECPI LOG..... NO
DET PH - 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
      2 1 .....
EXTEND TIME... 0.0 DELAY TIME... 15.0
USE ADDED INITIAL . CROSS SWITCH PH.. 0
LOCK IN..... NONE NTCIP VOL . OR OCC .
PMT QUEUE DELAY. NO
    
```

← NOTICE VEH
DET PLAN 2

← ENSURE DELAY
IS SET TO 15

- Place cursor in VEH DETECTOR [] position and enter "12".
- Set delay time to "15".

```

VEH DETECTOR ["12"] VEH DET PLAN [ 2]
TYPE: S-STANDARD
TS2 DETECTOR..... X ECPI LOG..... NO
DET PH - 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
      12 1 .....
EXTEND TIME... 0.0 DELAY TIME... 15.0
USE ADDED INITIAL . CROSS SWITCH PH.. 0
LOCK IN..... NONE NTCIP VOL . OR OCC .
PMT QUEUE DELAY. NO
    
```

← NOTICE VEH
DET PLAN 2

← ENSURE DELAY
IS SET TO 15

END PROGRAMMING

ECONOLITE ASC/3-2070 TOD ACTION PLAN

PROGRAMMING DETAIL FOR PHASE 1B & 1C

(program controller as shown)

- From Main Menu select **5. TIME BASE**
- From TIME BASE Submenu select **2. ACTION PLAN**

```

ACTION PLAN... [ 1]
PATTERN.....AUTO   SYS OVERRIDE.... NO
TIMING PLAN..... 0   SEQUENCE..... 0
VEH DETECTOR PLAN.. 2 DET LOG.....NONE
FLASH..... --   RED REST..... NO
VEH DET DIAG PLN... 0 PED DET DIAG PLN..0
DIMMING ENABLE.. NO  PRIORITY RETURN. NO
PED PR RETURN.. NO  QUEUE DELAY..... NO
PMT COND DELAY NO

PHASE 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
PED RCL . . . . .
WALK 2 . . . . .
VEX 2 . . . . .
VEH RCL . . . . .
MAX RCL . . . . .
MAX 2 . . . . .
PHASE 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
MAX 3 . . . . .
CS INH . . . . .
OMIT . . . . .
SPC FCT . . . . .
AUX FCT . . . . .

1 2 3 4 5 6 7 8 9 0 1 2 3 4 5
LP 1-15 . . . . .
LP 16-30 . . . . .
LP 31-45 . . . . .
LP 46-60 . . . . .
LP 61-75 . . . . .
LP 76-90 . . . . .
LP 91-100 . . . . .
    
```

- From Main Menu select **5. TIME BASE**
- From TIME BASE Submenu select **3. DAY PLAN/EVENT**

```

DAY PLAN [ 1] DAY PLAN IN EFFECT [ 0] V
EVENT ACTION PLAN START TIME
1 1 19:00
2 0 06:00
3 0 00:00
4 0 00:00
5 0 00:00
6 0 00:00
7 0 00:00
8 0 00:00
9 0 00:00
10 0 00:00
11 0 00:00
12 0 00:00
13 0 00:00
//
50 0 00:00
    
```

- From Main Menu select **5. TIME BASE**
- From TIME BASE Submenu select **4. SCHEDULE NUMBER**

```

SCHEDULE NUMBER [ 1]
DAY PLAN NO ..... 1 CLEAR ALL FIELDS..
SELECT ALL MONTHS.. X DOW.. . DOM.. .
MONTH J F M A M J J A S O N D
      X X X X X X X X X X X X
DAY (DOW): SUN MON TUE WED THU FRI SAT
      X X X X X X X X X
DAY(DOM):1 2 3 4 5 6 7 8 9 10 11
      X X X X X X X X X X X X
      12 13 14 15 16 17 18 19 20 21 22
      X X X X X X X X X X X X
      23 24 25 26 27 28 29 30 31
      X X X X X X X X X X
    
```

ECONOLITE ASC/3-2070 CLOCK & CALENDAR PROGRAMMING DATA

(program controller as shown)

- From Main Menu select **5. TIME BASE**
- From DETECTOR Submenu select **1. CLOCK/CALENDAR DATA**

```

DATE, DAY & TIME → CLOCK/CALENDAR DATA
                   XX/XX/XXXX DAY XX:XX:XX
                   ENA ACTION PLAN. 0
                   SYNC REF TIME.00:00 SYNC REF.. REF TIME
                   TIME FROM GMT...-04 DAY LIGHT SAVE.USDLS
                   TIME RESET INPUT SET TIME..... 00:00:00
    
```

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 01-0025
DESIGNED: MARCH 2018
SEALED: 09/20/2018
REVISED: N/A

Electrical Detail - Sheet 4 of 5

ELECTRICAL AND PROGRAMMING DETAILS FOR:		US 17-158 (Hughes Boulevard)	
Prepared for the Offices of:		at	
		US 17 Business (Road Street)/ SR 1327 (Griggs Street)	
Division 1 Pasquotank County		Elizabeth City	
PLAN DATE: March 2018	REVIEWED BY: AJ Davis	SEAL 022516	
PREPARED BY: DJ White	REVIEWED BY: LM Moon		
REVISIONS			
INIT.	DATE	DocuSigned by: Lisa M. Moon 9/20/2018	
		SIG. INVENTORY NO. 01-0025	

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SEAL

PROFESSIONAL ENGINEER

LISA M. MOON

9/20/2018

ECONOLITE ASC/3-2070 EMERGENCY VEHICLE PREEMPT PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select 4. PREEMPTOR/TSP
2. From PREEMPTOR/TSP/SCP Submenu select 1. PREEMPT PLAN 1-10

Place cursor in [] next to Preempt Plan and press 3. Then press the right cursor arrow and toggle the controller to YES. Next cursor down. This will select Emergency Vehicle Preempt #3.

```

PREEMPT PLAN [ 3 ]  ENABLE....YES
VEH/PED 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
OVERLAP A B C D E F G H I J K L M N O P
TRKCLR V . . . . .
TRKCLR O . . . . .
ENA TRL . . . . .
DWEL VEH X . . . . X . . . . .
DWEL PED . . . . .
DWEL OLPF1 .F1 . . . . .
CYC VEH . . . . .
CYC PED . . . . .
CYC OLP . . . . .
EXIT PH . X . . . X . . . . .
EXIT CAL . . . . .
SP FUNC . . . . .
    
```

```

ENABLE... YESIPMT OVRIDE..INTERLOCK. NO
DET LOCK... XIDELAY.. 0IINHIBIT... 0
OVERIDE FL. .IDURATION 0ICLR-GRN... NO
TERM OLP. NOIPC>YEL NOITERM PH NO
PED DARK.. NOITC RESRV NOIDWELL FL OFF
LINK PMT....OIX FLCOLR REDIEEXIT OPT. OFF
X TMG PLN...OIRE-SERV.. 0IFLT TYPE.HARD
FREE DUR PMTIR1 NOIR2 NOIR3 NOIR4 NO
--TIMING-----WALKIPED CLIMN GRI YELI RED
ENTRANCE TM. 255I 255I 1125.5125.5
-----MIN GRIEXT GRIMX GRI YELI RED
TRACK CLEAR 0I 0I 0I25.5I25.5
-----MIN DLIPMTEXTIMX TMI YELI RED
DWL/CYC-EXIT 12I 2.0I 120I25.5I25.5
PMT ACTIVE OUT..ON PMT ACT DWELL...NO
OTHER - PRI PMT.OFF NON-PRI PMT.....OFF
INH EXT TIME... 0.0 PED PR RETURN...OFF
PRIORITY RETURN.OFF QUEUE DELAY.... OFF
COND DELAY.....OFF
PHASES 1 2 3 4 5 6 7 8
PR RTN% 0 0 0 0 0 0 0 0
PHASES 9 10 11 12 13 14 15 16
PR RTN% 0 0 0 0 0 0 0 0
    
```

Place cursor in [] next to Preempt Plan and press 4. Then press the right cursor arrow and toggle the controller to YES. Next cursor down. This will select Emergency Vehicle Preempt #4.

```

PREEMPT PLAN [ 4 ]  ENABLE....YES
VEH/PED 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
OVERLAP A B C D E F G H I J K L M N O P
TRKCLR V . . . . .
TRKCLR O . . . . .
ENA TRL . . . . .
DWEL VEH . X . . . X . . . . .
DWEL PED . . . . .
DWEL OLPF1.F1 . . . . .
CYC VEH . . . . .
CYC PED . . . . .
CYC OLP . . . . .
EXIT PH . . X . . . . .
EXIT CAL . . . . .
SP FUNC . . . . .
    
```

```

ENABLE... YESIPMT OVRIDE..INTERLOCK. NO
DET LOCK... XIDELAY.. 0IINHIBIT... 0
OVERIDE FL. .IDURATION 0ICLR-GRN... NO
TERM OLP. NOIPC>YEL NOITERM PH NO
PED DARK.. NOITC RESRV NOIDWELL FL OFF
LINK PMT....OIX FLCOLR REDIEEXIT OPT. OFF
X TMG PLN...OIRE-SERV.. 0IFLT TYPE.HARD
FREE DUR PMTIR1 NOIR2 NOIR3 NOIR4 NO
--TIMING-----WALKIPED CLIMN GRI YELI RED
ENTRANCE TM. 255I 255I 1125.5I25.5
-----MIN GRIEXT GRIMX GRI YELI RED
TRACK CLEAR 0I 0I 0I25.5I25.5
-----MIN DLIPMTEXTIMX TMI YELI RED
DWL/CYC-EXIT 12I 2.0I 120I25.5I25.5
PMT ACTIVE OUT..ON PMT ACT DWELL...NO
OTHER - PRI PMT.OFF NON-PRI PMT.....OFF
INH EXT TIME... 0.0 PED PR RETURN...OFF
PRIORITY RETURN.OFF QUEUE DELAY.... OFF
COND DELAY.....OFF
PHASES 1 2 3 4 5 6 7 8
PR RTN% 0 0 0 0 0 0 0 0
PHASES 9 10 11 12 13 14 15 16
PR RTN% 0 0 0 0 0 0 0 0
    
```

Place cursor in [] next to Preempt Plan and press 5. Then press the right cursor arrow and toggle the controller to YES. Next cursor down. This will select Emergency Vehicle Preempt #5.

```

PREEMPT PLAN [ 5 ]  ENABLE....YES
VEH/PED 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
OVERLAP A B C D E F G H I J K L M N O P
TRKCLR V . . . . .
TRKCLR O . . . . .
ENA TRL . . . . .
DWEL VEH . . . X . . . . .
DWEL PED . . . . .
DWEL OLP . X . . . . .
CYC VEH . . . . .
CYC PED . . . . .
CYC OLP . . . . .
EXIT PH . X . . . X . . . . .
EXIT CAL . . . . .
SP FUNC . . . . .
    
```

```

ENABLE... YESIPMT OVRIDE..INTERLOCK. NO
DET LOCK... XIDELAY.. 0IINHIBIT... 0
OVERIDE FL. .IDURATION 0ICLR-GRN... NO
TERM OLP. NOIPC>YEL NOITERM PH NO
PED DARK.. NOITC RESRV NOIDWELL FL OFF
LINK PMT....OIX FLCOLR REDIEEXIT OPT. OFF
X TMG PLN...OIRE-SERV.. 0IFLT TYPE.HARD
FREE DUR PMTIR1 NOIR2 NOIR3 NOIR4 NO
--TIMING-----WALKIPED CLIMN GRI YELI RED
ENTRANCE TM. 255I 255I 1125.5I25.5
-----MIN GRIEXT GRIMX GRI YELI RED
TRACK CLEAR 0I 0I 0I25.5I25.5
-----MIN DLIPMTEXTIMX TMI YELI RED
DWL/CYC-EXIT 7I 2.0I 120I25.5I25.5
PMT ACTIVE OUT..ON PMT ACT DWELL...NO
OTHER - PRI PMT.OFF NON-PRI PMT.....OFF
INH EXT TIME... 0.0 PED PR RETURN...OFF
PRIORITY RETURN.OFF QUEUE DELAY.... OFF
COND DELAY.....OFF
PHASES 1 2 3 4 5 6 7 8
PR RTN% 0 0 0 0 0 0 0 0
PHASES 9 10 11 12 13 14 15 16
PR RTN% 0 0 0 0 0 0 0 0
    
```

ECONOLITE ASC/3-2070 PREEMPT FILTERING PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select 4. PREEMPTOR/TSP
2. From PREEMPT/TSP/SCP Submenu select 2. ENABLE PREEMPT FILTERING & TSP/SCP

```

ENABLE PREEMPT FILTERING & TSP/SCP
FILTERED SOLID PULSING
INPUT 1 ...BYPASSED...BY PASSED..
2 ...BYPASSED...BY PASSED..
3 ..PREEMPT 3. ...BYPASSED..
4 ..PREEMPT 4. ...BYPASSED..
5 ..PREEMPT 5. ...BYPASSED..
6 ...BYPASSED...BY PASSED..
7 ..PREEMPT 7. ...BYPASSED..
8 ...BYPASSED...BY PASSED..
9 ...BYPASSED...BY PASSED..
10 ...BYPASSED...BY PASSED..
    
```

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 01-0025
DESIGNED: MARCH 2018
SEALED: 09/20/2018
REVISED: N/A

Electrical Detail - Sheet 5 of 5


DOCUMENT NOT CONSIDERED FINAL
UNLESS ALL SIGNATURES COMPLETED

<p style="font-size: small;">ELECTRICAL AND PROGRAMMING DETAILS FOR:</p> <p style="font-size: x-small;">Prepared for the Offices of:</p> <p style="font-size: x-small;">Plans Prepared By:</p> <p style="font-size: x-small;">DRMP, Inc. 8000 Regency Parkway, Suite 175 Cary, NC 27519 NC License No. C-2215 (019) 650-1038</p>	<p style="text-align: center;">US 17-158 (Hughes Boulevard) at US 17 Business (Road Street)/ SR 1327 (Griggs Street)</p> <p style="font-size: small;">Division 1 Pasquotank County Elizabeth City</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; border-bottom: 1px solid black;">PLAN DATE: March 2018</td> <td style="width: 50%; border-bottom: 1px solid black;">REVIEWED BY: AJ Davis</td> </tr> <tr> <td style="border-bottom: 1px solid black;">PREPARED BY: DJ White</td> <td style="border-bottom: 1px solid black;">REVIEWED BY: LW Moon</td> </tr> </table> <table style="width: 100%; border-collapse: collapse; font-size: x-small;"> <tr> <th style="width: 60%;">REVISIONS</th> <th style="width: 20%;">INIT.</th> <th style="width: 20%;">DATE</th> </tr> <tr> <td> </td> <td> </td> <td> </td> </tr> </table>	PLAN DATE: March 2018	REVIEWED BY: AJ Davis	PREPARED BY: DJ White	REVIEWED BY: LW Moon	REVISIONS	INIT.	DATE				<p style="font-size: x-small;">SEAL</p> <p style="font-size: x-small;">DocuSigned by: Lisa M. Moon 9/20/2018</p> <p style="font-size: x-small;">SIG. INVENTORY NO. 01-0025</p>
PLAN DATE: March 2018	REVIEWED BY: AJ Davis											
PREPARED BY: DJ White	REVIEWED BY: LW Moon											
REVISIONS	INIT.	DATE										

EDI MODEL 2018ECLIP-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)

REMOVE DIODE JUMPERS 1-5, 1-6, 1-9, 1-11, 1-15, 2-5, 2-6, 2-9, 2-11, 2-13, 2-15, 3-7, 3-8, 3-10, 3-12, 3-16, 4-7, 4-8, 4-10, 4-12, 4-16, 5-9, 5-11, 5-13, 6-9, 6-11, 6-13, 6-15, 7-10, 7-12, 8-10, 8-12, 8-16, 9-11, 9-13, 9-15, 10-12, 10-16, 11-13, 11-15, 12-16 and 13-15.



REMOVE JUMPERS AS SHOWN

NOTES:

- 1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
3. Ensure that Red Enable is active at all times during normal operation.
4. Integrate monitor with Ethernet network in cabinet.

NOTES

- 1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
2. Program phases 4 and 8 for Dual Entry.
3. Program controller to start up in phase 2 WALK and 6 WALK.
4. The cabinet and controller are part of the Elizabeth City Signal System.
5. Ensure Delayed Green times shown in the Timing Chart on the signal design plan are accounted for to facilitate leading pedestrian interval.

EQUIPMENT INFORMATION

CONTROLLER.....2070LX
CABINET.....332 W/AUX
SOFTWARE.....ECONOLITE ASC/3-2070
CABINET MOUNT.....BASE
OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
LOAD SWITCHES USED.....S1,S2,S3,S4,S5,S7,S8,S9,S10,S11,
S12,AUX S1,AUX S2,AUX S4,AUX S5
PHASES USED.....1,2,2PED,3,4,5,6,6PED,7,8,8PED
OVERLAP "A".....*
OVERLAP "B".....*
OVERLAP "C".....*
OVERLAP "D".....*
* See overlap programming detail on sheet 2

SIGNAL HEAD HOOK-UP CHART


Table with columns for Load Switch No., S1-S12, AUX S1-S6 and rows for PHASE, SIGNAL HEAD NO., RED, YELLOW, GREEN, RED ARROW, YELLOW ARROW, FLASHING YELLOW ARROW, GREEN ARROW. Includes asterisks for load resistors and stars for head wiring details.

NU = Not Used

- * Denotes install load resistor. See load resistor installation detail this sheet.
* See pictorial of head wiring in detail on next sheet.

INPUT FILE POSITION LAYOUT

(front view)




EX.: 1A, 2A, ETC. = LOOP NO.'S
Wired Input - Do not populate slot with detector card
FS = FLASH SENSE
ST = STOP TIME

INPUT FILE CONNECTION & PROGRAMMING CHART

Table with columns: LOOP NO., LOOP TERMINAL, INPUT FILE POS., PIN NO., DETECTOR NO., NEMA PHASE, CALL, EXTEND TIME, DELAY TIME, ADDED INITIAL, DETECTOR TYPE. Includes notes about installing DC isolators in input file slots 112 and 113.

- 1 Add jumper from J1-W to J4-W, on rear of input file.
2 Add jumper from J5-W to J8-W, on rear of input file.
3 Add jumper from J1-W to J4-W, on rear of input file.
4 Add jumper from J5-W to J8-W, on rear of input file.



COUNTDOWN PEDESTRIAN SIGNAL OPERATION


Countdown Ped Signals are required to display timing only during Ped Clearance Interval. Consult Ped Signal Module user's manual for instructions on selecting this feature.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 01-0034
DESIGNED: FEBRUARY 2018
SEALED: 09/20/2018
REVISED: N/A

LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown)

Table with columns: VALUE (ohms), WATTAGE. Values: 1.5K - 1.9K, 25W (min); 2.0K - 3.0K, 10W (min).



DRMP, Inc. 8000 Regency Parkway, Suite 175 Cary, NC 27519 NC License No. C-2213 (019) 650-1038

Electrical Detail - Sheet 1 of 3

Professional engineering seal for Lisa M. Moon, License No. 022516, State of North Carolina. Includes project details for US 17 Bus. (W. Ehringhaus St.) at McArthur Dr. / Ent. to Southgate Mall.

ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select 2. CONTROLLER
2. From CONTROLLER Submenu select 2. VEHICLE OVERLAPS

OVERLAP A

Select TMG VEH OVLP [A] and 'PPLT FYA'

TMG VEH OVLP...[A] TYPE:PPLT FYA

PROTECTED LEFT TURN.... PHASE 1

OPPOSING THROUGH..... PHASE 2

FLASHING ARROW OUTPUT.....CH9 ISOLATE

DELAY START OF: FYA..0.0 CLEARANCE..0.0

ACTION PLAN SF BIT DISABLE..... 0

Toggle Once

OVERLAP B

Select TMG VEH OVLP [B] and 'PPLT FYA'

TMG VEH OVLP...[B] TYPE:PPLT FYA

PROTECTED LEFT TURN.... PHASE 3

OPPOSING THROUGH..... PHASE 4

FLASHING ARROW OUTPUT.....CH10 ISOLATE

DELAY START OF: FYA..0.0 CLEARANCE..0.0

ACTION PLAN SF BIT DISABLE..... 0

Toggle Once

OVERLAP C

Select TMG VEH OVLP [C] and 'PPLT FYA'

TMG VEH OVLP...[C] TYPE:PPLT FYA

PROTECTED LEFT TURN.... PHASE 5

OPPOSING THROUGH..... PHASE 6

FLASHING ARROW OUTPUT.....CH11 ISOLATE

DELAY START OF: FYA..0.0 CLEARANCE..0.0

ACTION PLAN SF BIT DISABLE..... 0

Toggle Once

OVERLAP D

Select TMG VEH OVLP [D] and 'PPLT FYA'

TMG VEH OVLP...[D] TYPE:PPLT FYA

PROTECTED LEFT TURN.... PHASE 7

OPPOSING THROUGH..... PHASE 8

FLASHING ARROW OUTPUT.....CH12 ISOLATE

DELAY START OF: FYA..0.0 CLEARANCE..0.0


ACTION PLAN SF BIT DISABLE..... 0

Toggle Once

END PROGRAMMING

FYA SIGNAL WIRING DETAIL

(wire signal heads as shown)



FLASHER CIRCUIT MODIFICATION DETAIL

IN ORDER TO ENSURE THAT SIGNALS FLASH CONCURRENTLY ON THE SAME APPROACH, MAKE THE FOLLOWING FLASHER CIRCUIT CHANGES:

1. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-4 AND TERMINATE ON T2-2.
2. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-5 AND TERMINATE ON T2-3.
3. REMOVE FLASHER UNIT 2.

THE CHANGES LISTED ABOVE TIES ALL PHASES AND OVERLAPS TO FLASHER UNIT 1.

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 01-0034
DESIGNED: FEBRUARY 2018
SEALED: 09/20/2018
REVISED: N/A


Electrical Detail - Sheet 2 of 3

<p style="text-align: center; font-size: small;">ELECTRICAL AND PROGRAMMING DETAILS FOR:</p> <p style="text-align: center; font-size: x-small;">Prepared for the Offices of:</p> <div style="text-align: center;"> DRMP <small>DRMP, Inc. 8000 Regency Parkway, Suite 175 Cary, NC 27519 NC License No. C-2215 (019) 650-1038</small> </div>	<p style="font-weight: bold; font-size: small;">US 17 Bus. (W. Ehringhaus St.) at McArthur Dr./ Ent. to Southgate Mall</p> <p style="font-size: x-small;">Division 1 Pasquotank County Elizabeth City</p> <table style="width: 100%; font-size: x-small;"> <tr> <td>PLAN DATE: February 2018</td> <td>REVIEWED BY: AJ Davis</td> </tr> <tr> <td>PREPARED BY: DJ White</td> <td>REVIEWED BY: LM Moon</td> </tr> </table>	PLAN DATE: February 2018	REVIEWED BY: AJ Davis	PREPARED BY: DJ White	REVIEWED BY: LM Moon	<p style="font-size: x-small;">DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED</p> <div style="text-align: center;"> <small>SEAL 022516 ENGINEER LISA M. MOON</small> </div> <p style="font-size: x-small;">DocuSigned by: <i>Lisa M. Moon</i> 9/20/2018 DATE SIG. INVENTORY NO. 01-0034</p>
PLAN DATE: February 2018	REVIEWED BY: AJ Davis					
PREPARED BY: DJ White	REVIEWED BY: LM Moon					

EDI MODEL 2018EClip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)

REMOVE DIODE JUMPERS 1-5, 1-6, 1-9, 1-11, 2-5, 2-6, 2-9, 2-11, 4-8, 5-9, 5-11, 6-9, 6-11 and 9-11.



NOTES:

1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
3. Ensure that Red Enable is active at all times during normal operation.
4. Integrate monitor with Ethernet network in cabinet.

NOTES

1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
2. Program phases 4 and 8 for Dual Entry.
3. Program controller to start up in phase 2 Green and 6 Green.
4. The cabinet and controller are part of the Elizabeth City Signal System.

EQUIPMENT INFORMATION

CONTROLLER.....2070LX
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S5,S7,S8,S11,AUX S1,
 AUX S4
 PHASES USED.....1,2,4,5,6,8
 OVERLAP "A".....*
 OVERLAP "B".....NOT USED
 OVERLAP "C".....*
 OVERLAP "D".....NOT USED

* See overlap programming detail on sheet 2

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6				
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18				
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE				
SIGNAL HEAD NO.	11*	82	21,22	NU	NU	41,42	NU	51*	42	61,62	NU	NU	81,82	NU	11*	NU	NU	51*	NU			
RED	*	128				101		*		134			107									
YELLOW		129				102				135			108									
GREEN		130				103				136			109									
RED ARROW																			A121		A114	
YELLOW ARROW	126									132										A122		A115
FLASHING YELLOW ARROW																				A123		A116
GREEN ARROW	127	127								133	133											


NU = Not Used

* Denotes install load resistor. See load resistor installation detail this sheet.

★ See pictorial of head wiring in detail this sheet.

INPUT FILE POSITION LAYOUT

(front view)




EX.: 1A, 2A, ETC. = LOOP NO.'S
 ⊗ Wired Input - Do not populate slot with detector card
 FS = FLASH SENSE
 ST = STOP TIME

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND TIME	DELAY TIME	ADDED INITIAL	DETECTOR TYPE
1A ¹	TB2-1,2	I1U	56	1	1	YES		15		S
	-	J4U	48	26	6	YES		3		S
1B	TB2-5,6	I2U	39	2	1	YES		15		S
2A/S1	TB2-9,10	I3U	63	32	2/SYS	YES				S
2B/S2	TB2-11,12	I3L	76	42	2/SYS	YES				S
4A	TB4-9,10	I6U	41	4	4	YES		3		S
5A ¹	TB3-1,2	J1U	55	5	5	YES		15		S
	-	I4U	47	22	2	YES		3		S
5B	TB3-5,6	J2U	40	6	5	YES		15		S
6A/S3	TB3-9,10	J3U	64	36	6/SYS	YES				S
6B/S4	TB3-11,12	J3L	77	46	6/SYS	YES				S
8A	TB5-9,10	J6U	42	8	8	YES		3		S


- 1 Add jumper from I1-W to J4-W, on rear of input file.
- 2 Add jumper from J1-W to I4-W, on rear of input file.

INPUT FILE POSITION LEGEND: J2L



FYA SIGNAL WIRING DETAIL


(wire signal heads as shown)



LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown)

VALUE (ohms)	WATTAGE
1.5K - 1.9K	25W (min)
2.0K - 3.0K	10W (min)



Electrical Detail - Sheet 1 of 2

Electrical and Programming Details for: **US 17 (US 17 South) at SR 1306 (Forest Park Road)/ Central Elementary School Ent.**

Division 1 Pasquotank County Elizabeth City

PLAN DATE: February 2018 REVIEWED BY: AJ Davis
 PREPARED BY: DJ White REVIEWED BY: LM Moon

REVISIONS: _____ INIT. DATE: _____

DRMP, Inc. 8000 Regency Parkway, Suite 175 Cary, NC 27518 NC License No. C-2215 (919) 650-1038

Seal: Lisa M. Moon, Professional Engineer, License No. 022516

DocuSigned by: Lisa M. Moon 9/20/2018

SIG. INVENTORY NO. 01-0092

20-SEP-2018 18:51 R:\415942\415942.dwg (User: jg) Plot: 01-0092.dwg (User: jg) Plot Date: 9/20/2018 18:51:00

ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select 2. CONTROLLER
2. From CONTROLLER Submenu select 2. VEHICLE OVERLAPS

OVERLAP A

Select TMG VEH OVLP [A] and 'PPLT FYA'

```

TMG VEH OVLP...[A] TYPE: .....PPLT FYA
PROTECTED LEFT TURN.... PHASE 1
OPPOSING THROUGH..... PHASE 2

FLASHING ARROW OUTPUT.....CH9 ISOLATE
DELAY START OF: FYA..0.0 CLEARANCE..0.0
ACTION PLAN SF BIT DISABLE..... 0
  
```

Toggle Twice

OVERLAP C

Select TMG VEH OVLP [C] and 'PPLT FYA'

```

TMG VEH OVLP...[C] TYPE: .....PPLT FYA
PROTECTED LEFT TURN.... PHASE 5
OPPOSING THROUGH..... PHASE 6

FLASHING ARROW OUTPUT.....CH11 ISOLATE
DELAY START OF: FYA..0.0 CLEARANCE..0.0
ACTION PLAN SF BIT DISABLE..... 0
  
```


END PROGRAMMING

THIS ELECTRICAL DETAIL IS FOR
 THE SIGNAL DESIGN: 01-0092
 DESIGNED: FEBRUARY 2018
 SEALED: 08/22/2018
 REVISED: N/A

20-SEP-2018 1:45:51
 R:\15942\51\0001\5\K05\0001\1\mg401-0092-08222018e.dgn
 lmoon AT CAR-LMCDNH-W7

Electrical Detail - Sheet 2 of 2

DOCUMENT NOT CONSIDERED
FINAL UNLESS ALL
SIGNATURES COMPLETED



ELECTRICAL AND PROGRAMMING DETAILS FOR:	
US 17 (US 17 South) at SR 1306 (Forest Park Road)/ Central Elementary School Ent. Division 1 Pasquotank County Elizabeth City	
PLAN DATE: February 2018	REVIEWED BY: AJ Davis
PREPARED BY: DJ White	REVIEWED BY: LM Moon
REVISIONS	INIT. DATE

SEAL

NORTH CAROLINA
PROFESSIONAL
SEAL
ENGINEER
LISA M. MOON

DocuSigned by:
Lisa M. Moon 9/20/2018
SIC6288B83D0F21 DATE
SIC. INVENTORY NO. 01-0092






TABLE OF OPERATION

SIGNAL FACE	PHASE											
	01+5	01+6	02+5	02+6	03+7	03+8	04+7	04+8	EVP 3	EVP 4	EVP 5	EVP 6
11	←	←	←	←	←	←	←	←	←	←	←	←
21,22	R	R	G	G	R	R	R	R	G	R	R	Y
31	←	←	←	←	←	←	←	←	←	←	←	←
41,42	R	R	R	R	R	R	R	G	G	R	R	R
51	←	←	←	←	←	←	←	←	←	←	←	←
61,62	R	G	R	G	R	R	R	R	G	R	R	Y
71	←	←	←	←	←	←	←	←	←	←	←	←
81,82	R	R	R	R	R	G	R	G	R	R	R	R


ASC/3 DETECTOR INSTALLATION CHART

LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	PROGRAMMING								
				NEW LOOP	PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE	SYSTEM LOOP	NEW CARD
1A	6X40	0	2-4-2	-	1	Yes	-	15	-	S	-	X
2A/S1	6X6	355	EXIST	-	2	Yes	-	-	-	X	N	X
2B/S2	6X6	355	EXIST	-	2	Yes	-	-	-	X	N	X
3A	6X60	+5	2-4-2	-	3	Yes	-	15	-	S	-	X
4A	6X60	+5	2-4-2	-	4	Yes	-	-	-	S	-	X
4B	6X40	+5	2-4-2	-	4	Yes	-	15	-	S	-	X
5A	6X40	0	2-4-2	-	5	Yes	-	15	-	S	-	X
6A/S3	6X6	355	EXIST	-	6	Yes	-	-	-	X	N	X
6B/S4	6X6	355	EXIST	-	6	Yes	-	-	-	X	N	X
7A	6X60	+5	2-4-2	-	7	Yes	-	15	-	S	-	X
8A	6X60	+5	2-4-2	-	8	Yes	-	-	-	S	-	X
8B	6X40	+5	2-4-2	-	8	Yes	-	15	-	S	-	X
S5	6X6	+160	3	X	-	-	-	-	-	-	N	X
S6	6X6	+160	3	X	-	-	-	-	-	-	N	X
S7	6X6	+160	4	X	-	-	-	-	-	-	N	X
S8	6X6	+160	4	X	-	-	-	-	-	-	N	X

8 Phase Fully Actuated w/ EV Preemption (Elizabeth City Signal System)

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 1 and/or phase 5 may be lagged.
- Phase 3 and/or phase 7 may be lagged.
- Set all detector units to presence mode.
- In the event of loop replacement, refer to the current ITS and Signals Design Manual and submit a Plan of Record to the Signal Design Section.
- Locate new cabinet so as not to obstruct sight distance of vehicles turning right on red.
- Pavement markings are existing.
- This intersection features an optical preemption system. Shown locations of optical detectors are conceptual only.
- Optical detector 3 calls EVP 3; Optical detector 4 calls EVP 4; Optical detector 5 calls EVP 5; Optical detector 6 calls EVP 6.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.



ASC/3 TIMING CHART


FEATURE	PHASE							
	1	2	3	4	5	6	7	8
Min Green *	7	14	7	7	7	14	7	7
Walk *	-	-	-	-	-	-	-	-
Ped Clear	-	-	-	-	-	-	-	-
Veh. Extension *	2.0	6.0	2.0	2.0	2.0	6.0	2.0	2.0
Max 1 *	15	90	15	20	15	90	15	20
Yellow	3.0	4.8	3.0	4.5	3.0	4.8	3.0	4.5
Red Clear	1.8	1.0	2.9	1.8	1.8	1.0	2.6	1.8
Actuations B4 Add *	-	0	-	-	-	0	-	-
Seconds / Actuation *	-	1.5	-	-	-	1.5	-	-
Max Initial *	-	40	-	-	-	40	-	-
Time Before Reduction *	-	20	-	-	-	20	-	-
Time To Reduce *	-	50	-	-	-	50	-	-
Minimum Gap	-	3.3	-	-	-	3.3	-	-
Locking Detector	-	X	-	-	-	X	-	-
Recall Position	-	VEH. RECALL	-	-	-	VEH. RECALL	-	-
Dual Entry	-	-	-	X	-	-	-	X
Simultaneous Gap	X	X	X	X	X	X	X	X

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

ASC/3 EV PREEMPT

FUNCTION	PRE 3	PRE 4	PRE 5	PRE 6
Exit Phase(s)	2,6	2,6	2,6	2,6
Preempt Override	OFF	OFF	OFF	OFF
Delay Time	0	0	0	0
Ped Clear Through Yellow	N	N	N	N
Terminate Phases	N	N	N	N
Entrance Walk	255*	255*	255*	255*
Entrance Ped Clear	255*	255*	255*	255*
Entrance Min Green	1	1	1	1
Entrance Yellow Change	25.5*	25.5*	25.5*	25.5*
Entrance Red Clear	25.5*	25.5*	25.5*	25.5*
Minimum Dwell Time	12	12	7	7
Preempt Input Extension Time	2	2	2	2
Preempt Max Time	120	120	120	120
Exit Yellow Change	25.5*	25.5*	25.5*	25.5*
Exit Red Clear	25.5*	25.5*	25.5*	25.5*

*Time defaults to time used for phase during normal operation



Signal Upgrade

Prepared for the Offices of:

 750 N. Greenfield Pkwy, Garner, NC 27529

NC 344 (Halstead Boulevard) At SR 1101 (Peartree Road)

Division 1 Pasquotank County Elizabeth City
 PLAN DATE: September 2018 REVIEWED BY: CBHolden
 PREPARED BY: DTSears REVIEWED BY: _____
 REVISIONS: _____ INIT. DATE: _____

PLANS PREPARED BY:

 RUMMEL, KLEPPER & KAHL, LLP
 900 RIDGEFIELD DRIVE SUITE 350
 RALEIGH, NORTH CAROLINA 27609-3960
 NC LICENSE NO. F-0112 • (919) 878-9560

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED


SEAL

 C. Byron Holden
 ENGINEER
 9/21/2018
 DATE: _____
 SIG. INVENTORY NO. 01-0217

EDI MODEL 2018ECLIP-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



REMOVE DIODE JUMPERS 1-5, 1-6, 1-9, 1-11, 2-5, 2-6, 2-9, 2-11, 3-7, 3-8, 3-10, 3-12, 4-7, 4-8, 4-10, 4-12, 5-9, 5-11, 6-9, 6-11, 7-10, 7-12, 8-10, 8-12, 9-11 AND 10-12.



REMOVE JUMPERS AS SHOWN

NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- Ensure that Red Enable is active at all times during normal operation.
- Integrate monitor with Ethernet network in cabinet.



NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Program phases 4 and 8 for Dual Entry.
- Program controller to start up in phase 2 Green and 6 Green.
- The cabinet and controller are part of the Elizabeth City Signal System.

EQUIPMENT INFORMATION

CONTROLLER.....2070LX
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S4,S5,S7,S8,S10,S11,
 AUX S1,AUX S2,AUX S4,AUX S5
 PHASES USED.....1,2,3,4,5,6,7,8
 OVERLAP "A".....*
 OVERLAP "B".....*
 OVERLAP "C".....*
 OVERLAP "D".....*
 * See overlap programming detail on sheet 2


SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	11	21,22	NU	31	41,42	NU	51	61,62	NU	71	81,82	NU	11	31	NU	51	71	NU
RED		128			101			134			107							
YELLOW	*	129		*	102		*	135		*	108							
GREEN		130			103			136			109							
RED ARROW													A121	A124		A114	A101	
YELLOW ARROW													A122	A125		A115	A102	
FLASHING YELLOW ARROW													A123	A126		A116	A103	
GREEN ARROW	127			118			133			124								

NU = Not Used

- * Denotes install load resistor. See load resistor installation detail on sheet 2 of 3.
- * See pictorial of head wiring in detail this sheet.

INPUT FILE POSITION LAYOUT (front view)



EX.: 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
ST = STOP TIME
PRE = PREEMPT


⊗ Wired Input - Do not populate slot with detector card

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND TIME	DELAY TIME	ADDED INITIAL	DETECTOR TYPE
1A ¹	TB2-1,2	I1U	56	1	1	YES		15		S
	-	J4U	48	26	6	YES		3		G
2A/S1	TB2-5,6	I2U	39	2	2/SYS	YES			X	N
	TB2-7,8	I2L	43	12	2/SYS	YES			X	N
3A ²	TB4-5,6	I5U	58	3	3	YES		15		S
	-	J8U	50	28	8	YES		3		G
4A	TB4-9,10	I6U	41	4	4	YES				S
4B	TB4-11,12	I6L	45	14	4	YES		15		S
* S5	TB6-9,10	I9U	60	11	SYS	NO				N
* S6	TB6-11,12	I9L	62	13	SYS	NO				N
5A ³	TB3-1,2	J1U	55	5	5	YES		15		S
	-	I4U	47	22	2	YES		3		G
6A/S3	TB3-5,6	J2U	40	6	6/SYS	YES			X	N
6B/S4	TB3-7,8	J2L	44	16	6/SYS	YES			X	N
7A ⁴	TB5-5,6	J5U	57	7	7	YES		15		S
	-	I8U	49	24	4	YES		3		G
8A	TB5-9,10	J6U	42	8	8	YES				S
8B	TB5-11,12	J6L	46	18	8	YES		15		S
* S7	TB7-9,10	J9U	59	15	SYS	NO				N
* S8	TB7-11,12	J9L	61	17	SYS	NO				N

* System detector only. Remove any assigned vehicle phase.


- Add jumper from I1-W to J4-W, on rear of input file.
- Add jumper from I5-W to J8-W, on rear of input file.
- Add jumper from J1-W to I4-W, on rear of input file.
- Add jumper from J5-W to I8-W, on rear of input file.



** OPTICAL PREEMPTION SYSTEM

- Install an optical preemption system for emergency vehicle preemption. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the preemption schemes shown on the Signal Design Plans.
- Ensure that the Optical Preemption System is fully compatible with equipment manufactured in accordance with the specification of the type 2070 controller.

FYA SIGNAL WIRING DETAIL (wire signal heads as shown)



THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 01-0217
 DESIGNED: September 2018
 SEALED: 09/21/2018
 REVISED: N/A

Electrical Detail - Sheet 1 of 3

PLANS PREPARED BY :

RUMMEL, KLEPPER & KAHL, LLP
 900 RIDGEFIELD DRIVE SUITE 350
 RALEIGH, NORTH CAROLINA 27609-3960
 NC LICENSE NO. F-0112 • (919) 878-9560

ELECTRICAL AND PROGRAMMING DETAILS FOR:

Prepared for the Offices of:

750 N. Greenfield Pkwy, Garner, NC 27529

NC 344 (Halstead Boulevard) at SR 1101 (Peartree Road)

Division 1 Pasquotank County Elizabeth City

PLAN DATE: September 2018 REVIEWED BY: J O Deaton

PREPARED BY: M W Yalch REVIEWED BY:

REVISIONS	INIT.	DATE

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SEAL

DocuSigned by: James O. Deaton 9/21/2018

SIG. INVENTORY NO. 01-0217

ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select 2. CONTROLLER
2. From CONTROLLER Submenu select 2. VEHICLE OVERLAPS

OVERLAP A

Select TMG VEH OVLP [A] and 'PPLT FYA'

TMG VEH OVLP...[A] TYPE:	PPLT FYA
PROTECTED LEFT TURN....	PHASE 1
OPPOSING THROUGH.....	PHASE 2
FLASHING ARROW OUTPUT.....CH9 ISOLATE	
DELAY START OF: FYA..0.0 CLEARANCE..0.0	
ACTION PLAN SF BIT DISABLE..... 0	

Toggle Once

OVERLAP B

Select TMG VEH OVLP [B] and 'PPLT FYA'

TMG VEH OVLP...[B] TYPE:	PPLT FYA
PROTECTED LEFT TURN....	PHASE 3
OPPOSING THROUGH.....	PHASE 4
FLASHING ARROW OUTPUT.....CH10 ISOLATE	
DELAY START OF: FYA..0.0 CLEARANCE..0.0	
ACTION PLAN SF BIT DISABLE..... 0	

Toggle Once

OVERLAP C

Select TMG VEH OVLP [C] and 'PPLT FYA'

TMG VEH OVLP...[C] TYPE:	PPLT FYA
PROTECTED LEFT TURN....	PHASE 5
OPPOSING THROUGH.....	PHASE 6
FLASHING ARROW OUTPUT.....CH11 ISOLATE	
DELAY START OF: FYA..0.0 CLEARANCE..0.0	
ACTION PLAN SF BIT DISABLE..... 0	

Toggle Once

OVERLAP D

Select TMG VEH OVLP [D] and 'PPLT FYA'

TMG VEH OVLP...[D] TYPE:	PPLT FYA
PROTECTED LEFT TURN....	PHASE 7
OPPOSING THROUGH.....	PHASE 8
FLASHING ARROW OUTPUT.....CH12 ISOLATE	
DELAY START OF: FYA..0.0 CLEARANCE..0.0	
ACTION PLAN SF BIT DISABLE..... 0	

END PROGRAMMING

FLASHER CIRCUIT MODIFICATION DETAIL

IN ORDER TO ENSURE THAT SIGNALS FLASH CONCURRENTLY ON THE SAME APPROACH, MAKE THE FOLLOWING FLASHER CIRCUIT CHANGES:


1. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-4 AND TERMINATE ON T2-2.
2. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-5 AND TERMINATE ON T2-3.
3. REMOVE FLASHER UNIT 2.

THE CHANGES LISTED ABOVE TIES ALL PHASES AND OVERLAPS TO FLASHER UNIT 1.

LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown)

ACCEPTABLE VALUES	
VALUE (ohms)	WATTAGE
1.5K - 1.9K	25W (min)
2.0K - 3.0K	10W (min)



ECONOLITE ASC/3-2070 PREEMPT FILTERING PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select 4. PREEMPTOR/TSP
2. From PREEMPT/TSP/SCP Submenu select 2. ENABLE PREEMPT FILTERING & TSP/SCP

ENABLE PREEMPT FILTERING & TSP/SCP		
FILTERED	SOLID	PULSING
INPUT 1	...BYPASSED..	...BYPASSED..
2	...BYPASSED..	...BYPASSED..
3	..PREEMPT	3. ...BYPASSED..
4	..PREEMPT	4. ...BYPASSED..
5	..PREEMPT	5. ...BYPASSED..
6	..PREEMPT	6. ...BYPASSED..
7	...BYPASSED..	...BYPASSED..
8	...BYPASSED..	...BYPASSED..
9	...BYPASSED..	...BYPASSED..
10	...BYPASSED..	...BYPASSED..

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 01-0217
DESIGNED: September 2018
SEALED: 09/21/2018
REVISED: N/A


Electrical Detail - Sheet 2 of 3

PLANS PREPARED BY :



RUMMEL, KLEPPER & KAHL, LLP
900 RIDGEFIELD DRIVE SUITE 350
RALEIGH, NORTH CAROLINA 27609-3960
NC LICENSE NO. F-0112 • (919) 878-9560

ELECTRICAL AND PROGRAMMING
DETAILS FOR:



NC 344 (Halstead Boulevard)
at
SR 1101 (Peartree Road)

Division 1 Pasquotank County Elizabeth City
PLAN DATE: September 2018 REVIEWED BY: J O Deaton
PREPARED BY: M W Yalch REVIEWED BY:

REVISIONS	INIT.	DATE

DOCUMENT NOT CONSIDERED
FINAL UNLESS ALL
SIGNATURES COMPLETED

SEAL

DocuSigned by:
James O. Deaton
9/21/2018
DATE
SIG. INVENTORY NO. 01-0217

ECONOLITE ASC/3-2070 EMERGENCY VEHICLE PREEMPT PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select **4. PREEMPTOR/TSP**

2. From PREEMPTOR/TSP/SCP Submenu select **1. PREEMPT PLAN 1-10**

Place cursor in [] next to Preempt Plan and press 3. Then press the right cursor arrow and toggle the controller to YES. Next cursor down. This will select Emergency Vehicle Preempt #3.

Place cursor in [] next to Preempt Plan and press 4. Then press the right cursor arrow and toggle the controller to YES. Next cursor down. This will select Emergency Vehicle Preempt #4.

Place cursor in [] next to Preempt Plan and press 5. Then press the right cursor arrow and toggle the controller to YES. Next cursor down. This will select Emergency Vehicle Preempt #5.

Place cursor in [] next to Preempt Plan and press 6. Then press the right cursor arrow and toggle the controller to YES. Next cursor down. This will select Emergency Vehicle Preempt #6.

```

PREEMPT PLAN [ 3]  ENABLE....YES
VEH/PED 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
OVERLAP A B C D E F G H I J K L M N O P
TRKCLR V . . . . .
TRKCLR O . . . . .
ENA TRL . . . . .
DWEL VEH . X . . X . . . . .
DWEL PED . . . . .
DWEL OLPF1 .F1 . . . . .
CYC VEH . . . . .
CYC PED . . . . .
CYC OLP . . . . .
EXIT PH . X . . . X . . . . .
EXIT CAL . . . . .
SP FUNC . . . . .

```

```

ENABLE... YESIPMT OVRIDE..IINTERLOCK. NO
DET LOCK... XIDELAY.. 0IINHIBIT... 0
OVERIDE FL. .IDURATION 0ICLR-GRN... NO
TERM OLP. NOIPC>YEL NOITERM PH NO
PED DARK.. NOITC RESRV NOIDWELL FL OFF
LINK PMT....0IX FLCOLR REDIEEXIT OPT. OFF
X TMG PLN...0IRE-SERV.. 0IFLT TYPE.HARD
FREE DUR PMTIR1 NOIR2 NOIR3 NOIR4 NO
--TIMING----WALKIPED CLIMN GRI YELI RED
ENTRANCE TM. 255I 255I 1125.5125.5
-----MIN GRIEXT GRIMX GRI YELI RED
TRACK CLEAR 0I 0I 0I25.5125.5
-----MIN DLIPMTEXTIMX TMI YELI RED
DWL/CYC-EXIT 12I 2.0I 120I25.5125.5
PMT ACTIVE OUT..ON PMT ACT DWELL...NO
OTHER - PRI PMT.OFF NON-PRI PMT....OFF
INH EXT TIME... 0.0 PED PR RETURN...OFF
PRIORITY RETURN.OFF QUEUE DELAY.... OFF
COND DELAY.....OFF
PHASES 1 2 3 4 5 6 7 8
PR RTN% 0 0 0 0 0 0 0 0
PHASES 9 10 11 12 13 14 15 16
PR RTN% 0 0 0 0 0 0 0 0

```

```

PREEMPT PLAN [ 4]  ENABLE....YES
VEH/PED 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
OVERLAP A B C D E F G H I J K L M N O P
TRKCLR V . . . . .
TRKCLR O . . . . .
ENA TRL . . . . .
DWEL VEH X . . . . X . . . . .
DWEL PED . . . . .
DWEL OLPF1 .F1 . . . . .
CYC VEH . . . . .
CYC PED . . . . .
CYC OLP . . . . .
EXIT PH . X . . . X . . . . .
EXIT CAL . . . . .
SP FUNC . . . . .

```

```

ENABLE... YESIPMT OVRIDE..IINTERLOCK. NO
DET LOCK... XIDELAY.. 0IINHIBIT... 0
OVERIDE FL. .IDURATION 0ICLR-GRN... NO
TERM OLP. NOIPC>YEL NOITERM PH NO
PED DARK.. NOITC RESRV NOIDWELL FL OFF
LINK PMT....0IX FLCOLR REDIEEXIT OPT. OFF
X TMG PLN...0IRE-SERV.. 0IFLT TYPE.HARD
FREE DUR PMTIR1 NOIR2 NOIR3 NOIR4 NO
--TIMING----WALKIPED CLIMN GRI YELI RED
ENTRANCE TM. 255I 255I 1125.5125.5
-----MIN GRIEXT GRIMX GRI YELI RED
TRACK CLEAR 0I 0I 0I25.5125.5
-----MIN DLIPMTEXTIMX TMI YELI RED
DWL/CYC-EXIT 12I 2.0I 120I25.5125.5
PMT ACTIVE OUT..ON PMT ACT DWELL...NO
OTHER - PRI PMT.OFF NON-PRI PMT....OFF
INH EXT TIME... 0.0 PED PR RETURN...OFF
PRIORITY RETURN.OFF QUEUE DELAY.... OFF
COND DELAY.....OFF
PHASES 1 2 3 4 5 6 7 8
PR RTN% 0 0 0 0 0 0 0 0
PHASES 9 10 11 12 13 14 15 16
PR RTN% 0 0 0 0 0 0 0 0

```

```

PREEMPT PLAN [ 5]  ENABLE....YES
VEH/PED 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
OVERLAP A B C D E F G H I J K L M N O P
TRKCLR V . . . . .
TRKCLR O . . . . .
ENA TRL . . . . .
DWEL VEH . . . X . . X . . . . .
DWEL PED . . . . .
DWEL OLP .F1 .F1 . . . . .
CYC VEH . . . . .
CYC PED . . . . .
CYC OLP . . . . .
EXIT PH . X . . . X . . . . .
EXIT CAL . . . . .
SP FUNC . . . . .

```

```

ENABLE... YESIPMT OVRIDE..IINTERLOCK. NO
DET LOCK... XIDELAY.. 0IINHIBIT... 0
OVERIDE FL. .IDURATION 0ICLR-GRN... NO
TERM OLP. NOIPC>YEL NOITERM PH NO
PED DARK.. NOITC RESRV NOIDWELL FL OFF
LINK PMT....0IX FLCOLR REDIEEXIT OPT. OFF
X TMG PLN...0IRE-SERV.. 0IFLT TYPE.HARD
FREE DUR PMTIR1 NOIR2 NOIR3 NOIR4 NO
--TIMING----WALKIPED CLIMN GRI YELI RED
ENTRANCE TM. 255I 255I 1125.5125.5
-----MIN GRIEXT GRIMX GRI YELI RED
TRACK CLEAR 0I 0I 0I25.5125.5
-----MIN DLIPMTEXTIMX TMI YELI RED
DWL/CYC-EXIT 7I 2.0I 120I25.5125.5
PMT ACTIVE OUT..ON PMT ACT DWELL...NO
OTHER - PRI PMT.OFF NON-PRI PMT....OFF
INH EXT TIME... 0.0 PED PR RETURN...OFF
PRIORITY RETURN.OFF QUEUE DELAY.... OFF
COND DELAY.....OFF
PHASES 1 2 3 4 5 6 7 8
PR RTN% 0 0 0 0 0 0 0 0
PHASES 9 10 11 12 13 14 15 16
PR RTN% 0 0 0 0 0 0 0 0

```

```

PREEMPT PLAN [ 6]  ENABLE....YES
VEH/PED 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
OVERLAP A B C D E F G H I J K L M N O P
TRKCLR V . . . . .
TRKCLR O . . . . .
ENA TRL . . . . .
DWEL VEH . . X . . . . X . . . . .
DWEL PED . . . . .
DWEL OLP .F1 .F1 . . . . .
CYC VEH . . . . .
CYC PED . . . . .
CYC OLP . . . . .
EXIT PH . X . . . X . . . . .
EXIT CAL . . . . .
SP FUNC . . . . .

```

```

ENABLE... YESIPMT OVRIDE..IINTERLOCK. NO
DET LOCK... XIDELAY.. 0IINHIBIT... 0
OVERIDE FL. .IDURATION 0ICLR-GRN... NO
TERM OLP. NOIPC>YEL NOITERM PH NO
PED DARK.. NOITC RESRV NOIDWELL FL OFF
LINK PMT....0IX FLCOLR REDIEEXIT OPT. OFF
X TMG PLN...0IRE-SERV.. 0IFLT TYPE.HARD
FREE DUR PMTIR1 NOIR2 NOIR3 NOIR4 NO
--TIMING----WALKIPED CLIMN GRI YELI RED
ENTRANCE TM. 255I 255I 1125.5125.5
-----MIN GRIEXT GRIMX GRI YELI RED
TRACK CLEAR 0I 0I 0I25.5125.5
-----MIN DLIPMTEXTIMX TMI YELI RED
DWL/CYC-EXIT 7I 2.0I 120I25.5125.5
PMT ACTIVE OUT..ON PMT ACT DWELL...NO
OTHER - PRI PMT.OFF NON-PRI PMT....OFF
INH EXT TIME... 0.0 PED PR RETURN...OFF
PRIORITY RETURN.OFF QUEUE DELAY.... OFF
COND DELAY.....OFF
PHASES 1 2 3 4 5 6 7 8
PR RTN% 0 0 0 0 0 0 0 0
PHASES 9 10 11 12 13 14 15 16
PR RTN% 0 0 0 0 0 0 0 0

```

PROGRAM EXTEND TIME ON OPTICAL DETECTOR UNITS FOR 2.0 SEC.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 01-0217
DESIGNED: September 2018
SEALED: 09/21/2018
REVISED: N/A


PLANS PREPARED BY :



RUMMEL, KLEPPER & KAHL, LLP
900 RIDGEFIELD DRIVE SUITE 350
RALEIGH, NORTH CAROLINA 27609-3960
NC LICENSE NO. F-0112 • (919) 878-9560

ELECTRICAL AND PROGRAMMING DETAILS FOR:

Prepared for the Offices of:



750 N. Greenfield Pkwy, Garner, NC 27529

NC 344 (Halstead Boulevard) at SR 1101 (Peartree Road)

Division 1 Pasquotank County Elizabeth City


PLAN DATE: September 2018 REVIEWED BY: J O Deaton

PREPARED BY: M W Yalch REVIEWED BY:

REVISIONS	INIT.	DATE

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SEAL



DocuSigned by: James O. Deaton 9/21/2018

SIG. INVENTORY NO. 01-0217

9/21/2018 R:\Truff\cws\signal\signal\electrical\Detail\01-0217e-04-200.dgn dsccsr5