

(program controller as shown below)

1. FROM MAIN MENU PRESS '2' (PHASE CONTROL), THEN '1' (PHASE CONTROL FUNCTIONS). SCROLL TO THE BOTTOM OF THE MENU AND ENABLE ACT LOGIC COMMANDS 1, 2, 3, 4, 5 AND 6.

2. FROM MAIN MENU PRESS '6' (OUTPUTS), THEN '3' (LOGICAL I/O PROCESSOR).







OVERLAP PROGRAMMING DETAIL FOR DEFAULT PHASING

(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS), THEN '1' (VEHICLE OVERLAP SETTINGS).





OVERLAP PROGRAMMING COMPLETE

OVERLAP PROGRAMMING DETAIL FOR ALTERNATE PHASING


PROJECT REFERENCE NO.

R-3830

Sig. 5.2

(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS). THEN '1' (VEHICLE OVERLAP SETTINGS). PRESS 'NEXT' TO ADVANCE TO PAGE 2.



¦12345678910111213141516 VEH OVL PARENTS: X VEH OVL NOT VEH: VEH OVL NOT PED: : VEH OVL GRN EXT: : STARTUP COLOR: _ RED _ YELLOW _ GREEN FLASH COLORS: _ RED _ YELLOW _ GREEN SELECT VEHICLE OVERLAP OPTIONS: (Y/N) FLASH YELLOW IN CONTROLLER FLASH?...Y GREEN EXTENSION (0-255 SEC)..... YELLOW CLEAR (O=PARENT,3-25.5 SEC)...0.0 RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0 OUTPUT AS PHASE # (O=NONE, 1-16)....0

PAGE 2: VEHICLE OVERLAP 'C' SETTINGS

NOTICE

PAGE 2

PHASE:

OVERLAP PROGRAMMING COMPLETE

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 08-0236T1 DESIGNED: March 2022 SEALED: 4/19/2022 REVISED: N/A

