

OUTPUT CHANNEL CONFIGURATION

Front Panel
Main Menu >Controller >More>Channels>Channels Config

Web Interface
Home >Controller >Advanced IO>Channels>Channels Configuration

Channel Configuration

Channel	Control Type	Control Source	Flash Yellow	Flash Red	Flash Alt	MMU Channel
1	Overlap	1	X		X	1
2	Phase Vehicle	2	X			2
3	Phase Vehicle	3		X	X	3
4	Phase Vehicle	4		X		4
5	Phase Vehicle	5		X		5
6	Phase Vehicle	6	X		X	6
7	Overlap	7		X		7
8	Phase Vehicle	8		X	X	8
9	Overlap	1	X		X	9
10	Overlap	2		X	X	10
11	Overlap	3	X			11
12	Overlap	4		X		12
13	Phase Ped	2				13
14	Phase Ped	4				14
15	Phase Ped	6				15
16	Phase Ped	8				16
17	Overlap	5		X	X	17
18	Overlap	6		X		18

NOTE: Phase Vehicle 1
Changed to Overlap 1

NOTE: Phase Vehicle 7
Changed to Overlap 7

PED YELLOW CONFLICT MONITOR WIRING DETAIL

(make cabinet wiring changes as shown below)

In order to use FYA COMPACT mode the cabinet must be wired such that the (unused) Ped Yellow load switch outputs are wired to the conflict monitor as follows: From 2 PY (field term. 114) to Channel 9 Green (monitor pin 13).

Follow the instructions below to make the appropriate connections:


STEP 1: Fold down rear panel of output file.

STEP 2: Find unused wiring harness from conflict monitor card edge connector (which should be tied and bundled together).

STEP 3: Find the conductors that correspond to the following conflict monitor card edge pins and solder wire to the appropriate terminal on the rear of the output file as shown below:

CMU-13 _____ 2PY (term. 114)

NOTE: Some cabinet manufacturers use keyed connectors to accomplish this wiring configuration. If connectors are used, fold down the rear panel of the output file and find the set of 3 keyed connectors and connect them as shown below:



FYA SIGNAL OUTPUT REMAPPING ASSIGNMENT PROGRAMMING DETAIL FOR SIGNAL HEAD 11

Front Panel
Main Menu >Controller >More >Advanced IO >Output Points

Web Interface
Home >Controller >Advanced IO >Cabinet Configuration >Output Points

IO Module 1

Output Point	Description	Output Control Type	Index
33	C1-35	Phase Green	1
34	C1-36	Not Active	15
35	C1-37	Not Active	14
36	C1-38	Not Active	16

NOTICE OUTPUT POINT 33
CONTROL TYPE & INDEX
REASSIGNMENT

OVERLAP PROGRAMMING

Front Panel
Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface
Home >Controller >Overlap Configuration >Overlaps
Overlap Plan 1

Overlap	1	7
Type	FYA 4 - Section	FYA 4 - Section
Included Phases	2	4
Modifier Phases	1	-
Modifier Overlaps	-	-
Trail Green	0	0
Trail Yellow	0.0	0.0
Trail Red	0.0	0.0

This Plan Supersedes Electrical
Detail Sealed on 11/16/2023

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 11-1208T1
DESIGNED: February 2024
SEALED: 3/4/2024
REVISED: N/A

Electrical Detail - Sheet 2 of 2

<p>Prepared in the Offices of: 750 N. Greenfield Pkwy, Garner, NC 27529</p>	US 601 (S. State Street) at US 421 Southbound Ramp		
	Division 11 Yadkin County Yadkinville PLAN DATE: November 2023 REVIEWED BY: PREPARED BY: Zarrar Zafar REVIEWED BY:	DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED	
REVISIONS INIT. DATE	DecSigned by: <i>D. Todd Joyce</i> 03/06/2024 DATE		SIG. INVENTORY NO. 11-1208T1