## OVERLAP PROGRAMMING DETAIL FOR DEFAULT PHASING

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

Overlap Plan 1

Overlap	1	2	3	4
Туре	FYA 4 - Section			
Included Phases	2	4	6	8
Modifier Phases	1	3	5	
Modifier Overlaps	=	-	-	-
Trail Green	0	0	0	0
Trail Yellow	0.0	0.0	0.0	0.0
Trail Red	0.0	0.0	0.0	0.0

## MAXTIME OVERLAP PROGRAMMING DETAIL FOR ALTERNATE PHASING

Front Panel

Main Menu > Controller > Overlap > Overlap Parameters / Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

In the table view of the web interface, right click on "Overlap" in the top left corner of the table. Copy the entire contents of Overlap Plan 1. Paste Overlap Plan 1 into Overlap Plan 2. Modify Overlap Plan 2 as shown below and save changes.

Overlap Plan 2

Overlap	1	2	3	4	
Туре	FYA 4 - Section	NOTICE REMOVED			
Included Phases	<u>-</u>	4	<u>.</u>	8	INCLUDED PHASES
Modifier Phases	1	3	5	·	INOCODEDITIAGES
Modifier Overlaps	-	-	-	<u>-</u>	
Trail Green	0	0	0	0	
Trail Yellow	0.0	0.0	0.0	0.0	
Trail Red	0.0	0.0	0.0	0.0	

#### FLASHER CIRCUIT MODIFICATION DETAIL

IN ORDER TO INSURE THAT SIGNALS FLASH CONCURRENTLY ON THE SAME APPROACH, MAKE THE FOLLOWING FLASHER CIRCUIT CHANGES:

- 1. ON REAR OF PDA REMOVE WIRE FROM TERM. T2-4 AND TERMINATE ON T2-2.
- 2. ON REAR OF PDA REMOVE WIRE FROM TERM. T2-5 AND TERMINATE ON T2-3.
- 3. REMOVE FLASHER UNIT 2.

THE CHANGES LISTED ABOVE TIES ALL PHASES AND OVERLAPS TO FLASHER UNIT 1.

#### VEHICLE DETECTOR PROGRAMMING DETAIL FOR ALTERNATE PHASING LOOPS 1A & 5A

Front Panel

Main Menu >Controller >Detector >Veh Det Plans

Web Interface

Home >Controller >Detector Configuration >Vehicle Detectors

In the table view of web interface right click on "Detector" in the top left corner of the table. Copy the entire contents of Detector Plan 1. Paste Detector Plan 1 into Detector Plan 2. Modify Detector Plan 2 as shown below and save changes.

> 0.0 0.0

Plan 2

Detector | Call Phase | Delay

1A

Call Phase Delay 0.0 0.0

PROJECT REFERENCE NO. Sig.5.2

#### MAXTIME ALTERNATE PHASING PATTERN PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Coordination >Patterns

Web Interface

Home >Controller >Coordination >Patterns

Pattern Parameters

Veh Det Plan | Overlap Plan

\*The Pattern number(s) are to be determined by the Division and/or City Traffic Engineer.

# MAXTIME ALTERNATE PHASING ACTIVATION DETAIL

To run alternate phasing, select a Pattern that is programmed to run Overlap Plan 2 and Detector Plan 2. A Pattern can be selected through the scheduler or manually by changing the Operational Mode.

OVERLAP PLAN	VEH DET PLAN
1	1
2	2
	OVERLAP PLAN  1 2

#### ALTERNATE PHASING CHANGE SUMMARY

THE FOLLOWING IS A SUMMARY OF WHAT TAKES PLACE WHEN OVERLAP PLAN 2 AND VEHICLE DETECTOR PLAN 2 ACTIVATE TO CALL THE "ALTERNATE PHASING":

OVERLAP PLAN 2: Modifies overlap included phases for heads 11 and 51 to run protected

turns only.

VEH DET PLAN 2: Disables phase 6 call on loop 1A

and reduces delay time for phase 1 call on loop 1A to 0 seconds.

Disables phase 2 call on loop 5A and reduces delay time for phase 5 call on loop 5A to 0 seconds.

Electrical Detail - Sheet 2 of 2

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 09-0735 DESIGNED: May 2024 SEALED: 05-09-2024 REVISED: N/A

1 Glenwood Avenue Raleigh, NC 27603 Tel:919.789.9977 750 N. Greenfield Pkwy, Garner, NC 27529 Fax: 919.789.9591

Electrical and Programming Details For:

NC 8 (Winston Road) US 29 SB / US 64-70 WB Ramp

Davidson County Division 9 May 2024 REVIEWED BY:

PLAN DATE: PREPARED BY: J.T. Rowe REVIEWED BY: G.G. Murr, Jr

SIG. INVENTORY NO. 09-0735

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED