PROJECT REFERENCE NO.	SHEET NO.
I-0914BA	Sig. 3.4

FYA SIGNAL OUTPUT REMAPPING ASSIGNMENT PROGRAMMING DETAIL FOR LOADSWITCH S5 (SIGNAL HEAD 51)

(program controller as shown below)

FROM MAIN MENU PRESS '6' (OUTPUTS). THEN
'1' (OUTPUT ASSIGNMENTS).
WITH CURSOR IN "OUTPUT ASSIGNMENT#" POSITION. ENTER "30"

```
PAGE:1  C1 PIN:32  VEHICLE PHASE
OUTPUT ASSIGNMENT #................30
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID,1=FLASH).............0
SELECT ASSIGNMENT:
NOT ENABLED........................_
VEHICLE PHASE......................Y
PEDESTRIAN PHASE...................._
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................._
WATCHDOG............................_
DETECTOR RESET......................_
ADVANCE BEACON......................_
OUT OF PHASE FLASHER................_
CONTROLLER FLASH...................._
RUN FREE............................_
RESERVED............................_
PREEMPT............................._
SOFT PREEMPT........................_
ANY PREEMPT........................._
COORDINATION PLAN..................._
OFFSET.............................._
PHASE CHECK........................._
PHASE ON............................_
PHASE NEXT.........................._
```

THE OUTPUT IS SET AS A VEHICLE PHASE BY DEFAULT. THIS "Y" WILL REMAIN UNTIL THE OUTPUT IS CHANGED.

ENTER A "Y" FOR VEHICLE OVERLAP.

```
PAGE:1  C1 PIN:32  VEHICLE PHASE
SELECT VEHICLE OVERLAP (A=1,P=16)...3
SELECT COLOR(0=RED,1=YEL,2=GRN).....0
```

WHEN A 'Y' IS ENTERED FOR 'VEHICLE OVERLAP'
THE SCREEN SHOWN ABOVE WILL APPEAR.
ENTER DATA AS SHOWN.

PRESS THE 'ENT' KEY AFTER INPUTTING DATA.
THEN 'ESC'.

DISPLAY WILL NOW SHOW THE SPECIFIED OUTPUT
ASSIGNED AS 'VEHICLE OVERLAP' AS SHOWN BELOW.

```
PAGE:1  C1 PIN32  VEHICLE OVERLAP
OUTPUT ASSIGNMENT #................30
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID,1=FLASH).............0
SELECT ASSIGNMENT:
NOT ENABLED........................_
VEHICLE PHASE......................_
PEDESTRIAN PHASE...................._
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................._
WATCHDOG............................_
DETECTOR RESET......................_
ADVANCE BEACON......................_
OUT OF PHASE FLASHER................_
CONTROLLER FLASH...................._
RUN FREE............................_
RESERVED............................_
PREEMPT............................._
SOFT PREEMPT........................_
ANY PREEMPT........................._
COORDINATION PLAN..................._
OFFSET.............................._
PHASE CHECK........................._
PHASE ON............................_
PHASE NEXT.........................._
```

PRESS "+" KEY FOR OUTPUT 31

```
PAGE:1  C1 PIN:33  VEHICLE PHASE
OUTPUT ASSIGNMENT #................31
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID,1=FLASH).............0
SELECT ASSIGNMENT:
NOT ENABLED........................_
VEHICLE PHASE......................Y
PEDESTRIAN PHASE...................._
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................._
WATCHDOG............................_
DETECTOR RESET......................_
ADVANCE BEACON......................_
OUT OF PHASE FLASHER................_
CONTROLLER FLASH...................._
RUN FREE............................_
RESERVED............................_
PREEMPT............................._
SOFT PREEMPT........................_
ANY PREEMPT........................._
COORDINATION PLAN..................._
OFFSET.............................._
PHASE CHECK........................._
PHASE ON............................_
PHASE NEXT.........................._
```

THE OUTPUT IS SET AS A VEHICLE PHASE BY DEFAULT. THIS "Y" WILL REMAIN UNTIL THE OUTPUT IS CHANGED.

ENTER A "Y" FOR VEHICLE OVERLAP.

```
PAGE:1  C1 PIN:33  VEHICLE PHASE
SELECT VEHICLE OVERLAP (A=1,P=16)...3
SELECT COLOR(0=RED,1=YEL,2=GRN).....1
```

WHEN A 'Y' IS ENTERED FOR 'VEHICLE OVERLAP'
THE SCREEN SHOWN ABOVE WILL APPEAR.
ENTER DATA AS SHOWN.

PRESS THE 'ENT' KEY AFTER INPUTTING DATA.
THEN 'ESC'.

DISPLAY WILL NOW SHOW THE SPECIFIED OUTPUT
ASSIGNED AS 'VEHICLE OVERLAP' AS SHOWN BELOW.

```
PAGE:1  C1 PIN:33  VEHICLE OVERLAP
OUTPUT ASSIGNMENT #................31
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID,1=FLASH).............0
SELECT ASSIGNMENT:
NOT ENABLED........................_
VEHICLE PHASE......................_
PEDESTRIAN PHASE...................._
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................._
WATCHDOG............................_
DETECTOR RESET......................_
ADVANCE BEACON......................_
OUT OF PHASE FLASHER................_
CONTROLLER FLASH...................._
RUN FREE............................_
RESERVED............................_
PREEMPT............................._
SOFT PREEMPT........................_
ANY PREEMPT........................._
COORDINATION PLAN..................._
OFFSET.............................._
PHASE CHECK........................._
PHASE ON............................_
PHASE NEXT.........................._
```

PRESS "+" KEY FOR OUTPUT 32

```
PAGE:1  C1 PIN:34  VEHICLE PHASE
OUTPUT ASSIGNMENT #................32
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID,1=FLASH).............0
SELECT ASSIGNMENT:
NOT ENABLED........................_
VEHICLE PHASE......................Y
PEDESTRIAN PHASE...................._
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................._
WATCHDOG............................_
DETECTOR RESET......................_
ADVANCE BEACON......................_
OUT OF PHASE FLASHER................_
CONTROLLER FLASH...................._
RUN FREE............................_
RESERVED............................_
PREEMPT............................._
SOFT PREEMPT........................_
ANY PREEMPT........................._
COORDINATION PLAN..................._
OFFSET.............................._
PHASE CHECK........................._
PHASE ON............................_
PHASE NEXT.........................._
```

THE OUTPUT IS SET AS A VEHICLE PHASE BY DEFAULT. THIS "Y" WILL REMAIN UNTIL THE OUTPUT IS CHANGED.

ENTER A "Y" FOR VEHICLE OVERLAP.

```
PAGE:1  C1 PIN:34  VEHICLE PHASE
SELECT VEHICLE OVERLAP (A=1,P=16)...3
SELECT COLOR(0=RED,1=YEL,2=GRN).....2
```

WHEN A 'Y' IS ENTERED FOR 'VEHICLE OVERLAP'
THE SCREEN SHOWN ABOVE WILL APPEAR.
ENTER DATA AS SHOWN.

PRESS THE 'ENT' KEY AFTER INPUTTING DATA.
THEN 'ESC'.

DISPLAY WILL NOW SHOW THE SPECIFIED OUTPUT
ASSIGNED AS 'VEHICLE OVERLAP' AS SHOWN BELOW.

```
PAGE:1  C1 PIN:34  VEHICLE OVERLAP
OUTPUT ASSIGNMENT #................32
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID,1=FLASH).............0
SELECT ASSIGNMENT:
NOT ENABLED........................_
VEHICLE PHASE......................_
PEDESTRIAN PHASE...................._
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................._
WATCHDOG............................_
DETECTOR RESET......................_
ADVANCE BEACON......................_
OUT OF PHASE FLASHER................_
CONTROLLER FLASH...................._
RUN FREE............................_
RESERVED............................_
PREEMPT............................._
SOFT PREEMPT........................_
ANY PREEMPT........................._
COORDINATION PLAN..................._
OFFSET.............................._
PHASE CHECK........................._
PHASE ON............................_
PHASE NEXT.........................._
```

PRESS "+" TWICE TO
REACH OUTPUT 34.

```
PAGE:1  C1 PIN:36  NOT ENABLED
OUTPUT ASSIGNMENT #................34
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID,1=FLASH).............0
SELECT ASSIGNMENT:
NOT ENABLED........................Y
VEHICLE PHASE......................Y
PEDESTRIAN PHASE...................._
VEHICLE OVERLAP....................._
PEDESTRIAN OVERLAP.................._
WATCHDOG............................_
DETECTOR RESET......................_
ADVANCE BEACON......................_
OUT OF PHASE FLASHER................_
CONTROLLER FLASH...................._
RUN FREE............................_
RESERVED............................_
PREEMPT............................._
SOFT PREEMPT........................_
ANY PREEMPT........................._
COORDINATION PLAN..................._
OFFSET.............................._
PHASE CHECK........................._
PHASE ON............................_
PHASE NEXT.........................._
```

THE OUTPUT IS SET AS "NOT ENABLED" BY DEFAULT. THIS "Y" WILL REMAIN UNTIL THE OUTPUT IS CHANGED.

ENTER A "Y" FOR VEHICLE PHASE.

```
PAGE:1  C1 PIN:36  NOT ENABLED
SELECT VEHICLE PHASE (1-16).........5
SELECT COLOR(0=RED,1=YEL,2=GRN).....2
```

WHEN A 'Y' IS ENTERED FOR 'VEHICLE PHASE'
THE SCREEN SHOWN ABOVE WILL APPEAR.
ENTER DATA AS SHOWN.

PRESS THE 'ENT' KEY AFTER INPUTTING DATA.
THEN 'ESC'.

DISPLAY WILL NOW SHOW THE SPECIFIED OUTPUT
ASSIGNED AS 'VEHICLE PHASE' AS SHOWN BELOW.

```
PAGE:1  C1 PIN:36  VEHICLE PHASE
OUTPUT ASSIGNMENT #................34
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID,1=FLASH).............0
SELECT ASSIGNMENT:
NOT ENABLED........................_
VEHICLE PHASE......................Y
PEDESTRIAN PHASE...................._
VEHICLE OVERLAP....................._
PEDESTRIAN OVERLAP.................._
WATCHDOG............................_
DETECTOR RESET......................_
ADVANCE BEACON......................_
OUT OF PHASE FLASHER................_
CONTROLLER FLASH...................._
RUN FREE............................_
RESERVED............................_
PREEMPT............................._
SOFT PREEMPT........................_
ANY PREEMPT........................._
COORDINATION PLAN..................._
OFFSET.............................._
PHASE CHECK........................._
PHASE ON............................_
PHASE NEXT.........................._
```

OUTPUT PROGRAMMING FOR HEAD 51 COMPLETE

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 05-1265T2
DESIGNED: December 2014
SEALED: 1/15/2015
REVISED: N/A

Electrical Detail - Temporary Design 2 (TMP Phase 3) - Sheet 4 of 4

ELECTRICAL AND PROGRAMMING DETAILS FOR:

Prepared in the Offices of:
Transportation Mobility and Safety Division
STATE OF NORTH CAROLINA DEPARTMENT OF TRANSPORTATION
Signals Management Section
750 N.Greenfield Pkwy,Garner,NC 27529

US 158 Bypass
at
SR 1310 (Ross Mill Road) and
Prosperity Drive

Division 5 Vance County Henderson

PLAN DATE:	January 2015	REVIEWED BY:	DS JTR
PREPARED BY:	S. Armstrong	REVIEWED BY:	

REVISIONS	INIT.	DATE

SEAL
NORTH CAROLINA PROFESSIONAL SEAL 008453 ENGINEER JOHN T. ROWE, JR.

DocuSigned by:
John T. Rowe, Jr. 1/16/2015
641D60C145EE4F5...
DATE

SIG. INVENTORY NO. 05-1265T2

15-JAN-2015 08:24
S:\TRADSIGN\TIS\Signals\Workgroups\Sig Mon\Armstrong\051265_sm_ele_xxx.dgn
sarmstrong