PROJECT REFERENCE NO.	SHEET NO.
I-0914BA	Sig. 6.3

LOADSWITCH S7 TO OVERLAP "E"
OUTPUT REASSIGNMENT PROGRAMMING DETAIL

(program controller as shown below)

1. FROM MAIN MENU PRESS '6' (OUTPUTS), THEN '1' (OUTPUT (ASSIGNMENTS).
2. WITH CURSOR IN "OUTPUT ASSIGNMENT #" FIELD, USE + KEY TO FIND THE OUTPUT ASSIGNMENT NUMBER 22, AS SHOWN BELOW.
3. PROGRAM CONTROLLER AS SHOWN:

SCROLL DOWN TO VIEW ALL DATA

```
PAGE:1  C1 PIN:24  VEHICLE PHASE
OUTPUT ASSIGNMENT #................22
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID, 1=FLASH.............0
SELECT ASSIGNMENT:
NOT ENABLED........................
VEHICLE PHASE......................Y
PEDESTRIAN PHASE...................
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................
WATCHDOG...........................
DETECTOR RESET.....................
ADVANCE BEACON.....................
OUT OF PHASE FLASHER...............
CONTROLLER FLASH...................
RUN FREE...........................
RESERVED...........................
PREEMPT............................
SOFT PREEMPT.......................
ANY PREEMPT........................
COORDINATION PLAN..................
OFFSET.............................
PHASE CHECK........................
PHASE ON...........................
PHASE NEXT.........................
```

EXISTING DEFAULT ENTRY

```
PAGE:1  C1 PIN:24  VEHICLE PHASE
SELECT VEHICLE OVERLAP (A=1, P=16)...5
SELECT COLOR (0=RED,1=YEL,2=GRN).....0
```

WHEN A "Y" IS ENTERED FOR "VEHICLE OVERLAP" THE SCREEN SHOWN ABOVE WILL APPEAR. ENTER DATA AS SHOWN.

PRESS ENTER AFTER ENTERING DATA, THEN ESC.

DISPLAY WILL NOW SHOW THE SPECIFIED OUTPUT ASSIGNED AS "VEHICLE OVERLAP" AS SHOWN BELOW:

```
PAGE:1  C1 PIN:24   VEHICLE OVERLAP
OUTPUT ASSIGNMENT #................22
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID, 1=FLASH.............0
SELECT ASSIGNMENT:
NOT ENABLED........................
VEHICLE PHASE......................
PEDESTRIAN PHASE...................
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................
WATCHDOG...........................
DETECTOR RESET.....................
ADVANCE BEACON.....................
OUT OF PHASE FLASHER...............
CONTROLLER FLASH...................
RUN FREE...........................
RESERVED...........................
PREEMPT............................
SOFT PREEMPT.......................
ANY PREEMPT........................
COORDINATION PLAN..................
OFFSET.............................
PHASE CHECK........................
PHASE ON...........................
PHASE NEXT.........................
```

VEHICLE OVERLAP E (RED) LOADSWITCH S7

1. FROM MAIN MENU PRESS '6' (OUTPUTS), THEN '1' (OUTPUT (ASSIGNMENTS).
2. WITH CURSOR IN "OUTPUT ASSIGNMENT #" FIELD, USE + KEY TO FIND THE OUTPUT ASSIGNMENT NUMBER 24, AS SHOWN BELOW.
3. PROGRAM CONTROLLER AS SHOWN:

SCROLL DOWN TO VIEW ALL DATA

```
PAGE:1  C1 PIN:26  VEHICLE PHASE
OUTPUT ASSIGNMENT #................24
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID, 1=FLASH.............0
SELECT ASSIGNMENT:
NOT ENABLED........................
VEHICLE PHASE......................Y
PEDESTRIAN PHASE...................
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................
WATCHDOG...........................
DETECTOR RESET.....................
ADVANCE BEACON.....................
OUT OF PHASE FLASHER...............
CONTROLLER FLASH...................
RUN FREE...........................
RESERVED...........................
PREEMPT............................
SOFT PREEMPT.......................
ANY PREEMPT........................
COORDINATION PLAN..................
OFFSET.............................
PHASE CHECK........................
PHASE ON...........................
PHASE NEXT.........................
```

EXISTING DEFAULT ENTRY

```
PAGE:1  C1 PIN:26  VEHICLE PHASE
SELECT VEHICLE OVERLAP (A=1, P=16)...5
SELECT COLOR (0=RED,1=YEL,2=GRN).....2
```

WHEN A "Y" IS ENTERED FOR "VEHICLE OVERLAP" THE SCREEN SHOWN ABOVE WILL APPEAR. ENTER DATA AS SHOWN.

PRESS ENTER AFTER ENTERING DATA, THEN ESC.

DISPLAY WILL NOW SHOW THE SPECIFIED OUTPUT ASSIGNED AS "VEHICLE OVERLAP" AS SHOWN BELOW:

```
PAGE:1  C1 PIN:26  VEHICLE OVERLAP
OUTPUT ASSIGNMENT #................24
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID, 1=FLASH.............0
SELECT ASSIGNMENT:
NOT ENABLED........................
VEHICLE PHASE......................
PEDESTRIAN PHASE...................
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................
WATCHDOG...........................
DETECTOR RESET.....................
ADVANCE BEACON.....................
OUT OF PHASE FLASHER...............
CONTROLLER FLASH...................
RUN FREE...........................
RESERVED...........................
PREEMPT............................
SOFT PREEMPT.......................
ANY PREEMPT........................
COORDINATION PLAN..................
OFFSET.............................
PHASE CHECK........................
PHASE ON...........................
PHASE NEXT.........................
```

VEHICLE OVERLAP E (GREEN) LOADSWITCH S7

1. FROM MAIN MENU PRESS '6' (OUTPUTS), THEN '1' (OUTPUT (ASSIGNMENTS).
2. WITH CURSOR IN "OUTPUT ASSIGNMENT #" FIELD, USE + KEY TO FIND THE OUTPUT ASSIGNMENT NUMBER 23, AS SHOWN BELOW.
3. PROGRAM CONTROLLER AS SHOWN:

SCROLL DOWN TO VIEW ALL DATA

```
PAGE:1  C1 PIN:25  VEHICLE PHASE
OUTPUT ASSIGNMENT #................23
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID, 1=FLASH.............0
SELECT ASSIGNMENT:
NOT ENABLED........................
VEHICLE PHASE......................Y
PEDESTRIAN PHASE...................
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................
WATCHDOG...........................
DETECTOR RESET.....................
ADVANCE BEACON.....................
OUT OF PHASE FLASHER...............
CONTROLLER FLASH...................
RUN FREE...........................
RESERVED...........................
PREEMPT............................
SOFT PREEMPT.......................
ANY PREEMPT........................
COORDINATION PLAN..................
OFFSET.............................
PHASE CHECK........................
PHASE ON...........................
PHASE NEXT.........................
```

EXISTING DEFAULT ENTRY

```
PAGE:1  C1 PIN:25  VEHICLE PHASE
SELECT VEHICLE OVERLAP (A=1, P=16)...5
SELECT COLOR (0=RED,1=YEL,2=GRN).....1
```

WHEN A "Y" IS ENTERED FOR "VEHICLE OVERLAP" THE SCREEN SHOWN ABOVE WILL APPEAR. ENTER DATA AS SHOWN.

PRESS ENTER AFTER ENTERING DATA, THEN ESC.

DISPLAY WILL NOW SHOW THE SPECIFIED OUTPUT ASSIGNED AS "VEHICLE OVERLAP" AS SHOWN BELOW:

```
PAGE:1  C1 PIN25   VEHICLE OVERLAP
OUTPUT ASSIGNMENT #................23
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID, 1=FLASH.............0
SELECT ASSIGNMENT:
NOT ENABLED........................
VEHICLE PHASE......................
PEDESTRIAN PHASE...................
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................
WATCHDOG...........................
DETECTOR RESET.....................
ADVANCE BEACON.....................
OUT OF PHASE FLASHER...............
CONTROLLER FLASH...................
RUN FREE...........................
RESERVED...........................
PREEMPT............................
SOFT PREEMPT.......................
ANY PREEMPT........................
COORDINATION PLAN..................
OFFSET.............................
PHASE CHECK........................
PHASE ON...........................
PHASE NEXT.........................
```

VEHICLE OVERLAP E (YELLOW) LOADSWITCH S7

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 05-1919T2
DESIGNED: September 2014
SEALED: 1/15/2015
REVISED: N/A

Electrical Detail - Temporary Design 2 (TMP Phase 1A-Stages 1-2) - Sheet 3 of 4

ELECTRICAL AND PROGRAMMING DETAILS FOR:

Prepared in the Offices of:

Transportation Mobility and Safety Division
STATE OF NORTH CAROLINA DEPARTMENT OF TRANSPORTATION
Signals Management Section

750 N.Greenfield Pkwy,Garner,NC 27529

NC 39 (W. Andrews Ave.)
at
I-85 NB/US 158 EB Ramps and
Ramsey Street/Outlet City

Division 5 Vance County Henderson

PLAN DATE:	January 2015	REVIEWED BY:	DS GTR
PREPARED BY:	S. Armstrong	REVIEWED BY:	

REVISIONS	INIT.	DATE

SEAL

NORTH CAROLINA PROFESSIONAL SEAL 008453 ENGINEER JOHN T. ROWE, JR.

DocuSigned by: John T. Rowe, Jr. 1/16/2015
641D60C145EE4F5...
DATE

SIG. INVENTORY NO. 05-1919T2

15-JAN-2015 08:39
S:\TISSAL\ITS\Signals\Workgroups\Sig Mon\Armstrong\051919_sm.ele.xxx.dgn
sarmstrong