PROJECT REFERENCE NO.	SHEET NO.
U-3465	Sig. 2.3

FYA SIGNAL OUTPUT REMAPPING ASSIGNMENT PROGRAMMING DETAIL FOR SIGNAL HEAD 31

(program controller as shown below)

STEP 1

FROM MAIN MENU PRESS '6' (OUTPUTS). THEN
'1' (OUTPUT ASSIGNMENTS).
WITH CURSOR IN "OUTPUT ASSIGNMENT#" POSITION. ENTER "6"

```
PAGE:1  C1 PIN:7   VEHICLE PHASE
OUTPUT ASSIGNMENT #................6
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID.1=FLASH).............0
SELECT ASSIGNMENT:
NOT ENABLED........................_
VEHICLE PHASE......................Y
PEDESTRIAN PHASE...................._
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................._
WATCHDOG............................_
DETECTOR RESET......................_
ADVANCE BEACON......................_
OUT OF PHASE FLASHER................_
CONTROLLER FLASH...................._
RUN FREE............................_
RESERVED............................_
PREEMPT............................._
SOFT PREEMPT........................_
ANY PREEMPT........................._
COORDINATION PLAN..................._
OFFSET.............................._
PHASE CHECK........................._
PHASE ON............................_
PHASE NEXT.........................._
```

LOADSWITCH S3 RED

THE OUTPUT IS SET AS A VEHICLE PHASE BY DEFAULT. THIS "Y" WILL REMAIN UNTIL THE OUTPUT IS CHANGED.

ENTER A "Y" FOR VEHICLE OVERLAP.

```
PAGE:1  C1 PIN:7   VEHICLE PHASE
SELECT VEHICLE OVERLAP (A=1.P=16)...2
SELECT COLOR(0=RED.1=YEL.2=GRN).....0
```

WHEN A 'Y' IS ENTERED FOR 'VEHICLE OVERLAP'
THE SCREEN SHOWN ABOVE WILL APPEAR.
ENTER DATA AS SHOWN.

PRESS THE 'ENT' KEY AFTER INPUTTING DATA.
THEN 'ESC'.

DISPLAY WILL NOW SHOW THE SPECIFIED OUTPUT
ASSIGNED AS 'VEHICLE OVERLAP' AS SHOWN BELOW.

```
PAGE:1  C1 PIN7   VEHICLE OVERLAP
OUTPUT ASSIGNMENT #................6
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID.1=FLASH).............0
SELECT ASSIGNMENT:
NOT ENABLED........................_
VEHICLE PHASE......................_
PEDESTRIAN PHASE...................._
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................._
WATCHDOG............................_
DETECTOR RESET......................_
ADVANCE BEACON......................_
OUT OF PHASE FLASHER................_
CONTROLLER FLASH...................._
RUN FREE............................_
RESERVED............................_
PREEMPT............................._
SOFT PREEMPT........................_
ANY PREEMPT........................._
COORDINATION PLAN..................._
OFFSET.............................._
PHASE CHECK........................._
PHASE ON............................_
PHASE NEXT.........................._
```

PRESS "+" KEY FOR OUTPUT 7

STEP 2

```
PAGE:1  C1 PIN:8   VEHICLE PHASE
OUTPUT ASSIGNMENT #................7
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID.1=FLASH).............0
SELECT ASSIGNMENT:
NOT ENABLED........................_
VEHICLE PHASE......................Y
PEDESTRIAN PHASE...................._
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................._
WATCHDOG............................_
DETECTOR RESET......................_
ADVANCE BEACON......................_
OUT OF PHASE FLASHER................_
CONTROLLER FLASH...................._
RUN FREE............................_
RESERVED............................_
PREEMPT............................._
SOFT PREEMPT........................_
ANY PREEMPT........................._
COORDINATION PLAN..................._
OFFSET.............................._
PHASE CHECK........................._
PHASE ON............................_
PHASE NEXT.........................._
```

LOADSWITCH S3 YELLOW

THE OUTPUT IS SET AS A VEHICLE PHASE BY DEFAULT. THIS "Y" WILL REMAIN UNTIL THE OUTPUT IS CHANGED.

ENTER A "Y" FOR VEHICLE OVERLAP.

```
PAGE:1  C1 PIN:8   VEHICLE PHASE
SELECT VEHICLE OVERLAP (A=1.P=16)...2
SELECT COLOR(0=RED.1=YEL.2=GRN).....1
```

WHEN A 'Y' IS ENTERED FOR 'VEHICLE OVERLAP'
THE SCREEN SHOWN ABOVE WILL APPEAR.
ENTER DATA AS SHOWN.

PRESS THE 'ENT' KEY AFTER INPUTTING DATA.
THEN 'ESC'.

DISPLAY WILL NOW SHOW THE SPECIFIED OUTPUT
ASSIGNED AS 'VEHICLE OVERLAP' AS SHOWN BELOW.

```
PAGE:1  C1 PIN:8   VEHICLE OVERLAP
OUTPUT ASSIGNMENT #................7
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID.1=FLASH).............0
SELECT ASSIGNMENT:
NOT ENABLED........................_
VEHICLE PHASE......................_
PEDESTRIAN PHASE...................._
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................._
WATCHDOG............................_
DETECTOR RESET......................_
ADVANCE BEACON......................_
OUT OF PHASE FLASHER................_
CONTROLLER FLASH...................._
RUN FREE............................_
RESERVED............................_
PREEMPT............................._
SOFT PREEMPT........................_
ANY PREEMPT........................._
COORDINATION PLAN..................._
OFFSET.............................._
PHASE CHECK........................._
PHASE ON............................_
PHASE NEXT.........................._
```

PRESS "+" KEY FOR OUTPUT 8

STEP 3

```
PAGE:1  C1 PIN:9   VEHICLE PHASE
OUTPUT ASSIGNMENT #................8
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID.1=FLASH).............0
SELECT ASSIGNMENT:
NOT ENABLED........................_
VEHICLE PHASE......................Y
PEDESTRIAN PHASE...................._
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................._
WATCHDOG............................_
DETECTOR RESET......................_
ADVANCE BEACON......................_
OUT OF PHASE FLASHER................_
CONTROLLER FLASH...................._
RUN FREE............................_
RESERVED............................_
PREEMPT............................._
SOFT PREEMPT........................_
ANY PREEMPT........................._
COORDINATION PLAN..................._
OFFSET.............................._
PHASE CHECK........................._
PHASE ON............................_
PHASE NEXT.........................._
```

LOADSWITCH S3 GREEN

THE OUTPUT IS SET AS A VEHICLE PHASE BY DEFAULT. THIS "Y" WILL REMAIN UNTIL THE OUTPUT IS CHANGED.

ENTER A "Y" FOR VEHICLE OVERLAP.

```
PAGE:1  C1 PIN:9   VEHICLE PHASE
SELECT VEHICLE OVERLAP (A=1.P=16)...2
SELECT COLOR(0=RED.1=YEL.2=GRN).....2
```

WHEN A 'Y' IS ENTERED FOR 'VEHICLE OVERLAP'
THE SCREEN SHOWN ABOVE WILL APPEAR.
ENTER DATA AS SHOWN.

PRESS THE 'ENT' KEY AFTER INPUTTING DATA.
THEN 'ESC'.

DISPLAY WILL NOW SHOW THE SPECIFIED OUTPUT
ASSIGNED AS 'VEHICLE OVERLAP' AS SHOWN BELOW.

```
PAGE:1  C1 PIN:9   VEHICLE OVERLAP
OUTPUT ASSIGNMENT #................8
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID.1=FLASH).............0
SELECT ASSIGNMENT:
NOT ENABLED........................_
VEHICLE PHASE......................_
PEDESTRIAN PHASE...................._
VEHICLE OVERLAP....................Y
PEDESTRIAN OVERLAP.................._
WATCHDOG............................_
DETECTOR RESET......................_
ADVANCE BEACON......................_
OUT OF PHASE FLASHER................_
CONTROLLER FLASH...................._
RUN FREE............................_
RESERVED............................_
PREEMPT............................._
SOFT PREEMPT........................_
ANY PREEMPT........................._
COORDINATION PLAN..................._
OFFSET.............................._
PHASE CHECK........................._
PHASE ON............................_
PHASE NEXT.........................._
```

PRESS "+" UNTIL OUTPUT 35
IS REACHED.

STEP 4

```
PAGE:1  C1 PIN:37  NOT ENABLED
OUTPUT ASSIGNMENT #................35
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID.1=FLASH).............0
SELECT ASSIGNMENT:
NOT ENABLED........................Y
VEHICLE PHASE......................Y
PEDESTRIAN PHASE...................._
VEHICLE OVERLAP....................._
PEDESTRIAN OVERLAP.................._
WATCHDOG............................_
DETECTOR RESET......................_
ADVANCE BEACON......................_
OUT OF PHASE FLASHER................_
CONTROLLER FLASH...................._
RUN FREE............................_
RESERVED............................_
PREEMPT............................._
SOFT PREEMPT........................_
ANY PREEMPT........................._
COORDINATION PLAN..................._
OFFSET.............................._
PHASE CHECK........................._
PHASE ON............................_
PHASE NEXT.........................._
```

THE OUTPUT IS SET AS "NOT ENABLED" BY DEFAULT. THIS "Y" WILL REMAIN UNTIL THE OUTPUT IS CHANGED.

ENTER A "Y" FOR VEHICLE PHASE.

```
PAGE:1  C1 PIN:37  NOT ENABLED
SELECT VEHICLE PHASE (1-16).........3
SELECT COLOR(0=RED.1=YEL.2=GRN).....2
```

WHEN A 'Y' IS ENTERED FOR 'VEHICLE PHASE'
THE SCREEN SHOWN ABOVE WILL APPEAR.
ENTER DATA AS SHOWN.

PRESS THE 'ENT' KEY AFTER INPUTTING DATA.
THEN 'ESC'.

DISPLAY WILL NOW SHOW THE SPECIFIED OUTPUT
ASSIGNED AS 'VEHICLE PHASE' AS SHOWN BELOW.

```
PAGE:1  C1 PIN:37  VEHICLE PHASE
OUTPUT ASSIGNMENT #................35
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID.1=FLASH).............0
SELECT ASSIGNMENT:
NOT ENABLED........................_
VEHICLE PHASE......................Y
PEDESTRIAN PHASE...................._
VEHICLE OVERLAP....................._
PEDESTRIAN OVERLAP.................._
WATCHDOG............................_
DETECTOR RESET......................_
ADVANCE BEACON......................_
OUT OF PHASE FLASHER................_
CONTROLLER FLASH...................._
RUN FREE............................_
RESERVED............................_
PREEMPT............................._
SOFT PREEMPT........................_
ANY PREEMPT........................._
COORDINATION PLAN..................._
OFFSET.............................._
PHASE CHECK........................._
PHASE ON............................_
PHASE NEXT.........................._
```

OUTPUT PROGRAMMING FOR HEAD 31 COMPLETE

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-0642T1
DESIGNED: May 2014
SEALED: 6/20/2014
REVISED: N/A

Electrical Detail - Temporary Design 1 (Phase I - Step 2) - Sheet 3 of 5

ELECTRICAL AND PROGRAMMING DETAILS FOR:

SR 1121 (Ray Road)
at
SR 1120 (Overhills Road)

Division 6 Harnett County Spring Lake

PLAN DATE: June 2014 REVIEWED BY: JTR
PREPARED BY: S. Armstrong REVIEWED BY:

REVISIONS	INIT.	DATE

Prepared in the Offices of:
Transportation Mobility and Safety Division
STATE OF NORTH CAROLINA DEPARTMENT OF TRANSPORTATION
Signals Management Section
750 N.Greenfield Pkwy.Garner,NC 27529

SEAL
NORTH CAROLINA PROFESSIONAL SEAL 008453 ENGINEER JOHN T. ROWE, JR.
DocuSigned by: John T. Rowe, Jr. 6/26/2014
841D90C145EE4F5
DATE
SIG. INVENTORY NO. 06-0642T1

26-JUN-2014 05:47
S:\TIS\SIG\TIS Signals\Workgroups\Sig Man\Armstrong\060642_sm.ele.xxx.dgn
sarmstrong