



4. MAINTAIN PROPER CLEARANCE FROM ALL UTILITIES PER THE NATIONAL ELECTRICAL SAFETY CODE.

6. REFERENCE "WIRELESS RADIO ANTENNA TYPICAL DETAILS."

5. INSTALL WIRELESS SERIAL RADIO MODEM WITH EXTERIOR DISCONNECT SWITCH LOCATED ON CABINET.

(NOTE: RF ANTENNA DISCONNECT SWITCH AND DECAL ARE NOT REQUIRED WHEN THE ANTENNA IS INSTALLED ON AN NCDOT-OWNED POLE.)

INIT. DATE

Docusigned by:

Greyory A. Fuller 1/26/20

7032CAOAEE874FF... DATE

CADD Filename:

DIVISION 14 TRANSYLVANIA CO. — DocuSigned by: BREVARD

PLAN DATE: JANUARY 2015 REVIEWED BY: Net Avery

O.N. Greenfield Pkwy., Garner, NC 27529 PREPARED BY: B.A. STOUCHKO REVIEWED BY: 09F5DB4CBED3

REVISIONS