



NOTES

1. INSTALL A MINIMUM OF THREE (3) GROUNDING ELECTRODES SPACED A MINIMUM OF 10 FEET APART. ENSURE THAT EXISTING UNDERGROUND FACILITIES ARE NOT DAMAGED DURING INSTALLATION.
2. TEST GROUNDING SYSTEM USING AN APPROVED METHOD. SYSTEM SHOULD MEASURE TWENTY (20) OHMS OR LESS. ADDITIONAL GROUNDING ELECTRODES SHALL BE INSTALLED AS DIRECTED BY THE ENGINEER TO MEET THIS REQUIREMENT.
3. MECHANICALLY CRIMP ALL CONNECTIONS TO GROUND RODS USING AN IRREVERSIBLE COMPRESSION TOOL.
4. INSTALL MARKER TAPE DIRECTLY ABOVE ALL GROUNDING ELECTRODES AND CONDUCTORS AT A DEPTH OF 12 INCHES.
5. REMOVE BONDING JUMPER IN EQUIPMENT CABINET IF INSTALLED BETWEEN AC NEUTRAL AND EQUIPMENT GROUND.
6. BOND ALL RIGID GALVANIZED STEEL CONDUITS ENTERING THE CABINET TO "EQUIPMENT GROUND".
7. INSTALL CONDUIT BETWEEN DISCONNECT AND CABINET.
8. ENSURE EQUIPMENT GROUND IS ELECTRICALLY BONDED TO CABINET.

Prepared in the Offices of:		DYNAMIC MESSAGE SIGN WITH UNDERGROUND ELECTRICAL SERVICE TYPICAL DETAIL		SEAL	
		DIVISION 07 GUILFORD CO. GREENSBORO			
PLAN DATE: NOVEMBER 2017		REVIEWED BY: P.P. MARAK, PE		DATE: 11/14/2017	
PREPARED BY: G.A. GREEN		REVIEWED BY: M.A. ASLANI, PE		SIGNATURE	
SCALE		REVISIONS		INIT.	
0					
N/A					
750 N. Greenfield Pkwy., Garner, NC 27529				CADD Filename:	