
PLANTING DETAILS


SEEDLING / LINER BAREROOT PLANTING DETAIL

HEALING IN


2. Excavate a flat bottom trench
12 inches deep and provide drainage.




3. Backfill the trench with 2 inches well rotted sawdust. Place a 2 inch layer of well rotted sawdust at a sloping angle at one end of the trench.




Place a single layer of plants against the sloping end so that the root collar is at ground level.







6. Repeat layers of plants and sawdust as necessary and water thoroughly.


DIBBLE PLANTING METHOD USING THE KBC PLANTING BAR









3. Insert planting bar 2 inches toward planter from seedling.



4. Pull handle of bar toward planter, firming soil at bottom.



5. Push handle forward firming soil at top.



6. Leave compaction hole open. Water thoroughly.


PLANTING NOTES:

PLANTING BAG During planting, seedlings shall be kept in a moist canvas bag or similar container to prevent the root systems from drying.



KBC PLANTING BAR
Planting bar shall have a
blade with a triangular
cross section, and shall
be 12 inches long,
4 inches wide and 1 inch thick at center.

ROOT PRUNING All seedlings shall be root pruned, if necessary, so that no roots extend more than 10 inches below the root collar.



REFORESTATION

☐ TREE REFORESTATION SHALL BE PLANTED 6 FT. TO 10 FT. ON CENTER, RANDOM SPACING, AVERAGING 8 FT. ON CENTER, APPROXIMATELY 680 PLANTS PER ACRE.

REFORESTATION

MIXTURE, TYPE, SIZE, AND FURNISH SHALL CONFORM TO THE FOLLOWING:

25%	PLATANUS OCCIDENTALIS	SYCAMORE	12	in	100004444	18	in	BR
25%	LIRIODENDRON TULIPIFERA	TULIP POPLAR	12	in		18	in	BR
25%	PRUNUS SEROTINA	BLACK CHERRY	12	in	Minimin	18	in	BR
25%	CORNUS FLORIDA	DOGWOOD	12	in		18	in	BR

REFORESTATION DETAIL SHEET

N.C.D.O.T. - ROADSIDE ENVIRONMENTAL UNIT