



**PHASING**

- STEP 1: - USING ROADWAY STANDARD DRAWING NO. 1101.03, SHEET 2 OF 9, CLOSE AUSTIN ROAD (SR 1214) -L- TO TRAFFIC.
  - INSTALL DETOUR SIGNING.
- STEP 2: - REMOVE THE EXISTING STRUCTURE AND CONSTRUCT THE PROPOSED STRUCTURE AND ROADWAY UP TO AND INCLUDING THE FINAL LAYER OF SURFACE COURSE. SEE CONSTRUCTION PLANS.
  - PLACE THE FINAL PAVEMENT MARKINGS (PAINT) ON AUSTIN ROAD (SR 1214) -L-.
- STEP 3: - REMOVE ALL TRAFFIC CONTROL DEVICES AND DETOUR ROUTE SIGNING. REOPEN AUSTIN ROAD (SR 1214) -L- TO THE FINAL TRAFFIC PATTERN.

**NOTES**

- ALL DETOUR SIGNS ARE BLACK ON ORANGE
- ALL DETOUR SIGNS ARE APPROXIMATE
- SEE ROADWAY STANDARD DRAWING NO. 1101.03, SHEET 1 OF 9, FOR ADDITIONAL WORK ZONE SIGNS.

\* SEE SHEET TCP-3

APPROVED: DATE: 07/04

SEAL:

**OFF-SITE DETOUR PHASING**

SCALE: NONE		REVISIONS
DATE: 07/04		
DWG. BY: TAG		
DESIGN BY: TAG		
REVIEWED BY: JWG		

14-JAN-2005 15:02  
 \\ets-cctfso\vb3r00s\TCP\TC\_Tcp1.dgn  
 +germiller AT TETC21233