


EDI MODEL 2018ECLIP-NC CONFLICT MONITOR PROGRAMMING DETAIL
(remove jumpers and set switches as shown)


REMOVE DIODE JUMPERS 1-5, 1-6, 1-9, 1-11, 2-5, 2-6, 2-9, 2-11, 4-8, 4-10, 5-9, 5-11, 6-9, 6-11, 8-10 AND 9-11.



REMOVE JUMPERS AS SHOWN

NOTES:

1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
3. Ensure that Red Enable is active at all times during normal operation.
4. Integrate monitor with Ethernet network in cabinet.



NOTES

1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
2. Program phases 4 and 8 for Dual Entry.
3. Enable Simultaneous Gap-Out for all Phases.
4. Program phases 2 and 6 for Variable Initial and Gap Reduction.
5. Program phases 2 and 6 for Startup In Green.
6. Program phases 2 and 6 for Yellow Flash, and overlaps 1 and 2 as Wag Overlaps.
7. The cabinet and controller are part of the High Point Signal System.

EQUIPMENT INFORMATION


CONTROLLER.....2070
 CABINET.....332 W/ AUX
 SOFTWARE.....ECONOLITE OASIS
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S3*,S5,S7,S8,S11,
 AUX S1,AUX S2,AUX S4
 PHASES USED.....1,2,4,5,6,8
 OVERLAP "A".....1+2
 OVERLAP "B".....4
 OVERLAP "C".....5+6
 OVERLAP "D".....NONE
 * S3 Used for Special Event Flasher

SIGNAL HEAD HOOK-UP CHART

| LOAD SWITCH NO. | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 | S11 | S12 | AUX S1 | AUX S2 | AUX S3 | AUX S4 | AUX S5 | AUX S6 |
|-----------------------|-----|-------|-----------------|----|----------|-------|-----|-------|-------|-----|----------|-------|--------|--------|--------|--------|--------|--------|
| CMU CHANNEL NO. | 1 | 2 | 13 | 3 | 4 | 14 | 5 | 6 | 15 | 7 | 8 | 16 | 9 | 10 | 17 | 11 | 12 | 18 |
| PHASE | 1 | 2 | SPECIAL FLASHER | 3 | 4 | 4 PED | 5 | 6 | 6 PED | 7 | 8 | 8 PED | OLA | OLB | SPARE | OLC | OLD | SPARE |
| SIGNAL HEAD NO. | 11 | 21,22 | 101 | NU | 41,42,43 | NU | 51 | 61,62 | NU | NU | 82,83,84 | NU | 11 | 81 | NU | 51 | NU | NU |
| RED | | 128 | | | 101 | | | 134 | | | 107 | | | | | | | |
| YELLOW | * | 129 | | | 102 | | * | 135 | | | 108 | | | | | | | |
| GREEN | | 130 | | | 103 | | | 136 | | | 109 | | | | | | | |
| RED ARROW | | | | | | | | | | | | | A121 | A124 | | A114 | | |
| YELLOW ARROW | | | | | | | | | | | | | A122 | A125 | | A115 | | |
| FLASHING YELLOW ARROW | | | | | | | | | | | | | A123 | A126 | | A116 | | |
| GREEN ARROW | 127 | | | | | | 133 | | | | | | | | | | | |
| PED YELLOW | | | | ** | 114 | | | | | | | | | | | | | |

NU = Not Used
 * Denotes install load resistor. See load resistor installation detail this sheet.
 * See pictorial of head wiring in detail this sheet.
 ** S3-Y is used for the Special Events. See sheet 3 for wiring and programming detail.


FYA SIGNAL WIRING DETAIL
(wire signal heads as shown)



NOTE

The sequence display for signal heads 11 and 51 requires special logic programming. See sheet 2 for programming instructions.

INPUT FILE POSITION LAYOUT
(front view)




EX.: 1A, 2A, ETC. = LOOP NO.'S
 FS = FLASH SENSE
 ST = STOP TIME

SPECIAL DETECTOR NOTE

Install a multiple zone microwave detection system for all vehicle detection zones. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.

LOAD RESISTOR INSTALLATION DETAIL
(install resistors as shown below)

| ACCEPTABLE VALUES | |
|-------------------|-----------|
| VALUE (ohms) | WATTAGE |
| 1.5K - 1.9K | 25W (min) |
| 2.0K - 3.0K | 10W (min) |



FLASHER CIRCUIT MODIFICATION DETAIL

IN ORDER TO INSURE THAT SIGNALS FLASH CONCURRENTLY ON THE SAME APPROACH, MAKE THE FOLLOWING FLASHER CIRCUIT CHANGES:

1. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-4 AND TERMINATE ON T2-2.
2. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-5 AND TERMINATE ON T2-3.
3. REMOVE FLASHER UNIT 2.

THE CHANGES LISTED ABOVE TIES ALL PHASES AND OVERLAPS TO FLASHER UNIT 1.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 07-1470T3
 DESIGNED: May 2018
 SEALED: May 20, 2018
 REVISED: N/A

Project #: 170908



Temporary Design 3; TMP-32
 Electrical Detail - Sheet 1 of 3

| | | | |
|---|---|---|--|
| Prepared for: 750 N. Greenfield Pkwy, Corner, NC 27529 | NC 68 (Eastchester Dr.) at Cypress Ct. | | SEAL NOTH CAROLINA PROFESSIONAL ENGINEERS ROYAL HINGSHAW SEAL 032117 |
| | Division 7 PLAN DATE: May 2018 PREPARED BY: A. Ravipati | High Point REVIEWED BY: L. Boyer REVIEWED BY: | |