

NOTES

1. SNAP PARKING LOT MARKERS INTO PLACE AFTER ECORASTER OR EQUIVALENT HAS BEEN IN-FILLED WITH AGGREGATES.
2. REMOVE SOME AGGREGATE BY HAND (ONLY WHERE MARKERS NEED TO SNAP IN) IF PARKING LOT MARKERS ARE NOT FULLY SNAPPING INTO PLACE.
3. COORDINATE CONSTRUCTION TO COMPLY WITH LOCAL AND FEDERAL ADA STANDARDS.
4. ACCESSIBLE SIGN SHALL BE MOUNTED AT 7 FEET FROM GRADE TO BOTTOM EDGE OF SIGN FACE (R7-8e) (MUTCD).
5. REFER TO MANUAL ON UNIFORM TRAFFIC CONTROL DEVICES, (MUTCD) U.S. DEPARTMENT OF TRANSPORTATION AND NORTH CAROLINA DEPARTMENT OF TRANSPORTATION SUPPLEMENT.

