PROJ. REFERENCE NO. SHEET NO.

I - 5746C TMP - 6C

Kisinger Campo & Associates Corp
301 Fayetteville St., Suite 1500
Raleigh, NC 27601

PAVEMENT PRESERVATION

LOCATION: 17E SOUTHBOUND

STEP 1: USE TMP-55, TMP-56, TMP-15 FOR OFFSITE DETOUR 39 AND NCDOT RSD 1101.02 SHEET 8 OF 14 TO INSTALL SIGNS AND DEVICES TO CLOSE LANES L1 AND L2 OF I-277 SB DURING ALLOWABLE LANE CLOSURE TIMES. PLACE DETOUR SIGNING AND DEVICES ALONG W. 11TH ST., AND I-277 SB ENTRANCE RAMPS. THIS OPERATION WILL CLOSE RAMP #39. COVER SIGNS UNTIL OFFSITE DETOUR IS READY FOR OPERATION. PERFORM MILLING OF EXISTING ASPHALT WEARING SURFACE, EVALUATION AND REPLACEMENT OF CONCRETE PAVEMENT, AND RESURFACING WITH ASPHALT WEARING SURFACE AS REQUIRED IN ROADWAY PLANS. AT THE END OF EACH WORK PERIOD REOPEN THE ROADWAY TO TRAFFIC.

STEP 2: USE TMP-57, TMP-58, TMP-15 FOR OFFSITE DETOUR 39 AND NCDOT RSD 1101.02 SHEET 8 OF 14 TO INSTALL SIGNS AND DEVICES TO CLOSE LANES L2 AND L3 OF I-277 SB DURING ALLOWABLE LANE CLOSURE TIMES. PLACE DETOUR SIGNING AND DEVICES ALONG W. 11TH ST., AND I-277 SB ENTRANCE RAMPS. THIS OPERATION WILL CLOSE RAMP #39. COVER SIGNS UNTIL OFFSITE DETOUR IS READY FOR OPERATION. PERFORM MILLING OF EXISTING ASPHALT WEARING SURFACE, EVALUATION AND REPLACEMENT OF CONCRETE PAVEMENT, AND RESURFACING WITH ASPHALT WEARING SURFACE AS REQUIRED IN ROADWAY PLANS. AT THE END OF EACH WORK PERIOD REOPEN THE ROADWAY TO TRAFFIC.


STEP 3: REPEAT STEPS 1 AND 2 UNTIL ALL WORK IS COMPLETE.


LOCATION: 18E SOUTHBOUND

STEP 1: USE TMP-59, TMP-60, TMP-14 FOR OFFSITE DETOUR 38 AND NCDOT RSD 1101.02 SHEET 8 OF 14 TO INSTALL SIGNS AND DEVICES TO CLOSE LANES L1 AND L2 OF I-277 SB DURING ALLOWABLE LANE CLOSURE TIMES. PLACE DETOUR SIGNING AND DEVICES ALONG W. 11TH ST., N. DAVIDSON ST., N. BREVARD ST., E 12TH ST. AND I-277 SB ENTRANCE RAMPS. THIS OPERATION WILL CLOSE RAMP #38. COVER SIGNS UNTIL OFFSITE DETOUR IS READY FOR OPERATION. PERFORM MILLING OF EXISTING ASPHALT WEARING SURFACE, EVALUATION AND REPLACEMENT OF CONCRETE PAVEMENT, AND RESURFACING WITH ASPHALT WEARING SURFACE AS REQUIRED IN ROADWAY PLANS. AT THE END OF EACH WORK PERIOD REOPEN THE ROADWAY TO TRAFFIC.

STEP 2: USE TMP-61, TMP-62, TMP-14 FOR OFFSITE DETOUR 38 AND NCDOT RSD 1101.02 SHEET 8 OF 14 TO INSTALL SIGNS AND DEVICES TO CLOSE LANES L2 AND L3 OF I-277 SB DURING ALLOWABLE LANE CLOSURE TIMES. PLACE DETOUR SIGNING AND DEVICES ALONG W. 11TH ST., N. DAVIDSON ST., N. BREVARD ST., E 12TH ST. AND I-277 SB ENTRANCE RAMPS. THIS OPERATION WILL CLOSE RAMP #38. COVER SIGNS UNTIL OFFSITE DETOUR IS READY FOR OPERATION. PERFORM MILLING OF EXISTING ASPHALT WEARING SURFACE, EVALUATION AND REPLACEMENT OF CONCRETE PAVEMENT, AND RESURFACING WITH ASPHALT WEARING SURFACE AS REQUIRED IN ROADWAY PLANS. AT THE END OF EACH WORK PERIOD REOPEN THE ROADWAY TO TRAFFIC.

STEP 3: REPEAT STEPS 1 AND 2 UNTIL ALL WORK IS COMPLETE.





UNLESS ALL SIGNATURES COMPLETED



PHASING NOTES
(3 OF 3)