



TO-CENTER TYPICAL SPACING. 4. INSTALL A CONCRETE LANDING PAD MEASURING A MINIMUM 4 INCHES DEEP, 24 INCHES WIDE, AND 36 INCHES LONG DIRECTLY

BENEATH THE LADDER. 5. USE ACTUAL DIMENSIONS AND WEIGHT OF THE DMS TO COMPLETE

- THE DESIGN OF THE DMS STRUCTURE. 6. FIELD VERIFY ALL FOOTING ELEVATIONS AND GROUND SLOPES AT THE FOOTING USING THE LATEST NCDOT STANDARD SPECIFICATIONS FOR
- 7. ENSURE THAT THE TOP OF THE FOOTING EXTENDS AT LEAST 6 INCHES AND NOT MORE THAN 24 INCHES ABOVE THE HIGHEST POINT OF THE GROUND SURFACE AT THE FOOTING.
- 8. VERIFY ALL UNDERGROUND UTILITY LOCATIONS BEFORE BEGINNING ANY UNDERGROUND WORK. DO NOT DAMAGE ANY EXISTING UTILITIES OR NCDOT CABLES DURING CONSTRUCTION.
- 9. DESIGN THE STRUCTURE AND DMS ENCLOSURE TO WITHSTAND WIND VELOCITIES OF 90 MPH.
- 10. SEE ROADWAY PLANS FOR GUARDRAIL DETAILS.

ROADS AND STRUCTURES.

NOTES





N/A

ELEVATION DETAIL

DIVISION 09 FORSYTH CO. WINSTON-SALEM PLAN DATE: AUGUST 2021 REVIEWED BY: A. SKUCE

750 N. Greenfield Pkwy., Garner, NC 27529 PREPARED BY: B. CHRISTIAN REVIEWED BY: REVISIONS INIT. DATE

ENGINEER andrew J. Skue DATE

050152