## PHASE I

NOTE: BEFORE BEGINNING CONSTRUCTION THE CONTRACTOR SHALL:

- PLACE WORK ZONE ADVANCE WARNING SIGNS ALONG US 23 BUS (-L1-/-L2-), WALNUT ST. (-Y4-), MAPLE ST. (-Y1-), E/W MARSHALL ST. (-Y2-), VANCE ST. (-Y3-/-Y5-), BRIDGES ST. (-Y6-) AND ALL -Y- LINES USING ROADWAY STANDARD DRAWING (RSD) 1101.01.
- INSTALL ONE (1) CHANGEABLE MESSAGE SIGNS (CMS) IN EACH DIRECTION OF US 23 BUS (-L1-/-L2-) AND WALNUT ST. AS DIRECTED BY THE ENGINEER. THESE CHANGEABLE MESSAGES SIGNS ARE TO BE UTILIZED TO INFORM & ALERT THE TRAVELLING PUBLIC TO TRAFFIC CONDITIONS AND MAY BE UTILIZED FOR TRAFFIC CONTROL OPERATIONS DURING CONSTRUCTION AS DIRECTED BY THE ENGINEER.

NOTE: THE CONTRACTOR SHALL COMPLETE PHASE I, STEPS 1 AND 2 IN A CONTINUOUS MANNER.

- STEP 1A) INSTALL ALL VANCE STREET, WALNUT STREET, US 23 BUSINESS FROM WALNUT STREET OFFSITE DETOUR SIGNING, US 23 BUSINESS TRUCK DETOUR SIGNING, ROAD CLOSURE SIGNING, DEVICES, AND DETOUR -Y4-, -Y5-, -Y6-, AND TRUCKS ON US 23 BUSINESS.

  [REFER TO SHEETS TMP-02A, 02B1, 04, 05, & 07]
- STEP 1B) USING RSD 1101.02, INSTALL TEMPORARY PAVEMENT MARKINGS, WATER-FILLED BARRIER, AND PEDESTRIAN CHANNELIZING FENCING ALONG -L1-/-L2-. DEACTIVATE AND REMOVE EXISTING SIGNAL. [REFER TO SHEETS TMP-04 THRU 06, & 21]
- STEP 1C) USING RSD 1101.02 AS NEEDED, INSTALL ALL PEDESTRIAN DETOUR SIGNING, PEDESTRIAN BARRICADES, TEMPORARY CROSSWALKS, AND DETOUR PEDESTRIANS.

[REFER TO SHEETS TMP-02, 04 THRU 06, & 21]

- STEP 2) USING RSD 1101.02, CONSTRUCT THE FOLLOWING UP TO BUT NOT INCLUDING THE FINAL LIFT OF SURFACE COURSE, INCLUDING CLEARING/GRUBBING, PROPOSED DRAINAGE, CURB AND GUTTER, UTILITIES, ETC. AT THE FOLLOWING LOCATIONS
  - [REFER TO SHEETS TMP-04 THRU 07, & 21]:
     -L1- FROM STA. 14+18 TO -RAB-
  - -L2- FROM -RAB- TO STA. 17+22
  - -RAB-
  - - Y3-
  - -Y4- AND PROPOSED CULVERT
  - -Y5- FROM STA. 13+50 TO -RAB-
  - -Y6-

NOTE: MAINTAIN ACCESS TO PARCEL 21 THROUGH PARCEL 11 AS NEEDED, AS DIRECTED BY THE ENGINEER.

USING RSD 1101.02, CONSTRUCT -L2- 'LEFT' FROM STA. 17+22 TO END CONSTRUCTION LIMITS AND -L2- 'RIGHT' FROM STA. 17+22 TO THE BEGIN RESURFACING LIMITS, INCLUDING CLEARING/GRUBBING, PROPOSED DRAINAGE, CURB AND GUTTER, UTILITIES, ETC. [REFER TO SHEET TMP-06]

STEP 2A) UPON COMPLETION OF WING WALL #3 ON THE -Y4- CULVERT, CLOSE VANCE ST. AS SHOWN ON SHEET TMP-07, INSTALL THE TEMPORARY RESIDENTIAL ACCESS AS SHOWN ON SHEET TMP-05, AND CONSTRUCT -Y5- FROM THE BEGIN PROJECT LIMITS TO STA. 13+50 +/- -Y5- UP TO BUT NOT INCLUDING THE FINAL LIFT OF SURFACE COURSE.

NOTE: MAINTAIN ACCESS TO DRIVEWAYS ON -Y3- AND -Y5- DURING CONSTRUCTION.

NOTE: PHASE I, STEPS 3 & 4 MAY BE CONSTRUCTED SIMULTANEOUSLY WITH PHASE I, STEPS 2 & 2A.

THE CONTRACTOR SHALL SHALL WORK IN A CONTINUOUS MANNER TO COMPLETE THE WORK IN PHASE I, STEPS 3 AND 4 FROM 6:00 P.M. FRIDAY TO 7:00 A.M. MONDAY. REPEAT WEEKEND WORK AS DIRECTED BY THE ENGINEER TO COMPLETE PHASE I, STEPS 3 AND 4 (SEE INTERMEDIATE CONTRACT TIME AND LIQUIDATED DAMAGES).

- STEP 3) INSTALL OFFSITE DETOUR SIGNING, DETOUR -L1-/-L2- TRAFFIC OFFSITE, AND CLOSE -L1-/-L2- WITH BARRICADES. INSTALL TEMPORARY CROSSWALK, PEDESTRIAN DETOUR SIGNING, PEDESTRIAN BARRICADES, AND DETOUR PEDESTRIANS TO -L2- 'LEFT'. INSTALL THE 42" CROSS PIPE LOCATED AT STA. 22+15 +/- -L2- AND ALL DRAINAGE UPSTREAM FROM THE CROSS PIPE. REPLACE THE CURB, GUTTER, AND SIDEWALK REMOVED TO INSTALL THE DRAINAGE. RETURN PEDESTRIANS BACK TO THE DETOUR ON -L2- 'RIGHT', REMOVE THE TEMPORARY CROSSWALK, OPEN -L1-/-L2- TO TRAFFIC, AND COVER THE DETOUR SIGNS INSTALLED AT THE BEGINNING OF STEP 3. THE SIDEWALK AND CURB AND GUTTER SHALL BE REPLACED BY THE END OF EACH WEEKEND WORK PERIOD. [REFER TO SHEETS TMP-02B & 08]
- STEP 4) UNCOVER THE DETOUR SIGNING INSTALLED IN STEP 3, CLOSE
  -L1-/-L2-, AND DETOUR -L1-/-L2- TRAFFIC OFFSITE. REMOVE THE
  PEDESTRIAN BARRICADES INSTALLED IN STEP 2 AND SHIFT
  PEDESTRIANS ONTO -L2- 'RIGHT'. REMOVE THE WATER-FILLED BARRIER,
  PEDESTRIAN CHANNELIZING FENCING, AND INSTALL THE 15" CROSS PIPE
  LOCATED AT STA. 18+90 +/- -L2-. OPEN -L1-/-L2- TO TRAFFIC,
  AND REMOVE THE OFFSITE DETOUR SIGNING INSTALLED IN STEP 3.
  [REFER TO SHEET TMP-02B & 09]

## PHASE II

NOTE: PHASE II, STEPS 1 & 2 SHALL BE CONSTRUCTED IN A CONTINUOUS MANNER.

STEP 1A) SHIFT 'ROAD CLOSED' BARRICADES ON -Y4- BEHIND -Y3- AND SHIFT -Y3- TRAFFIC ONTO -Y3-. CONSTRUCT REMAINING SECTION OF -Y4- SIDEWALK. REMOVE PEDESTRIAN BARRICADES FROM THIS SECTION OF SIDEWALK AFTER THE WORK IS COMPLETED.

[REFER TO SHEETS TMP-05 & 11]

REMOVE THE TRUCK DETOUR INSTALLED IN PHASE I.
[REFER TO SHEET TMP-OB1 FOR REMOVAL OF OFFSITE DETOUR SIGNING]

- STEP 1B) INSTALL OFFSITE DETOUR SIGNING AND ROAD CLOSURE SIGNING FOR BOTH US 23 BUSINESS AND MARSHALL ST. AND COVER. INSTALL TYPE III BARRICADES ON THE -L1- LEG OF -RAB-[REFER TO SHEET TMP-02C]
- STEP 1C) AWAY FROM TRAFFIC INSTALL TEMPORARY MARKINGS AND MARKERS ON THE FOLLOWING [REFER TO SHEETS TMP-11, 12, & 22]:
  - - L2- FROM RAB- TO STA. 17+22
  - - RAB-
  - - Y4 -- - Y5 -
- STEP 2) USING RSD 1101.02 AS NEEDED, COMPLETE THE FOLLOWING IN THIS ORDER [REFER TO SHEETS TMP-10 THRU 12, & 22]:
  - WEDGE -L2- EXCEPT FOR THE TIE-IN TO -DR1- UP TO BUT NOT INCLUDING THE FINAL LIFT OF SURFACE COURSE, INCLUDING TEMPORARY PAVEMENT MARKINGS AND MARKERS, (TIE WEDGING INTO EXISTING -DR1-)
  - OPEN -RAB-, -Y4-, -Y5-, AND -Y6- TO THE FINAL TRAFFIC PATTERN
  - UNCOVER DETOUR SIGNING, DETOUR -L1-/-L2- AND -Y2- TRAFFIC OFFSITE, AND CLOSE -L1-, -Y1-, -Y2-, AND -DR1-
  - CONSTRUCT DRAINAGE BOXES 0520 AND 0521 AND THE PIPE IN BETWEEN (COVER 0520 WITH STEEL PLATING)
  - COMPLETE THE WEDGING AT THE -L2-/-DR1- TIE-IN
  - INSTALL ALL PHASE II PEDESTRIAN SIGNING AND DEVICES, REMOVE THE PHASE I PEDESTRIAN SIGNING AND DEVICES, AND SHIFT PEDESTRIANS INTO THE PHASE II PATTERN

NOTE: MAINTAIN ACCESS TO ALL PARCELS DURING CONSTRUCTION, AS APPROVED BY THE ENGINEER.

- STEP 3) AWAY FROM TRAFFIC, CONSTRUCT THE FOLLOWING UP TO BUT NOT INCLUDING THE FINAL LIFT OF SURFACE COURSE, INCLUDING CLEARING/GRUBBING, PROPOSED DRAINAGE, CURB AND GUTTER, UTILITIES, ETC. [REFER TO SHEETS TMP-10, 11, & 22]:
  - -L1- FROM BEGIN PROJECT LIMITS TO STA. 14+18
  - - Y1 -- - Y2 -

## 1223 Jones Franklin Rd. Raleigh, N.C. 27606 License No. F-0377 Bus: 919 851 8077 Fax: 919 851 8107 TRANSPORTATION PLANNING/DESIGN - BRIDGE/STRUCTURE DESIGN CIVIL/SITE DESIGN - GIS/GPS - CONSTRUCTION OBSERVATION

## PHASE III


THE CONTRACTOR SHALL WORK IN A CONTINUOUS MANNER TO COMPLETE THE WORK IN PHASE III, STEPS 1 THRU 3 FROM 6:00 P.M. FRIDAY TO 7:00 A.M. MONDAY. REPEAT WEEKEND WORK AS DIRECTED BY THE ENGINEER TO COMPLETE PHASE III, STEPS 1 THRU 3 (SEE INTERMEDIATE CONTRACT TIME AND LIQUIDATED DAMAGES).

- STEP 1) INSTALL TYPE III BARRICADES ON -DR1-, REMOVE ENOUGH OF THE BARRICADES TO ALLOW PARCEL #3 ACCESS TO MARSHALL ST., ADJUST THE TYPE III BARRICADES ON MARSHALL ST. TO THE -Y2- END CONSTRUCTION LIMITS, AND ADJUST THE TYPE III BARRICADES ON -L1-TO THE BEGIN CONSTRUCTION LIMITS. THEN AWAY FROM TRAFFIC, INSTALL THE FINAL LIFT OF SURFACE COURSE, FINAL PAVEMENT MARKINGS, AND MARKERS ON -L1-, -Y1-, -Y2-, AND THE LOWER HALF OF -DR1-. RETURN ALL OF THE BARRICADES TO THE PHASE II LOCATIONS BY THE END OF THE WORK PERIOD. [REFER TO SHEETS TMP-10, 14, 15, AND THE FINAL PAVEMENT MARKING PLAN]
- STEP 2) USING RSD 1101.02 AND SHEETS TMP-17 & 18, COMPLETE THE FOLLOWING IN THIS ORDER [REFER TO SHEETS TMP-02A, 16, 17, AND THE FINAL PAVEMENT MARKING PLAN]:
  - UNCOVER THE VANCE STREET OFFSITE DETOUR SIGNING AND DETOUR -Y5- TRAFFIC OFFSITE
  - INSTALL TYPE III BARRICADES AT -RAB-/-Y5- AND AT -Y5-/-Y6-- INSTALL TYPE III BARRICADES ON -DR1- AND -L1- AT -Y2-,
  - INSTALL DRUMS AT THE -Y2-/-DR1- INTERSECTION, AND REMOVE THE TYPE III BARRICADES AT THE -Y2- BEGIN PROJECT LIMITS
  - INSTALL THE CMS DEVICES AND ADJUST THE PEDESTRIAN SIGNING AND BARRICADES
  - INSTALL THE THREE (3) MONOLITHIC CONCRETE ISLANDS AT -L2-/-DR1-
  - INSTALL THE FINAL LIFT OF SURFACE COURSE, FINAL PAVEMENT MARKINGS, AND MARKERS ON -L2- 'RIGHT', -RAB- 'RIGHT', -Y4- 'RIGHT', AND THE UPPER HALF OF -DR1-.
  - RETURN TRAFFIC AND PEDESTRIANS TO THE PHASE II TRAFFIC PATTERN ADJUSTING/REMOVING THE SIGNING/DEVICES IN THE REVERSE ORDER
- STEP 3) USING THE SAME PROCEDURE IN PHASE III STEP 2 INSTALL THE FINAL LIFT OF SURFACE COURSE, FINAL PAVEMENT MARKINGS, AND MARKERS ON THE FOLLOWING [REFER TO SHEETS TMP-02A, 19, & 20]
  - USING RSD 1101.02 AND SHEETS TMP-19 & 20: -L2- 'LEFT', -RAB- 'LEFT' AND -Y4- 'LEFT'
  - UNDER TRAFFIC AND USING DRUMS AS NEEDED: -Y3-, -Y5- FROM BEGIN CONSTRUCTION LIMITS TO -Y6-, AND -Y6-
  - AWAY FROM TRAFFIC: -Y5- FROM -Y6- TO -RAB-
- STEP 4) AT THE END OF PHASE III, STEP 3, REMOVE ALL TRAFFIC MANAGEMENT DEVICES AND DETOUR SIGNING, AND OPEN THE ENTIRE PROJECT TO THE FINAL TRAFFIC PATTERN.

[REFER TO SHEETS TMP-16, 19, & 20 FOR REMOVAL OF TRAFFIC MANAGEMENT DEVICES AND ON-SITE DETOUR SIGNING]
[REFER TO SHEETS TMP-02, 02A, & 02C FOR REMOVAL OF TRAFFI

[REFER TO SHEETS TMP-02, 02A, & 02C FOR REMOVAL OF TRAFFIC MANAGEMENT DEVICES, ROAD CLOSURE SIGNING, AND OFFSITE DETOUR SIGNING]

[REFER TO RSD 1101.01 FOR REMOVAL OF ALL ADVANCE WARNING SIGNING]



PHASING