

PROJECT REFERENCE NO.	SHEET NO.
A-0009CB	EC-08A/CONST.24
RW SHEET NO.	
ROADWAY DESIGN ENGINEER	HYDRAULICS ENGINEER

CULVERT CONSTRUCTION SEQUENCE STA. 275+68 -L-

1. INSTALL IMPERVIOUS DIKES #1 & #2 AND BEGIN PUMP AROUND OPERATION.
2. DEWATER WORK SITE AS NEEDED INTO SPECIAL STILLING BASIN(S).
3. REMOVE EXISTING 24" CMP.
4. CONSTRUCT 64"x43" CAA PIPE-ARCH.
5. STOP PUMP AROUND OPERATION.
6. REMOVE IMPERVIOUS DIKES #1 & #2 AND REESTABLISH STREAM.

