



TRENT BRANCH CULVERT CONSTRUCTION SEQUENCE 1 of 1 -RPC- STA 24 + 63.79

PHASE I

1. INSTALL STILLING BASIN (VOLUME \geq 140 CY) AT UPSTREAM SIDE OF EXISTING RCBC.
2. INSTALL IMPERVIOUS DIKES 1 AND 2 AND AND 24" TEMPORARY PIPE.
3. CONSTRUCT UPSTREAM CULVERT AND UPSTREAM CHANNEL WORK.
4. REMOVE IMPERVIOUS DIKES 1 AND 2, TEMPORARY PIPE, AND STILLING BASIN.

REVISIONS

8/17/99

I:\9\2024
 R:\Environment\Design\AAAAB_PSH\1-25\13AAAB-4C_PSH_10A.dgn
 samuelstata