

www.exultengineering.com

5. REMOVE AND DISPOSE OF EXISTING JUNCTION BOXES AND FIBER OPTIC CABLE. CUT CONDUITS AT 30" BELOW GRADE AND ABANDON. FILL

VOIDS AFTER REMOVALS WITH APPROVED MATERIALS.