

PROJECT REFERENCE NO.	SHEET NO.
NC-9	EC-08A/CONST.08
R/W SHEET NO.	

- 1.) UTILIZE SPECIAL STILLING BASIN(S) AS NEEDED THROUGHOUT PIPE INSTALLATION.
- 2.) INSTALL DEWATERING PUMPS, TEMPORARY FLEXIBLE HOSE, AND SPECIAL STILLING BASIN(S), SEE EXAMPLE PUMP-AROUND OPERATION ON EC-2B.
- 3.) INSTALL IMPERVIOUS DIKES #1, #2, AND #3 AND BEGIN PUMPING OPERATIONS FOR STREAM DIVERSION.
- 4.) DEWATER CONSTRUCTION AREA, UTILIZING SPECIAL STILLING BASIN(S) FOR PUMPED EFFLUENT.
- 5.) REMOVE EXISTING 24" CMP.
- 6.) TRENCHLESS INSTALL 66" WSP AND 54" WSP. CONSTRUCT ASSOCIATED HEADWALLS.
- 7.) CONSTRUCT DROP STRUCTURES AND STD. 8' BASE DITCH W/CL '11' RIP RAP.
- 8.) EXCAVATE ANY ACCUMULATED SILT AND DEWATER BEFORE REMOVAL OF IMPERVIOUS DIKES.
- 9.) REMOVE ANY REMAINING SPECIAL STILLING BASIN(S), IMPERVIOUS DIKES, PUMPS, AND TEMPORARY FLEXIBLE HOSE.
- 10.) COMPLETE ROADWAY.

