

UT TO FRENCH BROAD RIVER CULVERT CONSTRUCTION SEQUENCE -L- STA 64 + 71.36

1. INSTALL SPECIAL STILLING BASIN(S) AS NEEDED THROUGHOUT CULVERT CONSTRUCTION.
2. INSTALL IMPVERIOUS DIKES 1 AND 2 AND THE 24" TEMPORARY PIPE 1.
3. INSTALL SPIN CAST LINER AND CONCRETE INVERT IN EXISTING 72" CMP AS NOTED ON THE PLANS. NOTE: APPROX. 30' OF THE 72" CMP WILL BE REMOVED ON THE DOWNSTREAM END AND WILL NOT NEED THE SPIN CAST LINER AND CONCRETE INVERT.
4. REMOVE +/- 30' OF EXISTING 72" CMP ON DOWNSTREAM END AND CONSTRUCT JB W/SLAB LID, 66" RCP EXTENSION W/EW AND RIP RAP ON BANKS.
5. REMOVE IMPERVIOUS DIKE 1, IMPERVIOUS DIKE 2, AND TEMPORARY PIPE 1.
6. INSTALL IMPERVIOUS DIKE 3 AND 4 AND 24" TEMPORARY PIPE 2.
7. CONSTRUCT PROPOSED JB W/SLAB LID, AND 66" RCP EXTENSION W/HW, AND INSTALL RIP RAP ON BANKS ON UPSTREAM SIDE OF THE PROPOSED 66" RCP.
8. REMOVE REMAINING IMPERVIOUS DIKES AND TEMPORARY PIPE.

