

**STATE OF NORTH CAROLINA
RAIL DIVISION**

NOTE: EMBANKMENT COLUMN DOES NOT INCLUDE BACKFILL FOR UNDERCUT

CROSS-SECTION SUMMARY

Station	Uncl. Exc.	Embt	Undercut	Station	Uncl. Exc.	Embt	Undercut	Station	Uncl. Exc.	Embt	Undercut	Station	Uncl. Exc.	Embt	Undercut	Station	Uncl. Exc.	Embt	Station	Uncl. Exc.	Embt	
MAIN	(cu. yd.)	(cu. yd.)	(cu. yd.)	MAIN	(cu. yd.)	(cu. yd.)	(cu. yd.)	MAIN	(cu. yd.)	(cu. yd.)	(cu. yd.)	MAIN	(cu. yd.)	(cu. yd.)	(cu. yd.)	MAIN	(cu. yd.)	(cu. yd.)	MAIN	(cu. yd.)	(cu. yd.)	
09+25	0	0		58+00	223	2838		109+00	815	128		
10+00	86	20		59+00	516	1840		110+00	866	89		
11+00	134	42		60+00	707	1413		111+00	836	101		
12+00	230	63		61+00	722	1211		112+00	767	188		
13+00	294	35		62+00	648	1171		113+00	815	292		
14+00	304	7		63+00	361	1361		114+00	1041	331		
15+00	376	74		64+00	282	1439		115+00	1198	407		
16+00	486	167		65+00	359	1328		116+00	1028	553		
17+00	571	276		66+00	250	1359		117+00	800	631		
18+00	690	697		67+00	258	1385		118+00	967	578		
19+00	671	1337	800	68+00	239	1374		119+00	909	592		
20+00	589	2119	800	69+00	194	1224		120+00	455	741		
21+00	310	3227	800	SUMMARY #3	11063	109024	3700	121+00	156	972		
21+51.24	0	1992	800	70+00	310	964		122+00	36	1211		
SUMMARY #1	4739	10055	3200	71+00	390	853		123+00	111	961		
22+62.90	0	0		72+00	292	917		124+00	218	430		
23+00	0	1759	1366.67	73+00	152	1039		125+00	303	168		
24+00	0	4579	1366.67	74+00	84	1220		126+00	362	53		
25+00	10	4126	1366.67	75+00	95	1310		127+00	426	9		
26+00	131	4084		76+00	125	1157		128+00	504	0		
27+00	250	4728		77+00	382	1159		129+00	577	5		
28+00	244	5121		78+00	537	1349		SUMMARY #5	16045	17445	0	
29+00	236	4866		79+00	321	1736		130+00	674	18		
30+00	338	4351		80+00	286	1967		131+00	558	22		
31+00	502	4129		81+00	373	1949		132+00	662	16		
32+00	532	4360		82+00	357	1917		133+00	777	11		
33+00	366	5113		83+00	484	1612		134+00	454	10		
34+00	162	6232		84+00	845	1134		135+00	139	43		
35+00	44	6912		85+00	986	859		136+00	40	47		
36+00	0	6990		86+00	841	884		136+23	18	4		
37+00	0	6910		87+00	807	804		SUMMARY #6	3323	172	0	
38+00	0	6966		88+00	741	667	
38+26.84	0	1893		89+00	572	750	
SUMMARY #2	2813	83119	4100	90+00	432	1009	
39+58.55				91+00	306	1218	
40+00	105	2967		92+00	359	1044	
41+00	240	7075		93+00	476	731	
42+00	248	6854		94+00	529	570	
43+00	270	6519		95+00	547	485	
44+00	279	6206		96+00	504	468	
45+00	310	5890		97+00	526	458	
46+00	349	5479		98+00	616	453	
47+00	529	4969		99+00	697	484	
48+00	677	4596		SUMMARY #4	13971	31165	0
49+00	622	4560		100+00	708	600	
50+00	549	4710		101+00	549	835	
51+00	468	4895		102+00	307	1176	
52+00	395	4844		103+00	114	1547	
53+00	403	4514		104+00	60	1611	
54+00	429	4332		105+00	62	1345	
55+00	288	4399		106+00	97	1024	
56+00	85	4356	1850	107+00	328	603	
57+00	58	3916	1850	108+00	632	264	

**Quantities are approximate only. The Resident Engineer will
recross-section the work accurately when the project is staked
out. These cross-section notes will be used in computing the
final quantities for which the contractor will be paid.**