## LOGICAL I/O PROCESSOR PROGRAMMING DETAIL

TO PRODUCE SPECIAL FYA-PPLT SIGNAL SEQUENCE

(program controller as shown below)

1. From Main Menu press '2' (PHASE CONTROL), then '1' (PHASE CONTROL FUNCTIONS). Scroll to the bottom of the menu and Enable ACT Logic Commands 1, 2 and 3.

2. From Main Menu press '6' (OUTPUTS), then '3' (LOGICAL I/O PROCESSOR).

```
LOGICAL I/O COMMAND #1  (+/-COMMAND#)
IF  ACTIVE PHASE      #1  IS ON
AND RED CLEAR ON PHASE #1  IS ON
```
NOTE: Logic for Phase 1 RED Clear when transitioning from Phase 1 to Phase 2 (Head 11).

~~ SCROLL DOWN ~~

```
THEN:
SET OUTPUT  ASSIGNMENT #50 ON
SET OUTPUT  ASSIGNMENT #51 OFF
```
PRESS '+'

```
LOGICAL I/O COMMAND #2  (+/-COMMAND#)
IF  ACTIVE PHASE      #1  IS ON
```
NOTE: Logic for Switching Flashing Yellow Arrow "OFF" during Phase 1 (Head 11).

~~ SCROLL DOWN ~~

```
THEN:
SET OUTPUT  ASSIGNMENT #52 OFF
```
PRESS '+'

```
LOGICAL I/O COMMAND #3  (+/-COMMAND#)
IF  YELLOW ON PHASE    #1  IS ON
```
NOTE: Logic for Yellow Arrow Clearance from Phase 1 (Head 11).

~~ SCROLL DOWN ~~

```
THEN:
SET OUTPUT  ASSIGNMENT #51 ON
```

LOGIC I/O PROCESSOR PROGRAMMING COMPLETE

OUTPUT REFERENCE SCHEDULE

OUTPUT 50 = Overlap A Red
OUTPUT 51 = Overlap A Yellow
OUTPUT 52 = Overlap A Green

OVERLAP PROGRAMMING DETAIL

(program controller as shown below)

From Main Menu press '8' (OVERLAPS), then '1' (VEHICLE OVERLAP SETTINGS).

```
PAGE 1: VEHICLE OVERLAP 'A' SETTINGS
 PHASE:           |12345678910111213141516
VEH OVL PARENTS:|XX
VEH OVL NOT VEH:|
VEH OVL NOT PED:|
VEH OVL GRN EXT:|
STARTUP COLOR: _ RED  _ YELLOW  _ GREEN
FLASH COLORS:  _ RED  _ YELLOW  X GREEN   <-- NOTICE GREEN FLASH
SELECT VEHICLE OVERLAP OPTIONS:   (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (O-255 SEC)........O
YELLOW CLEAR (O=PARENT,3-25.5 SEC)..O.O
RED CLEAR (O=PARENT,0.1-25.5 SEC)...O.O
OUTPUT AS PHASE # (O=NONE, 1-16)....O
```
PRESS '+' TWICE

```
PAGE 1: VEHICLE OVERLAP 'C' SETTINGS
 PHASE:           |12345678910111213141516
VEH OVL PARENTS:|     X
VEH OVL NOT VEH:|
VEH OVL NOT PED:|
VEH OVL GRN EXT:|
STARTUP COLOR: _ RED  _ YELLOW  _ GREEN
FLASH COLORS:  _ RED  _ YELLOW  X GREEN   <-- NOTICE GREEN FLASH
SELECT VEHICLE OVERLAP OPTIONS:   (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (O-255 SEC)........O
YELLOW CLEAR (O=PARENT,3-25.5 SEC)..O.O
RED CLEAR (O=PARENT,0.1-25.5 SEC)...O.O
OUTPUT AS PHASE # (O=NONE, 1-16)....O
```

OVERLAP PROGRAMMING COMPLETE

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 07-0805
DESIGNED: July 2014
SEALED: 3/27/2015
REVISED: N/A

Electrical Detail - Sheet 2 of 2