


**EDI MODEL 2018ECLIP-NC CONFLICT MONITOR
PROGRAMMING DETAIL**

(remove jumpers and set switches as shown)


REMOVE DIODE JUMPERS I-6 and 2-6.



REMOVE JUMPERS AS SHOWN

NOTES:

1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
3. Ensure that Red Enable is active at all times during normal operation.
4. Integrate monitor with Ethernet network in cabinet.



NOTES

1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
2. Enable Simultaneous Gap-Out for all phases.
3. Program phases 2 and 6 for Start Up In Green.
4. Program phases 2 and 6 for Yellow Flash.
5. The cabinet and controller are part of the High Point Signal System.

EQUIPMENT INFORMATION

CONTROLLER.....2070
 CABINET.....332
 SOFTWARE.....ECONOLITE OASIS
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...12
 LOAD SWITCHES USED.....S1,S2,S5,S8
 PHASES USED.....1,2,4,6
 OVERLAPS.....NONE


SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED
SIGNAL HEAD NO.	11,12	21,22	NU	NU	41,42	NU	NU	61,62	NU	NU	NU	NU
RED		128			101			134				
YELLOW		129			102			135				
GREEN		130			103			136				
RED ARROW	125											
YELLOW ARROW	126											
GREEN ARROW	127											

NU = Not Used

INPUT FILE POSITION LAYOUT

(front view)



EX.: 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
 ST = STOP TIME

Note: Install a model 242 DC isolator in slot J2 for use with microwave detector. See the Microwave Detector Wiring Detail on sheet 2.

IMPORTANT: For proper operation of the microwave detector, remove surge protection from TB3-5 and TB3-6, and from TB3-7 and TB3-8.

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
1A	TB6-9,10	I9U	60	22	11	1	Y	Y			3
1B	TB6-11,12	I9L	62	24	13	1	Y	Y			
2A,2B	TB2-5,6	I2U	39	1	2	2	Y	Y		1.6	
2C,2D	TB2-7,8	I2L	43	5	12	2	Y	Y			
4A	TB4-9,10	I6U	41	3	4	4	Y	Y			
4B	TB4-11,12	I6L	45	7	14	4	Y	Y			
4C	TB6-1,2	I7U	65	27	34	4	Y	Y			15
★ 6A	TB3-5,6	J2U	40	2	6	6	Y	Y		1.6	
6B,6C	TB3-9,10	J3U	64	26	36	6	Y	Y			
* S1	TB7-9,10	J9U	59	21	15	SYS					
* S2	TB7-11,12	J9L	61	23	17	SYS					

* System detector only. Remove the vehicle phase assigned to this detector in the default programming.

★ Microwave Detector, see wiring details sheet 2.

INPUT FILE POSITION LEGEND: J2L



THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 07-1624
 DESIGNED: April 2014
 SEALED: 4/20/2015
 REVISED: N/A

Electrical Detail - Sheet 1 of 2

ELECTRICAL AND PROGRAMMING DETAILS FOR: Prepared In the Offices of: 750 N. Greenfield Pkwy, Garner, NC 27529	NC 68 (Eastchester Drive) at I-74 EB/US 311 SB Ramps		SEAL PROFESSIONAL ENGINEER SEAL 022013 GEORGE C. BROWN
	Division 7 PLAN DATE: May 2014 PREPARED BY: C. Strickland	Guilford County High Point REVIEWED BY: T. Joyce REVIEWED BY:	
REVISIONS		INIT. DATE	SIG. INVENTORY NO. 07-1624

24-Apr-2015 08:48
 C:\IT\SS\115\Sigma\work\p000055\g\Map\511-10k\and071624_sml.e_000.dgn
 C:\IT\SS\115\Sigma\work\p000055\g\Map\511-10k\and071624_sml.e_000.dgn
 C:\IT\SS\115\Sigma\work\p000055\g\Map\511-10k\and071624_sml.e_000.dgn