

CROSS SECTION INDEX SHEET

-L- (SECTION 1 - STA 101+02.53 TO STA 128+00.00)	X-2 THRU X-10
-L- (SECTION 2 - STA 128+40.00 TO STA 150+45.00)	X-11 THRU X-18
-L- (SECTION 3 - STA 200+25.00 TO STA 284+40.00)	X-19 THRU X-47
-L- (SECTION 4 - STA 303+10.87 TO STA 305+01.90)	X-48
-L- (SECTION 5 - STA 312+00.00 TO STA 334+40.00)	X-49 THRU X-56
-L- (SECTION 6 - STA 347+00.00 TO STA 376+93.00)	X-57 THRU X-66
-L- (SECTION 7 - STA 403+35.00 TO STA 423+72.00)	X-67 THRU X-75
-SRI- (STA 14+00.00 TO STA 21+57.71)	X-76 THRU X-77