ALTERNATE PHASING ACTIVATION DETAIL

To run ALT. Phasing during <u>Coordination</u> - Select all page changes (as shown below) within Coordination Plan programming.

To run ALT. Phasing during <u>Free Run</u> - Program page changes (shown below) in separate Time Of Day events. If page 1 is used, no event programming is necessary for that particular page.

PHASING

Active Page required to run NORMAL PHASING Active Page required to run <u>ALTERNATE PHASING</u>

NOTE: Pages not shown (i.e. Sequence, Phase Control, etc.) should remain as '1', or as defined by Timing Engineer.

IMPORTANT: If Alertnate Phasing is used during Free Run and Coordination, DO NOT operate Time Of Day page change events concurrently with Coordination Plan events in the Event Scheduler. EX: Free Run page change event should end before Coordination Plan event starts and Vice-Versa.

ALTERNATE PHASING PAGE CHANGE SUMMARY

The following is a summary of what takes place when the Overlap/Input page change activates to call the "Alternate Phasing":

Overlap Page 2:	Modifies Overlap Parer for Heads 11, 31 and 7 protected turn only.
Input Page 2:	Disables Phase 6 call Loop 1A and modifies D
	Disables Phase 8 call Loop 3A and modifies D
	Disables Phase 4 call Loop 7A and modifies D

INPUT PAGE	OVERLAP PAGE
1	1
2	2

ent Phase 71 to run

on Delay Time.

on Delay Time.

on Delay Time.

