



LOGICAL I/O PROCESSOR PROGRAMMING DETAIL FOR INDICATOR LAMP CONTROL

(program controller as shown below)

- FROM MAIN MENU PRESS '2' (PHASE CONTROL), THEN '1' (PHASE CONTROL FUNCTIONS), SCROLL TO THE BOTTOM OF THE MENU AND ENABLE ACT LOGIC COMMANDS 1 AND 2.
- FROM MAIN MENU PRESS '6' (OUTPUTS), THEN '3' (LOGICAL I/O PROCESSOR).



NOTE: FIRE HOUSE PILOT LAMP LOGIC.



NOTE: FIRE HOUSE PILOT LAMP LOGIC.


END OF PROGRAMMING

OUTPUT REFERENCE SCHEDULE	
USE TO INTERPRET LOGIC PROCESSOR	
INPUT 14 =	Preempt 2
OUTPUT 33 =	Phase 2 PED Yellow

EV Preemption Control Box Wiring Detail

(wire as shown below)

CABINET WIRING



PHASE 2 PED YELLOW (TERM. 114)

AC NEUTRAL

LAMP NOTES

- If field terminal 114 has a conflict monitor wire attached, remove, tape, and label wire.
- Make sure load resistors are in place as shown in the Load Resistor Installation Detail.
- Install a loadswitch in Output File Slot S3.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 04-0282
DESIGNED: June 2017
SEALED: 08/04/2017
REVISED: N/A

EMERGENCY VEHICLE PREEMPTION PROGRAMMING DETAIL

(program controller as shown below)

From Main Menu press 'A' (Preemption), then '1' (Standard Preemptions). Press 'NEXT' to advance to Preemption #2.

PREEMPTION #2	SETTINGS (NEXT:1-10)
INTERVAL/TIMING	CLEAR/DWELL PHASES
GRN YEL RED	12345678910111213141516
1 255 0.0 0.0	X
2 0 0.0 0.0	
3 0 0.0 0.0	
4 0 0.0 0.0	
5 1 0.0 0.0	X X
EXIT CALLS	
	OPTIONS
PRIORITY (Y/N TO SELECT)MED
DELAY TIMER (0-255 SEC)*
MIN GREEN BEFORE PRE (0= DEFAULT)1
PED CLEAR BEFORE PRE (0= DEFAULT)0
YELLOW CLEAR BEFORE PRE (0= DEFAULT)0.0
RED CLEAR BEFORE PRE (0= DEFAULT)0.0
DWELL MIN TIMER (0-255 SEC)*
DWELL MAX TIMER (0=OFF,1-255MIN)0
DWELL HOLD-OVER TIMER (0-255)0
LATCH CALL?Y
LINK TO NEXT PREEMPT?N
ENABLE BACKUP PROTECTION?N
HOLD CLEAR 1 PHASES DURING DELAY?N
FAST GREEN FLASH DWELL PHASES?N
PED CLEARANCE THROUGH YELLOW?N
INHIBIT OVERLAP GREEN EXTENSION?N
SERVICE DURING SOFTWARE FLASH?N
REST IN RED DURING DWELL INTERVAL?N
FLASH DWELL INTERVAL?N
ALLOW PEDS IN DWELL INTERVAL?N
RE-TIME DWELL INTERVAL?Y
OVERLAPS:	ABCDEFGHIJKLMNOP
DWELL INT FLASH YELLOW	
OMIT OVERLAPS:	


* Denotes timing to be determined in field.

NOTES

- Relay K1 is shown in the energized (Preempt not active) normal operation state.
- Relay 'K1' is an enclosed DPDT general purpose relay with a 120VAC coil, 10A contacts, and octal-style plug.
- Relay SSR1 is a SPST (normally open) Solid State Relay with AC input and AC (25 amp) output.
- AC Isolator Card shall activate preemption upon removal of AC+ from the input (as shown above). To accomplish this, set invert dip switch on AC Isolator Card.
- IMPORTANT!! Terminal TB9-12 (on input panel) shall be connected to AC neutral (jumper may have to be added).


PREEMPT 2 AC ISOLATOR (MODEL 252) OUTPUT PROGRAMMING DETAIL

(set DIP switches as shown below)



NOTE: IF ANOTHER MANUFACTURER TYPE OF AC ISOLATOR IS USED, OUTPUT PROGRAMMING IS LIKELY NOT TO EQUATE TO THAT SHOWN ABOVE.

FRONT VIEW



Electrical Detail - Sheet 2 of 3 - Signal Modification

Michael Baker INTERNATIONAL
8000 Regency Parkway, Suite 600
Cary, North Carolina 27518
Phone: 919-463-5488
NC License No.: F-1084
MBAKERINTL.COM

ELECTRICAL AND PROGRAMMING DETAILS FOR:
Prepared in the Offices of:
Transmission Mobility and Safety Solutions
A Division of
KELLY M. CORY ENGINEERS
Signal Management Solutions
750 N. Greenfield Pkwy, Garner, NC 27529

US 301 (Ward Boulevard) at New Bern Street
Division 4 Wilson County Wilson
PLAN DATE: June 2017 REVIEWED BY: W M Ruhssam
PREPARED BY: K M Cory REVIEWED BY:
REVISIONS INIT. DATE
DocuSigned by:
Kelly M Cory 8/4/2017
SIGNATURE DATE
SIG. INVENTORY NO. 04-0282

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED
SEAL
NORTH CAROLINA PROFESSIONAL ENGINEER
SEAL 038970
KELLY M. CORY
DATE 8/4/2017
SIG. INVENTORY NO. 04-0282