

**This electronic collection of documents is provided
for the convenience of the user
and is Not a Certified Document –**



**The documents contained herein were originally issued
and sealed by the individuals whose names and license
numbers appear on each page, on the dates appearing
with their signature on that page.**

**This file or an individual page
shall not be considered a certified document.**

CUMBERLAND COUNTY

LOCATION: BRIDGE NO. 22 OVER I-95 BUSINESS /US 301 ON NC 59

TYPE OF WORK: TRAFFIC SIGNALS



<i>Sheet #</i>	<i>Reference #</i>	<i>Location/Description</i>
<i>Sig. 1.0</i>	-----	<i>Title Sheet</i>
<i>Sig. 2.0-2.3</i>	<i>06-0946 Temp1</i>	<i>NC 59 (S Main Street) at I-95 Bus./US 301 SB Ramps /SR 2285 (Shipman Road)</i>
<i>Sig. 3.0-3.2</i>	<i>06-0946 Temp2</i>	<i>NC 59 (S Main Street) at I-95 Bus./US 301 SB Ramps /SR 2285 (Shipman Road)</i>
<i>Sig. 4.0-4.2</i>	<i>06-0946 Temp3</i>	<i>NC 59 (S Main Street) at I-95 Bus./US 301 SB Ramps /SR 2285 (Shipman Road)</i>
<i>Sig. 5.0-5.2</i>	<i>06-0946 Temp4</i>	<i>NC 59 (S Main Street) at I-95 Bus./US 301 SB Ramps /SR 2285 (Shipman Road)</i>
<i>Sig. 6.0-6.2</i>	<i>06-0946 Final</i>	<i>NC 59 (S Main Street) at I-95 Bus./US 301 SB Ramps /SR 2285 (Shipman Road)</i>
<i>Sig. 7.0-7.1</i>	<i>06-0955 Temp1</i>	<i>NC 59 (Chicken Foot Road) at I-95 Bus./US 301 NB Ramps /SR 2284 (State Road)</i>
<i>Sig. 8.0-8.1</i>	<i>06-0955 Temp2</i>	<i>NC 59 (Chicken Foot Road) at I-95 Bus./US 301 NB Ramps /SR 2284 (State Road)</i>
<i>Sig. 9.0-9.1</i>	<i>06-0955 Temp3</i>	<i>NC 59 (Chicken Foot Road) at I-95 Bus./US 301 NB Ramps /SR 2284 (State Road)</i>
<i>Sig.10.0-10.1</i>	<i>06-0955 Temp4</i>	<i>NC 59 (Chicken Foot Road) at I-95 Bus./US 301 NB Ramps /SR 2284 (State Road)</i>
<i>Sig.11.0-11.1</i>	<i>06-0955 Final</i>	<i>NC 59 (Chicken Foot Road) at I-95 Bus./US 301 NB Ramps /SR 2284 (State Road)</i>
<i>Sig.12.0-12.1</i>	<i>06-1356 Temp1</i>	<i>NC 59 (S Main Street) at SR 2274 (Marracco Drive)</i>
<i>Sig.13.0-13.1</i>	<i>06-1356 Temp2</i>	<i>NC 59 (S Main Street) at SR 2274 (Marracco Drive)</i>
<i>Sig.14.0-14.1</i>	<i>06-1356 Final</i>	<i>NC 59 (S Main Street) at SR 2274 (Marracco Drive)</i>
<i>Sig.15.0-15.1</i>	<i>06-1357</i>	<i>NC 59 (S Main Street) at I-95 SB Ramps</i>
<i>Sig.16.0</i>		<i>Electrical Service Grounding</i>
<i>Sig.M1-M8</i>		<i>Metal Pole Standards</i>
<i>Scp.1-8</i>		<i>Signal Communication</i>


*Refer to "Roadway Standard Drawings
NCDOT" dated January 2018 and
"Standard Specifications for Roads
and Structures" dated January 2018.*

INTELLIGENT TRANSPORTATION AND SIGNALS UNIT


Contacts:

Meredith McDiarmid, PE., CPM – ITS and Signals Engineer
Meghan E. LeBlanc, PE. – Eastern Region Signals Project Engineer
Keith M. Mims, PE – Signal Equipment Design Engineer
Mohd A. Aslami, PE – Signals Management Engineer

Prepared In the Office of:
DIVISION OF HIGHWAYS
TRANSPORTATION MOBILITY AND SAFETY
DIVISION



PHASING DIAGRAM




PHASING DIAGRAM DETECTION LEGEND

- DETECTED MOVEMENT
- UNDETECTED MOVEMENT (OVERLAP)
- UNSIGNALIZED MOVEMENT
- PEDESTRIAN MOVEMENT

SIGNAL FACE	PHASE			
	Ø 1 + 6	Ø 2 + 6	Ø 8	FLASH
11	←	→	→	→
21, 22	R	G	R	Y
61, 62	G	G	R	Y
81, 82	R	R	G	R

SIGNAL FACE I.D.

All Heads L.E.D.




OASIS 2070 LOOP & DETECTOR INSTALLATION CHART											
INDUCTIVE LOOPS						DETECTOR PROGRAMMING					
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PHASE	CALLING	EXTENSION	FULL TIME DELAY	STRETCH TIME	DELAY TIME	SYSTEM LOOP
1A	6X40	0	2-4-2	-	1	Y	Y	-	-	15	- Y
					6	Y	Y	Y	-	3	- Y
2A/S01	6X6	300	5	-	2	Y	Y	-	-	-	Y Y
6A/S02	6X6	300	*	-	6	Y	Y	-	-	-	Y Y
8A	6X40	0	2-4-2	-	8	Y	Y	-	-	3	- Y

* Microwave Detection Area

3 Phase
Fully Actuated
NC 59 Closed Loop System

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Enable Backup Protect for phase 6 to allow the controller to clear from phase 2+6 to phase 1+6 by progressing through an all red display.
- Set all detector units to presence mode.
- Pavement markings are existing.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Closed loop system data: Controller Asset #0946.
- Remove existing heads numbered 41, 42, and 51.



OASIS 2070 TIMING CHART

FEATURE	PHASE			
	1	2	6	8
Min Green 1 *	7	12	12	7
Extension 1 *	2.0	6.0	6.0	2.0
Max Green 1 *	20	90	90	25
Yellow Clearance	3.0	4.7	4.7	3.0
Red Clearance	2.1	1.6	1.6	3.1
Red Revert	2.0	2.0	5.0	2.0
Walk 1 *	-	-	-	-
Don't Walk 1	-	-	-	-
Seconds Per Actuation *	-	2.5	2.5	-
Max Variable Initial *	-	34	34	-
Time Before Reduction *	-	15	15	-
Time To Reduce *	-	30	30	-
Minimum Gap	-	3.0	3.0	-
Recall Mode	-	MIN RECALL	MIN RECALL	-
Vehicle Call Memory	-	YELLOW	YELLOW	-
Dual Entry	-	-	-	-
Simultaneous Gap	ON	ON	ON	ON

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND

PROPOSED	EXISTING

Signal Upgrade- Temporary 1 (Phase I)

	NC 59 (South Main Street) at I-95 Bus./US 301 SB Ramp/ SR 2285 (Shipman Road)	
	Division 6 Cumberland County Hope Mills PLAN DATE: September 2017 REVIEWED BY: ZWL PREPARED BY: Meghan LeBlanc REVIEWED BY:	
750 N. Greenfield Pkwy, Garner, NC 27529	REVISIONS	INIT. DATE
	0 SCALE 40 1"=40'	


DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SEAL
NORTH CAROLINA
PROFESSIONAL
SEAL
042608
ENGINEER
MEGHAN E. LEBLANC

Designed by: Meghan E. LeBlanc 11/28/2017
DATE
SIG. INVENTORY NO. 06-094611

EDI MODEL 2018ECL-NC CONFLICT MONITOR
PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Enable Simultaneous Gap-Out for all Phases.
- Program phases 2 and 6 for Variable Initial and Gap Reduction.
- Program phases 2 and 6 for Startup In Green.
- Program phases 2 and 6 for Yellow Flash, and overlap 1 as Wag Overlaps.
- The cabinet and controller are part of the NC 59 Closed Loop System.

EQUIPMENT INFORMATION

CONTROLLER.....2070
CABINET.....336
SOFTWARE.....ECONOLITE OASIS
CABINET MOUNT.....POLE
OUTPUT FILE POSITIONS...12
LOAD SWITCHES USED.....S1,S2,S3,S8,S11
PHASES USED.....1,2,6,8
OVERLAP "A".....1+2
OVERLAP "B".....NOT USED
OVERLAP "C".....NOT USED
OVERLAP "D".....NOT USED

BACKUP PROTECTION NOTE

(program controller as shown below)

From Main Menu press '2' (Phase Control), then '1' (Phase Control Functions). Program phase 6 for 'Backup Protect'. Make sure the Red Revert times shown on the Signal Design Plans are programmed in the 'Phase Timing' menu.

PED YELLOW CONFLICT MONITOR WIRING DETAIL

(make cabinet wiring changes as shown below)

In order to use FYA COMPACT mode with the 2018ECL-NC Monitor, the cabinet must be wired such that the (unused) Ped Yellow load switch outputs are wired to the conflict monitor as follows: From 2 PY (field term. 114) to chan. 9 green (monitor pin 13).

Follow the instructions below to make the appropriate connections:

STEP 1: Fold down rear panel of output file.

STEP 2: Find unused wiring harness from conflict monitor card edge connector (which should be tied and bundled together).

STEP 3: Find the conductors that correspond to the following conflict monitor card edge pins and solder wire to the appropriate terminal on the rear of the output file as shown below:

CMU-13 _____ 2PY (term. 114)

NOTE: Some cabinet manufacturers use keyed connectors to accomplish this wiring configuration. If connectors are used, fold down the rear panel of the output file and find the set of 3 keyed connectors and connect them as shown below:

1-2PY 1-CMU-13
2-4PY 2-CMU-16
3-6PY 3-CMU-R
4-8PY 4-CMU-U

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-0946T1
DESIGNED: September 2017
SEALED: 11-28-17
REVISED: N/A

PROJECT REFERENCE NO.	SHEET NO.
B-4491	Sig. 2.1

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3		S4	S5	S6	S7	S8	S9	S10	S11	S12
CMU CHANNEL NO.	1	2	9	13	3	4	14	5	6	15	7	8	16
PHASE	OLA	2	1 GRN	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED
SIGNAL HEAD NO.	11★	21,22	11★	NU	NU	NU	NU	NU	61,62	NU	NU	81,82	NU
RED		128							134			107	
YELLOW		129							135			108	
GREEN		130							136			109	
RED ARROW	125												
YELLOW ARROW	126												
FLASHING YELLOW ARROW	127												
													
GREEN ARROW			114										
				*									

NU = Not Used


* Denotes install load resistor. See load resistor installation detail this sheet.

★ See pictorial of head wiring in detail this sheet.


FYA SIGNAL WIRING DETAIL

(wire signal head as shown)


OLA RED (125)
(LOAD SWITCH S1-RED)




OLA YELLOW (126)
(LOAD SWITCH S1-YELLOW)



OLA GREEN (127)
(LOAD SWITCH S1-GREEN)



Ø1 GREEN (114)
(LOAD SWITCH S3-YELLOW)



11


NOTE

The sequence display for signal head 11 requires special logic and output remapping. See sheets 2 and 3 for programming instructions.

LOAD RESISTOR INSTALLATION DETAIL


(install resistor as shown below)

VALUE (ohms)	WATTAGE
1.5K - 1.9K	25W (min)
2.0K - 3.0K	10W (min)



Electrical Detail -Sheet 1 of 3 - Temp. 1 (Phase I)

ELECTRICAL AND PROGRAMMING
DETAILS FOR:



NC 59 (South Main Street)

at
I-95 Bus./US 301 SB Ramp/
SR 2285 (Shipman Road)

Division 6 Cumberland County Hope Mills

PLAN DATE: November 2017 REVIEWED BY:


PREPARED BY: James Peterson REVIEWED BY:

REVISIONS

INIT. DATE

DOCUMENT NOT CONSIDERED
FINAL UNLESS ALL
SIGNATURES COMPLETED

SEAL



DocuSigned by: Keith M. Mims 12/1/2017

2F8078E8C03466 DATE

SIG. INVENTORY NO. 06-0946T1

FYA SIGNAL OUTPUT REMAPPING ASSIGNMENT PROGRAMMING DETAIL
FOR LOADSWITCHES S1 & S3 (SIGNAL HEAD 11)

(program controller as shown below)

FROM MAIN MENU PRESS '6' (OUTPUTS), THEN
'1' (OUTPUT ASSIGNMENTS),
WITH CURSOR IN "OUTPUT ASSIGNMENT#" POSITION, ENTER "14"

```
PAGE:1 C1 PIN:16 VEHICLE PHASE
OUTPUT ASSIGNMENT #.....14
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID,1=FLASH)...0
SELECT ASSIGNMENT:
NOT ENABLED.....Y
VEHICLE PHASE.....Y
PEDESTRIAN PHASE.....Y
VEHICLE OVERLAP.....Y
PEDESTRIAN OVERLAP.....Y
WATCHDOG.....Y
DETECTOR RESET.....Y
ADVANCE BEACON.....Y
OUT OF PHASE FLASHER.....Y
CONTROLLER FLASH.....Y
RUN FREE.....Y
RESERVED.....Y
PREEMPT.....Y
SOFT PREEMPT.....Y
ANY PREEMPT.....Y
COORDINATION PLAN.....Y
OFFSET.....Y
PHASE CHECK.....Y
PHASE ON.....Y
PHASE NEXT.....Y
```

THE OUTPUT IS SET AS A VEHICLE PHASE BY DEFAULT, THIS
"Y" WILL REMAIN UNTIL THE OUTPUT IS CHANGED.
ENTER A "Y" FOR VEHICLE OVERLAP.

```
PAGE:1 C1 PIN:16 VEHICLE PHASE
SELECT VEHICLE OVERLAP (A=1,P=16)...1
SELECT COLOR(0=RED,1=YEL,2=GRN).....0
```

WHEN A 'Y' IS ENTERED FOR 'VEHICLE OVERLAP'
THE SCREEN SHOWN ABOVE WILL APPEAR.
ENTER DATA AS SHOWN.
PRESS THE 'ENT' KEY AFTER ENTERING DATA,
THEN 'ESC'.

DISPLAY WILL NOW SHOW THE SPECIFIED OUTPUT
ASSIGNED AS 'VEHICLE OVERLAP' AS SHOWN BELOW.

```
PAGE:1 C1 PIN:16 VEHICLE OVERLAP
OUTPUT ASSIGNMENT #.....14
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID,1=FLASH)...0
SELECT ASSIGNMENT:
NOT ENABLED.....Y
VEHICLE PHASE.....Y
PEDESTRIAN PHASE.....Y
VEHICLE OVERLAP.....Y
PEDESTRIAN OVERLAP.....Y
WATCHDOG.....Y
DETECTOR RESET.....Y
ADVANCE BEACON.....Y
OUT OF PHASE FLASHER.....Y
CONTROLLER FLASH.....Y
RUN FREE.....Y
RESERVED.....Y
PREEMPT.....Y
SOFT PREEMPT.....Y
ANY PREEMPT.....Y
COORDINATION PLAN.....Y
OFFSET.....Y
PHASE CHECK.....Y
PHASE ON.....Y
PHASE NEXT.....Y
```

PRESS "+" KEY FOR OUTPUT 15

```
PAGE:1 C1 PIN:17 VEHICLE PHASE
OUTPUT ASSIGNMENT #.....15
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID,1=FLASH)...0
SELECT ASSIGNMENT:
NOT ENABLED.....Y
VEHICLE PHASE.....Y
PEDESTRIAN PHASE.....Y
VEHICLE OVERLAP.....Y
PEDESTRIAN OVERLAP.....Y
WATCHDOG.....Y
DETECTOR RESET.....Y
ADVANCE BEACON.....Y
OUT OF PHASE FLASHER.....Y
CONTROLLER FLASH.....Y
RUN FREE.....Y
RESERVED.....Y
PREEMPT.....Y
SOFT PREEMPT.....Y
ANY PREEMPT.....Y
COORDINATION PLAN.....Y
OFFSET.....Y
PHASE CHECK.....Y
PHASE ON.....Y
PHASE NEXT.....Y
```

THE OUTPUT IS SET AS A VEHICLE PHASE BY DEFAULT, THIS
"Y" WILL REMAIN UNTIL THE OUTPUT IS CHANGED.
ENTER A "Y" FOR VEHICLE OVERLAP.

```
PAGE:1 C1 PIN:17 VEHICLE PHASE
SELECT VEHICLE OVERLAP (A=1,P=16)...1
SELECT COLOR(0=RED,1=YEL,2=GRN).....1
```

WHEN A 'Y' IS ENTERED FOR 'VEHICLE OVERLAP'
THE SCREEN SHOWN ABOVE WILL APPEAR.
ENTER DATA AS SHOWN.
PRESS THE 'ENT' KEY AFTER ENTERING DATA,
THEN 'ESC'.

DISPLAY WILL NOW SHOW THE SPECIFIED OUTPUT
ASSIGNED AS 'VEHICLE OVERLAP' AS SHOWN BELOW.

```
PAGE:1 C1 PIN:17 VEHICLE OVERLAP
OUTPUT ASSIGNMENT #.....15
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID,1=FLASH)...0
SELECT ASSIGNMENT:
NOT ENABLED.....Y
VEHICLE PHASE.....Y
PEDESTRIAN PHASE.....Y
VEHICLE OVERLAP.....Y
PEDESTRIAN OVERLAP.....Y
WATCHDOG.....Y
DETECTOR RESET.....Y
ADVANCE BEACON.....Y
OUT OF PHASE FLASHER.....Y
CONTROLLER FLASH.....Y
RUN FREE.....Y
RESERVED.....Y
PREEMPT.....Y
SOFT PREEMPT.....Y
ANY PREEMPT.....Y
COORDINATION PLAN.....Y
OFFSET.....Y
PHASE CHECK.....Y
PHASE ON.....Y
PHASE NEXT.....Y
```

PRESS "+" KEY FOR OUTPUT 16

```
PAGE:1 C1 PIN:18 VEHICLE PHASE
OUTPUT ASSIGNMENT #.....16
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID,1=FLASH)...0
SELECT ASSIGNMENT:
NOT ENABLED.....Y
VEHICLE PHASE.....Y
PEDESTRIAN PHASE.....Y
VEHICLE OVERLAP.....Y
PEDESTRIAN OVERLAP.....Y
WATCHDOG.....Y
DETECTOR RESET.....Y
ADVANCE BEACON.....Y
OUT OF PHASE FLASHER.....Y
CONTROLLER FLASH.....Y
RUN FREE.....Y
RESERVED.....Y
PREEMPT.....Y
SOFT PREEMPT.....Y
ANY PREEMPT.....Y
COORDINATION PLAN.....Y
OFFSET.....Y
PHASE CHECK.....Y
PHASE ON.....Y
PHASE NEXT.....Y
```

THE OUTPUT IS SET AS A VEHICLE PHASE BY DEFAULT, THIS
"Y" WILL REMAIN UNTIL THE OUTPUT IS CHANGED.
ENTER A "Y" FOR VEHICLE OVERLAP.

```
PAGE:1 C1 PIN:18 VEHICLE PHASE
SELECT VEHICLE OVERLAP (A=1,P=16)...1
SELECT COLOR(0=RED,1=YEL,2=GRN).....2
```

WHEN A 'Y' IS ENTERED FOR 'VEHICLE OVERLAP'
THE SCREEN SHOWN ABOVE WILL APPEAR.
ENTER DATA AS SHOWN.
PRESS THE 'ENT' KEY AFTER ENTERING DATA,
THEN 'ESC'.

DISPLAY WILL NOW SHOW THE SPECIFIED OUTPUT
ASSIGNED AS 'VEHICLE OVERLAP' AS SHOWN BELOW.

```
PAGE:1 C1 PIN:18 VEHICLE OVERLAP
OUTPUT ASSIGNMENT #.....16
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID,1=FLASH)...0
SELECT ASSIGNMENT:
NOT ENABLED.....Y
VEHICLE PHASE.....Y
PEDESTRIAN PHASE.....Y
VEHICLE OVERLAP.....Y
PEDESTRIAN OVERLAP.....Y
WATCHDOG.....Y
DETECTOR RESET.....Y
ADVANCE BEACON.....Y
OUT OF PHASE FLASHER.....Y
CONTROLLER FLASH.....Y
RUN FREE.....Y
RESERVED.....Y
PREEMPT.....Y
SOFT PREEMPT.....Y
ANY PREEMPT.....Y
COORDINATION PLAN.....Y
OFFSET.....Y
PHASE CHECK.....Y
PHASE ON.....Y
PHASE NEXT.....Y
```

PRESS "+" UNTIL OUTPUT 33
IS REACHED.

OVERLAP PROGRAMMING DETAIL

(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS), THEN
'1' (VEHICLE OVERLAP SETTINGS).

```
PAGE 1: VEHICLE OVERLAP 'A' SETTINGS
PHASE: 12345678910111213141516
VEH OVL PARENTS: XX
VEH OVL NOT VEH:
VEH OVL NOT PED:
VEH OVL GRN EXT:
STARTUP COLOR: _ RED _ YELLOW _ GREEN
FLASH COLORS: _ RED _ YELLOW X GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC).....0
YELLOW CLEAR (0=PARENT,3-25.5 SEC)...0.0
RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)....0
```

NOTICE GREEN FLASH

OVERLAP PROGRAMMING COMPLETE

DISPLAY WILL NOW SHOW THE SPECIFIED OUTPUT
ASSIGNED AS 'VEHICLE PHASE' AS SHOWN BELOW.

```
PAGE:1 C1 PIN:35 VEHICLE PHASE
OUTPUT ASSIGNMENT #.....33
FREQUENCY (0=DEFAULT) (0-25.5 HZ)...0.0
DUTY CYCLE (0=DEFAULT) (0 - 100%)...0
MODE (0=SOLID,1=FLASH)...0
SELECT ASSIGNMENT:
NOT ENABLED.....Y
VEHICLE PHASE.....Y
PEDESTRIAN PHASE.....Y
VEHICLE OVERLAP.....Y
PEDESTRIAN OVERLAP.....Y
WATCHDOG.....Y
DETECTOR RESET.....Y
ADVANCE BEACON.....Y
OUT OF PHASE FLASHER.....Y
CONTROLLER FLASH.....Y
RUN FREE.....Y
RESERVED.....Y
PREEMPT.....Y
SOFT PREEMPT.....Y
ANY PREEMPT.....Y
COORDINATION PLAN.....Y
OFFSET.....Y
PHASE CHECK.....Y
PHASE ON.....Y
PHASE NEXT.....Y
```

THE OUTPUT IS SET AS "NOT ENABLED" BY DEFAULT, THIS
"Y" WILL REMAIN UNTIL THE OUTPUT IS CHANGED.
ENTER A "Y" FOR VEHICLE PHASE.


```
PAGE:1 C1 PIN:35 NOT ENABLED
SELECT VEHICLE PHASE (1-16).....1
SELECT COLOR(0=RED,1=YEL,2=GRN).....2
```

WHEN A 'Y' IS ENTERED FOR 'VEHICLE PHASE'
THE SCREEN SHOWN ABOVE WILL APPEAR.
ENTER DATA AS SHOWN.
PRESS THE 'ENT' KEY AFTER ENTERING DATA,
THEN 'ESC'.


OUTPUT PROGRAMMING COMPLETE

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-0946T1
DESIGNED: September 2017
SEALED: 11-28-17
REVISED: N/A

Electrical Detail -Sheet 2 of 3 - Temp. 1 (Phase I)

ELECTRICAL AND PROGRAMMING DETAILS FOR: Prepared In the Office of:  750 N. Greenfield Pkwy, Garner, NC 27529	NC 59 (South Main Street) at I-95 Bus./US 301 SB Ramp/ SR 2285 (Shipman Road)		DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED
	Division 6 PLAN DATE: November 2017 PREPARED BY: James Peterson	Cumberland County REVIEWED BY: REVIEWED BY:	SEAL  12/1/2017
	REVISIONS	INIT.	DATE
	SIC. INVENTORY NO. 06-0946T1		

MICROWAVE DETECTOR WIRING DETAIL



TC26B WIRE LIST

COLOR	FUNCTION
black	12V to 24V AC/DC (no polarity)
red	12V to 24V AC/DC (no polarity)
orange	Output Relay Normally Open
white	Output Relay Normally Closed
green	Output Relay Common


NOTES:

- Sensor is a Microwave Sensors, Inc. Model TC-26B microwave motion detector mounted on poles as indicated on the Signal Design Plans.
- Microwave wiring shown above will cause a permanent call unless the Input Assignment Programming and Logical I/O Processor Programming details are entered as shown on this sheet. These programming details will cause a call to be placed upon opening the Normally Closed contact on TC26B.
- DC Isolator's LED will be ON when no call is present and will be OFF when a call is present.
- Important: For proper operation of the microwave detector, remove surge protection from TB21-11, TB21-12, TB23-11, and TB23-12 and insert 242 DC Isolator in slot 16.


LOGICAL I/O PROCESSOR PROGRAMMING DETAIL TO PRODUCE
SPECIAL FYA-PPLT SIGNAL SEQUENCE AND TO INVERT INPUT FROM MICROWAVE DETECTOR

(program controller as shown below)


- FROM MAIN MENU PRESS '2' (PHASE CONTROL), THEN '1' (PHASE CONTROL FUNCTIONS). SCROLL TO THE BOTTOM OF THE MENU AND ENABLE ACT LOGIC COMMANDS 1, 2, 3, 4 AND 5.
- FROM MAIN MENU PRESS '6' (OUTPUTS), THEN '3' (LOGICAL I/O PROCESSOR).




NOTE: LOGIC FOR PHASE 1 RED CLEAR WHEN TRANSITIONING FROM PHASE 1 TO PHASE 2 (HEAD 11).




NOTE: LOGIC FOR SWITCHING FLASHING YELLOW ARROW "OFF" DURING PHASE 1 (HEAD 11).



NOTE: LOGIC FOR YELLOW ARROW CLEARANCE FROM PHASE 1 (HEAD 11).



NOTE: MICROWAVE DETECTOR CONTACTS ARE CLOSED, SO NO CALL IS 'DETECTED' ON LOOP 6A.



NOTE: MICROWAVE DETECTOR CONTACTS ARE OPEN, SO A CALL IS 'DETECTED' ON LOOP 6A.

OVERLAP PROGRAMMING COMPLETE

OUTPUT REFERENCE SCHEDULE

INPUT 2 = Detector Physical Input (not enabled)
INPUT 64 = Dummy Detector Input (Detector 6)
OUTPUT 14 = Overlap A Red
OUTPUT 15 = Overlap A Yellow
OUTPUT 16 = Overlap A Green
OUTPUT 33 = Phase 1 Green

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-0946T1
DESIGNED: September 2017
SEALED: 11-28-17
REVISED: N/A

INPUT ASSIGNMENT PROGRAMMING DETAIL FOR MICROWAVE DETECTOR INPUT

(program controller as shown below)

FROM MAIN MENU PRESS '5' (INPUTS), THEN '+'
UNTIL INPUT 2 (PIN 40) IS REACHED. MODIFY
DEFAULT CONDITIONS AS INDICATED BY ARROWS.

PAGE: 1 C1 PIN:40 NOT ENABLED
INPUT ASSIGNMENT #.....2
DEBOUNCE TIME (0-25.5 SEC).....0.5
DELAY TIME (0-25.5 SEC).....0.0
HOLD-OVER TIME (0-25.5 SEC).....0.0
ASSIGNMENT SELECTION:
NOT ENABLED (Y/N).....Y
VEHICLE DETECTOR (1-64).....
PEDESTRIAN DETECTOR (1-16).....
ALTERNATE PED DETECTOR (1-16).....
PREEMPT (1-10).....
INVERTED PREEMPT (1-10).....
STOP TIME (Y/N).....
FLASH SENSE (Y/N).....
DOOR OPEN (Y/N).....
MANUAL CONTROL ENABLE (Y/N).....
MANUAL CONTROL ADVANCE (Y/N).....
SPECIAL FUNCTION ALARM (1-8).....
TOD HOUR SYNCHRONIZATION (0-23).....
FORCE OFF RING (1-4).....
HOLD PHASES (1-16).....
PLAN (65=FLSH,66=FREE)... OFFSET#...
CHANGE PHASE SEQUENCE PAGE (1-12)...
CHANGE PHASE TIMING PAGE (1-4).....
CHANGE PHASE CONTROL PAGE (1-4).....
CHANGE OVERLAP CONTROL PAGE (1-4).....
CHANGE INPUT PAGE (1-4).....
CHANGE OUTPUT PAGE (1-4).....
OVERRIDE PHASE CONTROL FUNCTION (Y)...

ENTER 'YES' for
Not Enabled

PAGE: 1 C1 PIN:0 VEHICLE DETECTOR
INPUT ASSIGNMENT #.....64
DEBOUNCE TIME (0-25.5 SEC).....0.5
DELAY TIME (0-25.5 SEC).....0.0
HOLD-OVER TIME (0-25.5 SEC).....0.0
ASSIGNMENT SELECTION:
NOT ENABLED (Y/N).....
VEHICLE DETECTOR (1-64).....6
PEDESTRIAN DETECTOR (1-16).....
ALTERNATE PED DETECTOR (1-16).....
PREEMPT (1-10).....
INVERTED PREEMPT (1-10).....
STOP TIME (Y/N).....
FLASH SENSE (Y/N).....
DOOR OPEN (Y/N).....
MANUAL CONTROL ENABLE (Y/N).....
MANUAL CONTROL ADVANCE (Y/N).....
SPECIAL FUNCTION ALARM (1-8).....
TOD HOUR SYNCHRONIZATION (0-23).....
FORCE OFF RING (1-4).....
HOLD PHASES (1-16).....
PLAN (65=FLSH,66=FREE)...65 OFFSET#...
CHANGE PHASE SEQUENCE PAGE (1-12)...
CHANGE PHASE TIMING PAGE (1-4).....
CHANGE PHASE CONTROL PAGE (1-4).....
CHANGE OVERLAP CONTROL PAGE (1-4).....
CHANGE INPUT PAGE (1-4).....
CHANGE OUTPUT PAGE (1-4).....
OVERRIDE PHASE CONTROL FUNCTION (Y)...

ENTER '6' for
Vehicle Detector


PROGRAMMING COMPLETE

PRESS '-' until Input
Assignment #64 is reached

NOTE:

This remapping removes the default detector from the microwave's physical input and reassigns it to unused INPUT 64. The Logical I/O Processor Programming Detail on this sheet will invert the disabled input and control INPUT 64 and the reassigned detector.

Electrical Detail -Sheet 3 of 3 - Temp. 1 (Phase I)



NC 59 (South Main Street)
at
I-95 Bus./US 301 SB Ramp/
SR 2285 (Shipman Road)

Division 6 Cumberland County Hope Mills


PLAN DATE: November 2017 REVIEWED BY:

PREPARED BY: James Peterson REVIEWED BY:

REVISIONS INIT. DATE


DATE

DOCUMENT NOT CONSIDERED
FINAL UNLESS ALL
SIGNATURES COMPLETED



SIG. INVENTORY NO. 06-0946T1

PHASING DIAGRAM




PHASING DIAGRAM DETECTION LEGEND

- DETECTED MOVEMENT
- UNDETECTED MOVEMENT (OVERLAP)
- UNSIGNALIZED MOVEMENT
- PEDESTRIAN MOVEMENT

SIGNAL FACE	PHASE			
	02+5	02+6	04	FLASH
21,22	G	G	R	Y
41	R	R	G	R
42	R	R	G	R
51	Y	Y	R	Y
61,62	R	G	R	Y

SIGNAL FACE I.D.

All Heads L.E.D.




OASIS 2070 LOOP & DETECTOR INSTALLATION CHART												
INDUCTIVE LOOPS					DETECTOR PROGRAMMING							
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PHASE	CALLING	EXTENSION	FULL TIME DELAY	STRETCH TIME	DELAY TIME	SYSTEM LOOP	NEW CARD
2A	6X6	300	6	Y	2	Y	Y	-	-	-	-	Y
4A	6X40	0	2-4-2	Y	4	Y	Y	-	-	3	-	Y
5A	6X40	0	2-4-2	Y	5	Y	Y	-	-	15	-	Y
					2	Y	Y	Y	-	3	-	Y
5B	6X40	0	2-4-2	Y	5	Y	Y	-	-	15	-	Y
6B/S15	6X6	355	6	Y	6	Y	Y	-	-	-	Y	Y

3 Phase
Fully Actuated
NC 59 Closed Loop System

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 5 may be lagged.
- Set all detector units to presence mode.
- Locate new cabinet so as not to obstruct sight distance of vehicles turning right on red.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Closed loop system data: Controller Asset # 0946.



OASIS 2070 TIMING CHART				
FEATURE	PHASE			
	2	4	5	6
Min Green 1 *	12	7	7	12
Extension 1 *	6.0	2.0	2.0	7.0
Max Green 1 *	90	25	20	90
Yellow Clearance	4.9	3.0	3.0	4.9
Red Clearance	1.6	2.8	2.6	1.6
Red Revert	2.0	2.0	2.0	2.0
Walk 1 *	-	-	-	-
Don't Walk 1	-	-	-	-
Seconds Per Actuation *	2.5	-	-	2.5
Max Variable Initial *	34	-	-	34
Time Before Reduction *	15	-	-	15
Time To Reduce *	30	-	-	30
Minimum Gap	3.0	-	-	3.0
Recall Mode	MIN RECALL	-	-	MIN RECALL
Vehicle Call Memory	YELLOW	-	-	YELLOW
Dual Entry	-	-	-	-
Simultaneous Gap	ON	ON	ON	ON

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND	
PROPOSED	EXISTING
	N/A
N/A	
N/A	
N/A	

Signal Upgrade - Temporary 2 (Phase I-18)

Prepared in the Offices of:

750 N. Greenfield Pkwy, Garner, NC 27529

NC 59 (South Main Street)
at
I-95 Bus./US 301 SB Ramp /
SR 2285 (Shipman Road)

Division 6 Cumberland County Hope Mills

PLAN DATE: September 2017 REVIEWED BY: ZWL

PREPARED BY: M.E. LeBlanc REVIEWED BY:

REVISIONS	INIT.	DATE

SCALE: 0 40 1"=40'

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SEAL
NORTH CAROLINA
PROFESSIONAL
SEAL
042608
ENGINEER
MICHAEL E. LEBLANC


DocuSigned by:
Michael E. LeBlanc
11/28/2017
DATE
SIC. INVENTORY NO. 06-0946T2

EDI MODEL 2018ECL-NC CONFLICT MONITOR

PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



REMOVE DIODE JUMPERS 2-5, 2-6, 2-11, 5-11 and 6-11.



REMOVE JUMPERS AS SHOWN

NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- Ensure that Red Enable is active at all times during normal operation.
- Connect serial cable from conflict monitor to comm. port 1 of 2070 controller. Ensure conflict monitor communicates with 2070.



■ = DENOTES POSITION OF SWITCH

NOTES


- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Enable Simultaneous Gap-Out for all Phases.
- Program phases 2 and 6 for Variable Initial and Gap Reduction.
- Program phases 2 and 6 for Startup In Green.
- Program phases 2 and 6 for Yellow Flash.
- The cabinet and controller are part of the NC 59 Closed Loop System.

EQUIPMENT INFORMATION

CONTROLLER.....2070
CABINET.....332 W/ AUX
SOFTWARE.....ECONOLITE OASIS
CABINET MOUNT.....BASE
OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
LOAD SWITCHES USED.....S2,S5,S7,S8,AUX S4
PHASES USED.....2,4,5,6
OVERLAP "A".....NOT USED
OVERLAP "B".....NOT USED
OVERLAP "C".....5+6
OVERLAP "D".....NOT USED

INPUT FILE POSITION LAYOUT

(front view)



EX.: 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
ST = STOP TIME


⊗ Wired Input - Do not populate slot with detector card

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
2A	TB2-5,6	I2U	39	1	2	2	Y	Y			
4A	TB4-9,10	I6U	41	3	4	4	Y	Y			3
5A ¹	TB3-1,2	J1U	55	17	5	5	Y	Y			15
	-	I4U	47	9	22	2	Y	Y	Y		3
5B	TB3-5,6	J2U	40	2	6	5	Y	Y			15
6B/S15	TB3-11,12	J3L	77	39	46	6/SYS	Y	Y			

¹Add jumper from J1-W to I4-W, on rear of input file.

INPUT FILE POSITION LEGEND: J2L



SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	NU	21,22	NU	NU	41,42	NU	42	51★	61,62	NU	NU	NU	NU	NU	NU	51★	NU	NU
RED		128			101			*	134									
YELLOW		129			102				135									
GREEN		130			103				136									
RED ARROW																A114		
YELLOW ARROW							132									A115		
FLASHING YELLOW ARROW																A116		
GREEN ARROW							133	133										


NU = Not Used

* Denotes install load resistor. See load resistor installation detail this sheet.

★ See pictorial of head wiring in detail this sheet.

FYA SIGNAL WIRING DETAIL

(wire signal head as shown)



NOTE


The sequence display for signal head 51 requires special logic programming. See sheet 2 for programming instructions.

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-0946T2
DESIGNED: September 2017
SEALED: 11-28-17
REVISED: N/A

Electrical Detail - Sheet 1 of 2 - Temp.2 (Phase I-18)

ELECTRICAL AND PROGRAMMING
DETAILS FOR:

Prepared In the Offices of:



750 N.Greenfield Pkwy,Garner,NC 27529

NC 59 (South Main Street)
at
I-95 Bus./US 301 SB Ramp /
SR 2285 (Shipman Road)

Division 6 Cumberland County Hope Mills

PLAN DATE: November 2017 REVIEWED BY:

PREPARED BY: James Peterson REVIEWED BY:


REVISIONS

INIT.

DATE

DOCUMENT NOT CONSIDERED
FINAL UNLESS ALL
SIGNATURES COMPLETED

SEAL




DocuSigned by: Keith M. Minns 12/1/2017

2F807B0E6CD34A5 DATE

SIG. INVENTORY NO. 06-0946T2


PHASING DIAGRAM



SIGNAL FACE	PHASE					
	Ø 1 + 5	Ø 1 + 6	Ø 2 + 5	Ø 2 + 6	Ø 4 + 8	FLASH
11	←	←	←	←	←	Y
21,22	R	R	G	G	R	Y
41	R	R	R	R	G	Y
42	R	R	R	R	G	R
51	←	←	←	←	←	Y
61,62	R	G	R	G	R	Y
81,82	R	R	R	R	G	R

SIGNAL FACE I.D.

All Heads L.E.D.




INDUCTIVE LOOPS						DETECTOR PROGRAMMING					
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PHASE	CALLING	EXTENSION	FULL TIME DELAY	STRETCH TIME	DELAY TIME	SYSTEM LOOP
1A	6X40	0	2-4-2	Y	1	Y	Y	-	-	15	- Y
2A	6X6	300	6	-	6	Y	Y	Y	-	3	- Y
4A	6X40	0	2-4-2	-	4	Y	Y	-	-	3	- -
5A	6X40	0	2-4-2	-	5	Y	Y	-	-	15	- -
5B	6X40	0	2-4-2	-	2	Y	Y	Y	-	3	- -
6B/S15	6X6	355	6	-	5	Y	Y	-	-	15	- -
8A	6X40	0	2-4-2	Y	8	Y	Y	-	-	3	- Y

5 Phase Fully Actuated NC 59 Closed Loop System

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 1 and/or phase 5 may be lagged.
- Set all detector units to presence mode.
- Locate new cabinet so as not to obstruct sight distance of vehicles turning right on red.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Closed loop system data: Controller Asset #0946.



OASIS 2070 TIMING CHART						
FEATURE	PHASE					
	1	2	4	5	6	8
Min Green 1 *	7	12	7	7	12	7
Extension 1 *	2.0	6.0	2.0	2.0	7.0	2.0
Max Green 1 *	20	90	25	20	90	25
Yellow Clearance	3.0	4.9	4.4	3.0	4.9	4.4
Red Clearance	2.2	1.6	1.0	2.6	1.6	1.4
Red Revert	2.0	2.0	2.0	2.0	2.0	2.0
Walk 1 *	-	-	-	-	-	-
Don't Walk 1	-	-	-	-	-	-
Seconds Per Actuation *	-	2.5	-	-	2.5	-
Max Variable Initial *	-	34	-	-	40	-
Time Before Reduction *	-	15	-	-	15	-
Time To Reduce *	-	30	-	-	30	-
Minimum Gap	-	3.0	-	-	3.0	-
Recall Mode	-	MIN RECALL	-	-	MIN RECALL	-
Vehicle Call Memory	-	YELLOW	-	-	YELLOW	-
Dual Entry	-	-	ON	-	-	ON
Simultaneous Gap	ON	ON	ON	ON	ON	ON

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND	
PROPOSED	EXISTING

Signal Upgrade - Temporary 3 (Phase II-5)

Prepared in the Offices of:

Transportation Mobility and Safety Solutions

STATE OF NORTH CAROLINA

DEPARTMENT OF TRANSPORTATION

Signal Design Section

750 N. Greenfield Pkwy, Garner, NC 27529

NC 59 (South Main Street) at I-95 Bus./US 301 SB Ramp / SR 2285 (Shipman Road)

Division 6 Cumberland County Hope Mills

PLAN DATE: September 2017 REVIEWED BY: ZML

PREPARED BY: M.E. LeBlanc REVIEWED BY:

REVISIONS

INIT. DATE

SCALE 0 40 1"=40'

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SEAL

PROFESSIONAL ENGINEER

SEAL

042608

WILLIAM E. LEBLANC


DocuSigned by: William E. LeBlanc 11/28/2017

SIG. INVENTORY NO. 06-094613

(remove jumpers and set switches as shown)

NOTES:

1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
3. Ensure that Red Enable is active at all times during normal operation.
4. Connect serial cable from conflict monitor to comm. port 1 of 2070 controller. Ensure conflict monitor communicates with 2070.



1. To prevent “flash-conflict” problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
2. Program phases 4 and 8 for Dual Entry.
3. Enable Simultaneous Gap-Out for all Phases.
4. Program phases 2 and 6 for Variable Initial and Gap Reduction.
5. Program phases 2 and 6 for Startup In Green.
6. Program phases 2 and 6 for Yellow Flash, and overlap 1 as Wag Overlaps.
7. The cabinet and controller are part of the NC 59 Closed Loop System.

```

CONTROLLER.....2070
CABINET.....332 W/ AUX
SOFTWARE.....ECONOLITE OASIS
CABINET MOUNT.....BASE
OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
LOAD SWITCHES USED.....S1,S2,S5,S7,S8,S11,AUX S1,AUX S4
PHASES USED.....1,2,4,5,6,8
OVERLAP "A".....1+2
OVERLAP "B".....NOT USED
OVERLAP "C".....5+6
OVERLAP "D".....NOT USED

```

[illegible]

NU = Not Used

* Denotes install load resistor. See load resistor installation detail this sheet.

★ See pictorial of head wiring in detail this sheet.

(front view)

[illegible]

EX.: 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
ST = STOP TIME


⊗ Wired Input - Do not populate slot with detector card

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
1A ¹	TB2-1,2	I1U	56	18	1	1	Y	Y			15
	-	J4U	48	10	26	6	Y	Y	Y		3
2A	TB2-5,6	I2U	39	1	2	2	Y	Y			
4A	TB4-9,10	I6U	41	3	4	4	Y	Y			3
5A ²	TB3-1,2	J1U	55	17	5	5	Y	Y			15
	-	I4U	47	9	22	2	Y	Y	Y		3
5B	TB3-5,6	J2U	40	2	6	5	Y	Y			15
6B/S15	TB3-11,12	J3L	77	39	46	6/SYS	Y	Y			
8A	TB5-9,10	J6U	42	4	8	8	Y	Y			3

¹Add jumper from I1-W to J4-W, on rear of input file.


²Add jumper from J1-W to J4-W, on rear of input file.

INPUT FILE POSITION LEGEND: J2L




(install resistors as shown below)

ACCEPTABLE VALUES	
VALUE (ohms)	WATTAGE
1.5K - 1.9K	25W (min)
2.0K - 3.0K	10W (min)



(wire signal heads as shown)



NOTE

The sequence display for signal heads 11 and 51 requires special logic programming. See sheet 2 for programming instructions.

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-0946T3
DESIGNED: September 2017
SEALED: 11-28-17
REVISED: N/A

NC 59 (South Main Street)
at
I-95 Bus./US 301 SB Ramp /
SR 2285 (Shipman Road)


Division 6 Cumberland County Hope Mills

PLAN DATE: November 2017

REVISIONS	INIT.	DATE
-----------	-------	------

**DOCUMENT NOT CONSIDERED
FINAL UNLESS ALL
SIGNATURES COMPLETED**

SEAL



DocuSigned by:  12/1/2017


Fertu M. Mins
258079859CD3446
DATE

SIG. INVENTORY NO. 06-0946T3


LOGICAL I/O PROCESSOR PROGRAMMING DETAIL
TO PRODUCE SPECIAL FYA-PPLT SIGNAL SEQUENCE

(program controller as shown below)


- FROM MAIN MENU PRESS '2' (PHASE CONTROL), THEN '1' (PHASE CONTROL FUNCTIONS). SCROLL TO THE BOTTOM OF THE MENU AND ENABLE ACT LOGIC COMMANDS 1, 2, 3, 4, 5 AND 6.
- FROM MAIN MENU PRESS '6' (OUTPUTS), THEN '3' (LOGICAL I/O PROCESSOR).




NOTE: LOGIC FOR
PHASE 1 RED
CLEAR WHEN
TRANSITIONING
FROM PHASE 1
TO PHASE 2
(HEAD 11).




NOTE: LOGIC FOR
SWITCHING
FLASHING YELLOW
ARROW "OFF"
DURING PHASE 1
(HEAD 11).




NOTE: LOGIC FOR
YELLOW
ARROW
CLEARANCE
FROM PHASE 1
(HEAD 11).



NOTE: LOGIC FOR
PHASE 5 RED
CLEAR WHEN
TRANSITIONING
FROM PHASE 5
TO PHASE 6
(HEAD 51).



NOTE: LOGIC FOR
SWITCHING
FLASHING YELLOW
ARROW "OFF"
DURING PHASE 5
(HEAD 51).



NOTE: LOGIC FOR
YELLOW
ARROW
CLEARANCE
FROM PHASE 5
(HEAD 51).

LOGIC I/O PROCESSOR PROGRAMMING COMPLETE

OUTPUT REFERENCE SCHEDULE

OUTPUT 42 = Overlap C Red
OUTPUT 43 = Overlap C Yellow
OUTPUT 44 = Overlap C Green
OUTPUT 50 = Overlap A Red
OUTPUT 51 = Overlap A Yellow
OUTPUT 52 = Overlap A Green

OVERLAP PROGRAMMING DETAIL

(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS), THEN '1' (VEHICLE OVERLAP SETTINGS).

PAGE 1: VEHICLE OVERLAP 'A' SETTINGS
PHASE: 12345678910111213141516
VEH OVL PARENTS: XX
VEH OVL NOT VEH:
VEH OVL NOT PED:
VEH OVL GRN EXT:
STARTUP COLOR: _ RED _ YELLOW _ GREEN
FLASH COLORS: _ RED _ YELLOW X GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC).....0
YELLOW CLEAR (0=PARENT.3-25.5 SEC)..0.0
RED CLEAR (0=PARENT.0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)....0

← NOTICE GREEN FLASH

PRESS '+' TWICE


PAGE 1: VEHICLE OVERLAP 'C' SETTINGS
PHASE: 12345678910111213141516
VEH OVL PARENTS: XX
VEH OVL NOT VEH:
VEH OVL NOT PED:
VEH OVL GRN EXT:
STARTUP COLOR: _ RED _ YELLOW _ GREEN
FLASH COLORS: _ RED _ YELLOW X GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC).....0
YELLOW CLEAR (0=PARENT.3-25.5 SEC)..0.0
RED CLEAR (0=PARENT.0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)....0

← NOTICE GREEN FLASH

OVERLAP PROGRAMMING COMPLETE

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-0946T3
DESIGNED: September 2017
SEALED: 11-28-17
REVISED: N/A

Electrical Detail - Sheet 2 of 2 - Temp.3 (Phase II-5)



NC 59 (South Main Street)
at
I-95 Bus./US 301 SB Ramp /
SR 2285 (Shipman Road)

Division 6 Cumberland County Hope Mills

PLAN DATE: November 2017 REVIEWED BY:

PREPARED BY: James Peterson REVIEWED BY:

REVISIONS INIT. DATE

DOCUMENT NOT CONSIDERED
FINAL UNLESS ALL
SIGNATURES COMPLETED

SEAL

SEAL

036880


KEITH M. MINS

ENGINEER

DocuSigned by:
Keith M. Mins 12/1/2017

SIG. INVENTORY NO. 06-0946T3


PHASING DIAGRAM



SIGNAL FACE	PHASE					
	0 1+5	0 1+6	0 2+5	0 2+6	0 4+8	F L A S H
11	←	←	←	←	←	←
21,22	R	R	G	G	R	Y
41	R	R	R	R	G	R
42	R	R	R	R	G	R
51	←	←	←	←	←	←
61,62	R	G	R	G	R	Y
81,82	R	R	R	R	G	R

SIGNAL FACE I.D.

All Heads L.E.D.




OASIS 2070 LOOP & DETECTOR INSTALLATION CHART												
INDUCTIVE LOOPS					DETECTOR PROGRAMMING							
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PHASE	CALLING	EXTENSION	FULL TIME DELAY	STRETCH TIME	DELAY TIME	SYSTEM LOOP	NEW CAR
1A	6X40	0	2-4-2	-	1	Y	Y	-	-	15	-	-
					6	Y	Y	Y	-	3	-	-
2B/S02	6X6	355	6	Y	2	Y	Y	-	-	-	Y	Y
4A	6X40	0	2-4-2	-	4	Y	Y	-	-	3	-	-
5A	6X60	+20	2-4-2	Y	5	Y	Y	-	-	15	-	Y
					2	Y	Y	Y	-	3	-	Y
5B	6X40	0	2-4-2	-	5	Y	Y	-	-	15	-	-
6B/S15	6X6	355	6	-	6	Y	Y	-	-	-	-	Y
8A	6X40	0	2-4-2	Y	8	Y	Y	-	-	3	-	Y
8B	6X40	0	2-4-2	Y	8	Y	Y	-	-	15	-	Y

5 Phase
Fully Actuated
NC 59 Closed Loop System

NOTES

1. Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
2. Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
3. Phase 1 and/or phase 5 may be lagged.
4. Reposition existing signal heads numbered 21, 22, and 51 as shown.
5. Set all detector units to presence mode.
6. Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
7. Closed loop system data:
Controller Asset #0946.

NC 59 (South Main Street)



OASIS 2070 TIMING CHART

OASIS 2070 TIMING CHART						
FEATURE	PHASE					
	1	2	4	5	6	8
Min Green 1 *	7	12	7	7	12	7
Extension 1 *	2.0	7.0	2.0	2.0	7.0	2.0
Max Green 1 *	20	90	25	20	90	25
Yellow Clearance	3.0	4.6	4.4	3.0	5.2	3.8
Red Clearance	2.9	1.5	1.8	3.2	1.3	2.0
Walk 1 *	-	-	-	-	-	-
Don't Walk 1	-	-	-	-	-	-
Seconds Per Actuation *	-	2.5	-	-	2.5	-
Max Variable Initial *	-	40	-	-	40	-
Time Before Reduction *	-	15	-	-	15	-
Time To Reduce *	-	30	-	-	30	-
Minimum Gap	-	3.0	-	-	3.0	-
Recall Mode	-	MIN RECALL	-	-	MIN RECALL	-
Vehicle Call Memory	-	YELLOW	-	-	YELLOW	-
Dual Entry	-	- ON	-	-	-	ON
Simultaneous Gap	ON	ON	ON	ON	ON	ON

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND

PROPOSED		EXISTING
	Traffic Signal Head	
	Modified Signal Head	N/A
	Sign	
	Pedestrian Signal Head	
	Sign With Push Button & Sign	
	Signal Pole with Guy	
	Signal Pole with Sidewalk Guy	
	Inductive Loop Detector	
	Controller & Cabinet	
	Junction Box	
	2-in Underground Conduit	
N/A	Right of Way	
	Directional Arrow	
N/A	Construction Zone Drums	
N/A	Concrete Barrier	
	Construction Zone	

Signal Upgrade - Temporary 4 (Phase III)

NC 59 (South Main Street)

at
I-95 Bus./US 301 SB Ramp /
SR 2285 (Shipman Road)

Division 6	Cumberland County	Hope Mills
PLAN DATE:	September 2017	REVIEWED BY: ZMI

29	PREPARED BY: M.E.LeBlanc	REVIEWED BY:
----	--------------------------	--------------

REVISIONS	INIT.	DATE
-----------	-------	------

[illegible]

--	--	--	--	--

DOCUMENT NOT CONSIDERED
FINAL UNLESS ALL
SIGNATURES COMPLETED

REAL

Signed by: 11/28/2017


Erhan E. Elblanc 11/28/2017
DATE

G. INVENTORY NO. 06-0946T4

EDI MODEL 2018ECL-NC CONFLICT MONITOR

PROGRAMMING DETAIL

(remove jumpers and set switches as shown)




NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- Ensure that Red Enable is active at all times during normal operation.
- Connect serial cable from conflict monitor to comm. port 1 of 2070 controller. Ensure conflict monitor communicates with 2070.

INPUT FILE POSITION LAYOUT

(front view)



EX.: 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
ST = STOP TIME

⊗ Wired Input - Do not populate slot with detector card

NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Program phases 4 and 8 for Dual Entry.
- Enable Simultaneous Gap-Out for all Phases.
- Program phases 2 and 6 for Variable Initial and Gap Reduction.
- Program phases 2 and 6 for Startup In Green.
- Program phases 2 and 6 for Yellow Flash, and overlap 1 as Wag Overlaps.
- The cabinet and controller are part of the NC 59 Closed Loop System.

EQUIPMENT INFORMATION

CONTROLLER.....2070
CABINET.....332 W/ AUX
SOFTWARE.....ECONOLITE OASIS
CABINET MOUNT.....BASE
OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
LOAD SWITCHES USED.....S1,S2,S5,S7,S8,S11,AUX S1,AUX S4
PHASES USED.....1,2,4,5,6,8
OVERLAP "A".....1+2
OVERLAP "B".....NOT USED
OVERLAP "C".....5+6
OVERLAP "D".....NOT USED


INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
1A ¹	TB2-1,2	I1U	56	18	1	1	Y	Y			15
	-	J4U	48	10	26	6	Y	Y	Y		3
2B/S02	TB2-7,8	I2L	43	5	12	2/SYS	Y	Y			
4A	TB4-9,10	I6U	41	3	4	4	Y	Y			3
5A ²	TB3-1,2	J1U	55	17	5	5	Y	Y			15
	-	I4U	47	9	22	2	Y	Y	Y		3
5B	TB3-5,6	J2U	40	2	6	5	Y	Y			15
6B/S15	TB3-11,12	J3L	77	39	46	6/SYS	Y	Y			
8A	TB5-9,10	J6U	42	4	8	8	Y	Y			3
8B	TB5-11,12	J6L	46	8	18	8	Y	Y			15

¹Add jumper from I1-W to J4-W, on rear of input file.

²Add jumper from J1-W to I4-W, on rear of input file.

INPUT FILE POSITION LEGEND: J2L



SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	11★	21,22	NU	NU	41,42	NU	42	51★	61,62	NU	NU	81,82	NU	11★	NU	NU	51★	NU
RED		128			101			*	134			107						
YELLOW	*	129			102				135			108						
GREEN		130			103				136			109						
RED ARROW													A121			A114		
YELLOW ARROW							132						A122			A115		
FLASHING YELLOW ARROW													A123			A116		
GREEN ARROW	127						133	133										


NU = Not Used

* Denotes install load resistor. See load resistor installation detail this sheet.

★ See pictorial of head wiring in detail this sheet.

FYA SIGNAL WIRING DETAIL

(wire signal heads as shown)



NOTE


The sequence display for signal heads 11 and 51 requires special logic programming. See sheet 2 for programming instructions.

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-0946T4
DESIGNED: September 2017
SEALED: 11-28-17
REVISED: N/A

LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown below)

ACCEPTABLE VALUES	
VALUE (ohms)	WATTAGE
1.5K - 1.9K	25W (min)
2.0K - 3.0K	10W (min)




Electrical Detail - Sheet 1 of 2 - Temp.4 (Phase III)

ELECTRICAL AND PROGRAMMING DETAILS FOR:		NC 59 (South Main Street)	
Prepared In the Offices of:		at	
I-95 Bus./US 301 SB Ramp / SR 2285 (Shipman Road)		Division 6 Cumberland County Hope Mills	
PLAN DATE: November 2017		REVIEWED BY:	
PREPARED BY: James Peterson		REVIEWED BY:	
REVISIONS		INIT. DATE	

DOCUMENT NOT CONSIDERED
FINAL UNLESS ALL
SIGNATURES COMPLETED

SEAL



DocuSigned by: Keith M. Mims 12/1/2017


2FB0780E8C0D34A5 DATE

SIG. INVENTORY NO. 06-0946T4


LOGICAL I/O PROCESSOR PROGRAMMING DETAIL
TO PRODUCE SPECIAL FYA-PPLT SIGNAL SEQUENCE

(program controller as shown below)


- FROM MAIN MENU PRESS '2' (PHASE CONTROL), THEN '1' (PHASE CONTROL FUNCTIONS). SCROLL TO THE BOTTOM OF THE MENU AND ENABLE ACT LOGIC COMMANDS 1, 2, 3, 4, 5 AND 6.
- FROM MAIN MENU PRESS '6' (OUTPUTS), THEN '3' (LOGICAL I/O PROCESSOR).




NOTE: LOGIC FOR
PHASE 1 RED
CLEAR WHEN
TRANSITIONING
FROM PHASE 1
TO PHASE 2
(HEAD 11).




NOTE: LOGIC FOR
SWITCHING
FLASHING YELLOW
ARROW "OFF"
DURING PHASE 1
(HEAD 11).




NOTE: LOGIC FOR
YELLOW
ARROW
CLEARANCE
FROM PHASE 1
(HEAD 11).



NOTE: LOGIC FOR
PHASE 5 RED
CLEAR WHEN
TRANSITIONING
FROM PHASE 5
TO PHASE 6
(HEAD 51).



NOTE: LOGIC FOR
SWITCHING
FLASHING YELLOW
ARROW "OFF"
DURING PHASE 5
(HEAD 51).



NOTE: LOGIC FOR
YELLOW
ARROW
CLEARANCE
FROM PHASE 5
(HEAD 51).

LOGIC I/O PROCESSOR PROGRAMMING COMPLETE

OUTPUT REFERENCE SCHEDULE

OUTPUT 42 = Overlap C Red
OUTPUT 43 = Overlap C Yellow
OUTPUT 44 = Overlap C Green
OUTPUT 50 = Overlap A Red
OUTPUT 51 = Overlap A Yellow
OUTPUT 52 = Overlap A Green

OVERLAP PROGRAMMING DETAIL

(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS), THEN '1' (VEHICLE OVERLAP SETTINGS).

PAGE 1: VEHICLE OVERLAP 'A' SETTINGS
PHASE: 12345678910111213141516
VEH OVL PARENTS: XX
VEH OVL NOT VEH:
VEH OVL NOT PED:
VEH OVL GRN EXT:
STARTUP COLOR: _ RED _ YELLOW _ GREEN
FLASH COLORS: _ RED _ YELLOW X GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC).....0
YELLOW CLEAR (0=PARENT.3-25.5 SEC)...0.0
RED CLEAR (0=PARENT.0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)....0

← NOTICE GREEN FLASH

PRESS '+' TWICE


PAGE 1: VEHICLE OVERLAP 'C' SETTINGS
PHASE: 12345678910111213141516
VEH OVL PARENTS: XX
VEH OVL NOT VEH:
VEH OVL NOT PED:
VEH OVL GRN EXT:
STARTUP COLOR: _ RED _ YELLOW _ GREEN
FLASH COLORS: _ RED _ YELLOW X GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC).....0
YELLOW CLEAR (0=PARENT.3-25.5 SEC)...0.0
RED CLEAR (0=PARENT.0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)....0

← NOTICE GREEN FLASH

OVERLAP PROGRAMMING COMPLETE

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-0946T4
DESIGNED: September 2017
SEALED: 11-28-17
REVISED: N/A

Electrical Detail - Sheet 1 of 2 - Temp.4 (Phase III)



NC 59 (South Main Street)
at
I-95 Bus./US 301 SB Ramp /
SR 2285 (Shipman Road)


Division 6 Cumberland County Hope Mills

PLAN DATE: November 2017 REVIEWED BY:


PREPARED BY: James Peterson REVIEWED BY:

REVISIONS INIT. DATE

DOCUMENT NOT CONSIDERED
FINAL UNLESS ALL
SIGNATURES COMPLETED




PHASING DIAGRAM



SIGNAL FACE	PHASE					
	Ø 1 + 5	Ø 1 + 6	Ø 2 + 5	Ø 2 + 6	Ø 4 + 8	FLASH
11	←	←	←	←	←	Y
21,22	R	R	G	G	R	Y
41	R	R	R	R	G	R
42	R	R	R	R	G	R
51	←	←	←	←	←	Y
61,62	R	G	R	G	R	Y
81,82	R	R	R	R	G	R

SIGNAL FACE I.D.

All Heads L.E.D.




OASIS 2070 LOOP & DETECTOR INSTALLATION CHART									
INDUCTIVE LOOPS					DETECTOR PROGRAMMING				
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PHASE	CALLING	EXTENSION	STRETCH TIME	DELAY TIME
1A	6X40	0	2-4-2	Y	1	Y	Y	-	15
2A/S01	6X6	355	6	Y	2	Y	Y	-	Y
2B/S02	6X6	355	6	-	2	Y	Y	-	Y
4A	6X40	0	2-4-2	-	4	Y	Y	-	3
5A	6X40	0	2-4-2	Y	5	Y	Y	-	15
5B	6X40	0	2-4-2	-	5	Y	Y	-	15
6A/S03	6X6	355	6	Y	6	Y	Y	-	Y
6B/S04	6X6	355	6	-	6	Y	Y	-	Y
8A	6X40	0	2-4-2	-	8	Y	Y	-	3
8B	6X40	0	2-4-2	-	8	Y	Y	-	15

5 Phase Fully Actuated NC 59 Closed Loop System

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 1 and/or phase 5 may be lagged.
- Renumber existing system detector numbered S15 to S04 as shown.
- Set all detector units to presence mode.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Closed loop system data: Controller Asset # 0946.



OASIS 2070 TIMING CHART						
FEATURE	PHASE					
	1	2	4	5	6	8
Min Green 1 *	7	12	7	7	12	7
Extension 1 *	2.0	6.0	2.0	2.0	6.0	2.0
Max Green 1 *	20	90	25	20	90	25
Yellow Clearance	3.0	5.2	4.4	3.0	5.2	3.8
Red Clearance	2.6	1.5	1.5	3.1	1.5	2.0
Walk 1 *	-	-	-	-	-	-
Don't Walk 1	-	-	-	-	-	-
Seconds Per Actuation *	-	1.5	-	-	1.5	-
Max Variable Initial *	-	40	-	-	40	-
Time Before Reduction *	-	15	-	-	15	-
Time To Reduce *	-	30	-	-	30	-
Minimum Gap	-	3.0	-	-	3.0	-
Recall Mode	-	MIN RECALL	-	-	MIN RECALL	-
Vehicle Call Memory	-	YELLOW	-	-	YELLOW	-
Dual Entry	-	-	ON	-	-	ON
Simultaneous Gap	ON	ON	ON	ON	ON	ON

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.


PROPOSED		EXISTING	
○→	Traffic Signal Head	●→	N/A
●→	Modified Signal Head	●→	N/A
⊥	Sign	⊥	N/A
⊥	Pedestrian Signal Head With Push Button & Sign	⊥	N/A
⊥	Signal Pole with Guy	⊥	N/A
⊥	Signal Pole with Sidewalk Guy	⊥	N/A
⊥	Inductive Loop Detector	⊥	N/A
⊥	Controller & Cabinet	⊥	N/A
⊥	Junction Box	⊥	N/A
⊥	2-in Underground Conduit	⊥	N/A
⊥	Right of Way	⊥	N/A
⊥	Directional Arrow	⊥	N/A
⊥	Metal Strain Pole	⊥	N/A
⊥	Construction Zone Drums	⊥	N/A
⊥	Concrete Barrier	⊥	N/A
⊥	Construction Zone	⊥	N/A

Signal Upgrade - Final

Prepared In the Offices of: TRANSPORTATION MOBILITY AND SAFETY DIVISION DEPARTMENT OF TRANSPORTATION Signal Design Section 750 N. Greenfield Pkwy, Garner, NC 27529	NC 59 (South Main Street) at I-95 Bus./US 301 SB Ramp / SR 2285 (Shipman Road) Division 6 Cumberland County Hope Mills PLAN DATE: September 2017 PREPARED BY: Jeff Spence REVIEWED BY: MEL	DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED SEAL NORTH CAROLINA PROFESSIONAL ENGINEER SEAL 042608 MEGAN E. LEBLANC 11/28/2017 SIC. INVENTORY NO. 06-0946
---	---	--

PROGRAMMING DETAIL

WD ENABLE  SW2



■ = DENOTES POSITION
OF SWITCH

NOTES:

1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
3. Ensure that Red Enable is active at all times during normal operation.
4. Connect serial cable from conflict monitor to comm. port 1 of 2070 controller. Ensure conflict monitor communicates with 2070.

1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
2. Program phases 4 and 8 for Dual Entry.
3. Enable Simultaneous Gap-Out for all Phases.
4. Program phases 2 and 6 for Variable Initial and Gap Reduction.
5. Program phases 2 and 6 for Startup In Green.
6. Program phases 2 and 6 for Yellow Flash, overlap 1 as Wag Overlaps.
7. The cabinet and controller are part of the NC 59 Closed Loop System.

```

CONTROLLER.....2070
CABINET.....332 W/ AUX
SOFTWARE.....ECONOLITE OASIS
CABINET MOUNT.....BASE
OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
LOAD SWITCHES USED.....S1,S2,S5,S7,S8,S11,AUX S1,AUX S4
PHASES USED.....1,2,4,5,6,8
OVERLAP "A".....1+2
OVERLAP "B".....NOT USED
OVERLAP "C".....5+6
OVERLAP "D".....NOT USED

```

[illegible]

NU = Not Used

* Denotes install load resistor. See load resistor installation detail this sheet.

★ See pictorial of head wiring in detail this sheet.

(front view)

EX.: 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
ST = STOP TIME


⊗ Wired Input - Do not populate slot with detector card

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
1A ¹	TB2-1,2	I1U	56	18	1	1	Y	Y			15
	-	J4U	48	10	26	6	Y	Y	Y		3
2A/S01	TB2-5,6	I2U	39	1	2	2/SYS	Y	Y			
2B/S02	TB2-7,8	I2L	43	5	12	2/SYS	Y	Y			
4A	TB4-9,10	I6U	41	3	4	4	Y	Y			3
5A ²	TB3-1,2	J1U	55	17	5	5	Y	Y			15
	-	I4U	47	9	22	2	Y	Y	Y		3
5B	TB3-5,6	J2U	40	2	6	5	Y	Y			15
6A/S03	TB3-9,10	J3U	64	26	36	6/SYS	Y	Y			
6B/S04	TB3-11,12	J3L	77	39	46	6/SYS	Y	Y			
8A	TB5-9,10	J6U	42	4	8	8	Y	Y			3
8B	TB5-11,12	J6L	46	8	18	8	Y	Y			15

¹ Add jumper from I1-W to J4-W, on rear of input file.

² Add jumper from J1-W to I4-W, on rear of input file.

INPUT FILE POSITION LEGEND: J2L



(install resistors as shown below)

Diagram illustrating the Phase 1 Yellow Field Terminal (126) and Phase 5 Red Field Terminal (131). Both terminals are connected to an AC source, indicated by the 'AC-' label and the wavy line symbol.

Electrical Detail - Sheet 1 of 2 - Final

NC 59 (South Main Street)
at
I-95 Bus./US 301 SB Ramp /
SR 2285 (Shipman Road)


Division 6 Cumberland County Hope Mills

PLAN DATE: November 2017	REVIEWED BY:
--------------------------	--------------

REVISIONS	INIT.	DATE
-----------	-------	------

**DOCUMENT NOT CONSIDERED
FINAL UNLESS ALL
SIGNATURES COMPLETED**

SEAL



DocuSigned by:  12/1/2017


Keith M. Mims 12/1/2017

SIC INVENTORY NO 06-0916


LOGICAL I/O PROCESSOR PROGRAMMING DETAIL
TO PRODUCE SPECIAL FYA-PPLT SIGNAL SEQUENCE

(program controller as shown below)


- FROM MAIN MENU PRESS '2' (PHASE CONTROL), THEN '1' (PHASE CONTROL FUNCTIONS). SCROLL TO THE BOTTOM OF THE MENU AND ENABLE ACT LOGIC COMMANDS 1, 2, 3, 4, 5 AND 6.
- FROM MAIN MENU PRESS '6' (OUTPUTS), THEN '3' (LOGICAL I/O PROCESSOR).




NOTE: LOGIC FOR
PHASE 1 RED
CLEAR WHEN
TRANSITIONING
FROM PHASE 1
TO PHASE 2
(HEAD 11).




NOTE: LOGIC FOR
SWITCHING
FLASHING YELLOW
ARROW "OFF"
DURING PHASE 1
(HEAD 11).




NOTE: LOGIC FOR
YELLOW
ARROW
CLEARANCE
FROM PHASE 1
(HEAD 11).



NOTE: LOGIC FOR
PHASE 5 RED
CLEAR WHEN
TRANSITIONING
FROM PHASE 5
TO PHASE 6
(HEAD 51).



NOTE: LOGIC FOR
SWITCHING
FLASHING YELLOW
ARROW "OFF"
DURING PHASE 5
(HEAD 51).



NOTE: LOGIC FOR
YELLOW
ARROW
CLEARANCE
FROM PHASE 5
(HEAD 51).

LOGIC I/O PROCESSOR PROGRAMMING COMPLETE

OUTPUT REFERENCE SCHEDULE

OUTPUT 42 = Overlap C Red
OUTPUT 43 = Overlap C Yellow
OUTPUT 44 = Overlap C Green
OUTPUT 50 = Overlap A Red
OUTPUT 51 = Overlap A Yellow
OUTPUT 52 = Overlap A Green

OVERLAP PROGRAMMING DETAIL

(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS), THEN '1' (VEHICLE OVERLAP SETTINGS).

PAGE 1: VEHICLE OVERLAP 'A' SETTINGS
PHASE: 12345678910111213141516
VEH OVL PARENTS: XX
VEH OVL NOT VEH:
VEH OVL NOT PED:
VEH OVL GRN EXT:
STARTUP COLOR: _ RED _ YELLOW _ GREEN
FLASH COLORS: _ RED _ YELLOW X GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC).....0
YELLOW CLEAR (0=PARENT.3-25.5 SEC)...0.0
RED CLEAR (0=PARENT.0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)....0

← NOTICE GREEN FLASH

PRESS '+' TWICE

PAGE 1: VEHICLE OVERLAP 'C' SETTINGS
PHASE: 12345678910111213141516
VEH OVL PARENTS: XX
VEH OVL NOT VEH:
VEH OVL NOT PED:
VEH OVL GRN EXT:
STARTUP COLOR: _ RED _ YELLOW _ GREEN
FLASH COLORS: _ RED _ YELLOW X GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC).....0
YELLOW CLEAR (0=PARENT.3-25.5 SEC)...0.0
RED CLEAR (0=PARENT.0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)....0

← NOTICE GREEN FLASH

OVERLAP PROGRAMMING COMPLETE


THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-0946
DESIGNED: September 2017
SEALED: 11-28-17
REVISED: N/A

Electrical Detail - Sheet 2 of 2 - Final

ELECTRICAL AND PROGRAMMING
DETAILS FOR:

NC 59 (South Main Street)

Prepared In the Offices of:



750 N. Greenfield Pkwy, Garner, NC 27529

at
I-95 Bus./US 301 SB Ramp /
SR 2285 (Shipman Road)

Division 6 Cumberland County Hope Mills


PLAN DATE: November 2017 REVIEWED BY:

PREPARED BY: James Peterson REVIEWED BY:

REVISIONS INIT. DATE

DOCUMENT NOT CONSIDERED
FINAL UNLESS ALL
SIGNATURES COMPLETED

SEAL




DocuSigned by: Keith M. Mims 12/1/2017

2F80796E8CD34A5 DATE

SIG. INVENTORY NO. 06-0946

PHASING DIAGRAM




PHASING DIAGRAM DETECTION LEGEND

- DETECTED MOVEMENT
- UNDETECTED MOVEMENT (OVERLAP)
- UNSIGNALIZED MOVEMENT
- PEDESTRIAN MOVEMENT

SIGNAL FACE	PHASE		
	Ø 2+6	Ø 8	FLASH
21,22,23	G	R	Y
61,62	G	R	Y
81,82	R	G	R

SIGNAL FACE I.D.

All Heads L.E.D.




OASIS 2070 LOOP & DETECTOR INSTALLATION CHART												
INDUCTIVE LOOPS				DETECTOR PROGRAMMING								
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PHASE	CALLING	EXTENSION	FULL TIME DELAY	STRETCH TIME	DELAY TIME	SYSTEM LOOP	NEW CARD
2A/S03	6X6	275	EXIST	-	2	Y	Y	-	-	-	Y	-
2B	6X60	0	2-4-2	-	DISCONNECT							-
6A/S04	6X6	0	EXIST	-	6	Y	Y	-	-	-	Y	-
6B	6X60	300	2-4-2	-	6	Y	Y	Y	-	3	-	-
8A	6X60	0	2-4-2	-	8	Y	Y	-	-	10	-	-
8B	6X6	0	EXIST	-	8	Y	Y	-	-	15	-	-

2 Phase
Fully Actuated
NC 59 Closed Loop System

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Reposition existing heads numbered 21 and 22 as shown.
- Remove existing heads numbered 41 and 42.
- Pavement markings existing.
- Set all detector units to presence mode.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Closed loop system data:
Master Asset #10614
Controller Asset #0955.



OASIS 2070 TIMING CHART			
FEATURE	PHASE		
	2	6	8
Min Green 1 *	12	12	7
Extension 1 *	6.0	6.0	2.0
Max Green 1 *	90	90	25
Yellow Clearance	4.7	4.4	3.0
Red Clearance	1.2	1.3	2.4
Walk 1 *	-	-	-
Don't Walk 1	-	-	-
Seconds Per Actuation *	2.5	2.5	-
Max Variable Initial *	34	34	-
Time Before Reduction *	15	15	-
Time To Reduce *	30	30	-
Minimum Gap	3.2	3.2	-
Recall Mode	MIN RECALL	MIN RECALL	-
Vehicle Call Memory	YELLOW	YELLOW	-
Dual Entry	-	-	-
Simultaneous Gap	ON	ON	ON

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND

PROPOSED		EXISTING
○→	Traffic Signal Head	●→
●→	Modified Signal Head	N/A
⊥	Sign	⊥
⊥	Pedestrian Signal Head	⊥
⊥	With Push Button & Sign	⊥
⊥	Signal Pole with Guy	⊥
⊥	Signal Pole with Sidewalk Guy	⊥
□	Inductive Loop Detector	□
□	Master Controller & Cabinet	□
□	Junction Box	□
---	2-in Underground Conduit	---
N/A	Right of Way	---
→	Directional Arrow	→
Ⓐ	"YIELD" Sign (R1-2)	Ⓐ
N/A	Construction Zone Drums	●

Signal Upgrade - Temp 1 (Phase I)

Prepared in the Offices of:

Transportation Mobility and Safety Division

DEPARTMENT OF TRANSPORTATION

STATE OF NORTH CAROLINA

Signal Design Section

750 N. Greenfield Pkwy, Garner, NC 27529

NC 59 (Chicken Foot Road)
at
I-95 Bus. /US 301 NB Ramps/
SR 2284 (State Road)

Division 6 Cumberland County Hope Mills

PLAN DATE: October 2017 REVIEWED BY: MEL

PREPARED BY: Jeff Spence REVIEWED BY:

REVISIONS

SCALE 0 40
1"=40'

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SEAL

PROFESSIONAL ENGINEER

SEAL 042608

CHRYSTIAN E. LEBLANC

DocuSigned by: *Myghave L. Blane* 11/28/2017

SIG. INVENTORY NO. 06-095511

(remove jumper and set switches as shown)

ON OFF



1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
2. Make sure jumpers SEL2-SEL5 are present on the monitor board.

■ = DENOTES POSITION
OF SWITCH

1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
2. Ensure that Red Enable is active at all times during normal operation. To prevent Red Failures on unused monitor channels, tie unused red monitor inputs 1,3,4,5, 7,9,10,11,12,13,14,15 & 16 to load switch AC+ per the cabinet manufacturer's instructions.
3. Enable Simultaneous Gap-Out for all Phases.
4. Program phases 2 and 6 for Variable Initial and Gap Reduction.
5. Program phases 2 and 6 for Startup In Green.
6. Program phases 2 and 6 for Yellow Flash.
7. The cabinet and controller are part of the NC 59 Closed Loop System.

```

CONTROLLER.....2070
CABINET.....332 W/AUX
SOFTWARE.....ECONOLITE OASIS
CABINET MOUNT.....BASE
OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
LOAD SWITCHES USED.....S2,S6,S8
PHASES USED.....2,6,8
OVERLAP "A".....NOT USED
OVERLAP "B".....NOT USED
OVERLAP "C".....NOT USED
OVERLAP "D".....NOT USED

```

[illegible]

NU = Not Used


(front view)



FS = FLASH SENSE
ST = STOP TIME

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
2A/S03	TB2-5,6	I2U	39	1	2	2/SYS	Y	Y			
6A/S04	TB3-5,6	J2U	40	2	6	6/SYS	Y	Y			
6B	TB3-7,8	J2L	44	6	16	6	Y	Y	Y		3
8A	TB5-9,10	J6U	42	4	8	8	Y	Y			10
8B	TB5-11,12	J6L	46	8	18	8	Y	Y			15

INPUT FILE POSITION LEGEND: J2L



THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-0955T1
DESIGNED: October 2017
SEALED: 11-28-17
REVISED: N/A

Electrical Detail - Temp. 1 (Phase I)

NC 59 (Chicken Foot Road)
at
I-95 Bus./US 301 NB Ramps /
SR 2284 (State Road)

Division 6 Cumberland County Hope Mills

PLAN DATE: November 2017

PREPARED BY: James Peterson

REVISIONS:

DATE


2/1/2017

-2F80786E8CD34A5

SIG. INVENTORY

01-DEC-2017 12:08
3:*ITS&SI*ITS Signals*Workgroups*Sig Men*Peterson*060955_sm_ele_xxx.dgn
itpeterson

PHASING DIAGRAM



SIGNAL FACE	PHASE		
	02+6	08	FLASH
21,22,23	G	R	Y
61,62	G	R	Y
81,82	R	G	R



OASIS 2070 LOOP & DETECTOR INSTALLATION CHART												
INDUCTIVE LOOPS				DETECTOR PROGRAMMING								
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PHASE	CALLING	EXTENSION	FULL TIME DELAY	STRETCH TIME	DELAY TIME	SYSTEM LOOP	NEW CARD
2A	6X6	355	6	Y	2	Y	Y	-	-	-	-	Y
6B/S08	6X6	350	6	Y	6	Y	Y	-	-	-	Y	Y
8A	6X40	0	2-4-2	Y	8	Y	Y	-	-	-	-	Y
8B	6X40	0	2-4-2	Y	8	Y	Y	-	-	15	-	Y

2 Phase
Fully Actuated
NC 59 Closed Loop System

- PHASING DIAGRAM DETECTION LEGEND
- DETECTED MOVEMENT
 - UNDETECTED MOVEMENT (OVERLAP)
 - UNSIGNALIZED MOVEMENT
 - PEDESTRIAN MOVEMENT

SIGNAL FACE I.D.

All Heads L.E.D.



OASIS 2070 TIMING CHART			
FEATURE	PHASE		
	2	6	8
Min Green 1 *	14	14	7
Extension 1 *	6.0	6.0	2.0
Max Green 1 *	90	90	25
Yellow Clearance	4.7	5.0	3.0
Red Clearance	1.0	1.1	2.3
Walk 1 *	-	-	-
Don't Walk 1	-	-	-
Seconds Per Actuation *	2.5	2.5	-
Max Variable Initial *	40	40	-
Time Before Reduction *	15	15	-
Time To Reduce *	30	30	-
Minimum Gap	3.0	3.0	-
Recall Mode	MIN RECALL	MIN RECALL	-
Vehicle Call Memory	YELLOW	YELLOW	-
Dual Entry	-	-	-
Simultaneous Gap	ON	ON	ON

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Set all detector units to presence mode.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Closed loop system data: Master Asset #10614 Controller Asset #0955.

LEGEND

PROPOSED	EXISTING

Signal Upgrade - Temp 2 (Phase II-3)

Prepared in the Offices of:
TRANSPORTATION MOBILITY AND SAFETY DIVISION
NORTH CAROLINA DEPARTMENT OF TRANSPORTATION
Signal Design Section
750 N. Greenfield Pkwy, Garner, NC 27529


NC 59 (Chicken Foot Road)
at
I-95 Bus. / US 301 NB Ramps /
SR 2284 (State Road)
Division 6 Cumberland County Hope Mills
PLAN DATE: October 2017
PREPARED BY: Meghan LeBlanc
REVIEWED BY: ZWL

SCALE
0 40
1"=40'

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED
SEAL
NORTH CAROLINA PROFESSIONAL ENGINEER
MEGHAN E. LEBLANC
042608
11/28/2017
SIG. INVENTORY NO. 06-095512

EDI MODEL 2018ECL-NC CONFLICT MONITOR
PROGRAMMING DETAIL

(remove jumper and set switches as shown)



NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Enable Simultaneous Gap-Out for all Phases.
- Program phases 2 and 6 for Variable Initial and Gap Reduction.
- Program phases 2 and 6 for Startup In Green.
- Program phases 2 and 6 for Yellow Flash.
- The cabinet and controller are part of the NC 59 Closed Loop System.

EQUIPMENT INFORMATION

CONTROLLER.....2070
CABINET.....332 W/ AUX
SOFTWARE.....ECONOLITE OASIS
CABINET MOUNT.....BASE
OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
LOAD SWITCHES USED.....S2,S8,S11
PHASES USED.....2,6,8
OVERLAP 'A'.....NOT USED
OVERLAP 'B'.....NOT USED
OVERLAP 'C'.....NOT USED
OVERLAP 'D'.....NOT USED


SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
EMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	NU	21,22	NU	NU	NU	NU	NU	61,62	NU	NU	81,82	NU	NU	NU	NU	NU	NU	NU
RED		128						134			107							
YELLOW		129						135			108							
GREEN		130						136			109							
RED ARROW																		
YELLOW ARROW																		
GREEN ARROW																		

NU = Not Used

INPUT FILE POSITION LAYOUT


(front view)



INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
2A	TB2-5,6	I2U	39	1	2	2	Y	Y			
6B/S08	TB3-7,8	J2L	44	6	16	6/SYS	Y	Y			
8A	TB5-9,10	J6U	42	4	8	8	Y	Y			
8B	TB5-11,12	J6L	46	8	18	8	Y	Y			15

INPUT FILE POSITION LEGEND: J2L




THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-0955T2
DESIGNED: October 2017
SEALED: 11-28-17
REVISED: N/A

Electrical Detail - Temp. 2 (Phase II-3)

ELECTRICAL AND PROGRAMMING DETAILS FOR:		NC 59 (Chicken Foot Road) at I-95 Bus./US 301 NB Ramps / SR 2284 (State Road)		DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED	
Prepared In the Offices of:		Division 6 Cumberland County Hope Mills		SEAL	
PLAN DATE: November 2017		REVIEWED BY:		NORTH CAROLINA PROFESSIONAL SEAL 036880	
PREPARED BY: James Peterson		REVIEWED BY:		ENGINEER KEITH M. MINS	
REVISIONS		INIT.		DATE	
750 N. Greenfield Pkwy, Garner, NC 27529		2F00780E6CD34A5		12/1/2017	
				DATE	
				SIG. INVENTORY NO. 06-0955T2	

PHASING DIAGRAM



SIGNAL FACE	PHASE		
	02+6	08	FLASH
21,22,23	G	R	Y
61,62	G	R	Y
81,82	R	G	R

OASIS 2070 LOOP & DETECTOR INSTALLATION CHART												
INDUCTIVE LOOPS				DETECTOR PROGRAMMING								
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PHASE	CALLING	EXTENSION	FULL TIME DELAY	STRETCH TIME	DELAY TIME	SYSTEM LOOP	NEW CARD
2A	6X6	355	6	-	2	Y	Y	-	-	-	-	-
6B/S08	6X6	350	6	-	6	Y	Y	-	-	-	Y	-
8A	6X40	0	2-4-2	-	8	Y	Y	-	-	3	-	-
8B	6X40	0	2-4-2	-	8	Y	Y	-	-	15	-	-



2 Phase
Fully Actuated
NC 59 Closed Loop System

PHASING DIAGRAM DETECTION LEGEND

- DETECTED MOVEMENT
- UNDETECTED MOVEMENT (OVERLAP)
- UNSIGNALIZED MOVEMENT
- PEDESTRIAN MOVEMENT

SIGNAL FACE I.D.

All Heads L.E.D.



OASIS 2070 TIMING CHART

FEATURE	PHASE		
	2	6	8
Min Green 1 *	14	14	7
Extension 1 *	6.0	6.0	2.0
Max Green 1 *	90	90	25
Yellow Clearance	5.0	5.0	3.0
Red Clearance	1.0	1.1	2.3
Walk 1 *	-	-	-
Don't Walk 1	-	-	-
Seconds Per Actuation *	2.5	2.5	-
Max Variable Initial *	40	40	-
Time Before Reduction *	15	15	-
Time To Reduce *	30	30	-
Minimum Gap	3.0	3.0	-
Recall Mode	MIN RECALL	MIN RECALL	-
Vehicle Call Memory	YELLOW	YELLOW	-
Dual Entry	-	-	-
Simultaneous Gap	ON	ON	ON

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND

PROPOSED	EXISTING
Traffic Signal Head	N/A
Modified Signal Head	N/A
Sign	N/A
Pedestrian Signal Head With Push Button & Sign	N/A
Signal Pole with Guy	N/A
Signal Pole with Sidewalk Guy	N/A
Inductive Loop Detector	N/A
Master Controller & Cabinet	N/A
Junction Box	N/A
2-in Underground Conduit	N/A
Right of Way	N/A
Directional Arrow	N/A
Construction Zone Drums	N/A
Concrete Barrier	N/A
Construction Zone	N/A

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Set all detector units to presence mode.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Closed loop system data: Master Asset #10614 Controller Asset #0955.

Signal Upgrade - Temp 3 (Phase II-4)

Prepared in the Offices of:

TRANSPORTATION MOBILITY AND SAFETY DIVISION
DEPARTMENT OF TRANSPORTATION
SIGNAL DESIGN SECTION

750 N. Greenfield Pkwy, Garner, NC 27529

NC 59 (Chicken Foot Road)
at
I-95 Bus. / US 301 NB Ramps /
SR 2284 (State Road)

Division 6 Cumberland County Hope Mills

PLAN DATE: October 2017 REVIEWED BY: ZWL

PREPARED BY: Meghan LeBlanc REVIEWED BY:

REVISIONS

SCALE: 0 40
1"=40'

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED


SEAL
NORTH CAROLINA
PROFESSIONAL ENGINEER
MEGHAN E. LEBLANC
042608

DocuSigned by:
Meghan E. LeBlanc
11/28/2017

SIG. INVENTORY NO. 06-095513

EDI MODEL 2018ECL-NC CONFLICT MONITOR
PROGRAMMING DETAIL

(remove jumper and set switches as shown)



NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Enable Simultaneous Gap-Out for all Phases.
- Program phases 2 and 6 for Variable Initial and Gap Reduction.
- Program phases 2 and 6 for Startup In Green.
- Program phases 2 and 6 for Yellow Flash.
- The cabinet and controller are part of the NC 59 Closed Loop System.

EQUIPMENT INFORMATION

CONTROLLER.....2070
CABINET.....332 W/ AUX
SOFTWARE.....ECONOLITE OASIS
CABINET MOUNT.....BASE
OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
LOAD SWITCHES USED.....S2,S8,S11
PHASES USED.....2,6,8
OVERLAP 'A'.....NOT USED
OVERLAP 'B'.....NOT USED
OVERLAP 'C'.....NOT USED
OVERLAP 'D'.....NOT USED


SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
EMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	NU	21,22	NU	NU	NU	NU	NU	61,62	NU	NU	81,82	NU	NU	NU	NU	NU	NU	NU
RED		128						134			107							
YELLOW		129						135			108							
GREEN		130						136			109							
RED ARROW																		
YELLOW ARROW																		
GREEN ARROW																		

NU = Not Used

INPUT FILE POSITION LAYOUT


(front view)



INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
2A	TB2-5,6	I2U	39	1	2	2	Y	Y			
6B/S08	TB3-7,8	J2L	44	6	16	6/SYS	Y	Y			
8A	TB5-9,10	J6U	42	4	8	8	Y	Y			3
8B	TB5-11,12	J6L	46	8	18	8	Y	Y			15

INPUT FILE POSITION LEGEND: J2L




THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-0955T3
DESIGNED: October 2017
SEALED: 11-28-17
REVISED: N/A

Electrical Detail - Temp. 3 (Phase II-4)

ELECTRICAL AND PROGRAMMING DETAILS FOR:		NC 59 (Chicken Foot Road) at I-95 Bus./US 301 NB Ramps / SR 2284 (State Road)		DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED	
Prepared In the Offices of:		Division 6 Cumberland County Hope Mills		SEAL	
PLAN DATE: November 2017		REVIEWED BY:		NORTH CAROLINA PROFESSIONAL SEAL 036880	
PREPARED BY: James Peterson		REVIEWED BY:		ENGINEER KEITH M. MINS	
REVISIONS		INIT.		DATE	
750 N. Greenfield Pkwy, Garner, NC 27529				DocuSigned by: Keith M. Mins 12/1/2017	
				DATE	
				SIG. INVENTORY NO. 06-0955T3	

PHASING DIAGRAM




PHASING DIAGRAM DETECTION LEGEND

- DETECTED MOVEMENT
- UNDETECTED MOVEMENT (OVERLAP)
- UNSIGNALIZED MOVEMENT
- PEDESTRIAN MOVEMENT

SIGNAL FACE	PHASE		
	02+6	08	FLASH
21,22,23	G	R	Y
61,62	G	R	Y
81,82	R	G	R

SIGNAL FACE I.D.

All Heads L.E.D.



21, 22
62, 63
81, 82

Metal Pole #1
Std. Case S35H2
Sta. 60+91 -L- +/-
58' LT +/-

Metal Pole #2
Std. Case S35H2
Sta. 62+26 -L- +/-
59' LT +/-

Metal Pole #3
Std. Case S35H2
Sta. 62+32 -L- +/-
68' RT +/-

Metal Pole #4
Std. Case S35H2
Sta. 60+90 -L- +/-
67' RT +/-

OASIS 2070 LOOP & DETECTOR INSTALLATION CHART												
INDUCTIVE LOOPS					DETECTOR PROGRAMMING							
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PHASE	CALLING	EXTENSION	DELAY FULL TIME	STRETCH TIME	DELAY TIME	SYSTEM LOOP	NEW CARD
2B/S06	6X6	355	6	Y	2	Y	Y	-	-	-	Y	Y
6B/S08	6X6	350	6	-	6	Y	Y	-	-	-	Y	-
8A	6X40	0	2-4-2	Y	8	Y	Y	-	-	3	-	-
8B	6X40	0	2-4-2	Y	8	Y	Y	-	-	15	-	-

2 Phase
Fully Actuated
NC 59 Closed Loop System

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Set all detector units to presence mode.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Closed loop system data: Master Asset #10614 Controller Asset #0955.

OASIS 2070 TIMING CHART

FEATURE	PHASE		
	2	6	8
Min Green 1 *	12	14	7
Extension 1 *	6.0	6.0	2.0
Max Green 1 *	90	90	25
Yellow Clearance	5.0	5.0	3.0
Red Clearance	1.2	1.1	3.2
Walk 1 *	-	-	-
Don't Walk 1	-	-	-
Seconds Per Actuation *	2.5	2.5	-
Max Variable Initial *	40	40	-
Time Before Reduction *	15	15	-
Time To Reduce *	30	30	-
Minimum Gap	3.0	3.0	-
Recall Mode	MIN RECALL	MIN RECALL	-
Vehicle Call Memory	YELLOW	YELLOW	-
Dual Entry	-	-	-
Simultaneous Gap	ON	ON	ON

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND

PROPOSED	EXISTING
Traffic Signal Head	N/A
Modified Signal Head	N/A
Sign	N/A
Pedestrian Signal Head With Push Button & Sign	N/A
Signal Pole with Guy	N/A
Signal Pole with Sidewalk Guy	N/A
Inductive Loop Detector	N/A
Master Controller & Cabinet	N/A
Junction Box	N/A
2-in Underground Conduit	N/A
Right of Way	N/A
Directional Arrow	N/A
Construction Zone Drums	N/A
Concrete Barrier	N/A
Construction Zone	N/A

Signal Upgrade - Temp 4 (Phase III)

Prepared in the Offices of:

750 N. Greenfield Pkwy, Garner, NC 27529

TRANSPORTATION MOBILITY AND SAFETY DIVISION
DEPARTMENT OF TRANSPORTATION
SIGNAL DESIGN SECTION

NC 59 (Chicken Foot Road)
at
I-95 Bus. / US 301 NB Ramps /
SR 2284 (State Road)

Division 6 Cumberland County Hope Mills

PLAN DATE: October 2017 REVIEWED BY: ZWL

PREPARED BY: Meghan LeBlanc REVIEWED BY:

REVISIONS

SCALE 0 40
1"=40'

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED


SEAL
NORTH CAROLINA
PROFESSIONAL ENGINEER
MEGHAN E. LEBLANC
042608

DocuSigned by:
Meghan E. LeBlanc 11/28/2017

SIG. INVENTORY NO. 06-095514

EDI MODEL 2018ECL-NC CONFLICT MONITOR
PROGRAMMING DETAIL

(remove jumper and set switches as shown)



NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Enable Simultaneous Gap-Out for all Phases.
- Program phases 2 and 6 for Variable Initial and Gap Reduction.
- Program phases 2 and 6 for Startup In Green.
- Program phases 2 and 6 for Yellow Flash.
- The cabinet and controller are part of the NC 59 Closed Loop System.

EQUIPMENT INFORMATION

CONTROLLER.....2070
CABINET.....332 W/ AUX
SOFTWARE.....ECONOLITE OASIS
CABINET MOUNT.....BASE
OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
LOAD SWITCHES USED.....S2,S8,S11
PHASES USED.....2,6,8
OVERLAP 'A'.....NOT USED
OVERLAP 'B'.....NOT USED
OVERLAP 'C'.....NOT USED
OVERLAP 'D'.....NOT USED

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
EMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	NU	21,22	NU	NU	NU	NU	NU	62,63	NU	NU	81,82	NU	NU	NU	NU	NU	NU	NU
RED		128						134			107							
YELLOW		129						135			108							
GREEN		130						136			109							
RED ARROW																		
YELLOW ARROW																		
GREEN ARROW																		

NU = Not Used

INPUT FILE POSITION LAYOUT

(front view)

	1	2	3	4	5	6	7	8	9	10	11	12	13	14
FILE "I"	S -OR- -<-v- ->-v- -<-v- ->-v-	NOT USED Ø2/SYS 2B/S06	S -OR- -<-v- ->-v- -<-v- ->-v-	S -OR- -<-v- ->-v- -<-v- ->-v-	S -OR- -<-v- ->-v- -<-v- ->-v-	S -OR- -<-v- ->-v- -<-v- ->-v-	S -OR- -<-v- ->-v- -<-v- ->-v-	S -OR- -<-v- ->-v- -<-v- ->-v-	S -OR- -<-v- ->-v- -<-v- ->-v-	S -OR- -<-v- ->-v- -<-v- ->-v-	S -OR- -<-v- ->-v- -<-v- ->-v-	S -OR- -<-v- ->-v- -<-v- ->-v-	S -OR- -<-v- ->-v- -<-v- ->-v-	FS DC ISOLATOR ST DC ISOLATOR
FILE "J"	S -OR- -<-v- ->-v- -<-v- ->-v-	NOT USED Ø6/SYS 6B/S08	S -OR- -<-v- ->-v- -<-v- ->-v-	S -OR- -<-v- ->-v- -<-v- ->-v-	S -OR- -<-v- ->-v- -<-v- ->-v-	Ø 8 8A Ø 8 8B	S -OR- -<-v- ->-v- -<-v- ->-v-	S -OR- -<-v- ->-v- -<-v- ->-v-	S -OR- -<-v- ->-v- -<-v- ->-v-	S -OR- -<-v- ->-v- -<-v- ->-v-	S -OR- -<-v- ->-v- -<-v- ->-v-	S -OR- -<-v- ->-v- -<-v- ->-v-	S -OR- -<-v- ->-v- -<-v- ->-v-	S -OR- -<-v- ->-v- -<-v- ->-v-

EX. : 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
ST = STOP TIME

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
2B/S06	TB2-7,8	I2L	43	5	12	2/SYS	Y	Y			
6B/S08	TB3-5,6	J2U	40	2	6	6/SYS	Y	Y			
8A	TB5-9,10	J6U	42	4	8	8	Y	Y			3
8B	TB5-11,12	J6L	46	8	18	8	Y	Y			15

INPUT FILE POSITION LEGEND: J2L


FILE J
SLOT 2
LOWER

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-0955T4
DESIGNED: October 2017
SEALED: 11-28-17
REVISED: N/A

Electrical Detail - Temp. 4 (Phase III)

ELECTRICAL AND PROGRAMMING
DETAILS FOR:

Prepared In the Offices of:



750 N. Greenfield Pkwy, Garner, NC 27529

NC 59 (Chicken Foot Road)
at
I-95 Bus./US 301 NB Ramps /
SR 2284 (State Road)

Division 6 Cumberland County Hope Mills

PLAN DATE: November 2017 REVIEWED BY:

PREPARED BY: James Peterson REVIEWED BY:


REVISIONS

INIT.

DATE

DOCUMENT NOT CONSIDERED
FINAL UNLESS ALL
SIGNATURES COMPLETED

SEAL




DocuSigned by: Keith M. Mins 12/1/2017

2F807865CD34A5 DATE

SIG. INVENTORY NO. 06-0955T4


PHASING DIAGRAM



SIGNAL FACE	PHASE		
	0 2 +6	0 8	F L A S H
21,22	G	R	Y
61	F	R	Y
62,63	G	R	Y
81,82	R	G	R

SIGNAL FACE I.D.

All Heads L.E.D.




OASIS 2070 LOOP & DETECTOR INSTALLATION CHART													
INDUCTIVE LOOPS					DETECTOR PROGRAMMING								
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PHASE	CALLING EXTENSION	FULL TIME DELAY	STRETCH TIME	DELAY TIME	SYSTEM LOOP	NEW CARD		
2A/S05	6X6	355	6	Y	2	Y	Y	-	-	-	Y	Y	
2B/S06	6X6	355	6	-	2	Y	Y	-	-	-	Y	-	
6A/S07	6X6	355	6	Y	6	Y	Y	-	-	-	Y	Y	
6B/S08	6X6	355	6	-	6	Y	Y	-	-	-	Y	-	
6C	6X40	0	2-4-2	Y	6	Y	Y	Y	-	3	-	Y	
8A	6X40	0	2-4-2	-	8	Y	Y	-	-	3	-	-	
8B	6X40	0	2-4-2	-	8	Y	Y	-	-	15	-	-	

2 Phase
Fully Actuated
NC 59 Closed Loop System

NOTES

1. Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
2. Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
3. Set all detector units to presence mode.
4. Reposition existing signal heads 21, 22, 62, and 63 as shown.
5. Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
6. Closed loop system data:
Master Asset #10614.
Controller Asset #0955.



OASIS 2070 TIMING CHART			
FEATURE	PHASE		
	2	6	8
Min Green 1 *	14	14	7
Extension 1 *	6.0	6.0	2.0
Max Green 1 *	90	90	25
Yellow Clearance	5.2	5.2	3.0
Red Clearance	1.3	1.3	3.1
Walk 1 *	-	-	-
Don't Walk 1	-	-	-
Seconds Per Actuation *	1.5	1.5	-
Max Variable Initial *	40	40	-
Time Before Reduction *	15	15	-
Time To Reduce *	30	30	-
Minimum Gap	3.0	3.0	-
Recall Mode	MIN RECALL	MIN RECALL	-
Vehicle Call Memory	YELLOW	YELLOW	-
Dual Entry	-	-	-
Simultaneous Gap	ON	ON	ON

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

Prepared In The Offices of

Transportation Mobility and Safety Division
NORTH CAROLINA
DEPARTMENT OF TRANSPORTATION
Signal Design Section

750 N. Greenfield Pkwy, Garner, NC

SCALE
0
1" = 40'

[illegible]

DOCUMENT NOT CONSIDERED
FINAL UNLESS ALL
SIGNATURES COMPLETED

SEAL


NORTH CAROLINA
PROFESSIONAL
SEAL
042608
ENGINEER
MECHAN E. LEBLANC

—DocuSigned by:
Mechan E. LeBlanc 11/28/2017

SIG. INVENTORY NO. 06-0955

EDI MODEL 2018ECL-NC CONFLICT MONITOR
PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- Ensure that Red Enable is active at all times during normal operation.
- Connect serial cable from conflict monitor to comm. port 1 of 2070 controller. Ensure conflict monitor communicates with 2070.

INPUT FILE POSITION LAYOUT

(front view)

	1	2	3	4	5	6	7	8	9	10	11	12	13	14
FILE U	S TOP	Ø2/SYS 2A/S05	TOP	S TOP	S TOP	S TOP	S TOP	S TOP	S TOP	S TOP	S TOP	S TOP	S TOP	FS ISOLATOR
FILE L	Y TOP	Ø2/SYS 2B/S06	Y TOP	Y TOP	Y TOP	Y TOP	Y TOP	Y TOP	Y TOP	Y TOP	Y TOP	Y TOP	Y TOP	ST ISOLATOR
FILE U	NOT USED	Ø6/SYS 6A/S07	Ø 6 6C	S TOP	S TOP	Ø 8 8A	S TOP	S TOP	S TOP	S TOP	S TOP	S TOP	S TOP	S TOP
FILE L	NOT USED	Ø6/SYS 6B/S08	NOT USED	Y TOP	Y TOP	Ø 8 8B	Y TOP	Y TOP	Y TOP	Y TOP	Y TOP	Y TOP	Y TOP	Y TOP


EX.: 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
ST = STOP TIME

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
2A/S05	TB2-5,6	I2U	39	1	2	2/SYS	Y	Y			
2B/S06	TB2-7,8	I2L	43	5	12	2/SYS	Y	Y			
6A/S07	TB3-5,6	J2U	40	2	6	6/SYS	Y	Y			
6B/S08	TB3-7,8	J2L	44	6	16	6/SYS	Y	Y			
6C	TB3-9,10	J3U	64	26	36	6	Y	Y	Y		3
8A	TB5-9,10	J6U	42	4	8	8	Y	Y			3
8B	TB5-11,12	J6L	46	8	18	8	Y	Y			15

INPUT FILE POSITION LEGEND: J2L



NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Enable Simultaneous Gap-Out for all Phases.
- Program phases 2 and 6 for Variable Initial and Gap Reduction.
- Program phases 2 and 6 for Startup In Green.
- Program phases 2 and 6 for Yellow Flash, and overlap 1 as Wag Overlaps.
- The cabinet and controller are part of the NC 59 Closed Loop System.

EQUIPMENT INFORMATION

CONTROLLER.....2070
CABINET.....332 W/ AUX
SOFTWARE.....ECONOLITE OASIS
CABINET MOUNT.....BASE
OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
LOAD SWITCHES USED.....S2,S8,S11,AUX S1
PHASES USED.....2,6,8
OVERLAP "A".....2
OVERLAP "B".....NOT USED
OVERLAP "C".....NOT USED
OVERLAP "D".....NOT USED

OVERLAP PROGRAMMING DETAIL

(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS), THEN
'1' (VEHICLE OVERLAP SETTINGS).

PAGE 1: VEHICLE OVERLAP 'A' SETTINGS
PHASE: 12345678910111213141516
VEH OVL PARENTS: X
VEH OVL NOT VEH: DC
VEH OVL NOT PED: DC
VEH OVL GRN EXT: ISOLATOR
STARTUP COLOR: RED YELLOW GREEN
FLASH COLORS: RED YELLOW X GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC).....0
YELLOW CLEAR (0=PARENT,3-25.5 SEC)...0.0
RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)....0

OVERLAP PROGRAMMING COMPLETE

SIGNAL HEAD HOOK-UP CHART


LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	NU	21,22	NU	NU	NU	NU	NU	62,63	NU	NU	81,82	NU	61	NU	NU	NU	NU	NU
RED		128						134			107							
YELLOW		129						135			108							
GREEN		130						136			109							
RED ARROW													A121					
YELLOW ARROW													A122					
FLASHING YELLOW ARROW													A123					
GREEN ARROW																		

NU = Not Used

★ See pictorial of head wiring in detail this sheet.

FYA SIGNAL WIRING DETAIL

(wire signal head as shown)




THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-0955
DESIGNED: September 2017
SEALED: 11-28-17
REVISED: N/A

Electrical Detail - Final

ELECTRICAL AND PROGRAMMING
DETAILS FOR:

Prepared In the Offices of:



750 N.Greenfield Pkwy,Garner,NC 27529

NC 59 (Chicken Foot Road)
at
I-95 Bus./US 301 NB Ramps /
SR 2284 (State Road)

Division 6 Cumberland County Hope Mills

PLAN DATE: November 2017 REVIEWED BY:

PREPARED BY: James Peterson REVIEWED BY:


REVISIONS

INIT. DATE

DATE

DOCUMENT NOT CONSIDERED
FINAL UNLESS ALL
SIGNATURES COMPLETED

SEAL




DocuSigned by
Keith M. Mims 12/1/2017

2F5079E6CD34A5 DATE

SIG. INVENTORY NO. 06-0955

PHASING DIAGRAM




PHASING DIAGRAM DETECTION LEGEND

- DETECTED MOVEMENT
- UNDETECTED MOVEMENT (OVERLAP)
- UNSIGNALIZED MOVEMENT
- PEDESTRIAN MOVEMENT

SIGNAL FACE	PHASE		
	02+6	04+8	FLASH
21	Y	R	Y
22,23	G	R	Y
41,42	R	G	R
61	Y	R	Y
62,63	G	R	Y
81,82	R	G	R

SIGNAL FACE I.D.




INDUCTIVE LOOPS				DETECTOR PROGRAMMING							SYSTEM LOOP	NEW CARD
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PHASE	CALLING	EXTENSION	FULL TIME DELAY	STRETCH TIME	DELAY TIME		
2A	6X6	325	5	Y	2	Y	Y	-	-	-	-	Y
2C	6X40	0	2-4-2	Y	2	Y	Y	Y	-	3	-	Y
4A	6X40	0	2-4-2	Y	4	Y	Y	-	-	3	-	Y
4B	6X40	0	2-4-2	Y	4	Y	Y	-	-	10	-	Y
6A	6X6	355	5	Y	6	Y	Y	-	-	-	-	Y
6C	6X40	0	2-4-2	Y	6	Y	Y	Y	-	3	-	Y
8A	6X40	0	2-4-2	Y	8	Y	Y	-	-	3	-	Y
8B	6X40	0	2-4-2	Y	8	Y	Y	-	-	10	-	Y

2 Phase
Fully Actuated
NC 59 Closed Loop System

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Set all detector units to presence mode.
- Locate new cabinet so as not to obstruct sight distance of vehicles turning right on red.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Closed loop system data: Controller asset #1356



OASIS 2070 TIMING CHART

FEATURE	PHASE			
	2	4	6	8
Min Green 1 *	14	7	14	7
Extension 1 *	6.0	2.0	6.0	2.0
Max Green 1 *	90	25	90	25
Yellow Clearance	4.9	5.3	4.9	5.2
Red Clearance	1.1	1.0	1.1	1.0
Walk 1 *	-	-	-	-
Don't Walk 1	-	-	-	-
Seconds Per Actuation *	1.5	-	1.5	-
Max Variable Initial *	40	-	40	-
Time Before Reduction *	15	-	15	-
Time To Reduce *	30	-	30	-
Minimum Gap	3.0	-	3.0	-
Recall Mode	MIN RECALL	-	MIN RECALL	-
Vehicle Call Memory	YELLOW	-	YELLOW	-
Dual Entry	-	ON	-	ON
Simultaneous Gap	ON	ON	ON	ON

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND

PROPOSED	EXISTING
Traffic Signal Head	N/A
Modified Signal Head	N/A
Sign	N/A
Pedestrian Signal Head With Push Button & Sign	N/A
Signal Pole with Guy	N/A
Signal Pole with Sidewalk Guy	N/A
Inductive Loop Detector	N/A
Controller & Cabinet	N/A
Junction Box	N/A
2-in Underground Conduit	N/A
Right of Way	N/A
Directional Arrow	N/A
Metal Strain Pole	N/A
Construction Zone Drums	N/A

New Installation - Temp 1 (Phase I-11)

Prepared in the Offices of:

750 N. Greenfield Pkwy, Garner, NC 27529

NC 59 (South Main Street)
at
SR 2274 (Marracco Drive)
Division 6 Cumberland County Hope Mills
PLAN DATE: October 2017 REVIEWED BY: MEL
PREPARED BY: Jeff Spence REVIEWED BY:

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SEAL
NORTH CAROLINA
PROFESSIONAL ENGINEER
SEAL 042608
MICHAEL E. LEBLANC
11/28/2017
SIC. INVENTORY NO. 06-135611

(remove jumpers and set switches as shown)

(remove jumpers and set switches as shown)



1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
3. Ensure that Red Enable is active at all times during normal operation.
4. Connect serial cable from conflict monitor to comm. port 1 of 2070 controller. Ensure conflict monitor communicates with 2070.

(front view)



FS = FLASH SENSE
ST = STOP TIME

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
2A	TB2-5,6	I2U	39	1	2	2	Y	Y			
2C	TB2-9,10	I3U	63	25	32	2	Y	Y	Y		3
4A	TB4-9,10	I6U	41	3	4	4	Y	Y			3
4B	TB4-11,12	I6L	45	7	14	4	Y	Y			10
6A	TB3-5,6	J2U	40	2	6	6	Y	Y			
6C	TB3-9,10	J3U	64	26	36	6	Y	Y	Y		3
8A	TB5-9,10	J6U	42	4	8	8	Y	Y			3
8B	TB5-11,12	J6L	46	8	18	8	Y	Y			10

INPUT FILE POSITION LEGEND: J2L

FILE J _____
SLOT 2 _____
LOWER _____

1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.

2. Program phases 4 and 8 for Dual Entry.
3. Enable Simultaneous Gap-Out for all Phases.
4. Program phases 2 and 6 for Variable Initial and Gap Reduction.
5. Program phases 2 and 6 for Startup In Green.
6. Program phases 2 and 6 for Yellow Flash, and overlap 1 as Wag Overlaps.
7. The cabinet and controller are part of the NC 59 Closed Loop System.

```
CONTROLLER.....2070
CABINET.....332 W/ AUX
SOFTWARE.....ECONOLITE OASIS
CABINET MOUNT.....BASE
OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
LOAD SWITCHES USED.....S2,S5,S8,S11,AUX S1,AUX S4
PHASES USED.....2,4,6,8
OVERLAP "A".....2
OVERLAP "B".....NOT USED
OVERLAP "C".....6
OVERLAP "D".....NOT USED
```

(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS), THEN
'1' (VEHICLE OVERLAP SETTINGS).

```

PAGE 1: VEHICLE OVERLAP 'A' SETTINGS
PHASE:      12345678910111213141516
VEH OVL PARENTS:  X
VEH OVL NOT VEH:
VEH OVL NOT PED:
VEH OVL GRN EXT:
STARTUP COLOR:  _ RED _ YELLOW _ GREEN
FLASH COLORS:  _ RED _ YELLOW X GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC).....0
YELLOW CLEAR (0=PARENT,3-25.5 SEC)...0.0
RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE,1-16)....0

```

← NOTICE GREEN FLASH

PRESS '+' TWICE

```

PAGE 1: VEHICLE OVERLAP 'C' SETTINGS
PHASE:      12345678910111213141516
VEH OVL PARENTS:      X
VEH OVL NOT VEH:
VEH OVL NOT PED:
VEH OVL GRN EXT:
STARTUP COLOR:  _ RED  _ YELLOW  _ GREEN
FLASH COLORS:  _ RED  _ YELLOW  X GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC).....0
YELLOW CLEAR (0=PARENT,3-25.5 SEC)...0.0
RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE,1-16)....0

```

← NOTICE GREEN FLASH

OVERLAP PROGRAMMING COMPLETE


PROJECT REFERENCE NO.	SHEET NO.
B-4491	Sig. 12.1

[illegible]

NU = Not Used

★ See pictorial of head wiring in detail this sheet.

(wire signal heads as shown)



THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-1356T1
DESIGNED: October 2017
SEALED: 11-28-17
REVISED: N/A

Electrical Detail - Temp. 1 (Phase I-11)

**DOCUMENT NOT CONSIDERED
FINAL UNLESS ALL
SIGNATURES COMPLETED**

SEAL

NC 59 (South Main Street)
at
SR 2274 (Marracco Drive)

Division 6 Cumberland County Hope Mills

PLAN DATE: November 2017	REVIEWED BY:
--------------------------	--------------

PREPARED BY: James Peterson	REVIEWED BY:
-----------------------------	--------------

REVISIONS

DATE _____

12/1/201

2F80788EBCD34A5... DATE


ELECTRICAL AND PROGRAMMING DETAILS FOR:

Prepared in the Offices of:



750 N.Greenfield Pkwy.Garner.NC 27529

PHASING DIAGRAM




PHASING DIAGRAM DETECTION LEGEND

- DETECTED MOVEMENT
- UNDETECTED MOVEMENT (OVERLAP)
- UNSIGNALIZED MOVEMENT
- PEDESTRIAN MOVEMENT

SIGNAL FACE	PHASE		
	02+6	04+8	FLASH
21	Y	Y	Y
22,23	G	R	Y
41,42	R	G	R
61	Y	Y	Y
62,63	G	R	Y
81,82	R	G	R

SIGNAL FACE I.D.




INDUCTIVE LOOPS				DETECTOR PROGRAMMING							SYSTEM LOOP	NEW CARD
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PHASE	CALLING	EXTENSION	FULL TIME DELAY	STRETCH TIME	DELAY TIME		
2A	6X6	325	5	-	2	Y	Y	-	-	-	-	-
2C	6X40	0	2-4-2	Y	2	Y	Y	Y	-	3	-	Y
4A	6X40	0	2-4-2	Y	4	Y	Y	-	-	3	-	-
4B	6X40	0	2-4-2	Y	4	Y	Y	-	-	10	-	-
4C	6X40	0	2-4-2	Y	4	Y	Y	-	-	15	-	Y
6B/S12	6X6	355	6	Y	6	Y	Y	-	-	-	Y	Y
6C	6X40	0	2-4-2	Y	6	Y	Y	Y	-	3	-	Y
8A	6X40	0	2-4-2	Y	8	Y	Y	-	-	3	-	-
8B	6X40	0	2-4-2	Y	8	Y	Y	-	-	10	-	-
8C	6X40	0	2-4-2	Y	8	Y	Y	-	-	15	-	Y

2 Phase
Fully Actuated
NC 59 Closed Loop System

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Reposition existing signal heads numbered 21,22,23 61,62,and 63.
- Set all detector units to presence mode.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Closed loop system data: Controller Asset # 1356.



OASIS 2070 TIMING CHART

FEATURE	PHASE			
	2	4	6	8
Min Green 1 *	14	7	14	7
Extension 1 *	6.0	2.0	6.0	2.0
Max Green 1 *	90	25	90	25
Yellow Clearance	4.9	5.3	4.9	5.2
Red Clearance	1.5	1.2	1.5	1.2
Walk 1 *	-	-	-	-
Don't Walk 1	-	-	-	-
Seconds Per Actuation *	1.5	-	1.5	-
Max Variable Initial *	40	-	40	-
Time Before Reduction *	15	-	15	-
Time To Reduce *	30	-	30	-
Minimum Gap	3.0	-	3.0	-
Recall Mode	MIN RECALL	-	MIN RECALL	-
Vehicle Call Memory	YELLOW	-	YELLOW	-
Dual Entry	-	ON	-	ON
Simultaneous Gap	ON	ON	ON	ON

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND

PROPOSED	EXISTING

New Installation- Temp 2 (Phase II)

Prepared in the Offices of:

750 N. Greenfield Pkwy, Garner, NC 27529

NC 59 (South Main Street)
at
SR 2274 (Marracco Drive)

Division 6 Cumberland County Hope Mills

PLAN DATE: October 2017 REVIEWED BY: MEL

PREPARED BY: Jeff Spence REVIEWED BY:

REVISIONS	INIT.	DATE

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SEAL

11/28/2017

SIG. INVENTORY NO. 06-135612

(remove jumpers and set switches as shown)

(remove jumpers and set switches as shown)



- = DENOTES POSITION
OF SWITCH

(front view)

EX.: 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
ST = STOP TIME

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
2A	TB2-5,6	I2U	39	1	2	2	Y	Y			
2C	TB2-9,10	I3U	63	25	32	2	Y	Y	Y		3
4A	TB4-9,10	I6U	41	3	4	4	Y	Y			3
4B	TB4-11,12	I6L	45	7	14	4	Y	Y			10
4C	TB6-1,2	I7U	65	27	34	4	Y	Y			15
6B/S12	TB3-7,8	J2L	44	6	16	6/SYS	Y	Y			
6C	TB3-9,10	J3U	64	26	36	6	Y	Y	Y		3
8A	TB5-9,10	J6U	42	4	8	8	Y	Y			3
8B	TB5-11,12	J6L	46	8	18	8	Y	Y			10
8C	TB7-1,2	J7U	66	28	38	8	Y	Y			15

INPUT FILE POSITION LEGEND: J2L



1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.

- ## EQUIPMENT INFORMATION

FYA SIGNAL WIRING DETAIL

(wire signal heads as shown)



(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS), THEN
'1' (VEHICLE OVERLAP SETTINGS).

```

PAGE 1: VEHICLE OVERLAP 'A' SETTINGS
PHASE:                12345678910111213141516
VEH OVL PARENTS:      X
VEH OVL NOT VEH:      :
VEH OVL NOT VEH:      :
VEH OVL NOT VEH:      :
VEH OVL GRN EXT:      :
STARTUP COLOR:         _ RED      _ YELLOW _ GREEN
FLASH COLORS:          _ RED      _ YELLOW X GREEN
-----
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC).....0
YELLOW CLEAR (0=PARENT.3-25.5 SEC)..0.0
RED CLEAR (0=PARENT.0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)....0

```

NOTICE GREEN FLASH

PRESS '+' TWICE

```

PAGE 1: VEHICLE OVERLAP 'C' SETTINGS
PHASE:      |12345678910111213141516
VEH OVL PARENTS:      |      X
VEH OVL NOT VEH:      |
VEH OVL NOT PEH:      |
VEH OVL GRN EXT:      |
STARTUP COLOR:  _ RED      _ YELLOW      _ GREEN
FLASH COLORS:   _ RED      _ YELLOW      X GREEN
-----
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC).....0
YELLOW CLEAR (0=PARENT,3-25.5 SEC)..0.0
RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)....0

```

NOTICE GREEN FLASH

OVERLAP PROGRAMMING COMPLETE

[illegible]

NU = Not Used

★ See pictorial of head wiring in detail this sheet.

OLA RED (A121)

OLA YELLOW (A122)

OLA GREEN (A123)

OLC RED (A114)

OLC YELLOW (A115)

OLC GREEN (A116)

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-1356T2
DESIGNED: October 2017
SEALED: 11-28-17
REVISED: N/A

Electrical Detail - Temp. 2 (Phase II)

**DOCUMENT NOT CONSIDERED
FINAL UNLESS ALL
SIGNATURES COMPLETED**

FAL

NC 59 (South Main Street)
at
SR 2274 (Marracco Drive)

Division 6 Cumberland County Hope Mills

PLAN DATE: November 2017

PREPARED BY: James Peterson

REVISIONS


DATE _____

K-11	M	M	12/1/2017
------	---	---	-----------

2E80788F8CD34A5 DATE

SIG. INVENTORY NO. 06-1356T2

PHASING DIAGRAM



PHASING DIAGRAM DETECTION LEGEND





TABLE OF OPERATION	
1	2
3	4
5	6
7	8
9	10
11	12
13	14
15	16
17	18
19	20
21	22
23	24
25	26
27	28
29	30
31	32
33	34
35	36
37	38
39	40
41	42
43	44
45	46
47	48
49	50
51	52
53	54
55	56
57	58
59	60
61	62
63	64
65	66
67	68
69	70
71	72
73	74
75	76
77	78
79	80
81	82
83	84
85	86
87	88
89	90
91	92
93	94
95	96
97	98
99	100

SIGNAL FACE	PHASE		
	0 2 + 6	0 4 + 8	F L A S H
21			
22,23	G	R	Y
41,42	R	G	R
61			
62,63	G	R	Y
81,82	R	G	R

SIGNAL FACE I.D.

All Heads L.E.D.



OASIS 2070 LOOP & DETECTOR INSTALLATION CHART

INDUCTIVE LOOPS					DETECTOR PROGRAMMING							
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PHASE	CALLING	EXTENSION	FULL TIME DELAY	STRETCH TIME	DELAY TIME	SYSTEM LOOP	NEW CARD
2A/S09	6X6	355	6	Y	2	Y	Y	-	-	-	Y	-
2B/S10	6X6	355	6	Y	2	Y	Y	-	-	-	Y	-
2C	6X40	0	2-4-2	-	2	Y	Y	Y	-	3	-	-
4A	6X40	0	2-4-2	-	4	Y	Y	-	-	3	-	-
4B	6X40	0	2-4-2	-	4	Y	Y	-	-	10	-	-
4C	6X20	0	2-4-2	-	4	Y	Y	-	-	15	-	-
6A/S11	6X6	355	6	Y	6	Y	Y	-	-	-	Y	Y
6B/S12	6X6	355	6	-	6	Y	Y	-	-	-	Y	-
6C	6X40	0	2-4-2	-	6	Y	Y	Y	-	3	-	-
8A	6X40	0	2-4-2	-	8	Y	Y	-	-	3	-	-
8B	6X40	0	2-4-2	-	8	Y	Y	-	-	10	-	-
8C	6X20	0	2-4-2	-	8	Y	Y	-	-	15	-	-

2 Phase
Fully Actuated
NC 59 Closed Loop System

NOTES

1. Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
2. Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
3. Reposition existing signal heads numbered 62 and 63.
4. Set all detector units to presence mode.
5. Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
6. Closed loop system data: Controller Asset # 1356.

LEGEND


PROPOSED		EXISTING
	Traffic Signal Head	
	Modified Signal Head	N/A
	Signal	
	Pedestrian Signal Head	
	With Push Button & Sign	
	Signal Pole with Guy	
	Signal Pole with Sidewalk Guy	
	Inductive Loop Detector	
	Controller & Cabinet	
	Junction Box	
	2-in Underground Conduit	
N/A	Right of Way	
	Directional Arrow	
	Directional Drill	N/A

OASIS 2070 TIMING CHART

FEATURE	PHASE			
	2	4	6	8
Min Green 1 *	14	7	14	7
Extension 1 *	6.0	2.0	6.0	2.0
Max Green 1 *	90	25	90	25
Yellow Clearance	4.9	5.3	4.9	5.2
Red Clearance	1.5	1.1	1.5	1.2
Walk 1 *	-	-	-	-
Don't Walk 1	-	-	-	-
Seconds Per Actuation *	1.5	-	1.5	-
Max Variable Initial *	40	-	40	-
Time Before Reduction *	15	-	15	-
Time To Reduce *	30	-	30	-
Minimum Gap	3.0	-	3.0	-
Recall Mode	MIN RECALL	-	MIN RECALL	-
Vehicle Call Memory	YELLOW	-	YELLOW	-
Dual Entry	-	ON	-	ON
Simultaneous Gap	ON	ON	ON	ON

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

New Installation- Final



NC 59 (South Main Street)
at
SR 2274 (Marracco Drive)

PLAN DATE:	October 2017	REVIEWED BY:	MEL
PREPARED BY:	Jeff Spence	REVIEWED BY:	

[illegible]

DOCUMENT NOT CONSIDERED
FINAL UNLESS ALL
SIGNATURES COMPLETED

SEAL

NORTH CAROLINA
PROFESSIONAL
SEAL
042608
ENGINEER
MECHAN. E. LEBLANC


-DocuSigned by:
Meghan E. LeBlanc 11/28/2017

0426080426080409

SIG. INVENTORY NO. 06-1356

EDI MODEL 2018ECL-NC CONFLICT MONITOR
PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



REMOVE JUMPERS AS SHOWN

NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- Ensure that Red Enable is active at all times during normal operation.
- Connect serial cable from conflict monitor to comm. port 1 of 2070 controller. Ensure conflict monitor communicates with 2070.

INPUT FILE POSITION LAYOUT

(front view)

	1	2	3	4	5	6	7	8	9	10	11	12	13	14
FILE "I"	U S -OF- -V-ZME -V-ZME	Ø2/SYS 2A/S09	Ø 2 2C	U S -OF- -V-ZME -V-ZME	U S -OF- -V-ZME -V-ZME	Ø 4 4A	Ø 4 4C	U S -OF- -V-ZME -V-ZME	U S -OF- -V-ZME -V-ZME	U S -OF- -V-ZME -V-ZME	U S -OF- -V-ZME -V-ZME	U S -OF- -V-ZME -V-ZME	U S -OF- -V-ZME -V-ZME	FS DC ISOLATOR ST DC ISOLATOR
FILE "J"	U S -OF- -V-ZME -V-ZME	Ø6/SYS 6A/S11	Ø 6 6C	U S -OF- -V-ZME -V-ZME	U S -OF- -V-ZME -V-ZME	Ø 8 8A	Ø 8 8C	U S -OF- -V-ZME -V-ZME	U S -OF- -V-ZME -V-ZME	U S -OF- -V-ZME -V-ZME	U S -OF- -V-ZME -V-ZME	U S -OF- -V-ZME -V-ZME	U S -OF- -V-ZME -V-ZME	U S -OF- -V-ZME -V-ZME

EX.: 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
ST = STOP TIME

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
2A/S09	TB2-5,6	I2U	39	1	2	2/SYS	Y	Y			
2B/S10	TB2-7,8	I2L	43	5	12	2/SYS	Y	Y			
2C	TB2-9,10	I3U	63	25	32	2	Y	Y	Y		3
4A	TB4-9,10	I6U	41	3	4	Y	Y	Y			3
4B	TB4-11,12	I6L	45	7	14	4	Y	Y			10
4C	TB6-1,2	I7U	65	27	34	4	Y	Y			15
6A/S11	TB3-5,6	J2U	40	2	6	6/SYS	Y	Y			
6B/S12	TB3-7,8	J2L	44	6	16	6/SYS	Y	Y			
6C	TB3-9,10	J3U	64	26	36	6	Y	Y	Y		3
8A	TB5-9,10	J6U	42	4	8	8	Y	Y			3
8B	TB5-11,12	J6L	46	8	18	8	Y	Y			10
8C	TB7-1,2	J7U	66	28	38	8	Y	Y			15

INPUT FILE POSITION LEGEND: J2L

FILE J
SLOT 2
LOWER

NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Program phases 4 and 8 for Dual Entry.
- Enable Simultaneous Gap-Out for all Phases.
- Program phases 2 and 6 for Variable Initial and Gap Reduction.
- Program phases 2 and 6 for Startup In Green.
- Program phases 2 and 6 for Yellow Flash, and overlap 1 as Wag Overlaps.
- The cabinet and controller are part of the NC 59 Closed Loop System.

EQUIPMENT INFORMATION

CONTROLLER.....2070
CABINET.....332 W/ AUX
SOFTWARE.....ECONOLITE OASIS
CABINET MOUNT.....BASE
OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
LOAD SWITCHES USED.....S2,S5,S8,S11,AUX S1,AUX S4
PHASES USED.....2,4,6,8
OVERLAP "A".....2
OVERLAP "B".....NOT USED
OVERLAP "C".....6
OVERLAP "D".....NOT USED

OVERLAP PROGRAMMING DETAIL

(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS). THEN
'1' (VEHICLE OVERLAP SETTINGS).

PAGE 1: VEHICLE OVERLAP 'A' SETTINGS
PHASE: 12345678910111213141516
VEH OVL PARENTS: X
VEH OVL NOT VEH:
VEH OVL NOT PED:
VEH OVL GRN EXT:
STARTUP COLOR: _ RED _ YELLOW _ GREEN
FLASH COLORS: _ RED _ YELLOW X GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC).....0
YELLOW CLEAR (0=PARENT,3-25.5 SEC)...0.0
RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)....0

← NOTICE GREEN FLASH

PRESS '+' TWICE

PAGE 1: VEHICLE OVERLAP 'C' SETTINGS
PHASE: 12345678910111213141516
VEH OVL PARENTS: X
VEH OVL NOT VEH:
VEH OVL NOT PED:
VEH OVL GRN EXT:
STARTUP COLOR: _ RED _ YELLOW _ GREEN
FLASH COLORS: _ RED _ YELLOW X GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC).....0
YELLOW CLEAR (0=PARENT,3-25.5 SEC)...0.0
RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)....0

← NOTICE GREEN FLASH

OVERLAP PROGRAMMING COMPLETE

PROJECT REFERENCE NO.	SHEET NO.
B-4491	Sig. 14.1

SIGNAL HEAD HOOK-UP CHART


LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	NU	22,23	NU	NU	41,42	NU	NU	62,63	NU	NU	81,82	NU	61★	NU	NU	21★	NU	NU
RED		128			101			134			107							
YELLOW		129			102			135			108							
GREEN		130			103			136			109							
RED ARROW													A121			A114		
YELLOW ARROW													A122			A115		
FLASHING YELLOW ARROW													A123			A116		
GREEN ARROW																		

NU = Not Used

★ See pictorial of head wiring in detail this sheet.

FYA SIGNAL WIRING DETAIL


(wire signal heads as shown)



THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-1356
DESIGNED: October 2017
SEALED: 11-28-17
REVISED: N/A

Electrical Detail - Final

ELECTRICAL AND PROGRAMMING
DETAILS FOR:



750 N. Greenfield Pkwy, Garner, NC 27529

NC 59 (South Main Street)
at
SR 2274 (Marracco Drive)

Division 6 Cumberland County Hope Mills

PLAN DATE: November 2017 REVIEWED BY:

PREPARED BY: James Peterson REVIEWED BY:


REVISIONS

INIT.

DATE

DOCUMENT NOT CONSIDERED
FINAL UNLESS ALL
SIGNATURES COMPLETED

SEAL




DocuSigned by:
Keith M. Mims 12/1/2017

260170859C734A65 DATE

SIG. INVENTORY NO. 06-1356


PHASING DIAGRAM



- PHASING DIAGRAM DETECTION LEGEND
- DETECTED MOVEMENT
 - UNDETECTED MOVEMENT (OVERLAP)
 - UNSIGNALIZED MOVEMENT
 - PEDESTRIAN MOVEMENT

SIGNAL FACE	PHASE		
	02+6	04	FLASH
21,22	G	R	Y
41,42	R	G	R
61	Y	Y	Y
62,63	G	R	Y

SIGNAL FACE I.D.




OASIS 2070 LOOP & DETECTOR INSTALLATION CHART												
INDUCTIVE LOOPS					DETECTOR PROGRAMMING							
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PHASE	CALLING	EXTENSION	FULL TIME DELAY	STRETCH TIME	DELAY TIME	SYSTEM LOOP	NEW CARD
2A	6X6	355	5	Y	2	Y	Y	-	-	-	-	Y
2B	6X6	355	5	Y	2	Y	Y	-	-	-	-	Y
4A	6X40	0	2-4-2	Y	4	Y	Y	-	-	3	-	Y
* 6A	*	355	*	Y	6	Y	Y	-	-	-	-	Y
6B	6X40	0	2-4-2	Y	6	Y	Y	-	-	3	-	Y

* Wireless Detection Zone

2 Phase
Fully Actuated
NC 59 Closed Loop System

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Set all detector units to presence mode.
- Locate new cabinet so as not to obstruct sight distance of vehicles turning right on red.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Closed loop system data: Controller Asset # 1357.



OASIS 2070 TIMING CHART

FEATURE	PHASE		
	2	4	6
Min Green 1 *	14	7	14
Extension 1 *	6.0	2.0	6.0
Max Green 1 *	90	25	90
Yellow Clearance	5.0	4.6	5.0
Red Clearance	1.2	1.1	1.2
Walk 1 *	-	-	-
Don't Walk 1	-	-	-
Seconds Per Actuation *	1.5	-	1.5
Max Variable Initial *	40	-	40
Time Before Reduction *	15	-	15
Time To Reduce *	30	-	30
Minimum Gap	3.0	-	3.0
Recall Mode	MIN RECALL	-	MIN RECALL
Vehicle Call Memory	YELLOW	-	YELLOW
Dual Entry	-	-	-
Simultaneous Gap	ON	ON	ON

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND

- | PROPOSED | EXISTING |
|----------|----------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

New Installation

Prepared in the Offices of: 750 N. Greenfield Pkwy, Garner, NC 27529		NC 59 (Chicken Foot Road) at I-95 SB Ramps Division 6 Cumberland County Hope Mills PLAN DATE: October 2017 REVIEWED BY: MEL PREPARED BY: Jeff Spence REVIEWED BY:		DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED SEAL NORTH CAROLINA PROFESSIONAL ENGINEER SEAL 042608 MICHAEL E. LEBLANC DocuSigned by: Michael E. LeBlanc 11/28/2017 SIC. INVENTORY NO. 06-1357	
SCALE 0 40 1"=40'		REVISIONS		INIT. DATE	

EDI MODEL 2018ECL-NC CONFLICT MONITOR

PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



REMOVE DIODE JUMPERS 2-6, 2-9 and 6-9.



REMOVE JUMPERS AS SHOWN

NOTES:

1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
3. Ensure that Red Enable is active at all times during normal operation.
4. Connect serial cable from conflict monitor to comm. port 1 of 2070 controller. Ensure conflict monitor communicates with 2070.



■ = DENOTES POSITION OF SWITCH

NOTES

1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
2. Enable Simultaneous Gap-Out for all Phases.
3. Program phases 2 and 6 for Variable Initial and Gap Reduction.
4. Program phases 2 and 6 for Startup In Green.
5. Program phases 2 and 6 for Yellow Flash, and overlap 1 as Wag Overlaps.
6. The cabinet and controller are part of the NC 59 Closed Loop System.

EQUIPMENT INFORMATION

CONTROLLER.....2070
CABINET.....332 W/ AUX
SOFTWARE.....ECONOLITE OASIS
CABINET MOUNT.....BASE
OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
LOAD SWITCHES USED.....S2,S5,S8,AUX S1
PHASES USED.....2,4,6
OVERLAP "A".....2
OVERLAP "B".....NOT USED
OVERLAP "C".....NOT USED
OVERLAP "D".....NOT USED

INPUT FILE POSITION LAYOUT

(front view)

	1	2	3	4	5	6	7	8	9	10	11	12	13	14
FILE U	S	Ø 2	S	S	S	Ø 4	S	S	S	S	S	S	S	FS
"I"	2A	2A	S	S	S	4A	S	S	S	S	S	S	S	DC ISOLATOR
L	2B	2B	S	S	S	NOT USED	S	S	S	S	S	S	S	DC ISOLATOR
FILE U	S	NOT USED	S	S	S	S	S	S	S	S	S	S	S	S
"J"	6B	6B	S	S	S	S	S	S	S	S	S	S	S	S
L	6B	6B	S	S	S	S	S	S	S	S	S	S	S	S


EX. : 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
ST = STOP TIME

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
2A	TB2-5,6	I2U	39	1	2	2	Y	Y			
2B	TB2-7,8	I2L	43	5	12	2	Y	Y			
4A	TB4-9,10	I6U	41	3	4	4	Y	Y			3
6B	TB3-7,8	J2L	44	6	16	6	Y	Y			3

INPUT FILE POSITION LEGEND: J2L



SPECIAL DETECTOR NOTE

For zone 6A install a wireless detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.

SIGNAL HEAD HOOK-UP CHART


LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	NU	21,22	NU	NU	41,42	NU	NU	62,63	NU	NU	NU	NU	61	NU	NU	NU	NU	NU
RED		128			101			134										
YELLOW		129			102			135										
GREEN		130			103			136										
RED ARROW													A121					
YELLOW ARROW													A122					
FLASHING YELLOW ARROW													A123					
GREEN ARROW																		

NU = Not Used

★ See pictorial of head wiring in detail this sheet.

FYA SIGNAL WIRING DETAIL

(wire signal head as shown)



61

OVERLAP PROGRAMMING DETAIL

(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS), THEN '1' (VEHICLE OVERLAP SETTINGS).

PAGE 1: VEHICLE OVERLAP 'A' SETTINGS
PHASE: 12345678910111213141516
VEH OVL PARENTS: X
VEH OVL NOT VEH: X
VEH OVL NOT PED: X
VEH OVL GRN EXT: X
STARTUP COLOR: - RED - YELLOW - GREEN
FLASH COLORS: - RED - YELLOW X GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC).....0
YELLOW CLEAR (0=PARENT, 3-25.5 SEC)...0.0
RED CLEAR (0=PARENT, 0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)....0

NOTICE GREEN FLASH


OVERLAP PROGRAMMING COMPLETE

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-1357
DESIGNED: October 2017
SEALED: 11-28-17
REVISED: N/A

Electrical Detail

ELECTRICAL AND PROGRAMMING
DETAILS FOR:

Prepared In the Office of:



750 N. Greenfield Pkwy, Garner, NC 27529

NC 59 (Chicken Foot Road)
at
I-95 SB Ramps

Division 6 Cumberland County Hope Mills

PLAN DATE: November 2017 REVIEWED BY:

PREPARED BY: James Peterson REVIEWED BY:


REVISIONS

INIT.

DATE

DOCUMENT NOT CONSIDERED
FINAL UNLESS ALL
SIGNATURES COMPLETED


SEAL



DocuSigned by: Keith M. Mims 12/1/2017


2F807865C0346X DATE

SIG. INVENTORY NO. 06-1357



ENGLISH STANDARD DRAWING FOR
ELECTRICAL SERVICE GROUNDING
GROUNDING AND BONDING

SHEET 1 OF 1
1700D01



ENGLISH STANDARD DRAWING FOR
WOOD POLES
METHODS OF ATTACHMENT AND GROUNDING


SHEET 1 OF 1
1720D01

11-OCT-2017 08:56
U:\2018 Std Drawings\Plate Sheets\2018_Plate Sheet .dgn
whough

DOCUMENT NOT CONSIDERED
FINAL UNLESS ALL
SIGNATURES COMPLETED


See Plate for Title

Prepared in the Offices of:



750 N. Greenfield Parkway
Garner, NC 27529

SEAL




DocuSigned by:
Mohd Aslami
5D960BA6DDB5495...

0/11/2017
DATE

STATE OF NORTH CAROLINA
DIVISION OF HIGHWAYS

PROJECT I.D. NO. B-4491
SHEET NO. Sig.M1


STANDARD DRAWINGS FOR ALL METAL POLES



WIND ZONE 1 (140 mph) Special Wind Zone	
WIND ZONE 2 (130 mph) Coastal Region	
WIND ZONE 3 (110 mph) Eastern Region	
WIND ZONE 4 (90 mph) Central & Mtn. Region	
WIND ZONE 5 (120 mph) Special Wind Zone	

<https://connect.ncdot.gov/resources/safety/Pages/ITS-Design-Resources.aspx>

Prepared In the Offices of:



Designed in conformance
with the latest
2015 Interim to the
6th Edition 2013

AASHTO

Standard Specifications for
Structural Supports for
Highway Signs, Luminaires,
and Traffic Signals

INDEX OF PLANS

DRAWING NUMBER	DESCRIPTION
Sig. M 1	Statewide Wind Zone Map
Sig. M 2	Typical Fabrication Details-All Metal Poles
Sig. M 3	Typical Fabrication Details-Strain Poles
Sig. M 4	Typical Fabrication Details-Mast Arm Poles
Sig. M 5	Typical Fabrication Details-Mast Arm Connection
Sig. M 6	Typical Fabrication Details-Strain Pole Attachments
Sig. M 7	Construction Details-Foundations
Sig. M 8	Standard Strain Pole Foundation-All Soil Conditions

NCDOT CONTACTS:

MOBILITY AND SAFETY DIVISION - ITS AND SIGNALS UNIT


G. A. FULLER, P.E. - STATE ITS AND SIGNALS ENGINEER

G. G. MURR, JR., P.E. - STATE SIGNALS ENGINEER

D. C. SARKAR, P.E. - ITS AND SIGNALS SENIOR STRUCTURAL ENGINEER

C. F. ANDREWS - ITS AND SIGNALS JOURNEY STRUCTURAL ENGINEER

SEAL




DocuSigned by:

Debesh C. Sarkar

2/17/2016

44E8E325 SIGNATURE

DATE



MFG _____ MFG. DATE: MM/YY
SHAFT D/T/L/Y _____
ARM-A D/T/L/Y _____
ARM-B D/T/L/Y _____
A.B. DIA./B.C./L/Y _____
NCDOT SIG. INV. NO. _____
NCDOT POLE NO. _____

Shaft I.D. Tag
(Provide on Shaft of Strain Poles and Mast Arm Poles Shaft)


Notes:

- 1) D= Diameter, T= Thickness, L= Length, Y= Yield Strength
- 2) A.B. = Anchor Bolt
- 3) B.C. = Bolt Circle of Anchor Bolts
- 4) If Custom Design, use "NCDOT STANDARD" line for Signal Inv. Number and pole I.D. number
- 5) See drawing M3 and M4 for mounting positions of I.D. tags.

Identification Tag Details


MFG _____ MFG. DATE:MM/YY
SECTION D/T/L/Y _____
NCDOT SIG. INV. NO. _____
NCDOT POLE NO. _____

Arm I.D. Tag
(Provide on each section of a multi-section mast arm.)




Construct Templates and Plates from 1/4" min. thick Steel. Galvanizing is not required.

Base Plate Template and Anchor Bolt Lock Plate Details




Anchor Bolt Detail




Note: Base plate may be circular, octagonal, square or rectangular in shape.

Typical Base Plate Detail



Typical Fabrication Details
For
All Metal Poles


PLAN DATE: FEBRUARY 2016	DESIGNED BY: C.F. ANDREWS
PREPARED BY: N. BITTING	REVIEWED BY: D.C. SARKAR
REVISIONS	INIT. DATE



2/17/2016
DATE






17-FEB-2016 16:04
S:\MS350\15 Signal\Signal Design Section\Eastern Region\MI Sheets\2016\2014 Sig.M3 Std. Fabrication Details-Strain Poles.dgn
J Gallaway

1. Opening in pole base plate shall be equal to pole base inside diameter minus $3\frac{1}{2}$ " but shall not be less than $8\frac{1}{2}$ ".





Welded Ring Stiffened Mast Arm Connection

PROJECT ID. NO.	SHEET NO.
B-4491	Sig.M5



- Notes:
1. Provide a permanent means of identification above the mast arm to indicate proper attachment orientation of the mast arm.
 2. Designer will determine the size of all structural components, plates, fasteners, and welds shown unless they are already specified.
 3. Fabricator is responsible for providing appropriate holes at drainage points to drain galvanizing materials.
 4. For minimum edge distance follow AISC Table J3.4 and J3.5. For nominal bolt hole size use Table J3.3.
 5. Provide upper handhole as necessary when shaft extensions are required for luminaire arms or camera. For poles without luminaires/camera, wiring can be done through the top of pole.
 6. Allowable range of flange tilt angle will vary from 0° to as required.



Prepared In the Offices of:

750 N. Greenfield Pkwy, Garner, NC 27529

Typical Fabrication Details
For
Mast Arm Connection To Pole

PLAN DATE:	FEBRUARY 2016	DESIGNED BY:	C.F. ANDREWS
PREPARED BY:	N. BITTING	REVIEWED BY:	D.C. SARKAR
REVISIONS	INIT.	DATE	


SCALE
0 NA
NONE

SEAL


DocuSigned by:
Debesh C. Sarkar

44E8E32E147E4C4...


2/17/2016
DATE



Concrete Shaft Elevation



Section A-A




Typical "C" Bar Detail

Typical Foundation Conduit Details

General Notes:

1. If actual subsurface conditions differ significantly from boring data contact the Engineer before excavating or placing concrete.
2. Circular tie reinforcing rings may be vertically adjusted by +/-3" at a depth between 2'-0" and 3'-0" to facilitate the installation of electrical conduit entering in the cage.
3. For standard foundations, see sheet Sig. M8 for details. Vertical reinforcing bars (V1) may be horizontally adjusted by +/-3" to facilitate the installation of electrical conduit entering into the cage.
4. Provide 2" to 5" foundation projection above ground level depending on the ground slope.
5. Unless otherwise shown, foundation designs are based on non-sloping level ground surfaces with slope ratios of 8:1 (H:V) or flatter. If actual ground line slopes are steeper contact the Engineer before excavating or placing concrete.
6. Construct foundations in accordance with NCDOT Standard Provisions SP09 R005- Foundations and Anchor Rod Assemblies for Metal Poles. All applicable 2012 NCDOT Standard Specifications are referenced in this provision. Refer to the NCDOT Resources/Specifications page located on the Connect NCDOT website.
[https://connect.ncdot.gov/resources/Specifications and Special Provisions.aspx](https://connect.ncdot.gov/resources/Specifications%20and%20Special%20Provisions.aspx)
7. Use air entrained AA concrete mix with a compression strength of f'c=4500 psi.(min.) after 28 days.
8. Use ASTM A615 grade 60 deformed bars for all reinforcing steel. Maintain at least 3" cover on all reinforcement.
9. Locate the Identification Tag on the top of the base plate, directly above the conduit's entry point.
10. Provide two layers of galvanized welded 23 gauge (0.25) 6" wide 4 mesh wire around pipes under the base plate and secure it with ties if necessary.
11. Preferred location for the I.D. Tag is as shown in Detail-A; directly above the conduit entering the foundation.




REINFORCING STEEL TABLE FOR STANDARD DRILL PIER SHAFT (4'-0" DIAMETER)						
"D" Shaft Dia.	Conc. Volume (cu. yds.)	Bar Name	MIN.	Size	Type	Length
4'-0"	.465 x L	V1	—	#8	STR.	**
		C	*	#4	CIR.	12'-6"

* See Note No. 2
** See Note No. 3

Typical Foundation Anchor Bolt Details

(Reinforcing Cage Not Shown for Clarity)



D = Diameter
L = Length/Depth
mm = Month
yy = Year

Detail-A

Prepared In the Offices of:

750 N. Greenfield Pkwy, Garner, NC 27529

Construction Details For Foundations
PLAN DATE: FEBRUARY 2016
DESIGNED BY: C.B. COGDILL
PREPARED BY: N. BITTING
REVIEWED BY: D.C. SARKAR
REV. NO. 1
COMMENTS: Revised Foundation Tag Details
INIT. N.B.
DATE: 5/11/2015

SEAL
NORTH CAROLINA
PROFESSIONAL ENGINEER
028094
D.C. SARKAR
DocuSigned by
Deshu C. Sarkar
44E8E32E147E4C4...

SOIL CONDITION

PROJECT ID. NO.	SHEET NO.
B-4491	Sig.M8

		STANDARD STRAIN POLES						STANDARD FOUNDATIONS 48" Diameter Drilled Pier Length (L) – Feet							Reinforcement			
		Case No.	Pole Height (Ft.)	Base Plate BC (In.)	Reactions at the Pole Base			Clay				Sand			Longitudinal		Stirrups	
					Axial (kip)	Shear (kip)	Moment (ft-kip)	Medium N-Value 4-8	Stiff N-Value 9-15	Very Stiff N-Value 16-30	Hard N-Value >30	Loose N-Value 4-10	Medium N-Value 11-30	Dense N-Value >30	Bar Size (#)	Quantity (ea.)	Bar Size (#)	Spacing (in.)
WIND ZONE 1	LIGHT	S26L3	26	25	2	11	270	19	13	10	8	17	14.5	12.5	8	12	4	12
		S30L3	30	25	2	11	300	19.5	13.5	10	8	17.5	15	13	8	14	4	12
		S35L3	35	25	3	11	320	20	13.5	10.5	8	17.5	15	13	8	14	4	12
	HEAVY	S30H3	30	29	3	16	450	24.5	16	12	9	21	17.5	15	8	16	4	6
		S35H3	35	29	4	16	515	26	17	12.5	9.5	22	18.5	16	8	16	4	6
WIND ZONE 2	LIGHT	S26L2	26	23	2	10	245	18	12.5	9.5	8	16.5	14	12	8	12	4	12
		S30L2	30	23	2	10	270	18.5	12.5	10	8	16.5	14	12.5	8	12	4	12
		S35L2	35	23	3	10	300	19.5	13	10	8	17	14.5	13	8	12	4	12
	HEAVY	S30H2	30	29	3	15	415	23	15.5	11.5	9	20	17	14.5	8	16	4	6
		S35H2	35	29	4	15	475	25	16.5	12	9.5	21	17.5	15.5	8	16	4	6
WIND ZONE 3	LIGHT	S26L2	26	23	2	10	245	18	12.5	9.5	8	16.5	14	12	8	12	4	12
		S30L2	30	23	2	10	270	18.5	12.5	10	8	16.5	14	12.5	8	12	4	12
		S35L2	35	23	3	10	300	19.5	13	10	8	17	14.5	13	8	12	4	12
	HEAVY	S30H2	30	29	3	15	415	23	15.5	11.5	9	20	17	14.5	8	16	4	6
		S35H2	35	29	4	15	475	25	16.5	12	9.5	21	17.5	15.5	8	16	4	6
WIND ZONE 4	LIGHT	S26L1	26	22	2	8	190	16	11.5	8.5	8	15	12.5	11	8	12	4	12
		S30L1	30	22	2	8	205	16.5	11.5	9	8	15	13	11.5	8	12	4	12
		S35L1	35	22	3	8	230	17	12	9	8	15.5	13.5	11.5	8	12	4	12
	HEAVY	S30H1	30	25	3	12	320	20.5	13.5	10.5	8	18	15	13.5	8	16	4	6
		S35H1	35	25	4	12	350	21	14	10.5	8.5	18.5	15.5	13.5	8	16	4	6
WIND ZONE 5	LIGHT	S26L2	26	23	2	10	245	18	12.5	9.5	8	16.5	14	12	8	12	4	12
		S30L2	30	23	2	10	270	18.5	12.5	10	8	16.5	14	12.5	8	12	4	12
		S35L2	35	23	3	10	300	19.5	13	10	8	17	14.5	13	8	12	4	12
	HEAVY	S30H2	30	29	3	15	415	23	15.5	11.5	9	20	17	14.5	8	16	4	6
		S35H2	35	29	4	15	475	25	16.5	12	9.5	21	17.5	15.5	8	16	4	6

General Notes:

1. Values shown in the "Reactions at the Pole Base" column represent the minimum acceptable capacity allowed for design using a design CSR of 1.00.
2. Use chairs and spacers to maintain proper clearance.
3. For foundation, always use air-entrain concrete mix.


Foundation Selection:

1. Perform a standard penetration test at each proposed foundation site to determine "N" value.
2. Select the appropriate wind zone from M 1 drawing.
3. Select the soil type (Clay or Sand) that best describes the soil characteristics.
4. Get the appropriate standard pole case number from the plans or from the Engineer.
5. Select the appropriate column under "Standard Foundations" based on soil type and "N" value. Select the appropriate row based on the pole load case.
6. The foundation depth is the value shown in the "Standard Foundations" category where the column and the row intersect.
7. Use Construction Procedures and Design Methods prescribed by FHWA-NHI-10-016 for Reference Drilled Shafts.

48" Dia. Foundations Concrete Volume (cubic yards) = (0.465) x Drilled Pier Length

Standard Strain Pole Foundation–All Soil Condition

Prepared In the Office of:



750 N. Greenfield Pkwy, Garner, NC 27529

SCALE
0 NA
NONE

Standard Strain Pole Foundation for All Soil Conditions

PLAN DATE: FEBRUARY 2016

DESIGNED BY: C.B. COGDELL

PREPARED BY: N. BITTING

REVIEWED BY: D.C. SARKAR

REVISIONS

Changed "Foundation Depth" to "Drilled Pier Length" in Conc. Exp.


INIT.

DATE

N.B.

7/12/2015

SEAL



DocuSigned by
Debesh C. Sarkar

SIGNATURE
44EBE32E147E4C4...

2/17/2016
DATE

- 1

INSTALL REA, PE – 22, SHIELDED, TWISTED PAIR COMMUNICATIONS CABLE
- 2

INSTALL COAX CABLE
- 3

INSTALL ETHERNET CABLE
- 4

INSTALL SMFO CABLE
- 5

INSTALL MMFO CABLE
- 6

INSTALL FIBER OPTIC DROP CABLE
- 7

INSTALL TRACER WIRE
- 8

TRENCH
- 9

INSTALL PVC CONDUIT
- 10

INSTALL RIGID, GALVANIZED STEEL CONDUIT
- 11

INSTALL RIGID, GALVANIZED STEEL RISER WITH WEATHERHEAD
- 12

INSTALL RIGID, GALVANIZED STEEL RISER WITH FIBER OPTIC CABLE SEAL
- 13

INSTALL OUTER-DUCT POLYETHYLENE CONDUIT
- 14

INSTALL POLYETHYLENE CONDUIT
- 15

DIRECTIONAL DRILL CONDUIT
- 16

BORE AND JACK CONDUIT
- 17

INSTALL CABLE(S) IN EXISTING CONDUIT
- 18

INSTALL CABLE(S) IN NEW CONDUIT
- 19

INSTALL CABLE(S) IN EXISTING RISER
- 20

INSTALL CABLE(S) IN NEW RISER
- 21

INSTALL CABLE(S) IN EXISTING CONDUIT STUB-OUTS
- 22

INSTALL NEW CONDUIT INTO EXISTING CABINET BASE (USE EXISTING CONDUIT STUB-OUTS WHEN AVAILABLE)
- 23

INSTALL NEW RISER INTO EXISTING CABINET BASE (USE EXISTING CONDUIT STUB-OUTS WHEN AVAILABLE)
- 24

INSTALL NEW CONDUIT INTO EXISTING POLE MOUNTED CABINET
- 25

INSTALL NEW RISER INTO EXISTING POLE MOUNTED CABINET
- 26

MODIFY EXISTING INTERCONNECT CENTER /SPLICE ENCLOSURE
- 27

INSTALL NEW FIBER OPTIC TRANSCEIVER
- 28

INSTALL INTERCONNECT CENTER, PATCH PANEL, JUMPERS AND FUSION SPLICE CABLE IN CABINET
- 29

INSTALL UNDERGROUND SPLICE ENCLOSURE
- 30

INSTALL AERIAL SPLICE ENCLOSURE
- 31

INSTALL POLE MOUNTED SPLICE CABINET
- 32

INSTALL BASE MOUNTED SPLICE CABINET
- 33

REMOVE EXISTING SPLICE CABINET

- 34

INSTALL CABINET FOUNDATION
- 35

REMOVE EXISTING CABINET FOUNDATION
- 36

INSTALL CCTV CAMERA ASSEMBLY
- 37

INSTALL CCTV CAMERA WOOD POLE
- 38

INSTALL CCTV CAMERA METAL POLE AND FOUNDATION
- 39

INSTALL JUNCTION BOX
- 40

INSTALL OVERSIZED JUNCTION BOX
- 41

REMOVE EXISTING JUNCTION BOX
- 42

INSTALL WOOD POLE
- 43

REMOVE EXISTING WOOD POLE
- 44

INSTALL AERIAL GUY ASSEMBLY
- 45

INSTALL STANDARD GUY ASSEMBLY
- 46

INSTALL SIDEWALK GUY ASSEMBLY
- 47

INSTALL MESSENGER CABLE
- 48

REMOVE EXISTING COMMUNICATIONS AND MESSENGER CABLE
- 49

REMOVE EXISTING MESSENGER CABLE
- 50

INSTALL CELLULAR MODEM
- 51

INSTALL CABLE STORAGE RACKS (SNOW SHOES) AND STORE 100 FEET OF CABLE
- 52

INSTALL DELINEATOR MARKER
- 53

STORE 20 FEET OF COMMUNICATIONS CABLE
- 54

LASH CABLE(S) TO EXISTING SIGNAL/COMMUNICATIONS CABLE
- 55

LASH CABLE(S) TO EXISTING MESSENGER CABLE
- 56

LASH CABLE(S) TO NEW MESSENGER CABLE
- 57

MODIFY EXISTING ELECTRICAL SERVICE
- 58

INSTALL NEW ELECTRICAL SERVICE
- 59

INSTALL NEW FIELD ETHERNET SWITCH
- 60

BOND TRACER WIRE TO EQUIPMENT GROUND BUS
- 61

DO NOT BOND TRACER WIRE TO EQUIPMENT GROUND BUS
- 62

BOND RISER AND MESSENGER CABLE TO POLE GROUND

ATTACHMENT POINT:

XX"/SS
YYY

DISTANCE ABOVE (IN)/ATTACHMENT POINT
REFERENCE POINT

YYY
XX"/SS

REFERENCE POINT
DISTANCE BELOW (IN)/ATTACHMENT POINT

SS" REFERENCE LOCATION

FS = FRONT SIDE OF POLE
BS = BACK SIDE OF POLE

LEGEND

FO

NEW FIBER OPTIC COMMUNICATIONS CABLE

TWIST PR

NEW TWISTED PAIR COMMUNICATIONS CABLE

EXI

EXISTING COMMUNICATIONS CABLE

REM

EXISTING COMMUNICATIONS CABLE TO BE REMOVED

NEW AERIAL GUY ASSEMBLY

NEW CONDUIT

EXISTING CONDUIT

DD

NEW DIRECTIONAL DRILLED CONDUIT

B&J

NEW BORED AND JACKED CONDUIT

NEW JUNCTION BOX

EXISTING JUNCTION BOX

NEW WOOD POLE

EXISTING WOOD POLE

S

AERIAL SPLICE ENCLOSURE

NEW METAL POLE

EXISTING METAL POLE

EXISTING CCTV ASSEMBLY

NEW STANDARD GUY ASSEMBLY

NEW SIDEWALK GUY ASSEMBLY

NEW CABLE STORAGE RACKS (SNOW SHOES)

X

EXISTING CONTROLLER AND CABINET

S

EXISTING SPLICE CABINET

S

NEW SPLICE CABINET

SP

SIGNAL POLE

XX-XXXX

SIGNAL INVENTORY NUMBER

CONSTRUCTION NOTE SYMBOLOGY KEY

XX

INDICATES NUMBER OF CABLES, LOOPS, ETC.

XX

INDICATES NUMBER OF FIBERS PER CABLE, TWISTED PAIRS PER CABLE, ETC.

XX

INDICATES NUMBER OF RISER(S)/CONDUIT(S)

XX

INDICATES DIAMETER OF RISER(S)/CONDUIT(S) (INCH)

NUMBER OF CABLE(S)

NUMBER OF FIBERS/TWISTED PAIRS

XX

XX

NUMBER OF RISER(S)/CONDUIT(S)

DIAMETER OF RISER(S)/CONDUIT(S) (INCH)

XX

XX

TMP FINAL

DOCUMENT NOT CONSIDERED FINAL
UNLESS ALL SIGNATURES COMPLETED

Prepared in the Offices of:

Seal of the State of North Carolina

750 N. Greenfield Pkwy., Garner, NC 27529

CONSTRUCTION NOTES

DIVISION 06 CUMBERLAND COUNTY

HOPE MILLS

PLAN DATE: NOVEMBER 2017

REVIEWED BY: Neil Avery

PREPARED BY: A. J. SKUCE

DOCSIGNED BY: MOHD A. ASLAMI

REVISIONS

INIT.

DATE


SEAL

Seal of the State of North Carolina

750 N. Greenfield Pkwy., Garner, NC 27529

DocuSigned by: MOHD A. ASLAMI



11/20/2017




1) FIVE (5) DAYS PRIOR TO BEGINNING WORK ON THE SIGNAL SYSTEM, CONTACT THE DIVISION TRAFFIC ENGINEER, FRANK WEST, AT (910)364-0606 TO ARRANGE FOR THE DIVISION TO PROGRAM THE NEW FIELD ETHERNET SWITCHES WITH THE NECESSARY NETWORK CONFIGURATION DATA, INCLUDING BUT NOT LIMITED TO: THE PROJECT IP ADDRESS, DEFAULT GATEWAY, SUBNET MASK AND VLAN ID INFORMATION. NOTIFY THE DIVISION TRAFFIC ENGINEER AFTER ALL WORK IS PERFORMED TO ENSURE THAT ALL FIBER CIRCUITS ARE FUNCTIONING PROPERLY. WORK IS NOT COMPLETE UNTIL THE SIGNAL SYSTEM IS BACK UP AND OPERATIONAL

TMP FINAL



DOCUMENT NOT CONSIDERED FINAL
UNLESS ALL SIGNATURES COMPLETED


 750 N. Greenfield Pkwy., Garner, NC 27529	COMMUNICATIONS CABLE AND CONDUIT ROUTING PLAN		SEAL 	
	DIVISION 06 CUMBERLAND COUNTY HOPE MILLS PLAN DATE: NOVEMBER 2017 PREPARED BY: A. J. SKUCE		REVIEWED BY: <i>Neil Avery</i> DATE: 11/20/2017 CADD Filename:	



TMP FINAL

DOCUMENT NOT CONSIDERED FINAL
UNLESS ALL SIGNATURES COMPLETED


 750 N. Greenfield Pkwy., Garner, NC 27529	COMMUNICATIONS CABLE AND CONDUIT ROUTING PLAN		SEAL 		
	DIVISION 06 CUMBERLAND COUNTY HOPE MILLS		DocuSigned by: MOHD A. ASLAM		
	PLAN DATE: NOVEMBER 2017	PREPARED BY: A. J. SKUCE	REVIEWED BY: Neil Avery	11/20/2017	
	SCALE 0 40' 1" = 40'		CADD Filename:		



- 1) FIVE (5) DAYS PRIOR TO BEGINNING WORK ON THE SIGNAL SYSTEM, CONTACT THE DIVISION TRAFFIC ENGINEER, FRANK WEST, AT (910)364-0606 TO ARRANGE FOR THE DIVISION TO PROGRAM THE NEW FIELD ETHERNET SWITCHES WITH THE NECESSARY NETWORK CONFIGURATION DATA, INCLUDING BUT NOT LIMITED TO: THE PROJECT IP ADDRESS, DEFAULT GATEWAY, SUBNET MASK AND VLAN ID INFORMATION. NOTIFY THE DIVISION TRAFFIC ENGINEER AFTER ALL WORK IS PERFORMED TO ENSURE THAT ALL FIBER CIRCUITS ARE FUNCTIONING PROPERLY. WORK IS NOT COMPLETE UNTIL THE SIGNAL SYSTEM IS BACK UP AND OPERATIONAL


TMP FINAL

DOCUMENT NOT CONSIDERED FINAL
UNLESS ALL SIGNATURES COMPLETED

 750 N. Greenfield Pkwy., Garner, NC 27529	COMMUNICATIONS CABLE AND CONDUIT ROUTING PLAN		SEAL	
	DIVISION 06 CUMBERLAND COUNTY HOPE MILLS		NORTH CAROLINA PROFESSIONAL ENGINEER SEAL 032108 MOHD A. ASLAMI	
	PLAN DATE: NOVEMBER 2017	REVIEWED BY: <i>Neil Avery</i>	INIT.	DATE
	PREPARED BY: A. J. SKUCE	REVISIONS	DATE	DATE

1" = 40'

CADD Filename:






- 1) FIVE (5) DAYS PRIOR TO BEGINNING WORK ON THE SIGNAL SYSTEM, CONTACT THE DIVISION TRAFFIC ENGINEER, FRANK WEST, AT (910)364-0606 TO ARRANGE FOR THE DIVISION TO PROGRAM THE NEW FIELD ETHERNET SWITCHES WITH THE NECESSARY NETWORK CONFIGURATION DATA, INCLUDING BUT NOT LIMITED TO: THE PROJECT IP ADDRESS, DEFAULT GATEWAY, SUBNET MASK AND VLAN ID INFORMATION. NOTIFY THE DIVISION TRAFFIC ENGINEER AFTER ALL WORK IS PERFORMED TO ENSURE THAT ALL FIBER CIRCUITS ARE FUNCTIONING PROPERLY. WORK IS NOT COMPLETE UNTIL THE SIGNAL SYSTEM IS BACK UP AND OPERATIONAL


TMP FINAL




DOCUMENT NOT CONSIDERED FINAL
UNLESS ALL SIGNATURES COMPLETED

 750 N. Greenfield Pkwy., Garner, NC 27529	COMMUNICATIONS CABLE AND CONDUIT ROUTING PLAN		SEAL NORTH CAROLINA PROFESSIONAL ENGINEER MOHD A. ASLAMI	
	DIVISION 06 CUMBERLAND COUNTY HOPE MILLS		DATE: 11/20/2017	
	PLAN DATE: NOVEMBER 2017	REVIEWED BY: Neil Avery	CADD Filename:	
	PREPARED BY: A. J. SKUCE	REVISIONS		




- 1) FIVE (5) DAYS PRIOR TO BEGINNING WORK ON THE SIGNAL SYSTEM, CONTACT THE DIVISION TRAFFIC ENGINEER, FRANK WEST, AT (910)364-0606 TO ARRANGE FOR THE DIVISION TO PROGRAM THE NEW FIELD ETHERNET SWITCHES WITH THE NECESSARY NETWORK CONFIGURATION DATA, INCLUDING BUT NOT LIMITED TO: THE PROJECT IP ADDRESS, DEFAULT GATEWAY, SUBNET MASK AND VLAN ID INFORMATION. NOTIFY THE DIVISION TRAFFIC ENGINEER AFTER ALL WORK IS PERFORMED TO ENSURE THAT ALL FIBER CIRCUITS ARE FUNCTIONING PROPERLY. WORK IS NOT COMPLETE UNTIL THE SIGNAL SYSTEM IS BACK UP AND OPERATIONAL
- 2) ETHERNET SWITCH TERMINATION CONFIGURATIONS ARE GENERIC. CONTRACTOR IS RESPONSIBLE FOR DETERMINING \ ENSURING PROPER TERMINATIONS.
- 3) INCLUDE ON THE COVER OF EACH SPLICE TRAY THE FOLLOWING:
REFERENCE SECTION 1731 "FIBER OPTIC SPLICE ENCLOSURE"
 - 1) SPLICE LOCATION
 - 2) DATE
 - 3) COMPANY NAME
 - 4) NAME OF INDIVIDUAL PERFORMING THE SPLICING





- 1) FIVE (5) DAYS PRIOR TO BEGINNING WORK ON THE SIGNAL SYSTEM, CONTACT THE DIVISION TRAFFIC ENGINEER, FRANK WEST, AT (910)364-0606 TO ARRANGE FOR THE DIVISION TO PROGRAM THE NEW FIELD ETHERNET SWITCHES WITH THE NECESSARY NETWORK CONFIGURATION DATA, INCLUDING BUT NOT LIMITED TO: THE PROJECT IP ADDRESS, DEFAULT GATEWAY, SUBNET MASK AND VLAN ID INFORMATION. NOTIFY THE DIVISION TRAFFIC ENGINEER AFTER ALL WORK IS PERFORMED TO ENSURE THAT ALL FIBER CIRCUITS ARE FUNCTIONING PROPERLY. WORK IS NOT COMPLETE UNTIL THE SIGNAL SYSTEM IS BACK UP AND OPERATIONAL
- 2) ETHERNET SWITCH TERMINATION CONFIGURATIONS ARE GENERIC. CONTRACTOR IS RESPONSIBLE FOR DETERMINING \ ENSURING PROPER TERMINATIONS.
- 3) INCLUDE ON THE COVER OF EACH SPLICE TRAY THE FOLLOWING:
REFERENCE SECTION 1731 "FIBER OPTIC SPLICE ENCLOSURE"



- 1) SPLICE LOCATION
- 2) DATE
- 3) COMPANY NAME
- 4) NAME OF INDIVIDUAL PERFORMING THE SPLICING

PRIOR TO INSTALLING THE COVER ON THE SPLICE TRAY TAKE A DIGITAL PHOTOGRAPH SHOWING THE SPLICE TRAY AND INFORMATION SHOWN ABOVE (1-4) AND SUBMIT PHOTOGRAPH ALONG WITH OTDR TEST RESULTS.

TMP FINAL	DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED
------------------	--

<i>Prepared in the Offices of:</i>  759 N. Greenfield Pkwy., Garner, NC 27529	SPLICE DETAIL	SEAL 												
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2" style="padding: 5px;"> DIVISION 06 CUMBERLAND COUNTY HOPE MILLS </td> </tr> <tr> <td style="width: 50%; padding: 5px;"> PLAN DATE: NOVEMBER 2017 </td> <td style="width: 50%; padding: 5px;"> REVIEWED BY: <i>Neil Avery</i> 09F50B0ABD0B6495 </td> </tr> <tr> <td colspan="2" style="padding: 5px;"> PREPARED BY: A. J. SKUCE </td> </tr> </table>			DIVISION 06 CUMBERLAND COUNTY HOPE MILLS		PLAN DATE: NOVEMBER 2017	REVIEWED BY: <i>Neil Avery</i> 09F50B0ABD0B6495	PREPARED BY: A. J. SKUCE							
DIVISION 06 CUMBERLAND COUNTY HOPE MILLS														
PLAN DATE: NOVEMBER 2017	REVIEWED BY: <i>Neil Avery</i> 09F50B0ABD0B6495													
PREPARED BY: A. J. SKUCE														
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 60%; padding: 5px;"> REVISIONS </td> <td style="width: 40%; padding: 5px;"> INIT. DATE </td> </tr> <tr><td style="height: 20px;"></td><td></td></tr> <tr><td style="height: 20px;"></td><td></td></tr> <tr><td style="height: 20px;"></td><td></td></tr> <tr><td style="height: 20px;"></td><td></td></tr> <tr><td style="height: 20px;"></td><td></td></tr> </table>			REVISIONS	INIT. DATE										
REVISIONS	INIT. DATE													
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 70%; padding: 5px;"> Documented by: <i>Mohd Aslami</i> 509B0B0ABD0B6495 </td> <td style="width: 30%; padding: 5px;"> 11/20/2017 DATE </td> </tr> </table>			Documented by: <i>Mohd Aslami</i> 509B0B0ABD0B6495	11/20/2017 DATE										
Documented by: <i>Mohd Aslami</i> 509B0B0ABD0B6495	11/20/2017 DATE													

