


**This electronic collection of documents is provided
for the convenience of the user
and is Not a Certified Document –**

**The documents contained herein were originally issued
and sealed by the individuals whose names and license
numbers appear on each page, on the dates appearing
with their signature on that page.**

**This file or an individual page
shall not be considered a certified document.**

PHASING DIAGRAM



PHASING DIAGRAM DETECTION LEGEND


- DETECTED MOVEMENT
- UNDETECTED MOVEMENT (OVERLAP)
- ⚡ UNSIGNALIZED MOVEMENT
- ➡ PEDESTRIAN MOVEMENT

TABLE OF OPERATION

SIGNAL FACE	PHASE					
	01+5	01+6	02+5	02+6	03	04
11	←	←	←	←	←	←
21,22	R	R	G	G	R	R
23	R	R	G	G	R	Y
31	R	R	R	R	G	R
32	R	R	R	R	G	R
41	R	R	R	R	G	R
42	R	R	R	R	G	R
43,44	→	→	R	R	R	R
51	←	←	←	←	←	←
61,62,63	R	G	R	G	R	Y
P21,P22	DW	DW	W	W	DW	DRK
P31,P32	DW	DW	DW	DW	W	DRK
P41,P42	DW	DW	DW	DW	W	DRK
P61,P62	DW	W	DW	W	DW	DRK

SIGNAL FACE I.D.

All Heads L.E.D.




ASC/3 DETECTOR INSTALLATION CHART

LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PROGRAMMING							
					PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE	LOOP SYSTEM	NEW CARD
1A	6X40	0	2-4-2	X	1	Yes	-	-	-	S	-	X
1B	6X40	0	2-4-2	X	1	Yes	-	15	-	S	-	X
1C	6X40	0	2-4-2	X	1	Yes	-	15	-	S	-	X
2A	6X6	300	5	X	2	Yes	-	-	X	N	-	X
2B	6X6	300	5	X	2	Yes	-	-	X	N	-	X
2C	6X6	300	5	X	2	Yes	-	-	X	N	-	X
3A	6X40	0	2-4-2	X	3	Yes	-	3	-	S	-	X
4A	6X40	0	2-4-2	X	4	Yes	-	3	-	S	-	X
5A	6X40	0	2-4-2	X	5	Yes	-	-	-	S	-	X
6A	6X6	300	4	X	6	Yes	-	-	X	N	-	X
6B	6X6	300	4	X	6	Yes	-	-	X	N	-	X
6C	6X6	300	4	X	6	Yes	-	-	X	N	-	X

6 Phase Fully Actuated Fayetteville Signal System

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 1 and/or Phase 5 may be lagged.
- The order of Phase 3 and Phase 4 may be reversed.
- Set all detector units to presence mode.
- Omit "WALK" and flashing "DON'T WALK" with no pedestrian calls.
- Program pedestrian heads to countdown the flashing "DON'T WALK" time only.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Pedestrian pedestals are conceptual and shown for reference only. See 2018 NCDOT Roadway Standard Drawings 1705.04 Sheets 1-3 for push button location details.



ASC/3 TIMING CHART

FEATURE	PHASE					
	1	2	3	4	5	6
Min Green *	7	12	7	7	7	12
Walk *	-	7	7	7	-	7
Ped Clear	-	25	29	22	-	9
Veh. Extension *	2.0	6.0	2.0	2.0	2.0	6.0
Max 1 *	50	90	20	25	20	90
Yellow	3.0	4.5	3.1	3.8	3.0	4.5
Red Clear	3.4	2.0	3.3	2.5	3.3	2.0
Red Revert	-	-	-	-	-	-
Actuations B4 Add *	-	-	-	-	-	-
Seconds / Actuation *	-	1.5	-	-	-	1.5
Max Initial *	-	34	-	-	-	34
Time Before Reduction *	-	15	-	-	-	15
Time To Reduce *	-	30	-	-	-	30
Minimum Gap	-	3.0	-	-	-	3.0
Locking Detector	-	X	-	-	-	X
Recall Position	-	VEH. RECALL	-	-	-	VEH. RECALL
Dual Entry	-	-	-	-	-	-
Simultaneous Gap	X	X	X	X	X	X

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND

- | PROPOSED | EXISTING |
|--|----------|
| ○ Traffic Signal Head | ● N/A |
| ○ Modified Signal Head | ○ N/A |
| ⊥ Sign | ⊥ |
| ⊥ Pedestrian Signal Head With Push Button & Sign | ⊥ |
| ⊥ Signal Pole with Guy | ⊥ |
| ⊥ Signal Pole with Sidewalk Guy | ⊥ |
| ⊥ Inductive Loop Detector | ⊥ |
| ⊥ Controller & Cabinet | ⊥ |
| ⊥ Junction Box | ⊥ |
| ⊥ 2-in Underground Conduit | ⊥ |
| → Right of Way | → |
| → Directional Arrow | → |
| ○ Metal Strain Pole | ○ |
| ○ Type II Signal Pedestal | ○ |
| ⊥ "U-TURN YIELD TO RIGHT TURN" Sign (R10-16) | ⊥ |

Signal Upgrade - Final Design

Stantec
 Stantec Consulting Services Inc.
 801 Jones Franklin Road-Suite 300
 Raleigh, NC 27606
 Tel. (919) 851-6866
 Fax. (919) 851-7024
 www.stantec.com
 License No. F-0672

Prepared for the Offices of:

 750 N. Greenfield Pkwy, Garner, NC 27526
 SCALE: 1" = 40'

US 401 (Raeford Road) at SR 1141 (Bingham Drive)
 Division 6 Cumberland County Fayetteville
 PLAN DATE: March 2018 REVIEWED BY: E D Harris
 PREPARED BY: G B Spell REVIEWED BY: B L Watson



Professional Engineer Seal
 SEAL 29449
 JESSY L. WATSON
 3/29/2018
 SIG. INVENTORY NO. 06-0358

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

3/29/2018 10:41:11 AM C:\Users\jgw\Documents\Signal Design\4405\sig_dsn_06-0358_Final.dgn User: jgw

EDI MODEL 2018ECLip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



- NOTES:**
- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
 - Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
 - Ensure that Red Enable is active at all times during normal operation.
 - Integrate monitor with Ethernet network in cabinet.

NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Program controller to start up in Phase 2 WALK and Phase 6 WALK.
- The cabinet and controller are part of the Fayetteville Signal System.

EQUIPMENT INFORMATION

CONTROLLER.....2070
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S3,S4, S5,S6,S7,S8, S9,S10,S12,AUX S5
 PHASES USED.....1,2,2PED,3,3PED, 4,4PED,5,6,6PED
 OVERLAP A.....NOT USED
 OVERLAP B.....NOT USED
 OVERLAP C.....NOT USED
 OVERLAP D.....*
 OVERLAP G.....*
 * See Overlap Programming Detail on sheet 2

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6			
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18			
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	OLG	8	3 PED	OLA	OLB	OLE	OLC	OLD	OLF			
SIGNAL HEAD NO.	11	21,22,23	P21,P22	31	32	41	42	23	P41,P42	51	61,62,63	P61,P62	43,44	NU	P31,P32	NU	NU	NU	43,44	NU	
RED	128			116	116	101	101						134							A121	
YELLOW	129			117	117	102	102						135								
GREEN	130			118	118	103	103						136								
RED ARROW	125												131								
YELLOW ARROW	126								102				132								A122
FLASHING YELLOW ARROW																					A123
GREEN ARROW	127			118	118	103	103			103			133								
Hand													113								110
Walker													115								112


NU = Not Used
 * See pictorial of head wiring in detail this sheet.

COUNTDOWN PEDESTRIAN SIGNAL OPERATION

Countdown Ped Signals are required to display timing only during Ped Clearance Interval. Consult Ped Signal Module user's manual for instructions on selecting this feature.

INPUT FILE POSITION LAYOUT

(front view)



INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND TIME	DELAY TIME	ADDED INITIAL	DETECTOR TYPE
1A	TB2-5,6	I2U	39	2	1	YES				S
1B	TB2-1,2	I1U	56	1	1	YES		15		S
1C	TB2-3,4	I1L	56	1	1	YES		15		S
2A	TB2-7,8	I2L	43	12	2	YES			X	N
2B	TB2-9,10	I3U	63	32	2	YES			X	N
2C	TB2-11,12	I3L	76	42	2	YES			X	N
3A	TB4-5,6	I5U	58	3	3	YES		5		S
4A	TB4-9,10	I6U	41	4	4	YES		3		S
5A	TB3-1,2	J1U	55	5	5	YES				S
6A	TB3-5,6	J2U	40	6	6	YES			X	N
6B	TB3-7,8	J2L	44	16	6	YES			X	N
6C	TB3-9,10	J3U	64	36	6	YES			X	N

NOTE: INSTALL DC ISOLATORS IN INPUT FILE SLOTS 112 AND 113.
 INPUT FILE POSITION LEGEND: J2L

ECONOLITE ASC/3-2070 PED 3 PROGRAMMING ASSIGNMENT DETAIL

(program controller as shown)

- From Main Menu select **6. DETECTORS**
- From DETECTOR Submenu select **3. PED DETECTOR INPUT ASSIGNMENT**

PED DET PHASE ASSIGNMENT MODE: NTCIP	
PHASE	1 2 3 4 5 6 7 8
DETECTOR	0 2 8 4 0 6 0 0
PHASE	9 10 11 12 13 14 15 16
DETECTOR	0 0 0 0 0 0 0 0

NOTICE PED DETECTOR 8 ASSIGNED TO PHASE 3


- From Main Menu select **1. CONFIGURATION**
- From CONFIGURATION Submenu select **3. LOAD SW ASSIGN**

LD SWITCH ASSIGN	PHASE	DIMMING	FLASH
/OVLP	TYPE	R Y G D	PWR AUT TGR
1	1	V	. . . + A Y X
2	2	V	. . . + A Y .
3	3	V	. . . + A R X
4	4	V	. . . + A R .
5	5	V	. . . + A Y .
6	6	V	. . . + A Y X
7	7	0	. . . - A R X
8	8	0	. . . - A R X
9	1	0	. . . + A R X
10	2	0	. . . + A R X
11	3	0	. . . - A R .
12	4	0	. . . - A R .
13	2	P	. . . + A . .
14	4	P	. . . + A . .
15	6	P	. . . + A . .
16	3	P	. . . - A . .

NOTICE PHASE 3 PED ASSIGNED TO LD SWITCH 16

FYA SIGNAL WIRING DETAIL

(wire signal head as shown)



43,44

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0358
 DESIGNED: March 2018
 SEALED: 03-29-2018
 REVISED: N/A

Final Design
 Electrical Detail - Sheet 1 of 2

Stantec Consulting Services Inc.
 801 Jones Franklin Road-Suite 300
 Raleigh, NC 27606
 Tel. (919) 851-6866
 Fax. (919) 851-7024
 www.stantec.com
 License No. F-0672

ELECTRICAL AND PROGRAMMING DETAILS FOR:

Prepared in the Offices of:

US 401 (Raeford Road)
 at
 SR 1141 (Bingham Drive)

Division 6 Cumberland County Fayetteville

PLAN DATE: March 2018 REVIEWED BY: L Overn

PREPARED BY: G B Spell REVIEWED BY:

SEAL

PROFESSIONAL ENGINEER

LAURENCE E. OVERN

3/29/2018

DATE

SIG. INVENTORY NO. 06-0358

DATE: U:\Projects\Signal\060358\electrical\Detail\sig\4405.sig.dwg User: rmanney

ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select 2. CONTROLLER
2. From CONTROLLER Submenu select 2. VEHICLE OVERLAPS
3. Toggle Until Positioned on Overlap G

OVERLAP G

Select TMG VEH OVLP [G] and 'NORMAL'

TMG VEH OVLP...[G] TYPE:NORMAL

PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6

INCLUDED . . . X

LAG GRN 0.0 YEL 0.0 RED 0.0

↓

Toggle Until Positioned
on Overlap D

OVERLAP D

Select TMG VEH OVLP [D] and 'PPLT FYA'

TMG VEH OVLP...[D] TYPE:PPLT FYA

PROTECTED PHASE (LEFT TURN)..... 1

PERMISSIVE PHASE (OPPOSING THRU).... G

FLASHING ARROW OUTPUT.....CH12 ISOLATE

DELAY START OF: FYA..0.0 CLEARANCE..0.0

ACTION PLAN SF BIT DISABLE..... 0

END PROGRAMMING

FLASHER CIRCUIT MODIFICATION DETAIL

IN ORDER TO INSURE THAT SIGNALS FLASH CONCURRENTLY ON THE SAME APPROACH, MAKE THE FOLLOWING FLASHER CIRCUIT CHANGES:

1. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-4 AND TERMINATE ON T2-2.
2. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-5 AND TERMINATE ON T2-3.
3. REMOVE FLASHER UNIT 2.

THE CHANGES LISTED ABOVE TIES ALL PHASES AND OVERLAPS TO FLASHER UNIT 1.

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-0358
DESIGNED: March 2018
SEALED: 03-29-2018
REVISED: N/A

Final Design
Electrical Detail - Sheet 2 of 2



DOCUMENT NOT CONSIDERED FINAL
UNLESS ALL SIGNATURES COMPLETED

 Stantec Consulting Services Inc. 801 Jones Franklin Road-Suite 300 Raleigh, NC 27606 Tel. (919) 851-6866 Fax. (919) 851-7024 www.stantec.com License No. F-0672	ELECTRICAL AND PROGRAMMING DETAILS FOR: Prepared in the Offices of: 750 N. Greenfield Pkwy, Garner, NC 27529	US 401 (Raeford Road) at SR 1141 (Bingham Drive) Division 6 Cumberland County Fayetteville PLAN DATE: March 2018 REVIEWED BY: L Overn PREPARED BY: G B Spell REVIEWED BY:	SEAL LAWRENCE E. OVERN ENGINEER 045933 3/29/2018											
		<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 70%;">REVISIONS</th> <th style="width: 10%;">INIT.</th> <th style="width: 20%;">DATE</th> </tr> </thead> <tbody> <tr> <td> </td> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> <td> </td> </tr> </tbody> </table>	REVISIONS	INIT.	DATE									
REVISIONS	INIT.	DATE												

DATE: 03/29/2018 10:45:11 AM User: rfmancey

EDI MODEL 2018ECLip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



NOTES:

1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
3. Ensure that Red Enable is active at all times during normal operation.
4. Integrate monitor with Ethernet network in cabinet.

NOTES

1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
2. Program controller to start up in phase 2 Green and 6 Green.
3. The cabinet and controller are part of the Fayetteville Signal System.

EQUIPMENT INFORMATION

CONTROLLER.....2070
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE LOAD SWITCHES USED.....S1,S2,S5,S7,S8,S11,AUX S1, AUX S4
 PHASES USED.....1,2,4,5,6,8
 OVERLAP A.....*
 OVERLAP B.....NOT USED
 OVERLAP C.....*
 OVERLAP D.....NOT USED

* See Overlap Programming Detail on Sheet 2

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	11*	21,22	NU	NU	41,42	NU	51*	61,62,63	NU	NU	81,82	NU	11*	NU	NU	51*	NU	NU
RED		128			101			134			107							
YELLOW	*	129			102		*	135			108							
GREEN		130			103			136			109							
RED ARROW													A121			A114		
YELLOW ARROW													A122			A115		
FLASHING YELLOW ARROW													A123			A116		
GREEN ARROW	127							133										


NU = Not Used
 * Denotes install load resistor. See load resistor installation detail this sheet.
 ★ See pictorial of head wiring in detail below.

DETECTOR NOTES

1. For all loops install a video detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.
2. For loops 1A and 5A detector card placements and slots reserved for wired inputs are typical for a NCDOT installation. Inputs associated with these slots are compatible with time of day instructions located on sheet 2 of this electrical detail.

INPUT FILE POSITION LAYOUT

(front view)




EX.: 1A, 2A, ETC. = LOOP NO.'S
 FS = FLASH SENSE
 ST = STOP TIME
 ⊗ Wired Input - Do not populate slot with detector card

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND TIME	DELAY TIME	ADDED INITIAL	DETECTOR TYPE
1A ¹	-	I1U	56	1★	1	YES		15		S
	-	J4U	48	26★	6	YES		3		G
5A ²	-	J1U	55	5★	5	YES		15		S
	-	I4U	47	22★	2	YES		3		G


¹Add jumper from I1-W to J4-W, on rear of input file.
²Add jumper from J1-W to I4-W, on rear of input file.

★ For the detectors to work as shown on the signal design plan, see the Vehicle Detector Setup Programming Detail for Alternate Phasing on sheet 2.



FYA SIGNAL WIRING DETAIL


(wire signal heads as shown)



LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown)

ACCEPTABLE VALUES	
VALUE (ohms)	WATTAGE
1.5K - 1.9K	25W (min)
2.0K - 3.0K	10W (min)



Temporary Design 1 - TMP Phase I Electrical Detail - Sheet 1 of 2

US 401 (Raeford Road) at Revere Street/ Time Warner Cable Driveway
 Division 6 Cumberland County Fayetteville
 PLAN DATE: March 2018 REVIEWED BY: L Overn
 PREPARED BY: G B Spell REVIEWED BY:

SEAL
 NORTH CAROLINA PROFESSIONAL ENGINEER
 LAWRENCE E. OVERN
 3/29/2018
 DATE
 SIG. INVENTORY NO. 06-0592T1

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0592T1
 DESIGNED: March 2018
 SEALED: 03-29-2018
 REVISED: N/A

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

DATE: U:\Traffic\Signal\Signal\Detail\Signal\Phase 1\U-4405.sig.ele_06-0592T1.dgn User: rfmuncy

ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL

(program controller as shown)

- From Main Menu select **2. CONTROLLER**
- From CONTROLLER Submenu select **2. VEHICLE OVERLAPS**

OVERLAP A

Select TMG VEH OVLP [A] and 'PPLT FYA'

```

TMG VEH OVLP...[A] TYPE: ....[PPLT FYA]
PROTECTED LEFT TURN.... PHASE 1
OPPOSING THROUGH..... PHASE 2

FLASHING ARROW OUTPUT....CH9 ISOLATE
DELAY START OF: FYA..0.0 CLEARANCE..0.0
ACTION PLAN SF BIT DISABLE..... 1
    
```

NOTICE SF BIT DISABLE 1 ←

Toggle Twice

OVERLAP C

Select TMG VEH OVLP [C] and 'PPLT FYA'

```

TMG VEH OVLP...[C] TYPE: ....[PPLT FYA]
PROTECTED LEFT TURN.... PHASE 5
OPPOSING THROUGH..... PHASE 6

FLASHING ARROW OUTPUT....CH11 ISOLATE
DELAY START OF: FYA..0.0 CLEARANCE..0.0
ACTION PLAN SF BIT DISABLE..... 5
    
```

NOTICE SF BIT DISABLE 1 ←

END PROGRAMMING

ECONOLITE ASC/3-2070 VEHICLE DETECTOR SETUP

PROGRAMMING DETAIL FOR
ALTERNATE PHASING LOOPS 1A, 5A

(program controller as shown)

IMPORTANT!

Program detectors per the input file connection and programming chart shown on sheet 1 before proceeding.

- From Main Menu select **8. UTILITIES**
- From UTILITIES Submenu select **1. COPY/CLEAR**
- Copy from DETECTOR PLAN "1" to DETECTOR PLAN "2".

```

COPY / CLEAR UTILITY
FROM          TO
PHASE TIMING... > PHASE TIMING...
TIMING PLAN... > TIMING PLAN...
PH DET OPT PLAN. > PH DET OPT PLAN.
DETECTOR PLAN... 1 > DETECTOR PLAN... 2
TOGGLE TO SELECT A "FROM" AND A "TO"
THEN PRESS ENTER
    
```

- From Main Menu select **6. DETECTORS**
- From DETECTOR Submenu select **2. VEHICLE DETECTOR SETUP**
- Place cursor in VEH DET PLAN [] position and enter "2".

- Place cursor in VEH DETECTOR [] position and enter "1".
- Set delay time to "3.0".

```

VEH DETECTOR [ 1]  VEH DET PLAN [ 2]
TYPE: S-STANDARD
TS2 DETECTOR..... ECPI LOG..... NO
DET PH - 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
1 1 .....
EXTEND TIME... 0.0 DELAY TIME... 3.0
USE ADDED INITIAL . CROSS SWITCH PH.. 0
LOCK IN..... NONE NTCIP VOL . OR OCC .
PMT QUEUE DELAY. NO
    
```

NOTICE VEH DET PLAN 2 ←

ENSURE DELAY IS SET TO '3.0' ←

- Place cursor in VEH DETECTOR [] position and enter "26".
- Set assigned phase to "0".

```

VEH DETECTOR [26]  VEH DET PLAN [ 2]
TYPE: G-GREEN EXTENSION/DELAY
TS2 DETECTOR..... ECPI LOG..... NO
DET PH - 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
26 0 .....
EXTEND TIME... 0.0 DELAY TIME... 3.0
USE ADDED INITIAL . CROSS SWITCH PH.. 0
LOCK IN..... NONE NTCIP VOL . OR OCC .
PMT QUEUE DELAY. NO
    
```

NOTICE VEH DET PLAN 2 ←

ENSURE PHASE IS SET TO "0" ←

- Place cursor in VEH DETECTOR [] position and enter "5".
- Set delay time to "3.0".

```

VEH DETECTOR [ 5]  VEH DET PLAN [ 2]
TYPE: S-STANDARD
TS2 DETECTOR..... ECPI LOG..... NO
DET PH - 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
5 5 .....
EXTEND TIME... 0.0 DELAY TIME... 3.0
USE ADDED INITIAL . CROSS SWITCH PH.. 0
LOCK IN..... NONE NTCIP VOL . OR OCC .
PMT QUEUE DELAY. NO
    
```

NOTICE VEH DET PLAN 2 ←

ENSURE DELAY IS SET TO '3.0' ←

- Place cursor in VEH DETECTOR [] position and enter "22".
- Set assigned phase to "0".

```

VEH DETECTOR [22]  VEH DET PLAN [ 2]
TYPE: G-GREEN EXTENSION/DELAY
TS2 DETECTOR..... ECPI LOG..... NO
DET PH - 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
22 0 .....
EXTEND TIME... 0.0 DELAY TIME... 3.0
USE ADDED INITIAL . CROSS SWITCH PH.. 0
LOCK IN..... NONE NTCIP VOL . OR OCC .
PMT QUEUE DELAY. NO
    
```

NOTICE VEH DET PLAN 2 ←

ENSURE PHASE IS SET TO "0" ←

END PROGRAMMING

ECONOLITE ASC/3-2070 ACTION PLAN

PROGRAMMING DETAIL

- From Main Menu select **5. TIME BASE**
- From TIME BASE Submenu select **2. ACTION PLAN**

```

ACTION PLAN...[ 1]
PATTERN.....AUTO  SYS OVERRIDE.... NO
TIMING PLAN..... 0  SEQUENCE..... 0
VEH DETECTOR PLAN.. 2  DET LOG.....NONE
FLASH..... --  RED REST..... NO
VEH DET DIAG PLN.. 0  PED DET DIAG PLN..0
DIMMING ENABLE.. NO  PRIORITY RETURN. NO
PED PR RETURN.. NO  QUEUE DELAY..... NO
PMT COND DELAY  NO

PHASE  1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
PED RCL . . . . .
WALK 2 . . . . .
VEX 2 . . . . .
VEH RCL . . . . .
MAX RCL . . . . .
MAX 2 . . . . .
PHASE  1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
MAX 3 . . . . .
CS INH . . . . .
OMIT . . . . .
SPC FCT X . . . X . . . (1-8)
AUX FCT . . . (1-3)

LP 1-15 . . . . .
LP 16-30 . . . . .
LP 31-45 . . . . .
LP 46-60 . . . . .
LP 61-75 . . . . .
LP 76-90 . . . . .
LP 91-100 . . . . .
    
```

ALTERNATE PHASING ACTIVATION DETAIL

TO RUN ALT. PHASING DURING FREE RUN - PROGRAM CHANGES (SHOWN BELOW) IN A TIME BASED ACTION PLAN. SCHEDULE A DAY PLAN THAT INCLUDES THE ACTION PLAN PROGRAMMED TO SELECT VEH DET PLAN 2 AND ENABLE SF BITS 1 and 5.

TO RUN ALT. PHASING DURING COORDINATION - SELECT THE TIME BASED ACTION PLAN THAT IS PROGRAMMED TO SELECT VEH DET PLAN 2 AND ENABLE SF BITS 1 and 5.

PHASING	VEH DET PLAN	SF BITS ENABLED
ACTIONS REQUIRED TO RUN <u>DEFAULT PHASING</u>	1	NONE
ACTIONS REQUIRED TO RUN <u>ALTERNATE PHASING</u>	2	1, 5

IMPORTANT: IF ALT. PHASING IS USED DURING FREE RUN AND COORDINATION, DO NOT OPERATE TIME OF DAY EVENTS CONCURRENTLY WITH COORDINATION PLAN EVENTS IN THE EVENT SCHEDULER. (EX. FREE RUN EVENT SHOULD END BEFORE COORDINATION PLAN EVENT STARTS AND VICE-VERSA).

ALTERNATE PHASING CHANGE SUMMARY

THE FOLLOWING IS A SUMMARY OF WHAT TAKES PLACE WHEN SF BITS 1 AND 5 AND VEH DET PLAN 2 ACTIVATE TO CALL THE "ALTERNATE PHASING":

- SF BITS 1,5:** Modifies overlap parent phases for heads 11 and 51 to run protected turns only.
- VEH DET PLAN 2:** Disables phase 6 call on loop 1A and reduces delay time for phase 1 call on loop 1A to 3 seconds.
Disables phase 2 call on loop 5A and reduces delay time for phase 5 call on loop 5A to 3 seconds.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0592T1
DESIGNED: March 2018
SEALED: 03-29-2018
REVISED: N/A


Temporary Design 1 - TMP Phase I
Electrical Detail - Sheet 2 of 2

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

<p>Stantec Consulting Services Inc. 801 Jones Franklin Road-Suite 300 Raleigh, NC 27606 Tel. (919) 851-6866 Fax. (919) 851-7024 www.stantec.com License No. F-0672</p>	<p>ELECTRICAL AND PROGRAMMING DETAILS FOR:</p> <p>Prepared in the Offices of:</p> <p>750 N. Greenfield Pkwy, Garner, NC 27529</p>	<p>US 401 (Raeford Road) at Revere Street/ Time Warner Cable Driveway</p> <p>Division 6 Cumberland County Fayetteville</p>		<p>SEAL</p> <p>3/29/2018</p>						
		<p>PLAN DATE: March 2018</p> <p>REVIEWED BY: L Overn</p> <p>PREPARED BY: G B Spell</p>	<p>REVIEWED BY:</p>		<p>REVISIONS</p> <table border="1"> <tr> <th>NO.</th> <th>DATE</th> <th>INIT.</th> <th>DATE</th> </tr> <tr> <td> </td> <td> </td> <td> </td> <td> </td> </tr> </table>	NO.	DATE	INIT.	DATE	
NO.	DATE	INIT.	DATE							

DATE: 03/29/2018 11:05:11 AM User: rmlmancy


DEFAULT PHASING DIAGRAM




DEFAULT TABLE OF OPERATION

SIGNAL FACE	PHASE					
	01+5	01+6	02+5	02+6	04+8	FLASH
11	←	←	←	←	←	Y
21,22	R	R	G	G	R	Y
41,42	R	R	R	R	G	R
51	←	←	←	←	←	Y
61,62	R	G	R	G	R	Y
81,82	R	R	R	R	G	R

SIGNAL FACE I.D.
All Heads L.E.D.



ALTERNATE PHASING DIAGRAM



ALTERNATE TABLE OF OPERATION

SIGNAL FACE	PHASE					
	01+5	01+6	02+5	02+6	04+8	FLASH
11	←	←	←	←	←	Y
21,22	R	R	G	G	R	Y
41,42	R	R	R	R	G	R
51	←	←	←	←	←	Y
61,62	R	G	R	G	R	Y
81,82	R	R	R	R	G	R

ASC/3 DETECTOR INSTALLATION CHART

LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PROGRAMMING							
					PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE	SYSTEM LOOP	NEW CARD
1A	6X40	0	*	-	1	Yes	-	15★	-	S	-	-
2A	6X6	300	*	-	2	Yes	-	-	-	N	-	-
2B	6X6	300	*	-	2	Yes	-	-	-	N	-	-
2C	6X40	0	*	-	2	Yes	2.0	5	-	G	-	-
2D	6X40	0	*	-	2	Yes	2.0	5	-	G	-	-
4A	6X40	0	*	-	4	Yes	-	3	-	S	-	-
4B	6X40	0	*	-	4	Yes	-	10	-	S	-	-
5A	6X40	0	*	-	5	Yes	-	15★	-	S	-	-
6A	6X6	300	*	-	6	Yes	-	-	-	N	-	-
6B	6X6	300	*	-	6	Yes	-	-	-	N	-	-
6C	6X40	0	*	-	6	Yes	2.0	5	-	G	-	-
6D	6X40	0	*	-	6	Yes	2.0	5	-	G	-	-
8A	6X40	0	*	-	8	Yes	-	5	-	S	-	-



*Video Detection Area. Camera locations should be confirmed in the field by the contractor in order to provide detection of the areas indicated.
Disable Phases call during Alternate Phasing Operation.
★ Reduce delay from 15 to 3 seconds during Alternate Phasing Operation.

5 Phase Fully Actuated Fayetteville Signal System


NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 1 and/or phase 5 may be lagged.
- Reposition existing signal heads numbered 21 and 22.
- Set all detector units to presence mode.
- The Division (City) Traffic Engineer will determine the hours of use for each phasing plan.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.

PHASING DIAGRAM DETECTION LEGEND



LEGEND



ASC/3 TIMING CHART

FEATURE	PHASE						
	1	2	4	5	6	8	
Min Green *	7	12	7	7	12	7	
Walk *	-	-	-	-	-	-	
Ped Clear	-	-	-	-	-	-	
Veh. Extension *	2.0	6.0	2.0	2.0	6.0	2.0	
Max 1 *	20	90	30	20	90	30	
Yellow	3.0	4.8	3.1	3.0	4.8	3.1	
Red Clear	2.4	1.3	2.9	2.6	1.3	2.4	
Actuations B4 Add *	-	-	-	-	-	-	
Seconds / Actuation *	-	-	-	-	-	-	
Max Initial *	-	-	-	-	-	-	
Time Before Reduction *	-	15	-	-	15	-	
Time To Reduce *	-	45	-	-	45	-	
Minimum Gap	-	3.0	-	-	3.0	-	
Locking Detector	-	-	-	-	-	-	
Recall Position	-	VEH. RECALL	-	-	VEH. RECALL	-	
Dual Entry	-	-	-	-	-	-	
Simultaneous Gap	X	X	X	X	X	X	

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

Signal Upgrade Temporary Design 2 - TMP Phase II

Stantec Consulting Services Inc.
801 Jones Franklin Road-Suite 300
Raleigh, NC 27606
Tel. (919) 851-6866
Fax. (919) 851-7024
www.stantec.com
License No. F-0672

Prepared For the Offices of:

750 N. Greenfield Pkwy, Garner, NC 27526

US 401 (Raeford Road) at Revere Street/ Time Warner Cable Driveway

Division 6 Cumberland County Fayetteville

PLAN DATE: March 2018 REVIEWED BY: E D Harris

PREPARED BY: R M Muncey REVIEWED BY: B L Watson

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

3/29/2018


DATE: 3/29/2018

SIG. INVENTORY NO. 06-059212

3/29/2018 10:58 AM
 User: rfmuncey
 Path: \\server\projects\signal\Design\Temporary_Signal_Design\Phase_2\U-4405.sig.dgn, 06-059212.dgn

EDI MODEL 2018ECLip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



- NOTES:
1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
 2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
 3. Ensure that Red Enable is active at all times during normal operation.
 4. Integrate monitor with Ethernet network in cabinet.

NOTES

1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
2. Program controller to start up in phase 2 Green and 6 Green.
3. The cabinet and controller are part of the Fayetteville Signal System.

EQUIPMENT INFORMATION

CONTROLLER.....2070
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE AUX S1, AUX S4
 LOAD SWITCHES USED.....S1,S2,S5,S7,S8,S11,AUX S1, AUX S4
 PHASES USED.....1,2,4,5,6,8
 OVERLAP A.....*
 OVERLAP B.....NOT USED
 OVERLAP C.....*
 OVERLAP D.....NOT USED

* See Overlap Programming Detail on Sheet 2

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	11*	21,22	NU	NU	41,42	NU	51*	61,62	NU	NU	81,82	NU	11*	NU	NU	51*	NU	NU
RED		128			101			134			107							
YELLOW	*	129			102		*	135			108							
GREEN		130			103			136			109							
RED ARROW													A121			A114		
YELLOW ARROW													A122			A115		
FLASHING YELLOW ARROW													A123			A116		
GREEN ARROW	127							133										


NU = Not Used
 * Denotes install load resistor. See load resistor installation detail this sheet.
 ★ See pictorial of head wiring in detail below.

DETECTOR NOTES

1. For all loops install a video detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.
2. For loops 1A and 5A detector card placements and slots reserved for wired inputs are typical for a NCDOT installation. Inputs associated with these slots are compatible with time of day instructions located on sheet 2 of this electrical detail.

INPUT FILE POSITION LAYOUT

(front view)




EX.: 1A, 2A, ETC. = LOOP NO.'S
 FS = FLASH SENSE
 ST = STOP TIME
 ⊗ Wired Input - Do not populate slot with detector card

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND TIME	DELAY TIME	ADDED INITIAL	DETECTOR TYPE
1A ¹	-	I1U	56	1★	1	YES		15		S
	-	J4U	48	26★	6	YES		3		G
5A ²	-	J1U	55	5★	5	YES		15		S
	-	I4U	47	22★	2	YES		3		G


- ¹Add jumper from I1-W to J4-W, on rear of input file.
 - ²Add jumper from J1-W to I4-W, on rear of input file.
- ★ For the detectors to work as shown on the signal design plan, see the Vehicle Detector Setup Programming Detail for Alternate Phasing on sheet 2.



LOAD RESISTOR INSTALLATION DETAIL


(install resistors as shown)

ACCEPTABLE VALUES	
VALUE (ohms)	WATTAGE
1.5K - 1.9K	25W (min)
2.0K - 3.0K	10W (min)



FYA SIGNAL WIRING DETAIL

(wire signal heads as shown)



Temporary Design 2 - TMP Phase II Electrical Detail - Sheet 1 of 2

Stantec Consulting Services Inc.
 801 Jones Franklin Road-Suite 300
 Raleigh, NC 27606
 Tel. (919) 851-6866
 Fax. (919) 851-7024
 www.stantec.com
 License No. F-0672

ELECTRICAL AND PROGRAMMING DETAILS FOR:

Prepared in the Offices of:

750 N. Greenfield Pkwy, Garner, NC 27529

US 401 (Raeford Road) at Revere Street/ Time Warner Cable Driveway
 Division 6 Cumberland County Fayetteville

PLAN DATE: March 2018 REVIEWED BY: L Overn
 PREPARED BY: G B Spell REVIEWED BY:

REVISIONS	INIT.	DATE

SEAL

3/29/2018

SIG. INVENTORY NO. 06-0592T2

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

DATE: U:\Projects\Signal\Signal\Temporary_Signals\Phase 2\U-4405.sig.ele_06-0592T2.dgn User: rrmunicy

ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL

(program controller as shown)

- From Main Menu select **2. CONTROLLER**
- From CONTROLLER Submenu select **2. VEHICLE OVERLAPS**

OVERLAP A

Select TMG VEH OVLP [A] and 'PPLT FYA'

```

TMG VEH OVLP...[A] TYPE: ....[PPLT FYA]
PROTECTED LEFT TURN.... PHASE 1
OPPOSING THROUGH..... PHASE 2

FLASHING ARROW OUTPUT....CH9 ISOLATE
DELAY START OF: FYA..0.0 CLEARANCE..0.0
ACTION PLAN SF BIT DISABLE..... 1
  
```

NOTICE SF BIT DISABLE 1 ←

Toggle Twice

OVERLAP C

Select TMG VEH OVLP [C] and 'PPLT FYA'

```

TMG VEH OVLP...[C] TYPE: ....[PPLT FYA]
PROTECTED LEFT TURN.... PHASE 5
OPPOSING THROUGH..... PHASE 6

FLASHING ARROW OUTPUT....CH11 ISOLATE
DELAY START OF: FYA..0.0 CLEARANCE..0.0
ACTION PLAN SF BIT DISABLE..... 5
  
```

NOTICE SF BIT DISABLE 1 ←

END PROGRAMMING

ECONOLITE ASC/3-2070 VEHICLE DETECTOR SETUP PROGRAMMING DETAIL FOR ALTERNATE PHASING LOOPS 1A, 5A

(program controller as shown)

IMPORTANT!

Program detectors per the input file connection and programming chart shown on sheet 1 before proceeding.

- From Main Menu select **8. UTILITIES**
- From UTILITIES Submenu select **1. COPY/CLEAR**
- Copy from DETECTOR PLAN "1" to DETECTOR PLAN "2".

```

COPY / CLEAR UTILITY
FROM          TO
PHASE TIMING... > PHASE TIMING...
TIMING PLAN... > TIMING PLAN...
PH DET OPT PLAN. > PH DET OPT PLAN.
DETECTOR PLAN... 1 > DETECTOR PLAN... 2
TOGGLE TO SELECT A "FROM" AND A "TO"
THEN PRESS ENTER
  
```

- From Main Menu select **6. DETECTORS**
- From DETECTOR Submenu select **2. VEHICLE DETECTOR SETUP**
- Place cursor in VEH DET PLAN [] position and enter "2".

- Place cursor in VEH DETECTOR [] position and enter "1".
- Set delay time to "3.0".

```

VEH DETECTOR [ 1] VEH DET PLAN [ 2]
TYPE: S-STANDARD
TS2 DETECTOR..... ECPI LOG..... NO
DET PH - 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
1 1
EXTEND TIME... 0.0 DELAY TIME... 3.0
USE ADDED INITIAL . CROSS SWITCH PH.. 0
LOCK IN..... NONE NTCIP VOL . OR OCC .
PMT QUEUE DELAY. NO
  
```

NOTICE VEH DET PLAN 2 ←

ENSURE DELAY IS SET TO '3.0' ←

- Place cursor in VEH DETECTOR [] position and enter "26".
- Set assigned phase to "0".

```

VEH DETECTOR [26] VEH DET PLAN [ 2]
TYPE: G-GREEN EXTENSION/DELAY
TS2 DETECTOR..... ECPI LOG..... NO
DET PH - 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
26 0
EXTEND TIME... 0.0 DELAY TIME... 3.0
USE ADDED INITIAL . CROSS SWITCH PH.. 0
LOCK IN..... NONE NTCIP VOL . OR OCC .
PMT QUEUE DELAY. NO
  
```

NOTICE VEH DET PLAN 2 ←

ENSURE PHASE IS SET TO "0" ←

- Place cursor in VEH DETECTOR [] position and enter "5".
- Set delay time to "3.0".

```

VEH DETECTOR [ 5] VEH DET PLAN [ 2]
TYPE: S-STANDARD
TS2 DETECTOR..... ECPI LOG..... NO
DET PH - 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
5 5
EXTEND TIME... 0.0 DELAY TIME... 3.0
USE ADDED INITIAL . CROSS SWITCH PH.. 0
LOCK IN..... NONE NTCIP VOL . OR OCC .
PMT QUEUE DELAY. NO
  
```

NOTICE VEH DET PLAN 2 ←

ENSURE DELAY IS SET TO '3.0' ←

- Place cursor in VEH DETECTOR [] position and enter "22".
- Set assigned phase to "0".

```

VEH DETECTOR [22] VEH DET PLAN [ 2]
TYPE: G-GREEN EXTENSION/DELAY
TS2 DETECTOR..... ECPI LOG..... NO
DET PH - 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
22 0
EXTEND TIME... 0.0 DELAY TIME... 3.0
USE ADDED INITIAL . CROSS SWITCH PH.. 0
LOCK IN..... NONE NTCIP VOL . OR OCC .
PMT QUEUE DELAY. NO
  
```

NOTICE VEH DET PLAN 2 ←

ENSURE PHASE IS SET TO "0" ←

END PROGRAMMING

ECONOLITE ASC/3-2070 ACTION PLAN PROGRAMMING DETAIL

- From Main Menu select **5. TIME BASE**
- From TIME BASE Submenu select **2. ACTION PLAN**

```

ACTION PLAN...[ 1]
PATTERN.....AUTO SYS OVERRIDE.... NO
TIMING PLAN..... 0 SEQUENCE..... 0
VEH DETECTOR PLAN.. 2 DET LOG.....NONE
FLASH..... -- RED REST..... NO
VEH DET DIAG PLN.. 0 PED DET DIAG PLN..0
DIMMING ENABLE.. NO PRIORITY RETURN. NO
PED PR RETURN.. NO QUEUE DELAY..... NO
PMT COND DELAY NO

PHASE 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
PED RCL . . . . .
WALK 2 . . . . .
VEX 2 . . . . .
VEH RCL . . . . .
MAX RCL . . . . .
MAX 2 . . . . .
PHASE 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
MAX 3 . . . . .
CS INH . . . . .
OMIT . . . . .
SPC FCT X . . . X . . . (1-8)
AUX FCT . . . (1-3)
1 2 3 4 5 6 7 8 9 0 1 2 3 4 5
LP 1-15 . . . . .
LP 16-30 . . . . .
LP 31-45 . . . . .
LP 46-60 . . . . .
LP 61-75 . . . . .
LP 76-90 . . . . .
LP 91-100 . . . . .
  
```

ALTERNATE PHASING ACTIVATION DETAIL

TO RUN ALT. PHASING DURING FREE RUN - PROGRAM CHANGES (SHOWN BELOW) IN A TIME BASED ACTION PLAN. SCHEDULE A DAY PLAN THAT INCLUDES THE ACTION PLAN PROGRAMMED TO SELECT VEH DET PLAN 2 AND ENABLE SF BITS 1 and 5.

TO RUN ALT. PHASING DURING COORDINATION - SELECT THE TIME BASED ACTION PLAN THAT IS PROGRAMMED TO SELECT VEH DET PLAN 2 AND ENABLE SF BITS 1 and 5.

PHASING	VEH DET PLAN	SF BITS ENABLED
ACTIONS REQUIRED TO RUN <u>DEFAULT PHASING</u>	1	NONE
ACTIONS REQUIRED TO RUN <u>ALTERNATE PHASING</u>	2	1, 5

IMPORTANT: IF ALT. PHASING IS USED DURING FREE RUN AND COORDINATION, DO NOT OPERATE TIME OF DAY EVENTS CONCURRENTLY WITH COORDINATION PLAN EVENTS IN THE EVENT SCHEDULER. (EX. FREE RUN EVENT SHOULD END BEFORE COORDINATION PLAN EVENT STARTS AND VICE-VERSA).

ALTERNATE PHASING CHANGE SUMMARY

THE FOLLOWING IS A SUMMARY OF WHAT TAKES PLACE WHEN SF BITS 1 AND 5 AND VEH DET PLAN 2 ACTIVATE TO CALL THE "ALTERNATE PHASING":

SF BITS 1,5: Modifies overlap parent phases for heads 11 and 51 to run protected turns only.

VEH DET PLAN 2: Disables phase 6 call on loop 1A and reduces delay time for phase 1 call on loop 1A to 3 seconds.

Disables phase 2 call on loop 5A and reduces delay time for phase 5 call on loop 5A to 3 seconds.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0592T2
DESIGNED: March 2018
SEALED: 03-29-2018
REVISED: N/A

Temporary Design 2 - TMP Phase II
Electrical Detail - Sheet 2 of 2


DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED



Stantec Consulting Services Inc.
801 Jones Franklin Road-Suite 300
Raleigh, NC 27606
Tel. (919) 851-6866
Fax. (919) 851-7024
www.stantec.com
License No. F-0672

ELECTRICAL AND PROGRAMMING DETAILS FOR:

Prepared in the Offices of:




750 N. Greenfield Pkwy, Garner, NC 27529

US 401 (Raeford Road)
at
Revere Street/
Time Warner Cable Driveway
Division 6 Cumberland County Fayetteville

PLAN DATE: March 2018 REVIEWED BY: L Overn
PREPARED BY: G B Spell REVIEWED BY:

REVISIONS	INIT.	DATE

SEAL



3/29/2018
DATE
SIG. INVENTORY NO. 06-0592T2

DATE: U:\Projects\Signal\Signal\Temp\Temporary Signal\Phase 2\U-4405-sig.ele_06-0592T2.dgn User: rmlunacy

PHASING DIAGRAM





TABLE OF OPERATION

SIGNAL FACE	PHASE					FLASH
	Ø1+5	Ø2+5	Ø2+6	Ø4+8	Ø1+6	
11	←	←	←	←	←	—
21,22	R	R	G	G	R	Y
41,42	R	R	R	R	G	R
51	←	←	←	←	←	—
61,62	R	G	R	G	R	Y
81,82	R	R	R	R	G	R

SIGNAL FACE I.D.



ASC/3 DETECTOR INSTALLATION CHART

LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PROGRAMMING					TYPE	SYSTEM LOOP	NEW CARD
					PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL			
1A	6X40	0	*	-	1	Yes	-	-	-	S	-	-
2A	6X6	300	*	-	2	Yes	-	-	-	N	-	-
2B	6X6	300	*	-	2	Yes	-	-	-	N	-	-
2C	6X40	0	*	-	2	Yes	2.0	5	-	G	-	-
2D	6X40	0	*	-	2	Yes	2.0	5	-	G	-	-
4A	6X40	0	*	-	4	Yes	-	3	-	S	-	-
4B	6X40	0	*	-	4	Yes	-	10	-	S	-	-
5A	6X40	0	*	-	5	Yes	-	-	-	S	-	-
6A	6X6	300	*	-	6	Yes	-	-	-	N	-	-
6B	6X6	300	*	-	6	Yes	-	-	-	N	-	-
6C	6X40	0	*	-	6	Yes	2.0	5	-	G	-	-
6D	6X40	0	*	-	6	Yes	2.0	5	-	G	-	-
8A	6X40	0	*	-	8	Yes	-	5	-	S	-	-

5 Phase Fully Actuated Fayetteville Signal System


NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 1 and/or phase 5 may be lagged.
- Reposition existing signal heads numbered 11, 21, 22, 51, 61, and 62.
- Set all detector units to presence mode.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.

*Video Detection Area. Camera locations should be confirmed in the field by the contractor in order to provide detection of the areas indicated.

PHASING DIAGRAM DETECTION LEGEND

- DETECTED MOVEMENT
- ◄ UNDETECTED MOVEMENT (OVERLAP)
- UNSIGNALIZED MOVEMENT
- ⤴ PEDESTRIAN MOVEMENT



ASC/3 TIMING CHART

FEATURE	PHASE					
	1	2	4	5	6	8
Min Green *	7	12	7	7	12	7
Walk *	-	-	-	-	-	-
Ped Clear	-	-	-	-	-	-
Veh. Extension *	2.0	6.0	2.0	2.0	6.0	2.0
Max I *	20	90	30	20	90	30
Yellow	3.0	4.8	3.1	3.0	4.8	3.1
Red Clear	3.1	1.3	3.1	3.3	1.3	3.2
Actuations B4 Add *	-	-	-	-	-	-
Seconds /Actuation *	-	-	-	-	-	-
Max Initial *	-	-	-	-	-	-
Time Before Reduction *	-	15	-	-	15	-
Time To Reduce *	-	45	-	-	45	-
Minimum Gap	-	3.0	-	-	3.0	-
Locking Detector	-	-	-	-	-	-
Recall Position	-	VEH. RECALL	-	-	VEH. RECALL	-
Dual Entry	-	-	-	-	-	-
Simultaneous Gap	X	X	X	X	X	X

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.


LEGEND

- | PROPOSED | EXISTING |
|--|-----------|
| ○ → Traffic Signal Head | ● → N/A |
| ○ → Modified Signal Head | ○ → N/A |
| ⊥ Sign | ⊥ N/A |
| ⊥ Pedestrian Signal Head With Push Button & Sign | ⊥ N/A |
| ○ → Signal Pole with Guy | ○ → N/A |
| ○ → Signal Pole with Sidewalk Guy | ○ → N/A |
| ⊠ Video Detection Area | ⊠ N/A |
| □ Controller & Cabinet Junction Box | □ N/A |
| --- 2-in Underground Conduit | --- N/A |
| --- Right of Way | --- N/A |
| → Directional Arrow | → N/A |
| ▬ Construction Zone | ▬ N/A |
| ● ● ● Video Detection Area | ● ● ● N/A |
| ● ● ● Drums | ● ● ● N/A |

Signal Upgrade Temporary Design 3 - TMP Phase III


<p>Stantec Consulting Services Inc. 801 Jones Franklin Road-Suite 300 Raleigh, NC 27606 Tel. (919) 851-6866 Fax. (919) 851-7024 www.stantec.com License No. F-0672</p>		<p>US 401 (Raeford Road) at Revere Street/ Time Warner Cable Driveway</p>	
		<p>Division 6 Cumberland County Fayetteville</p> <p>PLAN DATE: March 2018 REVIEWED BY: E D Harris</p> <p>PREPARED BY: R M Muncey REVIEWED BY: B L Watson</p>	<p>3/29/2018</p>

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED



EDI MODEL 2018ECLip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



NOTES:

1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
3. Ensure that Red Enable is active at all times during normal operation.
4. Integrate monitor with Ethernet network in cabinet.

NOTES

1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
2. Return controller to Factory Defaults before programming per this electrical detail.
3. Program controller to start up in phase 2 Green and 6 Green.
4. The cabinet and controller are part of the Fayetteville Signal System.

EQUIPMENT INFORMATION

CONTROLLER.....2070
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S5,S7,S8,S11
 PHASES USED.....1,2,4,5,6,8
 OVERLAP A.....NOT USED
 OVERLAP B.....NOT USED
 OVERLAP C.....NOT USED
 OVERLAP D.....NOT USED

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	11	21,22	NU	NU	41,42	NU	51	61,62	NU	NU	81,82	NU	NU	NU	NU	NU	NU	NU
RED		128			101			134			107							
YELLOW		129			102			135			108							
GREEN		130			103			136			109							
RED ARROW	125							131										
YELLOW ARROW	126							132										
GREEN ARROW	127							133										

NU = Not Used


★ See pictorial of head wiring in detail below.

DETECTOR NOTES

1. For all loops install a video detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.
2. Remove "Wired Inputs" from rear of input file to prevent unwanted calls to Phases 2 and 6.

INPUT FILE POSITION LAYOUT

(front view)




EX.: 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
 ST = STOP TIME

SIGNAL WIRING DETAIL


(wire signal heads as shown)



THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0592T3
 DESIGNED: March 2018
 SEALED: 03-29-2018
 REVISED: N/A

LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown)



Temporary Design 3 - TMP Phase III
 Electrical Detail

DOCUMENT NOT CONSIDERED FINAL
 UNLESS ALL SIGNATURES COMPLETED

Stantec Consulting Services Inc.
 801 Jones Franklin Road-Suite 300
 Raleigh, NC 27606
 Tel. (919) 851-6866
 Fax. (919) 851-7024
 www.stantec.com
 License No. F-0672

Prepared in the Offices of:


750 N. Greenfield Pkwy, Garner, NC 27529

US 401 (Raeford Road)
 at
 Revere Street/
 Time Warner Cable Driveway
 Division 6 Cumberland County Fayetteville

PLAN DATE: March 2018 REVIEWED BY: L Overn
 PREPARED BY: G B Spell REVIEWED BY:

REVISIONS	INIT.	DATE


DEFAULT PHASING DIAGRAM



DEFAULT TABLE OF OPERATION

SIGNAL FACE	PHASE						FLASH
	01+5	01+6	02+5	02+6	04+8	01+5	
11	←	←	←	←	←	←	Y
21,22,23	R	R	G	G	R	Y	
41,42	R	R	R	R	G	R	
51	←	←	←	←	←	Y	
61,62,63	R	G	R	G	R	Y	
81,82	R	R	R	R	G	R	
P21,P22	DW	DW	W	W	DW	DRK	
P41,P42	DW	DW	DW	DW	W	DRK	
P61,P62	DW	W	DW	W	DW	DRK	
P81,P82	DW	DW	DW	DW	W	DRK	


ALTERNATE PHASING DIAGRAM




ALTERNATE TABLE OF OPERATION

SIGNAL FACE	PHASE						FLASH
	01+5	01+6	02+5	02+6	04+8	01+5	
11	←	←	←	←	←	Y	
21,22,23	R	R	G	G	R	Y	
41,42	R	R	R	R	G	R	
51	←	←	←	←	←	Y	
61,62,63	R	G	R	G	R	Y	
81,82	R	R	R	R	G	R	
P21,P22	DW	DW	W	W	DW	DRK	
P41,P42	DW	DW	DW	DW	W	DRK	
P61,P62	DW	W	DW	W	DW	DRK	
P81,P82	DW	DW	DW	DW	W	DRK	

SIGNAL FACE I.D.



PHASING DIAGRAM DETECTION LEGEND




ASC/3 DETECTOR INSTALLATION CHART

LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PROGRAMMING							
					PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE	SYSTEM LOOP	NEW CARD
1A	6X40	0	2-4-2	X	1	Yes	-	15★	-	S	-	X
2A	6X6	300	6	X	2	Yes	-	-	X	N	-	X
2B	6X6	300	6	X	2	Yes	-	-	X	N	-	X
2C	6X6	300	6	X	2	Yes	-	-	X	N	-	X
4A	6X40	0	2-4-2	X	4	Yes	-	-	-	S	-	X
4B	6X40	0	2-4-2	X	4	Yes	-	-	-	S	-	X
5A	6X40	0	2-4-2	X	5	Yes	-	15★	-	S	-	X
6A	6X6	300	5	X	6	Yes	-	-	X	N	-	X
6B	6X6	300	5	X	6	Yes	-	-	X	N	-	X
6C	6X6	300	5	X	6	Yes	-	-	X	N	-	X
8A	6X40	0	2-4-2	X	8	Yes	-	10	-	S	-	X

5 Phase Fully Actuated Fayetteville Signal System


- NOTES**
- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
 - Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
 - Phase 1 and/or phase 5 may be lagged.
 - Set all detector units to presence mode.
 - Omit "WALK" and Flashing "DON'T WALK" with no pedestrian calls.
 - Program pedestrian heads to countdown the flashing "Don't Walk" time only.
 - The Division (City) Traffic Engineer will determine the hours of use for each phasing plan.
 - Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
 - Pedestrian pedestals are conceptual and shown for reference only. See 2018 NCDOT Roadway Standard Drawings 1704.04 Sheets 1-3 for push button location details.



ASC/3 TIMING CHART

FEATURE	PHASE					
	1	2	4	5	6	8
Min Green *	7	12	7	7	12	7
Walk *	-	7	7	-	7	7
Ped Clear	-	13	23	-	15	26
Veh. Extension *	2.0	6.0	2.0	2.0	6.0	2.0
Max I *	20	90	30	20	90	30
Yellow	3.0	4.8	3.1	3.0	4.8	3.1
Red Clear	2.9	1.8	3.3	3.3	1.8	3.3
Actuations B4 Add *	-	0	-	-	0	-
Seconds / Actuation *	-	1.2	-	-	1.2	-
Max Initial *	-	34	-	-	34	-
Time Before Reduction *	-	15	-	-	15	-
Time To Reduce *	-	45	-	-	45	-
Minimum Gap	-	3.0	-	-	3.0	-
Locking Detector	-	-	-	-	-	-
Recall Position	-	VEH. RECALL	-	-	VEH. RECALL	-
Dual Entry	-	-	-	-	-	-
Simultaneous Gap	X	X	X	X	X	X

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.




Signal Upgrade - Final Design

<p>Stantec Consulting Services Inc. 801 Jones Franklin Road-Suite 300 Raleigh, NC 27606 Tel. (919) 851-6866 Fax. (919) 851-7024 www.stantec.com License No. F-0672</p>	<p>Prepared for the Offices of:</p> <p>750 N. Greenfield Pkwy, Garner, NC 27526</p>	<p>US 401 (Raeford Road) at Revere Street/ Time Warner Cable Driveway</p>		
		<p>Division 6 Cumberland County Fayetteville</p> <p>PLAN DATE: March 2018 REVIEWED BY: E D Harris</p> <p>PREPARED BY: R M Muncey REVIEWED BY: B L Watson</p>	<p>DATE: 3/29/2018</p> <p>SIG. INVENTORY NO. 06-0592</p>	

3/29/2018 10:41:00 AM C:\Users\jgms\Documents\Signal Design\US401-4405-1-1-1.dgn User: jgms

PHASING DIAGRAM



PHASING DIAGRAM DETECTION LEGEND


- DETECTED MOVEMENT
- UNDETECTED MOVEMENT (OVERLAP)
- UNSIGNALIZED MOVEMENT
- PEDESTRIAN MOVEMENT

TABLE OF OPERATION

SIGNAL FACE	PHASE			
	02+5	04	02+6	02+5
21,22	G	G	R	Y
41,42	R	R	Y	R
43,44	Y	Y	R	R
51,52	R	R	Y	R
61,62	R	G	R	Y
63	R	G	Y	Y

SIGNAL FACE I.D.

All Heads L.E.D.



ASC/3 DETECTOR INSTALLATION CHART


LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PROGRAMMING							
					PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE	SYSTEM LOOP	NEW CARD
2A	6X6	300	*	X	2	Yes	-	-	-	N	-	X
2B	6X40	0	*	X	2	Yes	2.0	5	-	G	-	X
4A	6X40	0	*	X	4	Yes	-	-	-	S	-	X
4B	6X40	0	*	X	4	Yes	-	-	-	S	-	X
5A	6X40	0	*	X	5	Yes	-	-	-	S	-	X
5B	6X40	0	*	X	5	Yes	-	-	-	S	-	X
5C	6X40	0	*	X	5	Yes	-	15	-	S	-	X
5D	6X40	0	*	X	5	Yes	-	15	-	S	-	X
6A	6X6	300	*	X	6	Yes	-	-	-	N	-	X
6B	6X6	300	*	X	6	Yes	-	-	-	N	-	X
6C	6X6	300	*	X	6	Yes	-	-	-	N	-	X
6D	6X40	0	*	X	6	Yes	2.0	5	-	G	-	X
6E	6X40	0	*	X	6	Yes	2.0	5	-	G	-	X
6F	6X40	0	*	X	6	Yes	2.0	5	-	G	-	X

*Video Detection Area. Camera locations should be confirmed in the field by the contractor in order to provide detection of the areas indicated.

3 Phase Fully Actuated Fayetteville Signal System

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 5 may be lagged.
- Set all detector units to presence mode.
- Locate new cabinet foundation so as not to obstruct sight distance of vehicles turning right on red. Relocate existing cabinet and controller onto new foundation.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Field adjust temporary poles as needed.



ASC/3 TIMING CHART

FEATURE	PHASE			
	2	4	5	6
Min Green *	12	7	7	12
Walk *	-	-	-	-
Ped Clear	-	-	-	-
Veh. Extension *	6.0	2.0	2.0	6.0
Max 1 *	90	30	35	90
Yellow	4.5	3.0	3.0	4.8
Red Clear	1.6	3.6	3.3	1.8
Actuations B4 Add *	-	-	-	-
Seconds / Actuation *	-	-	-	-
Max Initial *	-	-	-	-
Time Before Reduction *	15	-	-	15
Time To Reduce *	45	-	-	45
Minimum Gap	3.0	-	-	3.0
Locking Detector	-	-	-	-
Recall Position	VEH. RECALL	-	-	VEH. RECALL
Dual Entry	-	-	-	-
Simultaneous Gap	X	X	X	X

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND

- | | | | |
|--|-----------------------------------|--|-----------------------------------|
| | Proposed Traffic Signal Head | | Existing Traffic Signal Head |
| | Proposed Modified Signal Head | | Existing Modified Signal Head |
| | Proposed Pedestrian Signal Head | | Existing Pedestrian Signal Head |
| | Proposed Signal Pole with Guy | | Existing Signal Pole with Guy |
| | Proposed Inductive Loop Detector | | Existing Inductive Loop Detector |
| | Proposed Controller & Cabinet | | Existing Controller & Cabinet |
| | Proposed Junction Box | | Existing Junction Box |
| | Proposed 2-in Underground Conduit | | Existing 2-in Underground Conduit |
| | Proposed Right of Way | | Existing Right of Way |
| | Proposed Directional Arrow | | Existing Directional Arrow |
| | Proposed Video Detection Area | | Existing Video Detection Area |
| | Proposed Construction Zone | | Existing Construction Zone |
| | Proposed Drums | | Existing Drums |

Signal Upgrade Temporary Design 1- TMP Phase I

Stantec
 Stantec Consulting Services Inc.
 801 Jones Franklin Road-Suite 300
 Raleigh, NC 27606
 Tel. (919) 851-6866
 Fax. (919) 851-7024
 www.stantec.com
 License No. F-0672

Prepared for the Offices of:

 750 N. Greenfield Pkwy, Garner, NC 27526
 SCALE: 0 40
 1" = 40'

US 401/US 401 Business (Raeford Road) at US 401 (Skibo Road)
 Division 6 Cumberland County Fayetteville
 PLAN DATE: March 2018 REVIEWED BY: E D Harris
 PREPARED BY: K Williams REVIEWED BY: B L Watson


REVISIONS	INIT.	DATE

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

E D Harris
 3/29/2018
 DATE
 SIG. INVENTORY NO. 06-009611

EDI MODEL 2018ECLip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



NOTES:

1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
3. Ensure that Red Enable is active at all times during normal operation.
4. Integrate monitor with Ethernet network in cabinet.

NOTES

1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
2. Program controller to start up in phase 2 Green and 6 Green.
3. The cabinet and controller are part of the Fayetteville Signal System.

EQUIPMENT INFORMATION

CONTROLLER.....2070
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 W/ AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S2,S5,S7,S8,AUX S4
 PHASES USED.....2,4,5,6
 OVERLAP A.....NOT USED
 OVERLAP B.....NOT USED
 OVERLAP C.....4+5
 OVERLAP D.....NOT USED


SIGNAL HEAD HOOK-UP CHART

	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	NU	21,22	NU	NU	41,42	63	NU	51,52	61,62,63	NU	NU	NU	NU	NU	NU	43,44	NU	NU
RED		128							134							A114		
YELLOW		129							135									
GREEN		130							136									
RED ARROW					101			131										
YELLOW ARROW					102	102		132								A115		
GREEN ARROW					103	103		133								A116		

NU = Not Used

INPUT FILE POSITION LAYOUT

(front view)



SPECIAL DETECTOR NOTE

Install a video detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.

FLASHER CIRCUIT MODIFICATION DETAIL

IN ORDER TO INSURE THAT SIGNALS FLASH CONCURRENTLY ON THE SAME APPROACH, MAKE THE FOLLOWING FLASHER CIRCUIT CHANGES:

1. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-4 AND TERMINATE ON T2-2.
2. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-5 AND TERMINATE ON T2-3.
3. REMOVE FLASHER UNIT 2.

THE CHANGES LISTED ABOVE TIES ALL PHASES AND OVERLAPS TO FLASHER UNIT 1.

ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select **2. CONTROLLER**
2. From CONTROLLER Submenu select **2. VEHICLE OVERLAPS**

OVERLAP C Toggle Twice

Select TMG VEH OVLP [C] and 'NORMAL'

TMG VEH OVLP...[C] TYPE:**NORMAL**

PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6

INCLUDED . . . X X

LAG GRN 0.0 YEL 0.0 RED 0.0

END PROGRAMMING


THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0096T1
 DESIGNED: March 2018
 SEALED: 03-29-2018
 REVISED: N/A

Temporary Design 1 - TMP Phase I
 Electrical Detail

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

<p>Stantec Consulting Services Inc. 801 Jones Franklin Road-Suite 300 Raleigh, NC 27606 Tel. (919) 851-6866 Fax. (919) 851-7024 www.stantec.com License No. F-0672</p>	<p>Lawrence E. Overn Professional Engineer License No. 045933</p>	ELECTRICIAN AND PROGRAMMING DETAILS FOR:		US 401/US 401 Business (Raeford Road) at US 401 (Skibo Road)	
		Prepared in the Offices of:		Division 6 Cumberland County Fayetteville	
PLAN DATE: March 2018		REVIEWED BY: L Overn		PREPARED BY: G B Spell	
REVISIONS		INIT.		DATE	
3/29/2018		DATE		SIG. INVENTORY NO. 06-0096T1	

PHASING DIAGRAM



PHASING DIAGRAM DETECTION LEGEND


- → DETECTED MOVEMENT
- → UNDETECTED MOVEMENT (OVERLAP)
- UNSIGNALIZED MOVEMENT
- ⤴ ⤵ PEDESTRIAN MOVEMENT

TABLE OF OPERATION

SIGNAL FACE	PHASE			
	02+5	02+6	04	Y
21,22	G	G	R	Y
41	←	←	←	←
42	→	→	→	→
51	←	←	←	←
61,62	R	G	R	Y

SIGNAL FACE I.D.

All Heads L.E.D.



ASC/3 DETECTOR INSTALLATION CHART


LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	PROGRAMMING									
			TURNS	NEW LOOP	PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE	SYSTEM LOOP	NEW CARD
2A	6X6	300	*	-	2	Yes	-	-	-	N	-	-
2B	6X6	300	*	-	2	Yes	-	-	-	N	-	-
2C	6X40	0	*	-	2	Yes	2.0	5	-	G	-	-
2D	6X40	0	*	-	2	Yes	2.0	5	-	G	-	-
4B	6X40	0	*	-	4	Yes	-	-	-	S	-	-
5A	6X40	0	*	-	5	Yes	-	-	-	S	-	-
5C	6X40	0	*	-	5	Yes	-	15	-	S	-	-
6A	6X6	300	*	-	6	Yes	-	-	-	N	-	-
6B	6X6	300	*	-	6	Yes	-	-	-	N	-	-
6C	6X40	0	*	-	6	Yes	2.0	5	-	G	-	-
6D	6X40	0	*	-	6	Yes	2.0	5	-	G	-	-

*Video Detection Area. Camera locations should be confirmed in the field by the contractor in order to provide detection of the areas indicated.

3 Phase Fully Actuated Fayetteville Signal System

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 5 may be lagged.
- Set all detector units to presence mode.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.



ASC/3 TIMING CHART

FEATURE	PHASE			
	2	4	5	6
Min Green *	12	7	7	12
Walk *	-	-	-	-
Ped Clear	-	-	-	-
Veh. Extension *	6.0	2.0	2.0	6.0
Max 1 *	90	30	35	90
Yellow	4.5	3.0	3.0	4.8
Red Clear	1.6	3.4	3.2	1.6
Actuations B4 Add *	-	-	-	-
Seconds / Actuation *	-	-	-	-
Max Initial *	-	-	-	-
Time Before Reduction *	15	-	-	15
Time To Reduce *	45	-	-	45
Minimum Gap	3.0	-	-	3.0
Locking Detector	-	-	-	-
Recall Position	VEH. RECALL	-	-	VEH. RECALL
Dual Entry	-	-	-	-
Simultaneous Gap	X	X	X	X

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND

- | PROPOSED | EXISTING |
|-----------------------------------|----------|
| ○ → Traffic Signal Head | ● → N/A |
| ○ → Modified Signal Head | ○ → N/A |
| ○ → Sign | ○ → N/A |
| ○ → Pedestrian Signal Head | ○ → N/A |
| ○ → With Push Button & Sign | ○ → N/A |
| ○ → Signal Pole with Guy | ○ → N/A |
| ○ → Signal Pole with Sidewalk Guy | ○ → N/A |
| ○ → Inductive Loop Detector | ○ → N/A |
| ○ → Controller & Cabinet | ○ → N/A |
| ○ → Junction Box | ○ → N/A |
| ○ → 2-in Underground Conduit | ○ → N/A |
| ○ → N/A | ○ → N/A |
| ○ → Right of Way | ○ → N/A |
| ○ → Directional Arrow | ○ → N/A |
| ○ → Video Detection Area | ○ → N/A |
| ○ → Construction Zone | ○ → N/A |
| ○ → Drums | ○ → N/A |


Signal Upgrade Temporary Design 2- TMP Phase II

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

<p>Stantec Consulting Services Inc. 801 Jones Franklin Road-Suite 300 Raleigh, NC 27606 Tel. (919) 851-6866 Fax. (919) 851-7024 www.stantec.com License No. F-0672</p>		<p>US 401/US 401 Business (Raeford Road) at US 401 (Skibo Road)</p>	
		<p>Division 6 Cumberland County Fayetteville</p> <p>PLAN DATE: March 2018 REVIEWED BY: E D Harris</p> <p>PREPARED BY: K Williams REVIEWED BY: B L Watson</p>	
<p>750 N. Greenfield Pkwy, Garner, NC 27526</p> <p>SCALE: 0 40 1" = 40'</p>		<p>3/29/2018 DATE</p> <p>SIG. INVENTORY NO. 06-009612</p>	

EDI MODEL 2018ECLip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



NOTES:

1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
3. Ensure that Red Enable is active at all times during normal operation.
4. Integrate monitor with Ethernet network in cabinet.

NOTES

1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
2. Program controller to start up in phase 2 Green and 6 Green.
3. The cabinet and controller are part of the Fayetteville Signal System.

EQUIPMENT INFORMATION

CONTROLLER.....2070
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 W/ AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S2,S5,S7,S8,AUX S4
 PHASES USED.....2,4,5,6
 OVERLAP A.....NOT USED
 OVERLAP B.....NOT USED
 OVERLAP C.....4+5
 OVERLAP D.....NOT USED


SIGNAL HEAD HOOK-UP CHART

	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	NU	21,22	NU	NU	41	NU	51	61,62	NU	NU	NU	NU	NU	NU	NU	42	NU	NU
RED		128						134								A114		
YELLOW		129						135										
GREEN		130						136										
RED ARROW					101		131											
YELLOW ARROW					102		132									A115		
GREEN ARROW					103		133									A116		

NU = Not Used

INPUT FILE POSITION LAYOUT

(front view)



SPECIAL DETECTOR NOTE

Install a video detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.

FLASHER CIRCUIT MODIFICATION DETAIL

IN ORDER TO INSURE THAT SIGNALS FLASH CONCURRENTLY ON THE SAME APPROACH, MAKE THE FOLLOWING FLASHER CIRCUIT CHANGES:

1. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-4 AND TERMINATE ON T2-2.
2. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-5 AND TERMINATE ON T2-3.
3. REMOVE FLASHER UNIT 2.

THE CHANGES LISTED ABOVE TIES ALL PHASES AND OVERLAPS TO FLASHER UNIT 1.

ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select **2. CONTROLLER**
2. From CONTROLLER Submenu select **2. VEHICLE OVERLAPS**

OVERLAP C Toggle Twice

Select TMG VEH OVLP [C] and 'NORMAL'

TMG VEH OVLP...[C] TYPE:**NORMAL**

PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6

INCLUDED . . . X X

LAG GRN 0.0 YEL 0.0 RED 0.0


END PROGRAMMING

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0096T2
 DESIGNED: March 2018
 SEALED: 03-29-2018
 REVISED: N/A

Temporary Design 2 - TMP Phase II Electrical Detail

<p>Stantec Consulting Services Inc. 801 Jones Franklin Road-Suite 300 Raleigh, NC 27606 Tel. (919) 851-6866 Fax. (919) 851-7024 www.stantec.com License No. F-0672</p>	<p>ELECTRICAL AND PROGRAMMING DETAILS FOR:</p> <p>Prepared in the Offices of:</p>	<p>US 401/US 401 Business (Raeford Road) at US 401 (Skibo Road)</p> <p>Division 6 Cumberland County Fayetteville</p>		<p>SEAL</p> <p>3/29/2018</p>					
		<p>PLAN DATE: March 2018</p> <p>REVIEWED BY: L Overn</p> <p>PREPARED BY: G B Spell</p>	<p>REVIEWED BY:</p>		<p>REVISIONS</p> <table border="1"> <tr> <th>NO.</th> <th>INIT.</th> <th>DATE</th> </tr> <tr> <td> </td> <td> </td> <td> </td> </tr> </table>	NO.	INIT.	DATE	
NO.	INIT.	DATE							

PHASING DIAGRAM



PHASING DIAGRAM DETECTION LEGEND


- DETECTED MOVEMENT
- UNDETECTED MOVEMENT (OVERLAP)
- UNSIGNALIZED MOVEMENT
- PEDESTRIAN MOVEMENT

TABLE OF OPERATION

SIGNAL FACE	PHASE			
	Ø 2+5	Ø 2+6	Ø 4	F L S Y
21,22	G	G	R	Y
41,42	R	R	L	R
43,44	L	R	L	R
51,52	L	R	R	R
61,62	R	G	R	Y

SIGNAL FACE I.D.

All Heads L.E.D.



41,42 51,52 21,22 61,62 43,44

ASC/3 DETECTOR INSTALLATION CHART


LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PROGRAMMING						SYSTEM LOOP	NEW CARD
					PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE		
2A	6X6	300	*	-	2	Yes	-	-	-	N	-	
2B	6X6	300	*	-	2	Yes	-	-	-	N	-	
2C	6X40	0	*	-	2	Yes	2.0	5	-	G	-	
2D	6X40	0	*	-	2	Yes	2.0	5	-	G	-	
4A	6X40	0	*	-	4	Yes	-	-	-	S	-	
4B	6X40	0	*	-	4	Yes	-	-	-	S	-	
5A	6X40	0	*	-	5	Yes	-	-	-	S	-	
5B	6X40	0	*	-	5	Yes	-	-	-	S	-	
5C	6X40	0	*	-	5	Yes	-	15	-	S	-	
5D	6X40	0	*	-	5	Yes	-	15	-	S	-	
6A	6X6	300	*	-	6	Yes	-	-	-	N	-	
6B	6X6	300	*	-	6	Yes	-	-	-	N	-	
6C	6X40	0	*	-	6	Yes	2.0	5	-	G	-	
6D	6X40	0	*	-	6	Yes	2.0	5	-	G	-	

*Video Detection Area. Camera locations should be confirmed in the field by the contractor in order to provide detection of the areas indicated.

3 Phase Fully Actuated Fayetteville Signal System

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 5 may be lagged.
- Set all detector units to presence mode.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.



ASC/3 TIMING CHART

FEATURE	PHASE			
	2	4	5	6
Min Green *	12	7	7	12
Walk *	-	-	-	-
Ped Clear	-	-	-	-
Veh. Extension *	6.0	2.0	2.0	6.0
Max 1 *	90	30	35	90
Yellow	4.5	3.0	3.0	4.8
Red Clear	1.4	3.2	3.3	1.9
Actuations B4 Add *	-	-	-	-
Seconds / Actuation *	-	-	-	-
Max Initial *	-	-	-	-
Time Before Reduction *	15	-	-	15
Time To Reduce *	45	-	-	45
Minimum Gap	3.0	-	-	3.0
Locking Detector	-	-	-	-
Recall Position	VEH. RECALL	-	-	VEH. RECALL
Dual Entry	-	-	-	-
Simultaneous Gap	X	X	X	X

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND

- | PROPOSED | EXISTING |
|---------------------------------|---------------------------------|
| ○ Traffic Signal Head | ● Traffic Signal Head |
| ○ Modified Signal Head | N/A |
| ○ Sign | ○ Sign |
| ○ Pedestrian Signal Head | ○ Pedestrian Signal Head |
| ○ With Push Button & Sign | ○ With Push Button & Sign |
| ○ Signal Pole with Guy | ○ Signal Pole with Guy |
| ○ Signal Pole with Sidewalk Guy | ○ Signal Pole with Sidewalk Guy |
| ○ Inductive Loop Detector | ○ Inductive Loop Detector |
| ○ Controller & Cabinet | ○ Controller & Cabinet |
| ○ Junction Box | ○ Junction Box |
| ○ 2-in Underground Conduit | ○ 2-in Underground Conduit |
| N/A Right of Way | ○ Right of Way |
| ○ Directional Arrow | ○ Directional Arrow |
| ■ Video Detection Area | N/A |
| ■ Construction Zone | N/A |
| ● Drums | N/A |


Signal Upgrade Temporary Design 3 - TMP Phase III - Step 2

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

<p>Stantec Consulting Services Inc. 801 Jones Franklin Road-Suite 300 Raleigh, NC 27606 Tel. (919) 851-6866 Fax. (919) 851-7024 www.stantec.com License No. F-0672</p>		<p>US 401/US 401 Business (Raeford Road) at US 401 (Skibo Road)</p>	
		<p>Division 6 Cumberland County Fayetteville</p> <p>PLAN DATE: March 2018 REVIEWED BY: E D Harris</p> <p>PREPARED BY: K Williams REVIEWED BY: B L Watson</p>	<p>3/29/2018</p> <p>DATE</p>

EDI MODEL 2018ECLip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



NOTES:

1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
3. Ensure that Red Enable is active at all times during normal operation.
4. Integrate monitor with Ethernet network in cabinet.

NOTES

1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
2. Program controller to start up in phase 2 Green and 6 Green.
3. The cabinet and controller are part of the Fayetteville Signal System.

EQUIPMENT INFORMATION

CONTROLLER.....2070
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 W/ AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S2,S5,S7,S8,AUX S4
 PHASES USED.....2,4,5,6
 OVERLAP A.....NOT USED
 OVERLAP B.....NOT USED
 OVERLAP C.....4+5
 OVERLAP D.....NOT USED

PROJECT REFERENCE NO.	SHEET NO.
U-4405	SIG-29.1


SIGNAL HEAD HOOK-UP CHART

	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	NU	21,22	NU	NU	41,42	NU	51,52	61,62	NU	NU	NU	NU	NU	NU	NU	43,44	NU	NU
RED		128						134								A114		
YELLOW		129						135										
GREEN		130						136										
RED ARROW						101		131										
YELLOW ARROW						102		132										A115
GREEN ARROW						103		133										A116

NU = Not Used

INPUT FILE POSITION LAYOUT

(front view)



EX.: 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
 ST = STOP TIME

SPECIAL DETECTOR NOTE

Install a video detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.

FLASHER CIRCUIT MODIFICATION DETAIL

IN ORDER TO INSURE THAT SIGNALS FLASH CONCURRENTLY ON THE SAME APPROACH, MAKE THE FOLLOWING FLASHER CIRCUIT CHANGES:

1. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-4 AND TERMINATE ON T2-2.
2. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-5 AND TERMINATE ON T2-3.
3. REMOVE FLASHER UNIT 2.

THE CHANGES LISTED ABOVE TIES ALL PHASES AND OVERLAPS TO FLASHER UNIT 1.

**ECONOLITE ASC/3-2070 OVERLAP
PROGRAMMING DETAIL**

(program controller as shown)

1. From Main Menu select **2. CONTROLLER**
2. From CONTROLLER Submenu select **2. VEHICLE OVERLAPS**

OVERLAP C Toggle Twice

Select TMG VEH OVLP [C] and 'NORMAL'

TMG VEH OVLP...[C] TYPE:**NORMAL**
 PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
 INCLUDED . . . X X
 LAG GRN 0.0 YEL 0.0 RED 0.0

END PROGRAMMING


THIS ELECTRICAL DETAIL IS FOR
 THE SIGNAL DESIGN: 06-0096T3
 DESIGNED: March 2018
 SEALED: 03-29-2018
 REVISED: N/A

Temporary Design 3 - TMP Phase III - Step 2
 Electrical Detail

DOCUMENT NOT CONSIDERED FINAL
 UNLESS ALL SIGNATURES COMPLETED

<p>Stantec Consulting Services Inc. 801 Jones Franklin Road-Suite 300 Raleigh, NC 27606 Tel. (919) 851-6866 Fax. (919) 851-7024 www.stantec.com License No. F-0672</p>	<p>Prepared in the Offices of: Mobility and Traffic Division STATE OF NORTH CAROLINA Department of Transportation Signal Management Section 750 N. Greenfield Pkwy, Garner, NC 27529</p>	<p>US 401/US 401 Business (Raeford Road) at US 401 (Skibo Road)</p>		<p>SEAL NORTH CAROLINA PROFESSIONAL ENGINEER SEAL 045933 LAWRENCE E. OVERN DATE 3/29/2018</p>
		<p>Division 6 Cumberland County Fayetteville</p>		
<p>PREPARED BY: G B Spell REVIEWED BY:</p>		<p>REVISIONS</p>	<p>INIT. DATE</p>	<p>DATE</p>
<p>DATE: 03/29/2018 User: rfmancey</p>		<p>INVENTORY NO. 06-0096T3</p>		

PHASING DIAGRAM



PHASING DIAGRAM DETECTION LEGEND


- → DETECTED MOVEMENT
- → UNDETECTED MOVEMENT (OVERLAP)
- ⋯ → UNSIGNALIZED MOVEMENT
- ⋯ → PEDESTRIAN MOVEMENT

TABLE OF OPERATION

SIGNAL FACE	PHASE			
	Ø 5	Ø 6	Ø 4	PEDEST
41,42	→	→	→	→
43,44	→	R	→	R
51,52	←	R	R	→
61,62,63	R	G	R	Y

SIGNAL FACE I.D.

All Heads L.E.D.




ASC/3 DETECTOR INSTALLATION CHART											
DETECTOR						PROGRAMMING					
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE	SYSTEM LOOP NEW CARD
4A	6X40	0	*	-	4	Yes	-	-	-	S	-
5A	6X40	0	*	-	5	Yes	-	-	-	S	-
5B	6X40	0	*	-	5	Yes	-	15	-	S	-
5C	6X40	0	*	-	5	Yes	-	15	-	S	-
6A	6X6	300	*	-	6	Yes	-	-	-	N	-
6B	6X6	300	*	-	6	Yes	-	-	-	N	-
6C	6X6	300	*	-	6	Yes	-	-	-	N	-
6D	6X40	0	*	-	6	Yes	2.0	5	-	G	-
6E	6X40	0	*	-	6	Yes	2.0	5	-	G	-
6F	6X40	0	*	-	6	Yes	2.0	5	-	G	-

* Video Detection Area. Camera locations should be confirmed in the field by the contractor in order to provide detection of the areas indicated.

3 Phase Fully Actuated Fayetteville Signal System

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 5 may be lagged.
- Set all detector units to presence mode.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.



ASC/3 TIMING CHART

FEATURE	PHASE		
	4	5	6
Min Green *	7	7	12
Walk *	-	-	-
Ped Clear	-	-	-
Veh. Extension *	2.0	2.0	6.0
Max 1 *	30	35	90
Yellow	3.0	3.0	4.8
Red Clear	3.1	2.9	2.0
Actuations B4 Add *	-	-	-
Seconds / Actuation *	-	-	-
Max Initial *	-	-	-
Time Before Reduction *	-	-	15
Time To Reduce *	-	-	45
Minimum Gap	-	-	3.0
Locking Detector	-	-	-
Recall Position	-	-	VEH. RECALL
Dual Entry	-	-	-
Simultaneous Gap	X	X	X

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND

- | PROPOSED | EXISTING |
|--|----------|
| ○ → Traffic Signal Head | ● → |
| ○ → Modified Signal Head | N/A |
| ⊥ Sign | ⊥ |
| ⊥ Pedestrian Signal Head With Push Button & Sign | ⊥ |
| ⊥ Signal Pole with Guy | ⊥ |
| ⊥ Signal Pole with Sidewalk Guy | ⊥ |
| ⊥ Inductive Loop Detector | ⊥ |
| ⊥ Controller & Cabinet | ⊥ |
| ⊥ Junction Box | ⊥ |
| ⊥ 2-in Underground Conduit | ⊥ |
| N/A Right of Way | --- |
| → Directional Arrow | → |
| ■ Video Detection Area | N/A |
| ■ Construction Zone | N/A |
| ● Drums | N/A |


Signal Upgrade Temporary Design 4 - TMP Phase III - Step 3

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

<p>Stantec Consulting Services Inc. 801 Jones Franklin Road-Suite 300 Raleigh, NC 27606 Tel. (919) 851-6866 Fax. (919) 851-7024 www.stantec.com License No. F-0672</p>	<p>750 N. Greenfield Pkwy, Garner, NC 27528</p>	<p>US 401/US 401 Business (Raeford Road) at US 401 (Skibo Road)</p>		<p>SEAL 29449 JEFFREY L. WATSON ENGINEER</p>
		<p>Prepared for the Offices of:</p> <p>Division 6 Cumberland County Fayetteville</p> <p>PLAN DATE: March 2018 REVIEWED BY: E D Harris</p> <p>PREPARED BY: R M Muncey REVIEWED BY: B L Watson</p>	<p>3/29/2018</p>	

EDI MODEL 2018ECLip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



NOTES:

1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
3. Ensure that Red Enable is active at all times during normal operation.
4. Integrate monitor with Ethernet network in cabinet.

NOTES

1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
2. Program controller to start up in phase 2 Green and 6 Green.
3. The cabinet and controller are part of the Fayetteville Signal System.

EQUIPMENT INFORMATION

CONTROLLER.....2070
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 W/ AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S5,S7,S8,AUX S4
 PHASES USED.....4,5,6
 OVERLAP A.....NOT USED
 OVERLAP B.....NOT USED
 OVERLAP C.....4+5
 OVERLAP D.....NOT USED

PROJECT REFERENCE NO.	SHEET NO.
U-4405	SIG-30.1


SIGNAL HEAD HOOK-UP CHART

	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	NU	NU	NU	NU	41,42	NU	51,52	61,62,63	NU	NU	NU	NU	NU	NU	NU	43,44	NU	NU
RED								134								A114		
YELLOW								135										
GREEN								136										
RED ARROW					101		131											
YELLOW ARROW					102		132									A115		
GREEN ARROW					103		133									A116		

NU = Not Used

INPUT FILE POSITION LAYOUT

(front view)



SPECIAL DETECTOR NOTE

Install a video detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.

FLASHER CIRCUIT MODIFICATION DETAIL

IN ORDER TO INSURE THAT SIGNALS FLASH CONCURRENTLY ON THE SAME APPROACH, MAKE THE FOLLOWING FLASHER CIRCUIT CHANGES:

1. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-4 AND TERMINATE ON T2-2.
2. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-5 AND TERMINATE ON T2-3.
3. REMOVE FLASHER UNIT 2.

THE CHANGES LISTED ABOVE TIES ALL PHASES AND OVERLAPS TO FLASHER UNIT 1.

ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select **2. CONTROLLER**
2. From CONTROLLER Submenu select **2. VEHICLE OVERLAPS**

OVERLAP C Toggle Twice

Select TMG VEH OVLP [C] and 'NORMAL'

TMG VEH OVLP...[C] TYPE:**NORMAL**
 PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
 INCLUDED . . . X X
 LAG GRN 0.0 YEL 0.0 RED 0.0

END PROGRAMMING

THIS ELECTRICAL DETAIL IS FOR
 THE SIGNAL DESIGN: 06-0096T4
 DESIGNED: March 2018
 SEALED: 03-29-2018
 REVISED: N/A


Temporary Design 4 - TMP Phase III - Step 3
 Electrical Detail

DOCUMENT NOT CONSIDERED FINAL
 UNLESS ALL SIGNATURES COMPLETED

<p>Stantec Consulting Services Inc. 801 Jones Franklin Road-Suite 300 Raleigh, NC 27606 Tel. (919) 851-6866 Fax. (919) 851-7024 www.stantec.com License No. F-0672</p>	<p>ELECTRICAL AND PROGRAMMING DETAILS FOR:</p> <p>Prepared in the Offices of:</p>	<p>US 401/US 401 Business (Raeford Road) at US 401 (Skibo Road)</p>		<p>SEAL NORTH CAROLINA PROFESSIONAL ENGINEER LAWRENCE E. OVERN License No. 045933</p>					
		<p>Division 6 Cumberland County Fayetteville</p>	<p>PLAN DATE: March 2018 REVIEWED BY: L Overn</p>						
<p>PREPARED BY: G B Spell REVIEWED BY:</p>	<p>REVISIONS</p> <table border="1"> <tr> <th>NO.</th> <th>INIT.</th> <th>DATE</th> </tr> <tr> <td> </td> <td> </td> <td> </td> </tr> </table>	NO.	INIT.	DATE				<p>DATE: 3/29/2018</p>	<p>DATE: 3/29/2018</p>
NO.	INIT.	DATE							

EDI MODEL 2018ECLip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- Ensure that Red Enable is active at all times during normal operation.
- Integrate monitor with Ethernet network in cabinet.

NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Program controller to start up in phase 6 WALK.
- The cabinet and controller are part of the Fayetteville Signal System.

SIGNAL HEAD HOOK-UP CHART

	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	NU	NU	NU	NU	41,42	NU	51,52	61,62,63	P61, P62	NU	NU	NU	NU	NU	NU	43,44	NU	NU
RED								134								A114		
YELLOW								135										
GREEN								136										
RED ARROW					101		131											
YELLOW ARROW					102		132									A115		
GREEN ARROW					103		133									A116		
Hand icon													119					
Walking person icon													121					

NU = Not Used

EQUIPMENT INFORMATION

CONTROLLER.....2070
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 W/ AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S5,S7,S8,S9,AUX S4
 PHASES USED.....4,5,6,6PED
 OVERLAP A.....NOT USED
 OVERLAP B.....NOT USED
 OVERLAP C.....4+5
 OVERLAP D.....NOT USED

COUNTDOWN PEDESTRIAN SIGNAL OPERATION

Countdown Ped Signals are required to display timing only during Ped Clearance Interval. Consult Ped Signal Module user's manual for instructions on selecting this feature.

INPUT FILE POSITION LAYOUT

(front view)

FILE "I"	1	2	3	4	5	6	7	8	9	10	11	12	13	14
U	S	S	S	S	∅ 4	∅ 4	S	S	S	S	S	S	∅ 6 PED	FS
L	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	DC ISOLATOR	DC ISOLATOR
U	∅ 5	∅ 5	∅ 6	∅ 6	S	S	S	S	S	S	S	S	S	S
L	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅
U	5A	5C	6A	6C	S	S	S	S	S	S	S	S	S	S
L	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅
U	∅ 5	∅ 5	∅ 6	NOT USED	S	S	S	S	S	S	S	S	S	S
L	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅	←-V-∅

EX. : 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
 ST = STOP TIME

FLASHER CIRCUIT MODIFICATION DETAIL

IN ORDER TO INSURE THAT SIGNALS FLASH CONCURRENTLY ON THE SAME APPROACH, MAKE THE FOLLOWING FLASHER CIRCUIT CHANGES:

- ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-4 AND TERMINATE ON T2-2.
- ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-5 AND TERMINATE ON T2-3.
- REMOVE FLASHER UNIT 2.

THE CHANGES LISTED ABOVE TIES ALL PHASES AND OVERLAPS TO FLASHER UNIT 1.

ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL

(program controller as shown)

- From Main Menu select **2. CONTROLLER**
- From CONTROLLER Submenu select **2. VEHICLE OVERLAPS**

OVERLAP C Toggle Twice

Select TMG VEH OVLP [C] and 'NORMAL'

TMG VEH OVLP...[C] TYPE:**NORMAL**
 PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
 INCLUDED . . . X X
 LAG GRN 0.0 YEL 0.0 RED 0.0


END PROGRAMMING

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND TIME	DELAY TIME	ADDED INITIAL	DETECTOR TYPE
4A	TB4-9,10	I6U	41	4	4	YES				S
4B	TB4-11,12	I6L	45	14	4	YES				S
5A	TB3-1,2	J1U	55	5	5	YES				S
5B	TB3-3,4	J1L	55	5	5	YES				S
5C	TB3-5,6	J2U	40	6	5	YES		15		S
5D	TB3-7,8	J2L	44	16	5	YES		15		S
6A	TB3-9,10	J3U	64	36	6	YES			X	N
6B	TB3-11,12	J3L	77	46	6	YES			X	N
6C	TB5-1,2	J4U	48	26	6	YES			X	N
PED PUSH BUTTONS										
P61,P62	TB8-7,9	I13U	68	PED 6	6 PED					

NOTE:
 INSTALL DC ISOLATORS IN INPUT FILE SLOTS 112 AND 113.

INPUT FILE POSITION LEGEND: J2L




THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0096
 DESIGNED: March 2018
 SEALED: 03-29-2018
 REVISED: N/A

**Final Design
Electrical Detail**


ELECTRICAL AND PROGRAMMING DETAILS FOR:
 Prepared in the Offices of:

US 401/US 401 Business (Raeford Road) at US 401 (Skibo Road)
 Division 6 Cumberland County Fayetteville
 PLAN DATE: March 2018 REVIEWED BY: L Overn
 PREPARED BY: G B Spell REVIEWED BY:
 REVISIONS: _____ INIT. DATE _____

SEAL
 NORTH CAROLINA PROFESSIONAL ENGINEER
 LAWRENCE E. OVERN
 3/29/2018
 DATE
 SIG. INVENTORY NO. 06-0096



SIGNAL FACE	PHASE					
	Ø1+5	Ø1+6	Ø2+5	Ø2+6	Ø4+8	FUTURE
11	←	←	←	←	←	←
21, 22	R	R	G	G	R	Y
41, 42	R	R	R	R	G	R
51	←	←	←	←	←	←
61, 62, 63	R	G	R	G	R	Y
81, 82	R	R	R	R	G	R





ASC/3 DETECTOR INSTALLATION CHART												
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PROGRAMMING							
					PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE	SYSTEM LOOP	NEW CARD
1A	6X40	0	*	-	1	Yes	-	15	-	S	-	X
2A	6X6	300	*	-	2	Yes	-	-	-	N	-	X
2B	6X6	300	*	-	2	Yes	-	-	-	N	-	X
2C	6X40	0	*	-	2	Yes	2.0	5	-	G	-	X
2D	6X40	0	*	-	2	Yes	2.0	5	-	G	-	X
4A	6X40	0	*	-	4	Yes	-	3	-	S	-	X
4B	6X40	0	*	-	4	Yes	-	10	-	S	-	X
5A	6X40	0	*	-	5	Yes	-	15	-	S	-	X
6A	6X6	300	*	-	6	Yes	-	-	-	N	-	X
6B	6X6	300	*	-	6	Yes	-	-	-	N	-	X
6C	6X6	300	*	-	6	Yes	-	-	-	N	-	X
6D	6X40	0	*	-	6	Yes	2.0	5	-	G	-	X
6E	6X40	0	*	-	6	Yes	2.0	5	-	G	-	X
6F	6X40	0	*	-	6	Yes	2.0	5	-	G	-	X
8A	6X40	0	*	-	8	Yes	-	3	-	S	-	X
8B	6X40	0	*	-	8	Yes	-	10	-	S	-	X

5 Phase Fully Actuated Fayetteville Signal System

NOTES


- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 1 and/or phase 5 may be lagged.
- Set all detector units to presence mode.
- Locate new cabinet foundation so as not to obstruct sight distance of vehicles turning right on red. Relocate existing cabinet and controller onto new foundation.
- The Division (City) Traffic Engineer will determine the hours of use for each phasing plan.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Field adjust temporary poles as needed.



*Video Detection Area. Camera locations should be confirmed in the field by the contractor in order to provide detection of the areas indicated.

FEATURE	ASC/3 TIMING CHART					
	1	2	4	5	6	8
Min Green *	7	12	7	7	12	7
Walk *	-	-	-	-	-	-
Ped Clear	-	-	-	-	-	-
Veh. Extension *	2.0	6.0	2.0	2.0	6.0	2.0
Max I *	15	90	15	15	90	15
Yellow	3.0	4.5	3.3	3.0	4.5	3.2
Red Clear	2.3	1.4	2.2	2.8	1.4	2.8
Red Revert	-	-	-	-	-	-
Actuations B4 Add *	-	-	-	-	-	-
Seconds /Actuation *	-	-	-	-	-	-
Max Initial *	-	-	-	-	-	-
Time Before Reduction *	-	15	-	-	15	-
Time To Reduce *	-	30	-	-	30	-
Minimum Gap	-	3.0	-	-	3.0	-
Locking Detector	-	-	-	-	-	-
Recall Position	-	VEH. RECALL	-	-	VEH. RECALL	-
Dual Entry	-	-	X	-	-	X
Simultaneous Gap	X	X	X	X	X	X

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.



Signal Upgrade Temporary Design 1 - TMP Phase I

US 401 Business (Raeford Road) at Sandalwood Drive/ Lafayette Ford Entrance

Division 6 Cumberland County Fayetteville

PLAN DATE: March 2018 REVIEWED BY: E D Harris

PREPARED BY: R M Muncey REVIEWED BY: B L Watson



REVISIONS	INIT.	DATE

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

3/29/2018 10:44:05 AM User: rfmuncey

EDI MODEL 2018EClip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- Ensure that Red Enable is active at all times during normal operation.
- Integrate monitor with Ethernet network in cabinet.

NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Program phases 4 and 8 for Dual Entry.
- Program controller to start up in phase 2 Green and 6 Green.
- The cabinet and controller are part of the Fayetteville Signal System.

EQUIPMENT INFORMATION

CONTROLLER.....2070
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S5,S7,S8,S11,AUX S1,AUX S4
 PHASES USED.....1,2,4,5,6,8
 OVERLAP "A".....*
 OVERLAP "B".....NOT USED
 OVERLAP "C".....*
 OVERLAP "D".....NOT USED
 * See overlap programming detail on sheet 2

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CNU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	11★	21,22	NU	NU	41,42	NU	51★	61,62,63	NU	NU	81,82	NU	11★	NU	NU	51★	NU	NU
RED		128			101			134			107							
YELLOW	*	129			102		*	135			108							
GREEN		130			103			136			109							
RED ARROW													A121			A114		
YELLOW ARROW																A122		A115
FLASHING YELLOW ARROW																A123		A116
GREEN ARROW	127							133										

NU = Not Used
 * Denotes install load resistor. See load resistor installation detail this sheet.
 ★ See pictorial of head wiring in detail this sheet.


REMOVE JUMPERS AS SHOWN

DETECTOR NOTES

- For all loops install a video detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.
- For loops 1A and 5A detector card placements and slots reserved for wired inputs are typical for a NCDOT installation.

INPUT FILE POSITION LAYOUT

(front view)




EX.: 1A, 2A, ETC. = LOOP NO.'S
 FS = FLASH SENSE
 ST = STOP TIME
 ⊗ Wired Input - Do not populate slot with detector card

INPUT FILE CONNECTION & PROGRAMMING CHART


LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND TIME	DELAY TIME	ADDED INITIAL	DETECTOR TYPE
1A ¹	-	I1U	56	1	1	YES		15		S
	-	J4U	48	26	6	YES		3		G
5A ²	-	J1U	55	5	5	YES		15		S
	-	I4U	47	22	2	YES		3		G

¹Add jumper from I1-W to J4-W, on rear of input file.
²Add jumper from J1-W to I4-W, on rear of input file.



FYA SIGNAL WIRING DETAIL


(wire signal heads as shown)



LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown)

VALUE (ohms)	WATTAGE
1.5K - 1.9K	25W (min)
2.0K - 3.0K	10W (min)



Temporary Design 1 - TMP Phase I
 Electrical Detail - Sheet 1 of 2

US 401 Business (Raeford Road)
 at
 Sandalwood Drive/
 Layfayette Ford Entrance
 Division 6 Cumberland County Fayetteville

PLAN DATE: March 2018 REVIEWED BY: L Overn
 PREPARED BY: R M Muncey REVIEWED BY:

REVISIONS	INIT.	DATE

SEAL
 NORTH CAROLINA
 PROFESSIONAL ENGINEER
 R. M. MUNCEY
 045933
 3/29/2018
 DATE
 SIG. INVENTORY NO. 06-049111

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select 2. CONTROLLER
2. From CONTROLLER Submenu select 2. VEHICLE OVERLAPS

```

OVERLAP A
Select TMG VEH OVLP [A] and 'PPLT FYA'
TMG VEH OVLP...[A] TYPE: ....PPLT FYA
PROTECTED LEFT TURN.... PHASE 1
OPPOSING THROUGH..... PHASE 2

FLASHING ARROW OUTPUT.....CH9 ISOLATE
DELAY START OF: FYA..0.0 CLEARANCE..0.0
ACTION PLAN SF BIT DISABLE..... 0

Toggle Twice

OVERLAP C
Select TMG VEH OVLP [C] and 'PPLT FYA'
TMG VEH OVLP...[C] TYPE: ....PPLT FYA
PROTECTED LEFT TURN.... PHASE 5
OPPOSING THROUGH..... PHASE 6

FLASHING ARROW OUTPUT.....CH11 ISOLATE
DELAY START OF: FYA..0.0 CLEARANCE..0.0
ACTION PLAN SF BIT DISABLE..... 0

END PROGRAMMING

```

DATE: U:\Projects\Signal\Signal\Electrical\Detail\Signal\Phase 1\U-4405.sig.ele.06-0491T1.dgn User: rnmuncey


THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-0491T1
DESIGNED: March 2018
SEALED: 03-29-2018
REVISED: N/A

Temporary Design 1 - TMP Phase I
Electrical Detail - Sheet 2 of 2

DOCUMENT NOT CONSIDERED FINAL
UNLESS ALL SIGNATURES COMPLETED


 Stantec <small>Stantec Consulting Services Inc. 801 Jones Franklin Road-Suite 300 Raleigh, NC 27606 Tel. (919) 851-6866 Fax. (919) 851-7024 www.stantec.com License No. F-0672</small>	<small>ELECTRICAL AND PROGRAMMING DETAILS FOR:</small> <small>Prepared in the Offices of:</small> <small>750 N. Greenfield Pkwy, Garner, NC 27529</small>	US 401 Business (Raeford Road) at Sandalwood Drive/ Layfayette Ford Entrance <small>Division 6 Cumberland County Fayetteville</small>	<small>SEAL</small> <small>SEAL 045933</small> <small>ENGINEER</small> <small>LAWRENCE E. OVERN</small>														
	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td>PLAN DATE: March 2018</td> <td>REVIEWED BY: L Overn</td> </tr> <tr> <td>PREPARED BY: R M Muncey</td> <td>REVIEWED BY:</td> </tr> <tr> <td style="font-size: x-small;">REVISIONS</td> <td style="font-size: x-small;">INIT. DATE</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </table>	PLAN DATE: March 2018	REVIEWED BY: L Overn	PREPARED BY: R M Muncey	REVIEWED BY:	REVISIONS	INIT. DATE					<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;"></td> <td style="width: 50%; text-align: right;">3/29/2018</td> </tr> <tr> <td> </td> <td style="text-align: right;">DATE</td> </tr> <tr> <td colspan="2" style="font-size: x-small;">SIG. INVENTORY NO. 06-0491T1</td> </tr> </table>		3/29/2018		DATE	SIG. INVENTORY NO. 06-0491T1
PLAN DATE: March 2018	REVIEWED BY: L Overn																
PREPARED BY: R M Muncey	REVIEWED BY:																
REVISIONS	INIT. DATE																
	3/29/2018																
	DATE																
SIG. INVENTORY NO. 06-0491T1																	

PHASING DIAGRAM



SIGNAL FACE	PHASE					
	01+5	01+6	02+5	02+6	04+8	F.L.H.O.P.A.
11	←	→	←	→	←	→
21, 22, 23	R	R	G	G	R	Y
41, 42	R	R	R	R	G	R
51	←	→	←	→	←	→
61, 62	R	G	R	G	R	Y
81, 82	R	R	R	R	G	R

SIGNAL FACE I.D.




ASC/3 DETECTOR INSTALLATION CHART											
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PROGRAMMING						
					PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE	LOOP SYSTEM
1A	6X40	0	*	-	1	Yes	-	15	-	S	-
					6	Yes	-	3	-	G	-
2A	6X6	300	*	-	2	Yes	-	-	-	N	-
2B	6X6	300	*	-	2	Yes	-	-	-	N	-
2C	6X6	300	*	-	2	Yes	-	-	-	N	-
2D	6X40	0	*	-	2	Yes	2.0	5	-	G	-
2E	6X40	0	*	-	2	Yes	2.0	5	-	G	-
2F	6X40	0	*	-	2	Yes	2.0	5	-	G	-
4A	6X40	0	*	-	4	Yes	-	3	-	S	-
4B	6X40	0	*	-	4	Yes	-	10	-	S	-
5A	6X40	0	*	-	5	Yes	-	15	-	S	-
					2	Yes	-	3	-	G	-
6A	6X6	300	*	-	6	Yes	-	-	-	N	-
6B	6X6	300	*	-	6	Yes	-	-	-	N	-
6C	6X40	0	*	-	6	Yes	2.0	5	-	G	-
6D	6X40	0	*	-	6	Yes	2.0	5	-	G	-
8A	6X40	0	*	-	8	Yes	-	3	-	S	-
8B	6X40	0	*	-	8	Yes	-	10	-	S	-

*Video Detection Area. Camera locations should be confirmed in the field by the contractor in order to provide detection of the areas indicated.

5 Phase Fully Actuated Fayetteville Signal System

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 1 and/or phase 5 may be lagged.
- Reposition signal heads numbered 11, 21, 22, 51, 61, and 62.
- Set all detector units to presence mode.
- The Division (City) Traffic Engineer will determine the hours of use for each phasing plan.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.



FEATURE	ASC/3 TIMING CHART					
	1	2	4	5	6	8
Min Green *	7	12	7	7	12	7
Walk *	-	-	-	-	-	-
Ped Clear	-	-	-	-	-	-
Veh. Extension *	2.0	6.0	2.0	2.0	6.0	2.0
Max I *	15	90	15	15	90	15
Yellow	3.0	4.5	3.3	3.0	4.5	3.2
Red Clear	2.6	1.1	2.6	2.4	1.1	2.7
Red Revert	-	-	-	-	-	-
Actuations B4 Add *	-	-	-	-	-	-
Seconds /Actuation *	-	-	-	-	-	-
Max Initial *	-	-	-	-	-	-
Time Before Reduction *	-	15	-	-	15	-
Time To Reduce *	-	30	-	-	30	-
Minimum Gap	-	3.0	-	-	3.0	-
Locking Detector	-	-	-	-	-	-
Recall Position	-	VEH. RECALL	-	-	VEH. RECALL	-
Dual Entry	-	-	X	-	-	X
Simultaneous Gap	X	X	X	X	X	X

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND	
PROPOSED	EXISTING
	Traffic Signal Head
	Modified Signal Head
	Pedestrian Signal Head
	Signal Pole with Guy
	Inductive Loop Detector
	Controller & Cabinet
	Junction Box
	2-in Underground Conduit
	Right of Way
	Directional Arrow
	Video Detection Area
	Construction Zone
	Drums

Signal Upgrade Temporary Design 2 - TMP Phase II

Stantec
 Stantec Consulting Services Inc.
 801 Jones Franklin Road-Suite 300
 Raleigh, NC 27606
 Tel. (919) 851-6866
 Fax. (919) 851-7024
 www.stantec.com
 License No. F-0672

Prepared for the Offices of:

 TRANSPORTATION MOBILITY AND SAFETY DIVISION
 STATE OF NORTH CAROLINA
 Signal Design Section
 750 N. Greenfield Pkwy, Garner, NC 27526
 SCALE 0 40

US 401 Business (Raeford Road) at Sandalwood Drive/ Lafayette Ford Entrance
 Division 6 Cumberland County Fayetteville
 PLAN DATE: March 2018 REVIEWED BY: E D Harris
 PREPARED BY: R M Muncey REVIEWED BY: B L Watson

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED


3/29/2018
 User: rlmuncey

3/29/2018
 User: B. L. Watson

SIG. INVENTORY NO. 06-0491T2

EDI MODEL 2018EClip-NC CONFLICT MONITOR PROGRAMMING DETAIL


(remove jumpers and set switches as shown)



REMOVE JUMPERS AS SHOWN

NOTES:

1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
3. Ensure that Red Enable is active at all times during normal operation.
4. Integrate monitor with Ethernet network in cabinet.



NOTES

1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
2. Program phases 4 and 8 for Dual Entry.
3. Program controller to start up in phase 2 Green and 6 Green.
4. The cabinet and controller are part of the Fayetteville Signal System.

EQUIPMENT INFORMATION

CONTROLLER.....2070
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S5,S7,S8,S11,AUX S1,AUX S4
 PHASES USED.....1,2,4,5,6,8
 OVERLAP "A".....*
 OVERLAP "B".....NOT USED
 OVERLAP "C".....*
 OVERLAP "D".....NOT USED
 * See overlap programming detail on sheet 2

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6	
CMI CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18	
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE	
SIGNAL HEAD NO.	11	21,22,23	NU	NU	41,42	NU	51	61,62	NU	81,82	NU	11	NU	NU	51	NU	NU	NU	
RED	128			101				134			107								
YELLOW	*	129			102		*	135			108								
GREEN		130			103			136			109								
RED ARROW													A121				A114		
YELLOW ARROW																		A115	
FLASHING YELLOW ARROW													A123					A116	
GREEN ARROW	127							133											

NU = Not Used

* Denotes install load resistor. See load resistor installation detail this sheet.


★ See pictorial of head wiring in detail this sheet.

DETECTOR NOTES

1. For all loops install a video detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.
2. For loops 1A and 5A detector card placements and slots reserved for wired inputs are typical for a NCDOT installation.

INPUT FILE POSITION LAYOUT

(front view)




EX.: 1A, 2A, ETC. = LOOP NO.'S
 FS = FLASH SENSE
 ST = STOP TIME
 * Wired Input - Do not populate slot with detector card

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND TIME	DELAY TIME	ADDED INITIAL	DETECTOR TYPE
1A ¹	-	I1U	56	1	1	YES		15		S
	-	J4U	48	26	6	YES		3		G
5A ²	-	J1U	55	5	5	YES		15		S
	-	I4U	47	22	2	YES		3		G


¹Add jumper from I1-W to J4-W, on rear of input file.
²Add jumper from J1-W to I4-W, on rear of input file.



LOAD RESISTOR INSTALLATION DETAIL


(install resistors as shown)

VALUE (ohms)	WATTAGE
1.5K - 1.9K	25W (min)
2.0K - 3.0K	10W (min)



FYA SIGNAL WIRING DETAIL

(wire signal heads as shown)



THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0491T2
 DESIGNED: March 2018
 SEALED: 03-29-2018
 REVISED: N/A

Temporary Design 2 - TMP Phase II
 Electrical Detail - Sheet 1 of 2

US 401 Business (Raeford Road)
 at
 Sandalwood Drive/
 Layfayette Ford Entrance
 Division 6 Cumberland County Fayetteville

PLAN DATE: March 2018 REVIEWED BY: L Overn
 PREPARED BY: R M Muncey REVIEWED BY:

REVISIONS	INIT.	DATE

SEAL
 NORTH CAROLINA PROFESSIONAL ENGINEER
 R. M. MUNCEY
 045933
 3/29/2018
 DATE
 SIG. INVENTORY NO. 06-0491T2

ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL

(program controller as shown)

- 1. From Main Menu select **2. CONTROLLER**
- 2. From CONTROLLER Submenu select **2. VEHICLE OVERLAPS**

```

OVERLAP A
Select TMG VEH OVLP [A] and 'PPLT FYA'
TMG VEH OVLP...[A] TYPE: .....PPLT FYA
PROTECTED LEFT TURN.... PHASE 1
OPPOSING THROUGH..... PHASE 2

FLASHING ARROW OUTPUT.....CH9 ISOLATE
DELAY START OF: FYA..0.0 CLEARANCE..0.0
ACTION PLAN SF BIT DISABLE..... 0

Toggle Twice
OVERLAP C
Select TMG VEH OVLP [C] and 'PPLT FYA'
TMG VEH OVLP...[C] TYPE: .....PPLT FYA
PROTECTED LEFT TURN.... PHASE 5
OPPOSING THROUGH..... PHASE 6

FLASHING ARROW OUTPUT.....CH11 ISOLATE
DELAY START OF: FYA..0.0 CLEARANCE..0.0
ACTION PLAN SF BIT DISABLE..... 0




END PROGRAMMING

```

THIS ELECTRICAL DETAIL IS FOR
 THE SIGNAL DESIGN: 06-0491T2
 DESIGNED: March 2018
 SEALED: 03-29-2018
 REVISED: N/A

Temporary Design 2 - TMP Phase II
 Electrical Detail - Sheet 2 of 2


**DOCUMENT NOT CONSIDERED FINAL
 UNLESS ALL SIGNATURES COMPLETED**

 Stantec Consulting Services Inc. 801 Jones Franklin Road-Suite 300 Raleigh, NC 27606 Tel. (919) 851-6866 Fax. (919) 851-7024 www.stantec.com License No. F-0672	 Prepared in the Offices of: Mobility and Safety Division STATE OF NORTH CAROLINA DEPARTMENT OF TRANSPORTATION Signal Management Section 750 N. Greenfield Pkwy, Garner, NC 27529	US 401 Business (Raeford Road) at Sandalwood Drive/ Layfayette Ford Entrance Division 6 Cumberland County Fayetteville		 SEAL NORTH CAROLINA PROFESSIONAL ENGINEER LAWRENCE E. OVERN 045933
		PLAN DATE: March 2018 PREPARED BY: R M Muncey	REVIEWED BY: L Overn REVIEWED BY:	

DATE: 03/29/2018 10:45:12 AM
 User: rlmuncey

EDI MODEL 2018EClip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Return controller to Factory Defaults before programming per this electrical detail.
- Program phases 4 and 8 for Dual Entry.
- Program controller to start up in phase 2 Green and 6 Green.
- The cabinet and controller are part of the Fayetteville Signal System.

EQUIPMENT INFORMATION

CONTROLLER.....2070
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S5,S7,S8,S11
 PHASES USED.....1,2,4,5,6,8
 OVERLAP "A".....NOT USED
 OVERLAP "B".....NOT USED
 OVERLAP "C".....NOT USED
 OVERLAP "D".....NOT USED


* See overlap programming detail on sheet 2

SIGNAL HEAD HOOK-UP CHART


LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	11	21,22	NU	NU	41,42	NU	51	61,62	NU	NU	81,82	NU	NU	NU	NU	NU	NU	NU
RED		128			101			134			107							
YELLOW		129			102			135			108							
GREEN		130			103			136			109							
RED ARROW	125							131										
YELLOW ARROW	126							132										
GREEN ARROW	127							133										

NU = Not Used
 * Denotes install load resistor. See load resistor installation detail this sheet.
 ★ See pictorial of head wiring in detail this sheet.


INPUT FILE POSITION LAYOUT



LOAD RESISTOR INSTALLATION DETAIL



SIGNAL WIRING DETAIL



DETECTOR NOTES

- For all loops install a video detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.
- Remove "Wired Inputs" from rear of input file to prevent unwanted calls to Phases 2 and 6.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0491T3
 DESIGNED: March 2018
 SEALED: 03-29-2018
 REVISED: N/A

Temporary Design 3 - TMP Phase III Electrical Detail

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

Stantec Consulting Services Inc.
 801 Jones Franklin Road-Suite 300
 Raleigh, NC 27606
 Tel. (919) 851-6866
 Fax. (919) 851-7024
 www.stantec.com
 License No. F-0672

Prepared in the Offices of:

750 N. Greenfield Pkwy, Garner, NC 27529

US 401 Business (Raeford Road)
 at
 Sandalwood Drive/
 Layfayette Ford Entrance
 Division 6 Cumberland County Fayetteville

PLAN DATE: March 2018 REVIEWED BY: L Overn
 PREPARED BY: R W Muncey REVIEWED BY:

REVISIONS	INIT.	DATE


3/29/2018
 DATE
 SIG. INVENTORY NO. 06-0491T3

5 Phase Fully Actuated Fayetteville Signal System

NOTES

1. Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
2. Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
3. Phase 1 and/or phase 5 may be lagged.
4. Set all detector units to presence mode.
5. Omit "WALK" and flashing "DON'T WALK" with no pedestrian calls.
6. Program pedestrian heads to countdown the flashing "Don't Walk" time only.
7. The Division (City) Traffic Engineer will determine the hours of use for each phasing plan.
8. Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
9. Pedestrian pedestals are conceptual and shown for reference only. See 2018 NCDOT Roadway Standard Drawings 1705.04 Sheets 1-3 for push button location details.



LEGEND



ASC/3 DETECTOR INSTALLATION CHART											
DETECTOR				PROGRAMMING							
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE	LOOP SYSTEM NEW CARD
1A	6X40	0	2-4-2	X	1	Yes	-	15★	-	S	- X
2A	6X6	300	4	X	2	Yes	-	3	-	G	- X
2B	6X6	300	4	X	2	Yes	-	-	X	N	- X
2C	6X6	300	4	X	2	Yes	-	-	X	N	- X
4A	6X40	0	2-4-2	X	4	Yes	-	3	-	S	- X
4B	6X40	0	2-4-2	X	4	Yes	-	10	-	S	- X
5A	6X40	0	2-4-2	X	5	Yes	-	15★	-	S	- X
6A	6X6	300	6	X	6	Yes	-	-	X	N	- X
6B	6X6	300	6	X	6	Yes	-	-	X	N	- X
6C	6X6	300	6	X	6	Yes	-	-	X	N	- X
8A	6X40	0	2-4-2	X	8	Yes	-	3	-	S	- X
8B	6X40	0	2-4-2	X	8	Yes	-	10	-	S	- X

Disable Phase(s) call during Alternate Phasing Operation.
★ Disable delay during Alternate Phasing Operation.



SIGNAL FACE I.D.



SIGNAL FACE	PHASE					
	01+5	01+6	02+5	02+6	04+8	FLASH
11	←	←	←	←	←	←
21,22,23	R	R	G	G	R	Y
41,42	R	R	R	R	G	R
51	←	←	←	←	←	←
61,62,63	R	G	R	G	R	Y
81,82	R	R	R	R	G	R
P21, P22	DW	DW	W	W	DW	DRK
P41, P42	DW	DW	DW	DW	W	DRK
P61, P62	DW	W	DW	W	DW	DRK
P81, P82	DW	DW	DW	DW	W	DRK

SIGNAL FACE	PHASE					
	01+5	01+6	02+5	02+6	04+8	FLASH
11	←	←	←	←	←	←
21,22,23	R	R	G	G	R	Y
41,42	R	R	R	R	G	R
51	←	←	←	←	←	←
61,62,63	R	G	R	G	R	Y
81,82	R	R	R	R	G	R
P21, P22	DW	DW	W	W	DW	DRK
P41, P42	DW	DW	DW	DW	W	DRK
P61, P62	DW	W	DW	W	DW	DRK
P81, P82	DW	DW	DW	DW	W	DRK

PHASING DIAGRAM DETECTION LEGEND



FEATURE	PHASE						
	1	2	4	5	6	8	
Min Green *	7	12	7	7	12	7	
Walk *	-	7	7	-	7	7	
Ped Clear	-	18	24	-	12	29	
Veh. Extension *	2.0	6.0	2.0	2.0	6.0	2.0	
Max 1 *	15	90	15	15	90	15	
Yellow	3.0	4.5	3.3	3.0	4.5	3.2	
Red Clear	2.9	1.9	3.3	3.3	1.9	3.3	
Red Revert	-	-	-	-	-	-	
Actuations B4 Add *	-	0	-	-	0	-	
Seconds /Actuation *	-	1.5	-	-	1.5	-	
Max Initial *	-	34	-	-	34	-	
Time Before Reduction *	-	15	-	-	15	-	
Time To Reduce *	-	30	-	-	30	-	
Minimum Gap	-	3.0	-	-	3.0	-	
Locking Detector	-	X	-	-	X	-	
Recall Position	-	VEH. RECALL	-	-	VEH. RECALL	-	
Dual Entry	-	-	X	-	-	X	
Simultaneous Gap	X	X	X	X	X	X	

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

Signal Upgrade - Final Design

Stantec Consulting Services Inc.
801 Jones Franklin Road-Suite 300
Raleigh, NC 27606
Tel. (919) 851-6866
Fax. (919) 851-7024
www.stantec.com
License No. F-0672

750 N. Greenfield Pkwy, Garner, NC 27526
SCALE
0 40
1" = 40'

US 401 Business (Raeford Road)
at
Sandalwood Drive/
Lafayette Ford Entrance

Division 6 Cumberland County Fayetteville

PLAN DATE: March 2018 REVIEWED BY: E D Harris

PREPARED BY: R M Muncey REVIEWED BY: B L Watson

REVISIONS	INIT.	DATE


SEAL 29449
JEFFREY L. WATSON
ENGINEER
3/29/2018
DATE
SIG. INVENTORY NO. 06-0491

3/29/2018 10:41:11 AM C:\Users\jwatson\Documents\Signal Design\4405\sig.dgn User: jwatson

EDI MODEL 2018EClip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)





REMOVE DIODE JUMPERS 1-5, 1-6, 1-9, 1-11, 1-15, 2-5, 2-6, 2-9, 2-11, 2-13, 2-15, 4-8, 4-11, 4-16, 5-9, 5-11, 5-13, 6-5, 6-11, 6-13, 6-15, 8-14, 8-16, 9-11, 9-13, 9-15, 11-13, 11-15, 13-15, and 14-16.



REMOVE JUMPERS AS SHOWN

NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- Ensure that Red Enable is active at all times during normal operation.
- Integrate monitor with Ethernet network in cabinet.



■ = DENOTES POSITION OF SWITCH

NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Program phases 4 and 8 for Dual Entry.
- Program controller to start up in phase 2 Walk and 6 Walk.
- The cabinet and controller are part of the Fayetteville Signal System.

EQUIPMENT INFORMATION

CONTROLLER.....2070
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S3,S5,S6,S7,S8,S9,S11,S12
 AUX S1,AUX S4
 PHASES USED.....1,2,2PED,4,4PED,5,6,6PED,8,8PED
 OVERLAP "A".....*
 OVERLAP "B".....NOT USED
 OVERLAP "C".....*
 OVERLAP "D".....NOT USED
 * See overlap programming detail on sheet 2

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6		
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18		
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE		
SIGNAL HEAD NO.	11	21,22,23	P21,P22	NU	41,42	P41,P42	51	61,62,63	P61,P62	NU	81,82	P81,P82	11	NU	NU	51	NU	NU		
RED		128			101			134			107									
YELLOW	*	129			102		*	135			108									
GREEN		130			103			136			109									
RED ARROW																		A121	A114	
YELLOW ARROW																			A122	A115
FLASHING YELLOW ARROW																			A123	A116
GREEN ARROW	127							133												
Hand icon					113			104			119								110	
Person icon					115			106			121								112	


NU = Not Used

* Denotes install load resistor. See load resistor installation detail this sheet.

* See pictorial of head wiring in detail this sheet.

INPUT FILE POSITION LAYOUT

(front view)



EX.: 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
 ST = STOP TIME

⊗ Wired Input - Do not populate slot with detector card


INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND TIME	DELAY TIME	ADDED INITIAL	DETECTOR TYPE
1A ¹	TB2-1,2	I1U	56	1	1	YES		15		S
	-	J4U	48	26	6	YES		3		G
2A	TB2-5,6	I2U	39	2	2	YES			X	N
2C	TB2-7,8	I2L	43	12	2	YES			X	N
2C	TB2-9,10	I3U	63	32	2	YES			X	N
4A	TB4-9,10	I6U	41	4	4	YES		3		S
4B	TB4-11,12	I6L	45	14	4	YES		10		S
5A ²	TB3-1,2	J1U	55	5	5	YES		15		S
	-	I4U	47	22	2	YES		3		G
6A	TB3-5,6	J2U	40	6	6	YES			X	N
6B	TB3-7,8	J2L	44	16	6	YES			X	N
6C	TB3-9,10	J3U	64	36	6	YES			X	N
8A	TB5-9,10	J6U	42	8	8	YES		3		S
8B	TB5-11,12	J6L	46	18	8	YES		10		S
PED PUSH BUTTONS										
P21,P22	TB8-4,6	I12U	67	PED 2	2	PED				
P41,P42	TB8-5,6	I12L	69	PED 4	4	PED				
P61,P62	TB8-7,9	I13U	68	PED 6	6	PED				
P81,P82	TB8-8,9	I13L	70	PED 8	8	PED				

NOTE:
 INSTALL DC ISOLATORS IN INPUT FILE SLOTS 112 AND 113.

- Add jumper from I1-W to J4-W, on rear of input file.
 - Add jumper from J1-W to I4-W, on rear of input file.
- * See vehicle detector setup programming detail for alternate phasing on sheet 3.


INPUT FILE POSITION LEGEND: J2L



LOAD RESISTOR INSTALLATION DETAIL


(install resistors as shown)

VALUE (ohms)	WATTAGE
1.5K - 1.9K	25W (min)
2.0K - 3.0K	10W (min)



FYA SIGNAL WIRING DETAIL

(wire signal heads as shown)




THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0491
 DESIGNED: March 2018
 SEALED: 03-29-2018
 REVISED: N/A

Final Design
 Electrical Detail - Sheet 1 of 3



Stantec Consulting Services Inc.
 801 Jones Franklin Road-Suite 300
 Raleigh, NC 27606
 Tel. (919) 851-6866
 Fax. (919) 851-7024
 www.stantec.com
 License No. F-0672



ELECTRICAL AND PROGRAMMING DETAILS FOR:
 US 401 Business (Raeford Road)
 at
 Sandalwood Drive/
 Layfayette Ford Entrance
 Division 6 Cumberland County Fayetteville
 PLAN DATE: March 2018 REVIEWED BY: L Overn
 PREPARED BY: R M Muncy REVIEWED BY:
 REVISIONS: INIT. DATE

SEAL
 NORTH CAROLINA
 PROFESSIONAL ENGINEER
 SEAL 045933
 LAWRENCE E. OVERN
 3/29/2018
 DATE
 SIG. INVENTORY NO. 06-0491

ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select 2. CONTROLLER
2. From CONTROLLER Submenu select 2. VEHICLE OVERLAPS

OVERLAP A

Select TMG VEH OVLP [A] and 'PPLT FYA'

TMG VEH OVLP...[A] TYPE:PPLT FYA

PROTECTED LEFT TURN.... PHASE 1

OPPOSING THROUGH..... PHASE 2

FLASHING ARROW OUTPUT.....CH9 ISOLATE

DELAY START OF: FYA..0.0 CLEARANCE..0.0

ACTION PLAN SF BIT DISABLE..... 1

← NOTICE ACTION PLAN SF BIT "1"

Toggle Twice

OVERLAP C

Select TMG VEH OVLP [C] and 'PPLT FYA'

TMG VEH OVLP...[C] TYPE:PPLT FYA

PROTECTED LEFT TURN.... PHASE 5

OPPOSING THROUGH..... PHASE 6

FLASHING ARROW OUTPUT.....CH11 ISOLATE

DELAY START OF: FYA..0.0 CLEARANCE..0.0

ACTION PLAN SF BIT DISABLE..... 5

← NOTICE ACTION PLAN SF BIT "5"

END PROGRAMMING

ALTERNATE PHASING ACTIVATION DETAIL

TO RUN ALT. PHASING DURING FREE RUN - PROGRAM CHANGES (SHOWN BELOW) IN A TIME BASED ACTION PLAN. SCHEDULE A DAY PLAN THAT INCLUDES THE ACTION PLAN PROGRAMMED TO SELECT VEH DET PLAN 2 AND ENABLE SF BITS 1, and 5.

TO RUN ALT. PHASING DURING COORDINATION - SELECT THE TIME BASED ACTION PLAN THAT IS PROGRAMMED TO SELECT VEH DET PLAN 2 AND ENABLE SF BITS 1, and 5.

PHASING	VEH DET PLAN	SF BITS ENABLED
ACTIONS REQUIRED TO RUN <u>DEFAULT PHASING</u>	1	NONE
ACTIONS REQUIRED TO RUN <u>ALTERNATE PHASING</u>	2	1, 5

IMPORTANT: IF ALT. PHASING IS USED DURING FREE RUN AND COORDINATION, DO NOT OPERATE TIME OF DAY EVENTS CONCURRENTLY WITH COORDINATION PLAN EVENTS IN THE EVENT SCHEDULER. (EX. FREE RUN EVENT SHOULD END BEFORE COORDINATION PLAN EVENT STARTS AND VICE-VERSA).

ALTERNATE PHASING CHANGE SUMMARY

THE FOLLOWING IS A SUMMARY OF WHAT TAKES PLACE WHEN SF BITS 1, AND 5 AND VEH DET PLAN 2 ACTIVATE TO CALL THE "ALTERNATE PHASING":

SF BITS 1,5: Modifies overlap parent phases for heads 11, and 51 to run protected turns only.

VEH DET PLAN 2: Disables phase 6 call on loop 1A and reduces delay time for phase 1 call on loop 1A to 0 seconds.

Disables phase 2 call on loop 5A and reduces delay time for phase 5 call on loop 5A to 0 seconds.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0491
 DESIGNED: March 2018
 SEALED: 03-29-2018
 REVISED: N/A

COUNTDOWN PEDESTRIAN SIGNAL OPERATION

Countdown Ped Signals are required to display timing only during Ped Clearance Interval. Consult Ped Signal Module user's manual for instructions on selecting this feature.


Final Design
 Electrical Detail - Sheet 2 of 3

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

 Stantec Consulting Services Inc. 801 Jones Franklin Road-Suite 300 Raleigh, NC 27606 Tel. (919) 851-6866 Fax. (919) 851-7024 www.stantec.com License No. F-0672	ELECTRICAL AND PROGRAMMING DETAILS FOR: Prepared in the Offices of: STATE OF NORTH CAROLINA DEPARTMENT OF TRANSPORTATION Signal Management Section 750 N. Greenfield Pkwy, Garner, NC 27529	US 401 Business (Raeford Road) at Sandalwood Drive/ Layfayette Ford Entrance Division 6 Cumberland County Fayetteville	SEAL LAWRENCE E. OVERN ENGINEER 045933 3/29/2018
	PLAN DATE: March 2018 REVIEWED BY: L Overn PREPARED BY: R M Muncey REVIEWED BY:		REVISIONS INIT. DATE

DATE: U:\Projects\Signal\Signal\electrical\Detail\Signal\4405.sig.dwg User: rnmuncy

PHASING DIAGRAM




PHASING DIAGRAM DETECTION LEGEND

- DETECTED MOVEMENT
- UNDETECTED MOVEMENT (OVERLAP)
- UNSIGNALIZED MOVEMENT
- PEDESTRIAN MOVEMENT

TABLE OF OPERATION

SIGNAL FACE	PHASE								
	Ø 1 + 5	Ø 1 + 6	Ø 2 + 5	Ø 2 + 6	Ø 3 + 7	Ø 3 + 8	Ø 4 + 7	Ø 4 + 8	F L A S H
11,12	←	←	←	←	←	←	←	←	—
21,22	R	R	G	G	R	R	R	R	Y
23	R	R	F	F	R	R	R	R	Y
31,32,33	←	←	←	←	←	←	←	←	—
41,42	R	R	R	R	R	R	G	G	R
43,44	←	←	←	←	←	←	F	F	R
51,52	←	←	←	←	←	←	←	←	—
61,62,63	R	G	R	G	R	R	R	R	Y
64	R	F	F	F	R	R	←	←	Y
71,72	←	←	←	←	←	←	←	←	—
81,82	R	R	R	R	R	G	R	G	R
83,84	←	←	←	←	←	F	R	F	R
P21,P22	DW	DW	W	W	DW	DW	DW	DW	DRK
P41,P42	DW	DW	DW	DW	DW	DW	W	W	DRK
P61,P62	DW	W	DW	DW	DW	DW	DW	DW	DRK
P81,P82	DW	DW	DW	DW	W	DW	W	DRK	

SIGNAL FACE I.D.



ASC/3 DETECTOR INSTALLATION CHART

LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PROGRAMMING							
					PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE	LOOP SYSTEM	NEW CARD
1A	6X40	0	*	-	1	Yes	-	-	-	S	-	X
1B	6X40	0	*	-	1	Yes	-	-	-	S	-	X
1C	6X40	0	*	-	1	Yes	-	15	-	S	-	X
1D	6X40	0	*	-	1	Yes	-	15	-	S	-	X
2A	6X6	300	*	-	2	Yes	-	-	-	N	-	X
2B	6X6	300	*	-	2	Yes	-	-	-	N	-	X
2C	6X40	0	*	-	2	Yes	2.0	5	-	G	-	X
2D	6X40	0	*	-	2	Yes	2.0	5	-	G	-	X
3A	6X40	0	*	-	3	Yes	-	3	-	S	-	X
3B	6X40	0	*	-	3	Yes	-	-	-	S	-	X
3C	6X40	0	*	-	3	Yes	-	-	-	S	-	X
4A	6X40	0	*	-	4	Yes	-	-	-	S	-	X
4B	6X40	0	*	-	4	Yes	-	-	-	S	-	X
5A	6X40	0	*	-	5	Yes	-	-	-	S	-	X
5B	6X40	0	*	-	5	Yes	-	-	-	S	-	X
5C	6X40	0	*	-	5	Yes	-	15	-	S	-	X
5D	6X40	0	*	-	5	Yes	-	15	-	S	-	X
6A	6X6	300	*	-	6	Yes	-	-	-	N	-	X
6B	6X6	300	*	-	6	Yes	-	-	-	N	-	X
6C	6X6	300	*	-	6	Yes	-	-	-	N	-	X

* Video Detection Area. Camera locations should be confirmed in the field by the contractor in order to provide detection of the areas indicated.

DETECTOR INSTALLATION CHART CONTINUED BELOW

ASC/3 DETECTOR INSTALLATION CHART- CONTINUED

LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PROGRAMMING							
					PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE	LOOP SYSTEM	NEW CARD
6D	6X40	0	*	-	6	Yes	2.0	5	-	G	-	X
6E	6X40	0	*	-	6	Yes	2.0	5	-	G	-	X
6F	6X40	0	*	-	6	Yes	2.0	5	-	G	-	X
7A	6X40	0	*	-	7	Yes	-	-	-	S	-	X
7B	6X40	0	*	-	7	Yes	-	-	-	S	-	X
8A	6X40	0	*	-	8	Yes	-	-	-	S	-	X
8B	6X40	0	*	-	8	Yes	-	-	-	S	-	X

* Video Detection Area. Camera locations should be confirmed in the field by the contractor in order to provide detection of the areas indicated.

8 Phase Fully Actuated Fayetteville Signal System

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 1 and/or phase 5 may be lagged.
- Phase 3 and/or phase 7 may be lagged.
- Reposition existing signal heads 23 and 24.
- Set all detector units to presence mode.
- Locate new cabinet foundation so as not to obstruct sight distance of vehicles turning right on red. Relocate existing cabinet and controller onto new foundation.
- Omit "WALK" and flashing "DON'T WALK" with no pedestrian calls.
- Program pedestrian heads to countdown the flashing "Don't Walk" time only.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Pedestrian pedestals are conceptual and shown for reference only. See 2018 NCDOT Roadway Standard Drawings 1705.04 Sheets 1-3 for push button location details.

LEGEND

- | PROPOSED | EXISTING |
|--|----------|
| ○ Traffic Signal Head | ● N/A |
| ○ Modified Signal Head | ○ N/A |
| ○ Sign | ○ N/A |
| ○ Pedestrian Signal Head With Push Button & Sign | ○ N/A |
| ○ Signal Pole with Guy | ○ N/A |
| ○ Signal Pole with Sidewalk Guy | ○ N/A |
| ○ Inductive Loop Detector | ○ N/A |
| ○ Controller & Cabinet | ○ N/A |
| ○ Junction Box | ○ N/A |
| ○ 2-in Underground Conduit | ○ N/A |
| ○ Right of Way | ○ N/A |
| ○ Directional Arrow | ○ N/A |
| ○ Metal Strain Pole | ○ N/A |
| ○ Type II Signal Pedestal | ○ N/A |
| ○ Video Detection Area | ○ N/A |
| ○ Construction Zone | ○ N/A |
| ○ Drums | ○ N/A |

ASC/3 TIMING CHART

FEATURE	PHASE							
	1	2	3	4	5	6	7	8
Min Green *	7	12	7	7	7	12	7	7
Walk *	-	7	-	7	-	7	-	7
Ped Clear	-	30	-	30	-	30	-	26
Veh. Extension *	2.0	6.0	2.0	2.0	2.0	6.0	2.0	2.0
Max I *	20	90	20	40	20	90	40	20
Yellow	3.0	4.5	3.0	3.8	3.0	4.5	3.0	4.6
Red Clear	4.2	2.6	4.1	3.1	4.2	2.5	3.8	2.4
Red Revert	-	-	-	-	-	-	-	-
Actuations B4 Add *	-	-	-	-	-	-	-	-
Seconds /Actuation *	-	-	-	-	-	-	-	-
Max Initial *	-	-	-	-	-	-	-	-
Time Before Reduction *	-	15	-	-	-	15	-	-
Time To Reduce *	-	30	-	-	-	30	-	-
Minimum Gap	-	3.0	-	-	-	3.0	-	-
Locking Detector	-	-	-	-	-	-	-	-
Recall Position	-	VEH. RECALL	-	-	-	VEH. RECALL	-	-
Dual Entry	-	-	-	-	-	-	-	-
Simultaneous Gap	X	X	X	X	X	X	X	X

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

Signal Upgrade Temporary Design 1 - TMP Phase I

Stantec
 Stantec Consulting Services Inc.
 801 Jones Franklin Road-Suite 300
 Raleigh, NC 27606
 Tel. (919) 851-6866
 Fax. (919) 851-7024
 www.stantec.com
 License No. F-0672

Prepared for the Offices of:
 Transportation Mobility and Safety Division
 NORTH CAROLINA DEPARTMENT OF TRANSPORTATION
 Signal Design Section
 750 N. Greenfield Pkwy, Garner, NC 27526


US 401 Business (Raeford Road) at NC 59 (Hope Mills Road) / SR 1592 (Glensford Drive)
 Division 6 Cumberland County Fayetteville
 PLAN DATE: March 2018 REVIEWED BY: E D Harris
 PREPARED BY: B L Watson REVIEWED BY: B L Watson

SEAL 29449
 PROFESSIONAL ENGINEER
 B L WATSON
 DATE: 3/29/2018
 SIG. INVENTORY NO. 06-015511

3/29/2018 10:51:11 AM C:\Users\gnas\OneDrive\Documents\Signal Design\Temporary_Signal_Design\Phase 1\U-4405.sig.dgn,06-015511.dgn User: rlmuncey

EDI MODEL 2018EClip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- Ensure that Red Enable is active at all times during normal operation.
- Integrate monitor with Ethernet network in cabinet.

NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Program controller to start up in phase 2 WALK and 6 WALK.
- The cabinet and controller are part of the Fayetteville Signal System.

COUNTDOWN PEDESTRIAN SIGNAL OPERATION

Countdown Ped Signals are required to display timing only during Ped Clearance Interval. Consult Ped Signal Module user's manual for instructions on selecting this feature.

EQUIPMENT INFORMATION

CONTROLLER.....2070
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S3,S4,S5,S6,S7,S8,S9,S10
 S11,S12,AUXS1,AUXS2,AUXS3,AUXS4
 AUXS5,AUXS6
 PHASES USED.....1,2,2PED,3,4,4PED,5,6,6PED,7,8,
 8PED


- OVERLAP "A".....*
 OVERLAP "B".....*
 OVERLAP "C".....*
 OVERLAP "D".....*
 OVERLAP "E".....3
 OVERLAP "F".....7
 OVERLAP "G".....7
 OVERLAP "H".....3
- * See overlap programming detail on sheet 2

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6				
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18				
PHASE	1	2	2 PED	OLG	4	4 PED	5	6	6 PED	OLH	8	8 PED	OLA	OLB	OLE	OLC	OLD	OLF				
SIGNAL HEAD NO.	11,12	83,84	21,22	P21, P22	64	41,42	P41, P42	43,44	51,52	61,62, 63	P61, P62	23	81,82	P81, P82	83,84	64	31,32, 33	43,44	23	71,72		
RED			128		101				134			107			A121	A124		A114	A101			
YELLOW			129		*	102			135		*	108										
GREEN			130			103			136			109										
RED ARROW	125								131								A111				A104	
YELLOW ARROW	126								132								A122	A125	A112	A115	A102	A105
FLASHING YELLOW ARROW																	A123	A126		A116	A103	
GREEN ARROW	127	127			118			133	133			124							A113			A106
Hand					113			104				119							110			
Walking Person					115			106				121							112			

NU = Not Used
 * Denotes install load resistor. See load resistor installation detail this sheet.
 ★ See pictorial of head wiring in detail this sheet.
 NOTE: Output functions for load switches S4 and S10 have been reassigned. See sheet 2 for details.


INPUT FILE POSITION LAYOUT



INPUT FILE CONNECTION & PROGRAMMING CHART


LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	DETECTOR NO.	NEMA PHASE
PED PUSH BUTTONS					
P21,P22	TB8-4,6	I12U	67	PED 2	2 PED
P41,P42	TB8-5,6	I12L	69	PED 4	4 PED
P61,P62	TB8-7,9	I13U	68	PED 6	6 PED
P81,P82	TB8-8,9	I13L	70	PED 8	8 PED

NOTE: INSTALL DC ISOLATORS IN INPUT FILE SLOTS 112 AND 113.




FYA SIGNAL WIRING DETAIL

(wire signal heads as shown)



LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown)



VALUE (ohms)	WATTAGE
1.5K - 1.9K	25W (min)
2.0K - 3.0K	10W (min)

SPECIAL DETECTOR NOTE

Install a video detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0155T1
 DESIGNED: March 2018
 SEALED: 03-29-2018
 REVISED: N/A

Temporary Design 1 - TMP Phase I Electrical Detail - Sheet 1 of 3

US 401 Business (Raeford Road) at NC 59 (Hope Mills Road) / SR 1592 (Glensford Drive)
 Division 6 Cumberland County Fayetteville
 PLAN DATE: March 2018 REVIEWED BY: L Overn
 PREPARED BY: G B Spell REVIEWED BY:
 REVISIONS: INIT. DATE

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED
 SEAL
 NORTH CAROLINA PROFESSIONAL ENGINEER
 LAWRENCE E. OVERN
 3/29/2018
 DATE
 SIG. INVENTORY NO. 06-0155T1

ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select 2. CONTROLLER
2. From CONTROLLER Submenu select 2. VEHICLE OVERLAPS

OVERLAP A

Select TMG VEH OVLP [A] and 'OTHER/ECONOLITE'

```

TMG VEH OVLP...[A] TYPE: OTHER/ECONOLITE
PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
INCLUDED X . . . . . X . . . . .
PROTECT . . . . .
PED PRTC . . . . .
NOT OVLP . . . . .
FLSH GRN 1 . . . . . 1 . . . . .
LAG X PH . . . . .
LAG 2 PH . . . . .

LAG GRN 0.0 YEL 0.0 RED 0.0 ADV GRN 0.0
    
```

Toggle Once

OVERLAP B

Select TMG VEH OVLP [B] and 'OTHER/ECONOLITE'

```

TMG VEH OVLP...[B] TYPE: OTHER/ECONOLITE
PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
INCLUDED . . . . . X X . . . . .
PROTECT . . . . .
PED PRTC . . . . .
NOT OVLP . . . . .
FLSH GRN . . . . . 1 1 . . . . .
LAG X PH . . . . .
LAG 2 PH . . . . .

LAG GRN 0.0 YEL 0.0 RED 0.0 ADV GRN 0.0
    
```

Toggle Once

OVERLAP C

Select TMG VEH OVLP [C] and 'OTHER/ECONOLITE'

```

TMG VEH OVLP...[C] TYPE: OTHER/ECONOLITE
PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
INCLUDED . . . . . X X . . . . .
PROTECT . . . . .
PED PRTC . . . . .
NOT OVLP . . . . .
FLSH GRN . . . . . 1 1 . . . . .
LAG X PH . . . . .
LAG 2 PH . . . . .

LAG GRN 0.0 YEL 0.0 RED 0.0 ADV GRN 0.0
    
```

Toggle Once

OVERLAP D

Select TMG VEH OVLP [D] and 'OTHER/ECONOLITE'

```

TMG VEH OVLP...[D] TYPE: OTHER/ECONOLITE
PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
INCLUDED . X X . . . . .
PROTECT . . . . .
PED PRTC . . . . .
NOT OVLP . . . . .
FLSH GRN . 1 1 . . . . .
LAG X PH . . . . .
LAG 2 PH . . . . .

LAG GRN 0.0 YEL 0.0 RED 0.0 ADV GRN 0.0
    
```

Toggle Once

OVERLAP E

Select TMG VEH OVLP [E] and 'NORMAL'

```

TMG VEH OVLP...[E] TYPE: . . . . . NORMAL
PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
INCLUDED . . X . . . . .

LAG GRN 0.0 YEL 0.0 RED 0.0
    
```

Toggle Once

OVERLAP F

Select TMG VEH OVLP [F] and 'NORMAL'

```

TMG VEH OVLP...[F] TYPE: . . . . . NORMAL
PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
INCLUDED . . . . . X . . . . .

LAG GRN 0.0 YEL 0.0 RED 0.0
    
```

Toggle Once

OVERLAP G

Select TMG VEH OVLP [G] and 'NORMAL'

```

TMG VEH OVLP...[G] TYPE: . . . . . NORMAL
PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
INCLUDED . . . . . X . . . . .

LAG GRN 0.0 YEL 0.0 RED 0.0
    
```

Toggle Once

OVERLAP H

Select TMG VEH OVLP [H] and 'NORMAL'

```

TMG VEH OVLP...[H] TYPE: . . . . . NORMAL
PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
INCLUDED . . X . . . . .

LAG GRN 0.0 YEL 0.0 RED 0.0
    
```

END PROGRAMMING

ECONOLITE ASC/3-2070 LOAD SWITCH ASSIGNMENT DETAIL

(program controller as shown)

To assign load switch S4 and S10 as OLG and OLH, program LD SWITCH 3 as OVLP '7' TYPE 'O' and LD SWITCH 7 as OVLP '8' TYPE 'O' as shown below.

1. From Main Menu select 1. CONFIGURATION
2. From CONFIGURATION Submenu select 3. LOAD SW ASSIGN

LD SWITCH ASSIGN									
PHASE	TYPE	DIMMING	FLASH						
/OVLP		R Y G D	PWR	AUT	TGR				
1	1	V	. . . +	A	R	X			
2	2	V	. . . +	A	Y	.			
3	7	O	. . . +	A	R	X			
4	4	V	. . . +	A	R	.			
5	5	V	. . . -	A	R	.			
6	6	V	. . . -	A	Y	X			
7	8	O	. . . -	A	R	.			
8	8	V	. . . -	A	R	X			
9	1	O	. . . +	A	R	X			
10	2	O	. . . +	A	Y	X			
11	3	O	. . . -	A	R	.			
12	4	O	. . . -	A	Y	.			
13	2	P	. . . +	A	.	.			
14	4	P	. . . -	A	.	.			
15	6	P	. . . +	A	.	.			
16	8	P	. . . -	A	.	.			



FLASHER CIRCUIT MODIFICATION DETAIL

In order to ensure that signals flash concurrently on the same approach, make the following flasher circuit changes:

1. On rear of PDA - remove wire from Term. T2-4 and terminate on T2-2.
2. On rear of PDA - remove wire from Term. T2-5 and terminate on T2-3.
3. Remove flasher unit 2.

The changes listed above ties all phases and overlaps to flasher unit 1.

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-0155T1
DESIGNED: March 2018
SEALED: 03-29-2018
REVISED: N/A

Temporary Design 1 - TMP Phase I
Electrical Detail - Sheet 2 of 3

DOCUMENT NOT CONSIDERED FINAL
UNLESS ALL SIGNATURES COMPLETED

 Stantec Consulting Services Inc. 801 Jones Franklin Road-Suite 300 Raleigh, NC 27606 Tel. (919) 851-6866 Fax. (919) 851-7024 www.stantec.com License No. F-0672	ELECTRICAL AND PROGRAMMING DETAILS FOR: Prepared in the Offices of: 	US 401 Business (Raeford Road) at NC 59 (Hope Mills Road)/ SR 1592 (Glensford Drive) Division 6 Cumberland County Fayetteville PLAN DATE: March 2018 REVIEWED BY: L Overn PREPARED BY: R M Muncey REVIEWED BY:	SEAL 3/29/2018
	REVISIONS INIT. DATE	REVISIONS INIT. DATE	REVISIONS INIT. DATE

DATE: 03/29/2018 10:45:11 AM USER: rfmuncey

ECONOLITE ASC/3-2070 LOGIC PROCESSOR PROGRAMMING DETAIL

(program controller as shown)

- From Main Menu select **1. CONFIGURATION**
- From CONFIGURATION Submenu select **8. LOGIC PROCESSOR**
- From LOGIC PROCESSOR Submenu select **2. LOGIC STATEMENTS**

ENTER A "1" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 1 COPY FROM: 1 ACTIVE: M FALSE
IF   CTR PHASE TMING 1 IS ON
THEN SIG SET OLP GREEN 1 OFF
ELSE

```

LOGIC FOR TURNING FLASHING YELLOW ARROW OFF DURING PHASE 1 (HEADS 83,84)

ENTER A "7" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 7 COPY FROM: 7 ACTIVE: M FALSE
IF   CTR PHASE TMING 5 IS ON
THEN SIG SET OLP GREEN 3 OFF
ELSE

```

LOGIC FOR TURNING FLASHING YELLOW ARROW OFF DURING PHASE 5 (HEADS 43,44)

4. From LOGIC PROCESSOR Submenu select **1. LOGIC STATEMENT CONTROL**

ENABLE LOGIC PROCESSOR STATEMENTS 1-12 BY POSITIONING THE CURSOR OVER THE FIELDS SHOWN BELOW AND USING THE TOGGLE KEY TO ENABLE THEM.

LOGIC STATEMENT CONTROL	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5
LP 1-15	E	E	E	E	E	E	E	E	E	E	E	E	E	E	E
LP 16-30
LP 31-45
LP 46-60
LP 61-75
LP 76-90

END PROGRAMMING

ENTER A "2" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 2 COPY FROM: 2 ACTIVE: M FALSE
IF   VEH YELLOW ON PH 1 IS ON
THEN SIG SET OLP YELLOW 1 ON
ELSE

```

LOGIC FOR YELLOW ARROW CLEARANCE WHEN LEAVING PHASE 1 (HEADS 83,84)

ENTER A "8" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 8 COPY FROM: 8 ACTIVE: M FALSE
IF   VEH YELLOW ON PH 5 IS ON
THEN SIG SET OLP YELLOW 3 ON
ELSE

```

LOGIC FOR YELLOW ARROW CLEARANCE WHEN LEAVING PHASE 5 (HEADS 43,44)

ENTER A "3" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 3 COPY FROM: 3 ACTIVE: M FALSE
IF   CTR PHASE TIMING 1 IS ON
AND  VEH RED ON PHASE 1 IS ON
THEN SIG SET OLP RED 1 ON
ELSE

```

LOGIC FOR RED SIGNAL CLEARANCE WHEN LEAVING PHASE 1 (HEADS 83,84)

ENTER A "9" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 9 COPY FROM: 9 ACTIVE: M FALSE
IF   CTR PHASE TIMING 5 IS ON
AND  VEH RED ON PHASE 5 IS ON
THEN SIG SET OLP RED 3 ON
ELSE

```

LOGIC FOR RED SIGNAL CLEARANCE WHEN LEAVING PHASE 5 (HEADS 43,44)

ENTER A "4" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 4 COPY FROM: 4 ACTIVE: M FALSE
IF   VEH OVERLAP 7 IS ON
THEN SIG SET OVL P GREEN 2 OFF
ELSE

```

LOGIC FOR TURNING FLASHING YELLOW ARROW OFF DURING OLG, WHICH HAS PARENT PHASE 7 (HEAD 64)

ENTER A "10" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 10 COPY FROM: 10 ACTIVE: M FALSE
IF   VEH OVERLAP 8 IS ON
THEN SIG SET OVL P GREEN 4 OFF
ELSE

```

LOGIC FOR TURNING FLASHING YELLOW ARROW OFF DURING OLH, WHICH HAS PARENT PHASE 3 (HEAD 23)

ENTER A "5" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 5 COPY FROM: 5 ACTIVE: M FALSE
IF   VEH OVERLAP YLW 7 IS ON
THEN SIG SET OLP YELLOW 2 ON
ELSE

```

LOGIC FOR YELLOW ARROW CLEARANCE WHEN LEAVING OLG, WHICH HAS PARENT PHASE 7 (HEAD 64)

ENTER A "11" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 11 COPY FROM: 11 ACTIVE: M FALSE
IF   VEH OVERLAP YLW 8 IS ON
THEN SIG SET OLP YELLOW 4 ON
ELSE

```

LOGIC FOR YELLOW ARROW CLEARANCE WHEN LEAVING OLH, WHICH HAS PARENT PHASE 3 (HEAD 23)

ENTER A "6" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 6 COPY FROM: 6 ACTIVE: M FALSE
IF   VEH OVERLAP 7 IS ON
AND  VEH OVERLAP RED 7 IS ON
THEN SIG SET OLP RED 2 ON
ELSE

```

LOGIC FOR RED SIGNAL CLEARANCE WHEN LEAVING OLG, WHICH HAS PARENT PHASE 7 (HEAD 64)

ENTER A "12" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 12 COPY FROM: 12 ACTIVE: M FALSE
IF   VEH OVERLAP 8 IS ON
AND  VEH OVERLAP RED 8 IS ON
THEN SIG SET OLP RED 4 ON
ELSE

```

LOGIC FOR RED SIGNAL CLEARANCE WHEN LEAVING OLH, WHICH HAS PARENT PHASE 3 (HEAD 23)

END PROGRAMMING

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0155T1
DESIGNED: March 2018
SEALED: 03-29-2018
REVISED: N/A


Temporary Design 1 - TMP Phase I Electrical Detail - Sheet 3 of 3



Stantec Consulting Services Inc.
801 Jones Franklin Road-Suite 300
Raleigh, NC 27606
Tel. (919) 851-6866
Fax. (919) 851-7024
www.stantec.com
License No. F-0672

ELECTRICAL AND PROGRAMMING DETAILS FOR:

Prepared in the Offices of:



750 N. Greenfield Pkwy, Garner, NC 27529

US 401 Business (Raeford Road)
at NC 59 (Hope Mills Road) /
SR 1592 (Glensford Drive)

Division 6 Cumberland County Fayetteville


PLAN DATE: March 2018 REVIEWED BY: L Overn

PREPARED BY: G B Spell REVIEWED BY:

REVISIONS	INIT.	DATE

DOCUMENT NOT CONSIDERED FINAL
UNLESS ALL SIGNATURES COMPLETED


SEAL



3/29/2018


SIG. INVENTORY NO. 06-0155T1

PHASING DIAGRAM



SIGNAL FACE	PHASE							
	Ø1+5	Ø1+6	Ø2+5	Ø2+6	Ø3+7	Ø3+8	Ø4+7	Ø4+8
11,12	←	←	←	←	←	←	←	←
21,22,23	R	R	G	G	R	R	R	Y
24	R	R	F	F	F	F	F	Y
31,32	←	←	←	←	←	←	←	←
41,42	R	R	R	R	R	R	G	R
43	←	R	←	R	R	R	F	R
51,52	←	←	←	←	←	←	←	←
61,62	R	G	R	G	R	R	R	Y
63	R	F	R	F	R	R	←	Y
71,72	←	←	←	←	←	←	←	←
81,82	R	R	R	R	R	G	G	R
83,84	←	←	R	R	F	F	F	R
P21,P22	DW	DW	W	W	DW	DW	DW	DRK
P41,P42	DW	DW	DW	DW	DW	DW	W	DRK
P61,P62	DW	W	DW	W	DW	DW	DW	DRK
P81,P82	DW	DW	DW	DW	DW	W	DW	DRK

SIGNAL FACE I.D.




ASC/3 DETECTOR INSTALLATION CHART										
DETECTOR					PROGRAMMING					
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	URNS	NEW LOOP	PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE
1A	6X40	0	*	-	1	Yes	-	-	-	S
1B	6X40	0	*	-	1	Yes	-	-	-	S
1C	6X40	0	*	-	1	Yes	-	15	-	S
1D	6X40	0	*	-	1	Yes	-	15	-	S
2A	6X6	300	*	-	2	Yes	-	-	-	N
2B	6X6	300	*	-	2	Yes	-	-	-	N
2C	6X6	300	*	-	2	Yes	-	-	-	N
2D	6X40	0	*	-	2	Yes	2.0	5	-	G
2E	6X40	0	*	-	2	Yes	2.0	5	-	G
2F	6X40	0	*	-	2	Yes	2.0	5	-	G
3A	6X40	0	*	-	3	Yes	-	3	-	S
3B	6X40	0	*	-	3	Yes	-	-	-	S
4A	6X40	0	*	-	4	Yes	-	-	-	S
4B	6X40	0	*	-	4	Yes	-	-	-	S
5A	6X40	0	*	-	5	Yes	-	-	-	S
5B	6X40	0	*	-	5	Yes	-	-	-	S
5C	6X40	0	*	-	5	Yes	-	15	-	S
6A	6X6	300	*	-	6	Yes	-	-	-	N
6B	6X6	300	*	-	6	Yes	-	-	-	N

8 Phase Fully Actuated Fayetteville Signal System

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 1 and/or phase 5 may be lagged.
- Phase 3 and/or phase 7 may be lagged.
- Reposition existing signal head 24 and 63.
- Set all detector units to presence mode.
- Omit "WALK" and flashing "DON'T WALK" with no pedestrian calls.
- Program pedestrian heads to countdown the flashing "Don't Walk" time only.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Pedestrian pedestals are conceptual and shown for reference only. See 2018 NCDOT Roadway Standard Drawings 1705.04 Sheets 1-3 for push button location details.




*Video Detection Area. Camera locations should be confirmed in the field by the contractor in order to provide detection of the areas indicated.

DETECTOR INSTALLATION CHART CONTINUED BELOW


ASC/3 DETECTOR INSTALLATION CHART- CONTINUED										
DETECTOR					PROGRAMMING					
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	URNS	NEW LOOP	PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE
6C	6X40	0	*	-	6	Yes	2.0	5	-	G
6D	6X40	0	*	-	6	Yes	2.0	5	-	G
7A	6X40	0	*	-	7	Yes	-	-	-	S
7B	6X40	0	*	-	7	Yes	-	-	-	S
8A	6X40	0	*	-	8	Yes	-	-	-	S
8B	6X40	0	*	-	8	Yes	-	-	-	S

*Video Detection Area. Camera locations should be confirmed in the field by the contractor in order to provide detection of the areas indicated.



FEATURE	ASC/3 TIMING CHART PHASE							
	1	2	3	4	5	6	7	8
Min Green *	7	12	7	7	7	12	7	7
Walk *	-	7	-	7	-	7	-	7
Ped Clear	-	30	-	30	-	30	-	26
Veh. Extension *	2.0	6.0	2.0	2.0	2.0	6.0	2.0	2.0
Max I *	20	90	20	40	20	90	40	20
Yellow	3.0	4.5	3.0	3.8	3.0	4.5	3.0	4.6
Red Clear	4.2	2.6	3.9	3.1	4.2	2.6	3.8	2.4
Red Revert	-	-	-	-	-	-	-	-
Actuations B4 Add *	-	-	-	-	-	-	-	-
Seconds /Actuation *	-	-	-	-	-	-	-	-
Max Initial *	-	-	-	-	-	-	-	-
Time Before Reduction *	-	15	-	-	-	15	-	-
Time To Reduce *	-	30	-	-	-	30	-	-
Minimum Gap	-	3.0	-	-	-	3.0	-	-
Locking Detector	-	-	-	-	-	-	-	-
Recall Position	-	VEH. RECALL	-	-	-	VEH. RECALL	-	-
Dual Entry	-	-	-	-	-	-	-	-
Simultaneous Gap	X	X	X	X	X	X	X	X

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.



Signal Upgrade Temporary Design 2 - TMP Phase II

Stantec
 Stantec Consulting Services Inc.
 801 Jones Franklin Road-Suite 300
 Raleigh, NC 27606
 Tel. (919) 851-6866
 Fax. (919) 851-7024
 www.stantec.com
 License No. F-0672

Prepared for the Offices of:
 Transportation Mobility and Safety Division
 NORTH CAROLINA DEPARTMENT OF TRANSPORTATION
 SIGNAL DESIGN SECTION
 750 N. Greenfield Pkwy, Garner, NC 27526
 SCALE: 0 40
 1" = 40'


US 401 Business (Raeford Road) at NC 59 (Hope Mills Road) / SR 1592 (Glensford Drive)
 Division 6 Cumberland County Fayetteville
 PLAN DATE: March 2018 REVIEWED BY: E D Harris
 PREPARED BY: R M Muncey REVIEWED BY: B L Watson

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED
 NORTH CAROLINA PROFESSIONAL ENGINEER
 SEAL 29449
 BENJY L. WATSON
 3/29/2018
 SIG. INVENTORY NO. 06-015512

3/29/2018 10:11:11 AM
 User: rlmuncey
 Design: Signal Design Temporary - Signal Design Phase 2 - U-4405 - 015512 - 001

EDI MODEL 2018EClip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- Ensure that Red Enable is active at all times during normal operation.
- Integrate monitor with Ethernet network in cabinet.

NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Program controller to start up in phase 2 WALK and 6 WALK.
- The cabinet and controller are part of the Fayetteville Signal System.

COUNTDOWN PEDESTRIAN SIGNAL OPERATION

Countdown Ped Signals are required to display timing only during Ped Clearance Interval. Consult Ped Signal Module user's manual for instructions on selecting this feature.

EQUIPMENT INFORMATION

CONTROLLER.....2070
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S3,S4,S5,S6,S7,S8,S9,S10
 S11,S12,AUXS1,AUXS2,AUXS3,AUXS4
 AUXS5,AUXS6
 PHASES USED.....1,2,2PED,3,4,4PED,5,6,6PED,7,8,
 8PED


- OVERLAP "A".....*
 OVERLAP "B".....*
 OVERLAP "C".....*
 OVERLAP "D".....*
 OVERLAP "E".....3
 OVERLAP "F".....7
 OVERLAP "G".....7
 OVERLAP "H".....3
- * See overlap programming detail on sheet 2

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6			
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18			
PHASE	1	2	2 PED	OLG	4	4 PED	5	6	6 PED	OLH	8	8 PED	OLA	OLB	OLE	OLC	OLD	OLF			
SIGNAL HEAD NO.	11,12	83,84	21,22, 23	P21, P22	63	41,42	P41, P42	43	51,52	61,62	P61, P62	24	81,82	P81, P82	83,84	63	31,32	43	24	71,72	
RED		128			101					134					A121	A124		A114	A101		
YELLOW			129	*	102					135	*	108									
GREEN			130		103					136		109									
RED ARROW	125								131							A111				A104	
YELLOW ARROW	126								132							A122	A125	A112	A115	A102	A105
FLASHING YELLOW ARROW																A123	A126		A116	A103	
GREEN ARROW	127	127			118			133	133			124						A113			A106
Hand					113			104				119									
Walking								106				121									

NU = Not Used
 * Denotes install load resistor. See load resistor installation detail this sheet.
 ★ See pictorial of head wiring in detail this sheet.
 NOTE: Output functions for load switches S4 and S10 have been reassigned. See sheet 2 for details.


INPUT FILE POSITION LAYOUT



INPUT FILE CONNECTION & PROGRAMMING CHART


LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	DETECTOR NO.	NEMA PHASE
PED PUSH BUTTONS					
P21,P22	TB8-4,6	I12U	67	PED 2	2 PED
P41,P42	TB8-5,6	I12L	69	PED 4	4 PED
P61,P62	TB8-7,9	I13U	68	PED 6	6 PED
P81,P82	TB8-8,9	I13L	70	PED 8	8 PED

NOTE: INSTALL DC ISOLATORS IN INPUT FILE SLOTS 112 AND 113.




FYA SIGNAL WIRING DETAIL

(wire signal heads as shown)



LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown)



SPECIAL DETECTOR NOTE

Install a video detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0155T2
 DESIGNED: March 2018
 SEALED: 03-29-2018
 REVISED: N/A

Temporary Design 2 - TMP Phase II Electrical Detail - Sheet 1 of 3

US 401 Business (Raeford Road) at NC 59 (Hope Mills Road) / SR 1592 (Glensford Drive)

PLAN DATE: March 2018	REVIEWED BY: L Overn
PREPARED BY: G B Spell	REVIEWED BY:
REVISIONS	INIT. DATE

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SEAL
 NORTH CAROLINA PROFESSIONAL ENGINEER
 LAWRENCE E. OVERN
 045933
 3/29/2018
 SIG. INVENTORY NO. 06-0155T2

DATE: U:\Projects\Signal\Temp\Temp\Detail\SignalPhase 2\U-4405.sig.ele.06-0155T2.dgn User: rrmunicy

ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select 2. CONTROLLER
2. From CONTROLLER Submenu select 2. VEHICLE OVERLAPS

OVERLAP A

Select TMG VEH OVLP [A] and 'OTHER/ECONOLITE'

```

TMG VEH OVLP...[A] TYPE: OTHER/ECONOLITE
 PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
 INCLUDED X . . . . . X . . . . .
 PROTECT . . . . .
 PED PRTC . . . . .
 NOT OVLP . . . . .
 FLSH GRN 1 . . . . . 1 . . . . .
 LAG X PH . . . . .
 LAG 2 PH . . . . .

 LAG GRN 0.0 YEL 0.0 RED 0.0 ADV GRN 0.0
    
```

Toggle Once

OVERLAP B

Select TMG VEH OVLP [B] and 'OTHER/ECONOLITE'

```

TMG VEH OVLP...[B] TYPE: OTHER/ECONOLITE
 PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
 INCLUDED . . . . . X X . . . . .
 PROTECT . . . . .
 PED PRTC . . . . .
 NOT OVLP . . . . .
 FLSH GRN . . . . . 1 1 . . . . .
 LAG X PH . . . . .
 LAG 2 PH . . . . .

 LAG GRN 0.0 YEL 0.0 RED 0.0 ADV GRN 0.0
    
```

Toggle Once

OVERLAP C

Select TMG VEH OVLP [C] and 'OTHER/ECONOLITE'

```

TMG VEH OVLP...[C] TYPE: OTHER/ECONOLITE
 PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
 INCLUDED . . . X X . . . . .
 PROTECT . . . . .
 PED PRTC . . . . .
 NOT OVLP . . . . .
 FLSH GRN . . . 1 1 . . . . .
 LAG X PH . . . . .
 LAG 2 PH . . . . .

 LAG GRN 0.0 YEL 0.0 RED 0.0 ADV GRN 0.0
    
```

Toggle Once

OVERLAP D

Select TMG VEH OVLP [D] and 'OTHER/ECONOLITE'

```

TMG VEH OVLP...[D] TYPE: OTHER/ECONOLITE
 PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
 INCLUDED . X X . . . . .
 PROTECT . . . . .
 PED PRTC . . . . .
 NOT OVLP . . . . .
 FLSH GRN . 1 1 . . . . .
 LAG X PH . . . . .
 LAG 2 PH . . . . .

 LAG GRN 0.0 YEL 0.0 RED 0.0 ADV GRN 0.0
    
```

Toggle Once

OVERLAP E

Select TMG VEH OVLP [E] and 'NORMAL'

```

TMG VEH OVLP...[E] TYPE: . . . . . NORMAL
 PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
 INCLUDED . . X . . . . .

 LAG GRN 0.0 YEL 0.0 RED 0.0
    
```

Toggle Once

OVERLAP F

Select TMG VEH OVLP [F] and 'NORMAL'

```

TMG VEH OVLP...[F] TYPE: . . . . . NORMAL
 PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
 INCLUDED . . . . . X . . . . .

 LAG GRN 0.0 YEL 0.0 RED 0.0
    
```

Toggle Once

OVERLAP G

Select TMG VEH OVLP [G] and 'NORMAL'

```

TMG VEH OVLP...[G] TYPE: . . . . . NORMAL
 PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
 INCLUDED . . . . . X . . . . .

 LAG GRN 0.0 YEL 0.0 RED 0.0
    
```

Toggle Once

OVERLAP H

Select TMG VEH OVLP [H] and 'NORMAL'

```

TMG VEH OVLP...[H] TYPE: . . . . . NORMAL
 PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
 INCLUDED . . X . . . . .

 LAG GRN 0.0 YEL 0.0 RED 0.0
    
```

END PROGRAMMING


ECONOLITE ASC/3-2070 LOAD SWITCH ASSIGNMENT DETAIL

(program controller as shown)

To assign load switch S4 and S10 as OLG and OLH, program LD SWITCH 3 as OVLP '7' TYPE 'O' and LD SWITCH 7 as OVLP '8' TYPE 'O' as shown below.

1. From Main Menu select 1. CONFIGURATION
2. From CONFIGURATION Submenu select 3. LOAD SW ASSIGN

LD SWITCH ASSIGN									
PHASE	TYPE	DIMMING	FLASH						
/OVLP		R Y G D	PWR	AUT	TGR				
1	1	V	. . . +	A	R	X			
2	2	V	. . . +	A	Y	.			
3	7	O	. . . +	A	R	X			
4	4	V	. . . +	A	R	.			
5	5	V	. . . -	A	R	.			
6	6	V	. . . -	A	Y	X			
7	8	O	. . . -	A	R	.			
8	8	V	. . . -	A	R	X			
9	1	O	. . . +	A	R	X			
10	2	O	. . . +	A	Y	X			
11	3	O	. . . -	A	R	.			
12	4	O	. . . -	A	Y	.			
13	2	P	. . . +	A	.	.			
14	4	P	. . . -	A	.	.			
15	6	P	. . . +	A	.	.			
16	8	P	. . . -	A	.	.			



FLASHER CIRCUIT MODIFICATION DETAIL

In order to ensure that signals flash concurrently on the same approach, make the following flasher circuit changes:

1. On rear of PDA - remove wire from Term. T2-4 and terminate on T2-2.
2. On rear of PDA - remove wire from Term. T2-5 and terminate on T2-3.
3. Remove flasher unit 2.

The changes listed above ties all phases and overlaps to flasher unit 1.

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-0155T2
DESIGNED: March 2018
SEALED: 03-29-2018
REVISED: N/A

Temporary Design 2 - TMP Phase II
Electrical Detail - Sheet 2 of 3

DOCUMENT NOT CONSIDERED FINAL
UNLESS ALL SIGNATURES COMPLETED

 Stantec Consulting Services Inc. 801 Jones Franklin Road-Suite 300 Raleigh, NC 27606 Tel. (919) 851-6866 Fax. (919) 851-7024 www.stantec.com License No. F-0672	ELECTRICAL AND PROGRAMMING DETAILS FOR: Prepared in the Offices of: STATE OF NORTH CAROLINA DEPARTMENT OF TRANSPORTATION DIVISION OF SIGNALS MANAGEMENT 750 N. Greenfield Pkwy, Garner, NC 27529	US 401 Business (Raeford Road) at NC 59 (Hope Mills Road) / SR 1592 (Glensford Drive) Division 6 Cumberland County Fayetteville PLAN DATE: March 2018 REVIEWED BY: L Overn PREPARED BY: G B Spell REVIEWED BY:	SEAL LAWRENCE E. OVERN ENGINEER 045933 3/29/2018
	REVISIONS INIT. DATE _____ _____	DATE _____ _____	DATE _____ _____

DATE: 03/29/2018 10:45:11 AM; USER: rfmancey; FILE: \\fs1\projects\signal\design\temp\phase 2\mu-4405\sig\ele_06-0155t2.dgn

ECONOLITE ASC/3-2070 LOGIC PROCESSOR PROGRAMMING DETAIL

(program controller as shown)

- From Main Menu select **1. CONFIGURATION**
- From CONFIGURATION Submenu select **8. LOGIC PROCESSOR**
- From LOGIC PROCESSOR Submenu select **2. LOGIC STATEMENTS**

ENTER A "1" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#:  1 COPY FROM:  1 ACTIVE:  M FALSE
IF   CTR PHASE TMING    1  IS ON
THEN SIG SET OLP GREEN  1    OFF

ELSE

```

LOGIC FOR TURNING FLASHING YELLOW ARROW OFF DURING PHASE 1 (HEADS 83,84)

ENTER A "2" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#:  2 COPY FROM:  2 ACTIVE:  M FALSE
IF   VEH YELLOW ON PH  1  IS ON
THEN SIG SET OLP YELLOW 1    ON

ELSE

```

LOGIC FOR YELLOW ARROW CLEARANCE WHEN LEAVING PHASE 1 (HEADS 83,84)

ENTER A "3" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#:  3 COPY FROM:  3 ACTIVE:  M FALSE
IF   VEH RED ON PHASE  1  IS ON
AND  CTR PHASE TIMING  1  IS ON
THEN SIG SET OLP RED   1    ON

ELSE

```

LOGIC FOR RED SIGNAL CLEARANCE WHEN LEAVING PHASE 1 (HEADS 83,84)

ENTER A "4" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#:  4 COPY FROM:  4 ACTIVE:  M FALSE
IF   VEH OVERLAP      7  IS ON
THEN SIG SET OVL P GREEN 2    OFF

ELSE

```

LOGIC FOR TURNING FLASHING YELLOW ARROW OFF DURING OLG, WHICH HAS PARENT PHASE 7 (HEAD 63)

ENTER A "5" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#:  5 COPY FROM:  5 ACTIVE:  M FALSE
IF   VEH OVERLAP YLW  7  IS ON
THEN SIG SET OLP YELLOW 2    ON

ELSE

```

LOGIC FOR YELLOW ARROW CLEARANCE WHEN LEAVING OLG, WHICH HAS PARENT PHASE 7 (HEAD 63)

ENTER A "6" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#:  6 COPY FROM:  6 ACTIVE:  M FALSE
IF   VEH OVERLAP      7  IS ON
AND  VEH OVERLAP RED  7  IS ON
THEN SIG SET OLP RED   2    ON

ELSE

```

LOGIC FOR RED SIGNAL CLEARANCE WHEN LEAVING OLG, WHICH HAS PARENT PHASE 7 (HEAD 63)

ENTER A "7" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#:  7 COPY FROM:  7 ACTIVE:  M FALSE
IF   CTR PHASE TMING    5  IS ON
THEN SIG SET OLP GREEN  3    OFF

ELSE

```

LOGIC FOR TURNING FLASHING YELLOW ARROW OFF DURING PHASE 5 (HEAD 43)

ENTER A "8" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#:  8 COPY FROM:  8 ACTIVE:  M FALSE
IF   VEH YELLOW ON PH  5  IS ON
THEN SIG SET OLP YELLOW 3    ON

ELSE

```

LOGIC FOR YELLOW ARROW CLEARANCE WHEN LEAVING PHASE 5 (HEAD 43)

ENTER A "9" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#:  9 COPY FROM:  9 ACTIVE:  M FALSE
IF   VEH RED ON PHASE  5  IS ON
AND  CTR PHASE TIMING  5  IS ON
THEN SIG SET OLP RED   3    ON

ELSE

```

LOGIC FOR RED SIGNAL CLEARANCE WHEN LEAVING PHASE 5 (HEAD 43)

ENTER A "10" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 10 COPY FROM: 10 ACTIVE:  M FALSE
IF   VEH OVERLAP      8  IS ON
THEN SIG SET OVL P GREEN 4    OFF

ELSE

```

LOGIC FOR TURNING FLASHING YELLOW ARROW OFF DURING OLH, WHICH HAS PARENT PHASE 3 (HEAD 24)

ENTER A "11" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 11 COPY FROM: 11 ACTIVE:  M FALSE
IF   VEH OVERLAP YLW  8  IS ON
THEN SIG SET OLP YELLOW 4    ON

ELSE

```

LOGIC FOR YELLOW ARROW CLEARANCE WHEN LEAVING OLH, WHICH HAS PARENT PHASE 3 (HEAD 24)

ENTER A "12" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 12 COPY FROM: 12 ACTIVE:  M FALSE
IF   VEH OVERLAP      8  IS ON
AND  VEH OVERLAP RED  8  IS ON
THEN SIG SET OLP RED   4    ON

ELSE

```

LOGIC FOR RED SIGNAL CLEARANCE WHEN LEAVING OLH, WHICH HAS PARENT PHASE 3 (HEAD 24)

END PROGRAMMING

- From LOGIC PROCESSOR Submenu select **1. LOGIC STATEMENT CONTROL**

ENABLE LOGIC PROCESSOR STATEMENTS 1-12 BY POSITIONING THE CURSOR OVER THE FIELDS SHOWN BELOW AND USING THE TOGGLE KEY TO ENABLE THEM.

LOGIC STATEMENT CONTROL	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5
LP 1-15	E	E	E	E	E	E	E	E	E	E	E	E	E	E	E
LP 16-30
LP 31-45
LP 46-60
LP 61-75
LP 76-90

END PROGRAMMING

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0155T2
DESIGNED: March 2018
SEALED: 03-29-2018
REVISED: N/A


Temporary Design 2 - TMP Phase II Electrical Detail - Sheet 3 of 3



Stantec Consulting Services Inc.
801 Jones Franklin Road-Suite 300
Raleigh, NC 27606
Tel. (919) 851-6866
Fax. (919) 851-7024
www.stantec.com
License No. F-0672

ELECTRICAL AND PROGRAMMING
DETAILS FOR:

Prepared in the Offices of:



750 N. Greenfield Pkwy, Garner, NC 27529


US 401 Business (Raeford Road) at NC 59 (Hope Mills Road) / SR 1592 (Glensford Drive)	
Division 6	Cumberland County Fayetteville
PLAN DATE: March 2018	REVIEWED BY: L Overn
PREPARED BY: G B Spell	REVIEWED BY:
REVISIONS	INIT. DATE

DOCUMENT NOT CONSIDERED FINAL
UNLESS ALL SIGNATURES COMPLETED


SEAL
NORTH CAROLINA
PROFESSIONAL
ENGINEER
LAWRENCE E. OVERN
045933
3/29/2018
DATE
SIG. INVENTORY NO. 06-0155T2

DATE: U:\Projects\Signal\Temp\Temp\Detail\Signal\Phase 2\U-4405.sig.ele_06-0155T2.dgn User: rmluncey


PHASING DIAGRAM



SIGNAL FACE	PHASE							
	01+5	01+6	02+5	02+6	03+7	03+8	04+7	04+8
11,12	←	←	←	←	←	←	←	←
21,22	R	R	G	G	R	R	R	Y
23,24	R	R	←	←	←	←	←	←
31,32	←	←	←	←	←	←	←	←
41,42	R	R	R	R	R	R	G	G
43,44	←	←	←	←	←	←	←	←
51,52	←	←	←	←	←	←	←	←
61,62	R	G	R	G	R	R	R	Y
71,72	←	←	←	←	←	←	←	←
81,82	R	R	R	R	R	R	G	G
83,84	←	←	←	←	←	←	←	←
P21,P22	DW	DW	W	W	DW	DW	DW	DRK
P41,P42	DW	DW	DW	DW	DW	DW	W	DRK
P61,P62	DW	W	DW	W	DW	DW	DW	DRK
P81,P82	DW	DW	DW	DW	W	DW	W	DRK



SIGNAL FACE I.D.



ASC/3 DETECTOR INSTALLATION CHART											
DETECTOR				PROGRAMMING							
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE	NEW CARD
1A	6X40	0	*	-	1	Yes	-	-	-	S	-
1B	6X40	0	*	-	1	Yes	-	-	-	S	-
1C	6X40	0	*	-	1	Yes	-	15	-	S	-
1D	6X40	0	*	-	1	Yes	-	15	-	S	-
2A	6X6	300	*	-	2	Yes	-	-	-	N	-
2B	6X6	300	*	-	2	Yes	-	-	-	N	-
2C	6X40	0	*	-	2	Yes	2.0	5	-	G	-
2D	6X40	0	*	-	2	Yes	2.0	5	-	G	-
3A	6X40	0	*	-	3	Yes	-	3	-	S	-
3B	6X40	0	*	-	3	Yes	-	-	-	S	-
4A	6X40	0	*	-	4	Yes	-	-	-	S	-
4B	6X40	0	*	-	4	Yes	-	-	-	S	-
5A	6X40	0	*	-	5	Yes	-	-	-	S	-
5B	6X40	0	*	-	5	Yes	-	-	-	S	-
5C	6X40	0	*	-	5	Yes	-	15	-	S	-
5D	6X40	0	*	-	5	Yes	-	15	-	S	-
6A	6X6	300	*	-	6	Yes	-	-	-	N	-
6B	6X6	300	*	-	6	Yes	-	-	-	N	-



*Video Detection Area. Camera locations should be confirmed in the field by the contractor in order to provide detection of the areas indicated.

DETECTOR INSTALLATION CHART CONTINUED BELOW

8 Phase Fully Actuated Fayetteville Signal System

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 1 and/or phase 5 may be lagged.
- Phase 3 and/or phase 7 may be lagged.
- Reposition existing signal heads 11, 12, 22, 23, 31, 32, 51, 52, 61, and 62.
- Set all detector units to presence mode.
- Omit "WALK" and flashing "DON'T WALK" with no pedestrian calls.
- Program pedestrian heads to countdown the flashing "Don't Walk" time only.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.



FEATURE	ASC/3 TIMING CHART PHASE							
	1	2	3	4	5	6	7	8
Min Green *	7	12	7	7	7	12	7	7
Walk *	-	7	-	7	-	7	-	7
Ped Clear	-	30	-	31	-	29	-	27
Veh. Extension *	2.0	6.0	2.0	2.0	2.0	6.0	2.0	2.0
Max I *	20	90	20	40	20	90	40	20
Yellow	3.0	4.5	3.0	3.8	3.0	4.5	3.0	4.6
Red Clear	4.3	2.8	4.2	3.1	3.9	2.8	4.0	2.4
Red Revert	-	-	-	-	-	-	-	-
Actuations B4 Add *	-	-	-	-	-	-	-	-
Seconds / Actuation *	-	-	-	-	-	-	-	-
Max Initial *	-	-	-	-	-	-	-	-
Time Before Reduction *	-	15	-	-	-	15	-	-
Time To Reduce *	-	30	-	-	-	30	-	-
Minimum Gap	-	3.0	-	-	-	3.0	-	-
Locking Detector	-	-	-	-	-	-	-	-
Recall Position	-	VEH. RECALL	-	-	-	VEH. RECALL	-	-
Dual Entry	-	-	-	-	-	-	-	-
Simultaneous Gap	X	X	X	X	X	X	X	X

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

ASC/3 DETECTOR INSTALLATION CHART- CONTINUED											
DETECTOR				PROGRAMMING							
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE	NEW CARD
6C	6X40	0	*	-	6	Yes	2.0	5	-	G	-
6D	6X40	0	*	-	6	Yes	2.0	5	-	G	-
7A	6X40	0	*	-	7	Yes	-	-	-	S	-
7B	6X40	0	*	-	7	Yes	-	-	-	S	-
8A	6X40	0	*	-	8	Yes	-	-	-	S	-
8B	6X40	0	*	-	8	Yes	-	-	-	S	-

*Video Detection Area. Camera locations should be confirmed in the field by the contractor in order to provide detection of the areas indicated.

Signal Upgrade Temporary Design 3 - TMP Phase III

Stantec
 Stantec Consulting Services Inc.
 801 Jones Franklin Road-Suite 300
 Raleigh, NC 27606
 Tel. (919) 851-6866
 Fax. (919) 851-7024
 www.stantec.com
 License No. F-0672

Prepared for the Offices of:
 Transportation Mobility and Safety Division
 NORTH CAROLINA DEPARTMENT OF TRANSPORTATION
 STATE OF NORTH CAROLINA
 Signal Design Section
 750 N. Greenfield Pkwy, Garner, NC 27526
 SCALE: 0 40
 1" = 40'

US 401 Business (Raeford Road) at NC 59 (Hope Mills Road) / SR 1592 (Glensford Drive)
 Division 6 Cumberland County Fayetteville
 PLAN DATE: March 2018 REVIEWED BY: E D Harris
 PREPARED BY: R M Muncey REVIEWED BY: B L Watson

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED


Professional Engineer Seal: E D Harris, No. 29449
 Date: 3/29/2018
 Signature: E D Harris

3/29/2018 10:11:11 AM
 User: rmmuncey
 Design: Signal Design Section
 Project: US 401 Business (Raeford Road) at NC 59 (Hope Mills Road) / SR 1592 (Glensford Drive)
 Drawing: Signal Upgrade Temporary Design 3 - TMP Phase III

EDI MODEL 2018EClip-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)


REMOVE DIODE JUMPERS 1-5, 1-6, 1-9, 1-11, 1-15, 2-5, 2-6, 2-11, 2-12, 2-13, 2-15, 3-7, 3-8, 3-9, 3-12, 3-16, 3-18, 4-8, 4-9, 4-11, 4-14, 4-16, 4-18, 5-9, 5-11, 5-12, 5-13, 6-9, 6-12, 6-13, 6-15, 7-8, 7-9, 7-12, 7-16, 7-18, 8-9, 8-11, 8-12, 8-14, 8-16, 9-11, 9-12, 9-14, 9-15, 9-16, 11-12, 11-13, 11-14, 11-16, 11-18, 12-13, 12-15, 12-16, 13-15, 14-16, and 14-18.



REMOVE JUMPERS AS SHOWN

NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- Ensure that Red Enable is active at all times during normal operation.
- Integrate monitor with Ethernet network in cabinet.



NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Program controller to start up in phase 2 WALK and 6 WALK.
- The cabinet and controller are part of the Fayetteville Signal System.

COUNTDOWN PEDESTRIAN SIGNAL OPERATION

Countdown Ped Signals are required to display timing only during Ped Clearance Interval. Consult Ped Signal Module user's manual for instructions on selecting this feature.

EQUIPMENT INFORMATION

CONTROLLER.....2070
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S3,S4,S5,S6,S7,S8,S9,S10
 S11,S12,AUXS1,AUXS4,AUXS5,AUXS6
 PHASES USED.....1,2,2PED,3,4,4PED,5,6,6PED,7,8,8PED
 OVERLAP "A".....*
 OVERLAP "B".....NOT USED
 OVERLAP "C".....*
 OVERLAP "D".....*
 OVERLAP "F".....7
 OVERLAP "H".....3
 * See overlap programming detail on sheet 2


SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6		
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18		
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	OLH	8	8 PED	OLA	OLB	SPARE	OLC	OLD	OLF		
SIGNAL HEAD NO.	11,12	83,84	21,22	P21, P22	31,32	41,42	P41, P42	43,44	51,52	61,62	P61, P62	23,24	81,82	P81, P82	83,84	NU	NU	43,44	23,24	71,72
RED		128			101				134							A121		A114	A101	
YELLOW		129			102				135		*	108								
GREEN		130			103				136			109								
RED ARROW	125				116				131											A104
YELLOW ARROW	126				117				132							A122		A115	A102	A105
FLASHING YELLOW ARROW																A123		A116	A103	
GREEN ARROW	127	127			118			133	133			124								A106
Hand					113			104				119								
Walking					115			106				121								

NU = Not Used
 * Denotes install load resistor. See load resistor installation detail this sheet.
 ★ See pictorial of head wiring in detail this sheet.
 NOTE: Output functions for load switch S10 have been reassigned. See sheet 2 for details.

INPUT FILE POSITION LAYOUT

(front view)




EX.: 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
 ST = STOP TIME

INPUT FILE CONNECTION & PROGRAMMING CHART


LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	DETECTOR NO.	NEMA PHASE
PED PUSH BUTTONS					
P21,P22	TB8-4,6	I12U	67	PED 2	2 PED
P41,P42	TB8-5,6	I12L	69	PED 4	4 PED
P61,P62	TB8-7,9	I13U	68	PED 6	6 PED
P81,P82	TB8-8,9	I13L	70	PED 8	8 PED

NOTE: INSTALL DC ISOLATORS IN INPUT FILE SLOTS 112 AND 113.



FYA SIGNAL WIRING DETAIL

(wire signal heads as shown)




LOAD RESISTOR INSTALLATION DETAIL

(install resistor as shown)

ACCEPTABLE VALUES

VALUE (ohms)	WATTAGE
1.5K - 1.9K	25W (min)
2.0K - 3.0K	10W (min)



IMPORTANT! Remove resistor from field terminal as shown above, if present.

SPECIAL DETECTOR NOTE

Install a video detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0155T3
 DESIGNED: March 2018
 SEALED: 03-29-2018
 REVISED: N/A

Temporary Design 3 - TMP Phase III
 Electrical Detail - Sheet 1 of 3

ELECTRICAL AND PROGRAMMING DETAILS FOR:

US 401 Business (Raeford Road) at NC 59 (Hope Mills Road) / SR 1592 (Glensford Drive)

Division 6 Cumberland County Fayetteville

PLAN DATE: March 2018	REVIEWED BY: L Overn
PREPARED BY: G B Spell	REVIEWED BY:

REVISIONS	INIT.	DATE

SEAL

DATE: 3/29/2018

SIG. INVENTORY NO. 06-0155T3

ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select 2. CONTROLLER
2. From CONTROLLER Submenu select 2. VEHICLE OVERLAPS

OVERLAP A

Select TMG VEH OVLP [A] and 'OTHER/ECONOLITE'

```

TMG VEH OVLP...[A] TYPE: OTHER/ECONOLITE
 PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
INCLUDED X . . . . . X . . . . .
PROTECT . . . . .
PED PRTC . . . . .
NOT OVLP . . . . .
FLSH GRN 1 . . . . . 1 . . . . .
LAG X PH . . . . .
LAG 2 PH . . . . .

LAG GRN 0.0 YEL 0.0 RED 0.0 ADV GRN 0.0
    
```

Toggle Twice

OVERLAP C

Select TMG VEH OVLP [C] and 'OTHER/ECONOLITE'

```

TMG VEH OVLP...[C] TYPE: OTHER/ECONOLITE
 PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
INCLUDED . . . X X . . . . .
PROTECT . . . . .
PED PRTC . . . . .
NOT OVLP . . . . .
FLSH GRN . . . 1 1 . . . . .
LAG X PH . . . . .
LAG 2 PH . . . . .

LAG GRN 0.0 YEL 0.0 RED 0.0 ADV GRN 0.0
    
```

Toggle Once

OVERLAP D

Select TMG VEH OVLP [D] and 'OTHER/ECONOLITE'

```

TMG VEH OVLP...[D] TYPE: OTHER/ECONOLITE
 PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
INCLUDED . X X . . . . .
PROTECT . . . . .
PED PRTC . . . . .
NOT OVLP . . . . .
FLSH GRN . 1 1 . . . . .
LAG X PH . . . . .
LAG 2 PH . . . . .

LAG GRN 0.0 YEL 0.0 RED 0.0 ADV GRN 0.0
    
```

Toggle Twice

OVERLAP F

Select TMG VEH OVLP [F] and 'NORMAL'

```

TMG VEH OVLP...[F] TYPE: . . . . . NORMAL
 PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
INCLUDED . . . . . X . . . . .

LAG GRN 0.0 YEL 0.0 RED 0.0
    
```

Toggle Twice

OVERLAP H

Select TMG VEH OVLP [H] and 'NORMAL'

```

TMG VEH OVLP...[H] TYPE: . . . . . NORMAL
 PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
INCLUDED . . X . . . . .

LAG GRN 0.0 YEL 0.0 RED 0.0
    
```

END PROGRAMMING

ECONOLITE ASC/3-2070 LOAD SWITCH ASSIGNMENT DETAIL

(program controller as shown)

To assign load switch S10 as DLH, program LD SWITCH 7 as OVLP '8' TYPE '0' as shown below.

1. From Main Menu select 1. CONFIGURATION
2. From CONFIGURATION Submenu select 3. LOAD SW ASSIGN

LD SWITCH ASSIGN									
PHASE	DIMMING	---	FLASH---						
/OVLP	TYPE	R	Y	G	D	PWR	AUT	TGR	
1	1	V	.	.	.	+	A	R	X
2	2	V	.	.	.	+	A	Y	.
3	3	V	.	.	.	+	A	R	X
4	4	V	.	.	.	+	A	R	.
5	5	V	.	.	.	-	A	R	.
6	6	V	.	.	.	-	A	Y	X
7	8	0	.	.	.	-	A	R	.
8	8	V	.	.	.	-	A	R	X
9	1	O	.	.	.	+	A	R	X
10	2	O	.	.	.	+	A	R	X
11	3	O	.	.	.	-	A	R	.
12	4	O	.	.	.	-	A	Y	.
13	2	P	.	.	.	+	A	.	.
14	4	P	.	.	.	-	A	.	.
15	6	P	.	.	.	+	A	.	.
16	8	P	.	.	.	-	A	.	.

FLASHER CIRCUIT MODIFICATION DETAIL

In order to ensure that signals flash concurrently on the Same approach, make the following flasher circuit changes:

1. On rear of PDA - remove wire from Term. T2-4 and terminate on T2-2.
2. On rear of PDA - remove wire from Term. T2-5 and terminate on T2-3.
3. Remove flasher unit 2.

The changes listed above ties all phases and overlaps to flasher unit 1.

THIS ELECTRICAL DETAIL IS FOR
 THE SIGNAL DESIGN: 06-0155T3
 DESIGNED: March 2018
 SEALED: 03-29-2018
 REVISED: N/A

Temporary Design 3 - TMP Phase III
 Electrical Detail - Sheet 2 of 3

DOCUMENT NOT CONSIDERED FINAL
UNLESS ALL SIGNATURES COMPLETED

 Stantec Consulting Services Inc. 801 Jones Franklin Road-Suite 300 Raleigh, NC 27606 Tel. (919) 851-6866 Fax. (919) 851-7024 www.stantec.com License No. F-0672	ELECTRICAL AND PROGRAMMING DETAILS FOR: Prepared in the Offices of: 750 N. Greenfield Pkwy, Garner, NC 27529	US 401 Business (Raeford Road) at NC 59 (Hope Mills Road) / SR 1592 (Glensford Drive) Division 6 Cumberland County Fayetteville PLAN DATE: March 2018 REVIEWED BY: L Overn PREPARED BY: G B Spell REVIEWED BY:	SEAL 3/29/2018 DATE																
	REVISIONS <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>NO.</th> <th>DESCRIPTION</th> <th>INIT.</th> <th>DATE</th> </tr> </thead> <tbody> <tr><td> </td><td> </td><td> </td><td> </td></tr> <tr><td> </td><td> </td><td> </td><td> </td></tr> <tr><td> </td><td> </td><td> </td><td> </td></tr> </tbody> </table>		NO.	DESCRIPTION	INIT.	DATE													INVENTORY NO. 06-0155T3
NO.	DESCRIPTION	INIT.	DATE																

DATE: 03/29/2018 10:45:12 AM User: rfmancey

ECONOLITE ASC/3-2070 LOGIC PROCESSOR PROGRAMMING DETAIL

(program controller as shown)

- 1. From Main Menu select 1. CONFIGURATION
- 2. From CONFIGURATION Submenu select 8. LOGIC PROCESSOR

- 3. From LOGIC PROCESSOR Submenu select 2. LOGIC STATEMENTS

ENTER A "1" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 1 COPY FROM: 1 ACTIVE: M FALSE
IF   CTR PHASE TMING      1 IS ON
THEN SIG SET OLP GREEN   1 OFF
ELSE

```

LOGIC FOR TURNING FLASHING YELLOW ARROW OFF DURING PHASE 1 (HEADS 83,84)

ENTER A "2" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 2 COPY FROM: 2 ACTIVE: M FALSE
IF   VEH YELLOW ON PH    1 IS ON
THEN SIG SET OLP YELLOW  1 ON
ELSE

```

LOGIC FOR YELLOW ARROW CLEARANCE WHEN LEAVING PHASE 1 (HEADS 83,84)

ENTER A "3" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 3 COPY FROM: 3 ACTIVE: M FALSE
IF   CTR PHASE TIMING    1 IS ON
AND  VEH RED ON PHASE    1 IS ON
THEN SIG SET OLP RED     1 ON
ELSE

```

LOGIC FOR RED SIGNAL CLEARANCE WHEN LEAVING PHASE 1 (HEADS 83,84)

ENTER A "4" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 4 COPY FROM: 4 ACTIVE: M FALSE
IF   CTR PHASE TMING     5 IS ON
THEN SIG SET OLP GREEN   3 OFF
ELSE

```

LOGIC FOR TURNING FLASHING YELLOW ARROW OFF DURING PHASE 5 (HEADS 43,44)

ENTER A "5" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 5 COPY FROM: 5 ACTIVE: M FALSE
IF   VEH YELLOW ON PH    5 IS ON
THEN SIG SET OLP YELLOW  3 ON
ELSE

```

LOGIC FOR YELLOW ARROW CLEARANCE WHEN LEAVING PHASE 5 (HEADS 43,44)

ENTER A "6" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 6 COPY FROM: 6 ACTIVE: M FALSE
IF   CTR PHASE TIMING    5 IS ON
AND  VEH RED ON PHASE    5 IS ON
THEN SIG SET OLP RED     3 ON
ELSE

```

LOGIC FOR RED SIGNAL CLEARANCE WHEN LEAVING PHASE 5 (HEADS 43,44)

ENTER A "7" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 7 COPY FROM: 7 ACTIVE: M FALSE
IF   VEH OVERLAP         8 IS ON
THEN SIG SET OVLP GREEN  4 OFF
ELSE

```

LOGIC FOR TURNING FLASHING YELLOW ARROW OFF DURING OLH, WHICH HAS PARENT PHASE 3 (HEADS 23,24)

ENTER A "8" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 8 COPY FROM: 8 ACTIVE: M FALSE
IF   VEH OVERLAP YLW     8 IS ON
THEN SIG SET OLP YELLOW  4 ON
ELSE

```

LOGIC FOR YELLOW ARROW CLEARANCE WHEN LEAVING OLH, WHICH HAS PARENT PHASE 3 (HEADS 23,24)

ENTER A "9" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 9 COPY FROM: 9 ACTIVE: M FALSE
IF   VEH OVERLAP         8 IS ON
AND  VEH OVERLAP RED     8 IS ON
THEN SIG SET OLP RED     4 ON
ELSE

```

LOGIC FOR RED SIGNAL CLEARANCE WHEN LEAVING OLH, WHICH HAS PARENT PHASE 3 (HEADS 23,24)

END PROGRAMMING

- 4. From LOGIC PROCESSOR Submenu select 1. LOGIC STATEMENT CONTROL

ENABLE LOGIC PROCESSOR STATEMENTS 1-9 BY POSITIONING THE CURSOR OVER THE FIELDS SHOWN BELOW AND USING THE TOGGLE KEY TO ENABLE THEM.

LOGIC STATEMENT CONTROL	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5
LP 1-15	E	E	E	E	E	E	E	E	E	E
LP 16-30
LP 31-45
LP 46-60
LP 61-75
LP 76-90

END PROGRAMMING

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0155T3
 DESIGNED: March 2018
 SEALED: 03-29-2018
 REVISED: N/A

DATE: U:\Projects\Signal\Signal\Temp\Phase 3\U-4405\Sig.ele.06-0155T3.dgn User: rmluncey


Temporary Design 3 - TMP Phase III Electrical Detail - Sheet 3 of 3



Stantec Consulting Services Inc.
 801 Jones Franklin Road-Suite 300
 Raleigh, NC 27606
 Tel. (919) 851-6866
 Fax. (919) 851-7024
 www.stantec.com
 License No. F-0672

ELECTRICAL AND PROGRAMMING DETAILS FOR:

Prepared in the Offices of:



750 N. Greenfield Pkwy, Garner, NC 27529

US 401 Business (Raeford Road)
 at NC 59 (Hope Mills Road) /
 SR 1592 (Glensford Drive)


Division 6 Cumberland County Fayetteville

PLAN DATE: March 2018 REVIEWED BY: L Overn

PREPARED BY: G B Spell REVIEWED BY:

REVISIONS	INIT.	DATE


SEAL



LAURENCE E. OVERN
 ENGINEER
 045933
 3/29/2018
 DATE
 SIG. INVENTORY NO. 06-0155T3

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

PHASING DIAGRAM



PHASING DIAGRAM DETECTION LEGEND





TABLE OF OPERATION

SIGNAL FACE	PHASE							
	Ø 1 + 5	Ø 1 + 6	Ø 2 + 5	Ø 2 + 6	Ø 3 + 7	Ø 3 + 8	Ø 4 + 7	Ø 4 + 8
11,12	←	←	←	←	←	←	←	←
21,22,23	R	R	G	G	R	R	R	Y
24,25	R	R	←	←	←	←	R	R
31,32,33	←	←	←	←	←	←	←	←
41,42	R	R	R	R	R	R	G	G
43,44	←	←	←	←	←	←	←	←
51,52	←	←	←	←	←	←	←	←
61,62,63	R	G	R	G	R	R	R	Y
71,72	←	←	←	←	←	←	←	←
81,82	R	R	R	R	R	R	G	R
83,84	←	←	←	←	←	←	←	←
P21,P22	DW	DW	W	W	DW	DW	DW	DRK
P41,P42	DW	DW	DW	DW	DW	W	W	DRK
P61,P62	DW	W	DW	W	DW	DW	DW	DRK
P81,P82	DW	DW	DW	DW	W	DW	W	DRK

SIGNAL FACE I.D.




ASC/3 DETECTOR INSTALLATION CHART

LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PROGRAMMING							
					PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE	SYSTEM LOOP	NEW CARD
1A	6X40	0	2-4-2	X	1	Yes	-	-	-	S	-	X
1B	6X40	0	2-4-2	X	1	Yes	-	-	-	S	-	X
1C	6X40	0	2-4-2	X	1	Yes	-	15	-	S	-	X
1D	6X40	0	2-4-2	X	1	Yes	-	15	-	S	-	X
2A	6X6	300	6	X	2	Yes	-	-	X	N	-	X
2B	6X6	300	6	X	2	Yes	-	-	X	N	-	X
2C	6X6	300	6	X	2	Yes	-	-	X	N	-	X
3A	6X40	0	2-4-2	X	3	Yes	-	3	-	S	-	X
3B	6X40	0	2-4-2	X	3	Yes	-	-	-	S	-	X
3C	6X40	0	2-4-2	X	3	Yes	-	-	-	S	-	X
4A	6X40	0	2-4-2	X	4	Yes	-	-	-	S	-	X
4B	6X40	0	2-4-2	X	4	Yes	-	-	-	S	-	X
5A	6X40	0	2-4-2	X	5	Yes	-	-	-	S	-	X
5B	6X40	0	2-4-2	X	5	Yes	-	-	-	S	-	X
5C	6X40	0	2-4-2	X	5	Yes	-	15	-	S	-	X
5D	6X40	0	2-4-2	X	5	Yes	-	15	-	S	-	X
6A	6X6	300	6	X	6	Yes	-	-	X	N	-	X
6B	6X6	300	6	X	6	Yes	-	-	X	N	-	X
6C	6X6	300	6	X	6	Yes	-	-	X	N	-	X
7A	6X40	0	2-4-2	X	7	Yes	-	-	-	S	-	X
7B	6X40	0	2-4-2	X	7	Yes	-	-	-	S	-	X
8A	6X40	0	2-4-2	X	8	Yes	-	-	-	S	-	X
8B	6X40	0	2-4-2	X	8	Yes	-	-	-	S	-	X

8 Phase Fully Actuated Fayetteville Signal System

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated July 2018 and "Standard Specifications for Roads and Structures" dated July 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 1 and/or Phase 5 may be lagged.
- Phase 3 and/or Phase 7 may be lagged.
- Reposition existing signal heads 11, 12, 21, 22, 24, 25, 51, 52, 61, and 62.
- Set all detector units to presence mode.
- Omit "WALK" and flashing "DON'T WALK" with no pedestrian calls.
- Program pedestrian heads to countdown the flashing "DON'T WALK" time only.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Pedestrian pedestals are conceptual and shown for reference only. See 2018 NCDOT Roadway Standard Drawings 1705.04 Sheets 1-3 for push button location details.




ASC/3 TIMING CHART

FEATURE	PHASE							
	1	2	3	4	5	6	7	8
Min Green *	7	12	7	7	7	12	7	7
Walk *	-	7	-	7	-	7	-	7
Ped Clear	-	32	-	31	-	29	-	27
Veh. Extension *	2.0	6.0	2.0	2.0	2.0	6.0	2.0	2.0
Max 1 *	20	90	20	40	20	90	40	20
Yellow	3.0	4.5	3.0	3.8	3.0	4.5	3.0	4.6
Red Clear	4.4	2.8	4.2	3.1	4.1	2.8	3.9	2.4
Red Revert	-	-	-	-	-	-	-	-
Actuations B4 Add *	-	0	-	-	-	0	-	-
Seconds / Actuation *	-	1.5	-	-	-	1.5	-	-
Max Initial *	-	34	-	-	-	34	-	-
Time Before Reduction *	-	15	-	-	-	15	-	-
Time To Reduce *	-	30	-	-	-	30	-	-
Minimum Gap	-	3.0	-	-	-	3.0	-	-
Locking Detector	-	X	-	-	-	X	-	-
Recall Position	-	VEH. RECALL	-	-	-	VEH. RECALL	-	-
Dual Entry	-	-	-	-	-	-	-	-
Simultaneous Gap	X	X	X	X	X	X	X	X

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND



Signal Upgrade - Final Design

US 401 Business (Raeford Road) at NC 59 (Hope Mills Road) / SR 1592 (Glensford Drive)

Division 6 Cumberland County Fayetteville

PLAN DATE: March 2018 REVIEWED BY: E D Harris

PREPARED BY: B L Watson REVIEWED BY: B L Watson

REVISIONS	INIT.	DATE

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

3/29/2018

DATE: 3/29/2018

SIG. INVENTORY NO. 06-0155

3/29/2018 10:41:11 AM C:\Users\jgms\Documents\Signal Design\4405\sig_dsm\06-0155_Final.dgn
 User: jgms

ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select 2. CONTROLLER
2. From CONTROLLER Submenu select 2. VEHICLE OVERLAPS

OVERLAP A

Select TMG VEH OVLP [A] and 'OTHER/ECONOLITE'

```

TMG VEH OVLP...[A] TYPE: OTHER/ECONOLITE
 PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
 INCLUDED X . . . . . X . . . . .
 PROTECT . . . . .
 PED PRTC . . . . .
 NOT OVLP . . . . .
 FLSH GRN 1 . . . . . 1 . . . . .
 LAG X PH . . . . .
 LAG 2 PH . . . . .
 LAG GRN 0.0 YEL 0.0 RED 0.0 ADV GRN 0.0
    
```

Toggle Twice

OVERLAP C

Select TMG VEH OVLP [C] and 'OTHER/ECONOLITE'

```

TMG VEH OVLP...[C] TYPE: OTHER/ECONOLITE
 PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
 INCLUDED . . . X X . . . . .
 PROTECT . . . . .
 PED PRTC . . . . .
 NOT OVLP . . . . .
 FLSH GRN . . . 1 1 . . . . .
 LAG X PH . . . . .
 LAG 2 PH . . . . .
 LAG GRN 0.0 YEL 0.0 RED 0.0 ADV GRN 0.0
    
```

Toggle Once

OVERLAP D

Select TMG VEH OVLP [D] and 'OTHER/ECONOLITE'

```

TMG VEH OVLP...[D] TYPE: OTHER/ECONOLITE
 PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
 INCLUDED . X X . . . . .
 PROTECT . . . . .
 PED PRTC . . . . .
 NOT OVLP . . . . .
 FLSH GRN . 1 1 . . . . .
 LAG X PH . . . . .
 LAG 2 PH . . . . .
 LAG GRN 0.0 YEL 0.0 RED 0.0 ADV GRN 0.0
    
```

Toggle Twice

OVERLAP F

Select TMG VEH OVLP [F] and 'NORMAL'

```

TMG VEH OVLP...[F] TYPE: . . . . . NORMAL
 PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
 INCLUDED . . . . . X . . . . .
 LAG GRN 0.0 YEL 0.0 RED 0.0
    
```

Toggle Twice

OVERLAP H

Select TMG VEH OVLP [H] and 'NORMAL'

```

TMG VEH OVLP...[H] TYPE: . . . . . NORMAL
 PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
 INCLUDED . . X . . . . .
 LAG GRN 0.0 YEL 0.0 RED 0.0
    
```

END PROGRAMMING

ECONOLITE ASC/3-2070 LOAD SWITCH ASSIGNMENT DETAIL

(program controller as shown)

To assign load switch S10 as DLH, program LD SWITCH 7 as OVLP '8' TYPE '0' as shown below.

1. From Main Menu select 1. CONFIGURATION
2. From CONFIGURATION Submenu select 3. LOAD SW ASSIGN

LD SWITCH ASSIGN									
PHASE	DIMMING	---	FLASH	---					
/OVLP	TYPE	R	Y	G	D	PWR	AUT	TGR	
1	1	V	.	.	.	+	A	R	X
2	2	V	.	.	.	+	A	Y	.
3	3	V	.	.	.	+	A	R	X
4	4	V	.	.	.	+	A	R	.
5	5	V	.	.	.	-	A	R	.
6	6	V	.	.	.	-	A	Y	X
7	8	0	.	.	.	-	A	R	.
8	8	V	.	.	.	-	A	R	X
9	1	O	.	.	.	+	A	R	X
10	2	O	.	.	.	+	A	R	X
11	3	O	.	.	.	-	A	R	.
12	4	O	.	.	.	-	A	Y	.
13	2	P	.	.	.	+	A	.	.
14	4	P	.	.	.	-	A	.	.
15	6	P	.	.	.	+	A	.	.
16	8	P	.	.	.	-	A	.	.

FLASHER CIRCUIT MODIFICATION DETAIL

In order to ensure that signals flash concurrently on the Same approach, make the following flasher circuit changes:

1. On rear of PDA - remove wire from Term. T2-4 and terminate on T2-2.
2. On rear of PDA - remove wire from Term. T2-5 and terminate on T2-3.
3. Remove flasher unit 2.

The changes listed above ties all phases and overlaps to flasher unit 1.

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-0155
DESIGNED: March 2018
SEALED: 03-29-2018
REVISED: N/A

Final Design
Electrical Detail - Sheet 2 of 3

DOCUMENT NOT CONSIDERED FINAL
UNLESS ALL SIGNATURES COMPLETED

 Stantec Consulting Services Inc. 801 Jones Franklin Road-Suite 300 Raleigh, NC 27606 Tel. (919) 851-6866 Fax. (919) 851-7024 www.stantec.com License No. F-0672	Prepared in the Offices of: LAWRENCE E. OVERN ENGINEER 045933	US 401 Business (Raeford Road) at NC 59 (Hope Mills Road) / SR 1592 (Glensford Drive) Division 6 Cumberland County Fayetteville PLAN DATE: March 2018 REVIEWED BY: L Overn PREPARED BY: R M Muncey REVIEWED BY:	SEAL LAWRENCE E. OVERN ENGINEER 045933 3/29/2018																
	REVISIONS <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>NO.</th> <th>DESCRIPTION</th> <th>INIT.</th> <th>DATE</th> </tr> </thead> <tbody> <tr><td> </td><td> </td><td> </td><td> </td></tr> <tr><td> </td><td> </td><td> </td><td> </td></tr> <tr><td> </td><td> </td><td> </td><td> </td></tr> </tbody> </table>		NO.	DESCRIPTION	INIT.	DATE													DATE: 3/29/2018 INVENTORY NO. 06-0155
NO.	DESCRIPTION	INIT.	DATE																

DATE: 03/29/2018 10:45:12 AM User: rlmuncy

ECONOLITE ASC/3-2070 LOGIC PROCESSOR PROGRAMMING DETAIL

(program controller as shown)

- 1. From Main Menu select 1. CONFIGURATION
- 2. From CONFIGURATION Submenu select 8. LOGIC PROCESSOR

3. From LOGIC PROCESSOR Submenu select 2. LOGIC STATEMENTS

ENTER A "1" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 1 COPY FROM: 1 ACTIVE: M FALSE
IF   CTR PHASE TMING      1 IS ON
THEN SIG SET OLP GREEN    1 OFF
ELSE

```

LOGIC FOR TURNING FLASHING YELLOW ARROW OFF DURING PHASE 1 (HEADS 83,84)

ENTER A "2" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 2 COPY FROM: 2 ACTIVE: M FALSE
IF   VEH YELLOW ON PH     1 IS ON
THEN SIG SET OLP YELLOW   1 ON
ELSE

```

LOGIC FOR YELLOW ARROW CLEARANCE WHEN LEAVING PHASE 1 (HEADS 83,84)

ENTER A "3" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 3 COPY FROM: 3 ACTIVE: M FALSE
IF   CTR PHASE TIMING     1 IS ON
AND  VEH RED ON PHASE     1 IS ON
THEN SIG SET OLP RED      1 ON
ELSE

```

LOGIC FOR RED SIGNAL CLEARANCE WHEN LEAVING PHASE 1 (HEADS 83,84)

ENTER A "4" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 4 COPY FROM: 4 ACTIVE: M FALSE
IF   CTR PHASE TMING      5 IS ON
THEN SIG SET OLP GREEN    3 OFF
ELSE

```

LOGIC FOR TURNING FLASHING YELLOW ARROW OFF DURING PHASE 5 (HEADS 43,44)

ENTER A "5" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 5 COPY FROM: 5 ACTIVE: M FALSE
IF   VEH YELLOW ON PH     5 IS ON
THEN SIG SET OLP YELLOW   3 ON
ELSE

```

LOGIC FOR YELLOW ARROW CLEARANCE WHEN LEAVING PHASE 5 (HEADS 43,44)

ENTER A "6" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 6 COPY FROM: 6 ACTIVE: M FALSE
IF   CTR PHASE TIMING     5 IS ON
AND  VEH RED ON PHASE     5 IS ON
THEN SIG SET OLP RED      3 ON
ELSE

```

LOGIC FOR RED SIGNAL CLEARANCE WHEN LEAVING PHASE 5 (HEADS 43,44)

ENTER A "7" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 7 COPY FROM: 7 ACTIVE: M FALSE
IF   VEH OVERLAP          8 IS ON
THEN SIG SET OVLP GREEN   4 OFF
ELSE

```

LOGIC FOR TURNING FLASHING YELLOW ARROW OFF DURING OLH, WHICH HAS PARENT PHASE 3 (HEADS 24,25)

ENTER A "8" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 8 COPY FROM: 8 ACTIVE: M FALSE
IF   VEH OVERLAP YLW      8 IS ON
THEN SIG SET OLP YELLOW   4 ON
ELSE

```

LOGIC FOR YELLOW ARROW CLEARANCE WHEN LEAVING OLH, WHICH HAS PARENT PHASE 3 (HEADS 24,25)

ENTER A "9" IN THE LP# FIELD, PRESS 'ENTER', AND PROGRAM AS SHOWN.

```

LP#: 9 COPY FROM: 9 ACTIVE: M FALSE
IF   VEH OVERLAP          8 IS ON
AND  VEH OVERLAP RED     8 IS ON
THEN SIG SET OLP RED      4 ON
ELSE

```

LOGIC FOR RED SIGNAL CLEARANCE WHEN LEAVING OLH, WHICH HAS PARENT PHASE 3 (HEADS 24,25)

END PROGRAMMING

4. From LOGIC PROCESSOR Submenu select 1. LOGIC STATEMENT CONTROL

ENABLE LOGIC PROCESSOR STATEMENTS 1-9 BY POSITIONING THE CURSOR OVER THE FIELDS SHOWN BELOW AND USING THE TOGGLE KEY TO ENABLE THEM.

LOGIC STATEMENT CONTROL	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5
LP 1-15	E	E	E	E	E	E	E	E	E	E
LP 16-30
LP 31-45
LP 46-60
LP 61-75
LP 76-90

END PROGRAMMING

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0155
 DESIGNED: March 2018
 SEALED: 03-29-2018
 REVISED: N/A

DATE: 03/29/2018 11:45:11 AM User: rlmuncey


Final Design
Electrical Detail - Sheet 3 of 3



Stantec Consulting Services Inc.
 801 Jones Franklin Road-Suite 300
 Raleigh, NC 27606
 Tel. (919) 851-6866
 Fax. (919) 851-7024
 www.stantec.com
 License No. F-0672

ELECTRICAL AND PROGRAMMING DETAILS FOR:

Prepared in the Offices of:



750 N. Greenfield Pkwy, Garner, NC 27529

US 401 Business (Raeford Road)
 at NC 59 (Hope Mills Road) /
 SR 1592 (Glensford Drive)


Division 6 Cumberland County Fayetteville

PLAN DATE: March 2018 REVIEWED BY: L Overn

PREPARED BY: R M Muncey REVIEWED BY:

REVISIONS	INIT.	DATE

SEAL




3/29/2018

SIG. INVENTORY NO. 06-0155

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED


DEFAULT PHASING DIAGRAM



DEFAULT TABLE OF OPERATION

SIGNAL FACE	PHASE						FLASH
	01+5	01+6	02+5	02+6	04+8	04+8	
11	←	←	←	←	←	←	Y
21,22	R	R	G	G	R	Y	
41,42	R	R	R	R	G	R	
51	←	←	←	←	←	←	Y
61,62,63	R	G	R	G	R	Y	
81,82	R	R	R	R	G	R	

ALTERNATE PHASING DIAGRAM



ALTERNATE TABLE OF OPERATION

SIGNAL FACE	PHASE						FLASH
	01+5	01+6	02+5	02+6	04+8	04+8	
11	←	←	←	←	←	←	Y
21,22	R	R	G	G	R	Y	
41,42	R	R	R	R	G	R	
51	←	←	←	←	←	←	Y
61,62,63	R	G	R	G	R	Y	
81,82	R	R	R	R	G	R	

ASC/3 DETECTOR INSTALLATION CHART

LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PROGRAMMING							
					PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	TYPE	SYSTEM LOOP	NEW CARD
1A	6X40	0	*	-	1	Yes	-	15★	-	S	-	X
2A	6X6	300	*	-	2	Yes	-	-	-	N	-	X
2B	6X6	300	*	-	2	Yes	-	-	-	N	-	X
2C	6X40	0	*	-	2	Yes	2.0	5	-	G	-	X
2D	6X40	0	*	-	2	Yes	2.0	5	-	G	-	X
4A	6X40	0	*	-	4	Yes	-	3	-	S	-	X
4B	6X40	0	*	-	4	Yes	-	10	-	S	-	X
5A	6X40	0	*	-	5	Yes	-	15★	-	S	-	X
6A	6X6	300	*	-	6	Yes	-	-	-	N	-	X
6B	6X6	300	*	-	6	Yes	-	-	-	N	-	X
6C	6X6	300	*	-	6	Yes	-	-	-	N	-	X
6D	6X40	0	*	-	6	Yes	2.0	5	-	G	-	X
6E	6X40	0	*	-	6	Yes	2.0	5	-	G	-	X
6F	6X40	0	*	-	6	Yes	2.0	5	-	G	-	X
8A	6X40	0	*	-	8	Yes	-	3	-	S	-	X
8B	6X40	0	*	-	8	Yes	-	10	-	S	-	X

5 Phase Fully Actuated Fayetteville Signal System



NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer. Phase 1 and/or phase 5 may be lagged.
- Set all detector units to presence mode.
- Locate new cabinet foundation so as not to obstruct sight distance of vehicles turning right on red. Relocate existing cabinet and controller onto new foundation.
- The Division (City) Traffic Engineer will determine the hours of use for each phasing plan.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Field adjust temporary poles as needed.

PHASING DIAGRAM DETECTION LEGEND

- DETECTED MOVEMENT
- ← UNDETECTED MOVEMENT (OVERLAP)
- UNSIGNALIZED MOVEMENT
- ↔ PEDESTRIAN MOVEMENT

SIGNAL FACE I.D.



ASC/3 TIMING CHART

FEATURE	PHASE					
	1	2	4	5	6	8
Min Green *	7	12	7	7	12	7
Walk *	-	-	-	-	-	-
Ped Clear	-	-	-	-	-	-
Veh. Extension *	2.0	6.0	2.0	2.0	6.0	2.0
Max 1 *	15	90	25	15	90	25
Yellow	3.0	4.5	3.2	3.0	4.5	3.2
Red Clear	2.3	1.1	2.5	2.6	1.1	2.5
Red Revert	-	-	-	-	-	-
Actuations B4 Add *	-	-	-	-	-	-
Seconds / Actuation *	-	-	-	-	-	-
Max Initial *	-	-	-	-	-	-
Time Before Reduction *	-	15	-	-	15	-
Time To Reduce *	-	45	-	-	45	-
Minimum Gap	-	3.0	-	-	3.0	-
Locking Detector	-	-	-	-	-	-
Recall Position	-	VEH. RECALL	-	-	VEH. RECALL	-
Dual Entry	-	-	X	-	-	X
Simultaneous Gap	X	X	X	X	X	X

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND

- | PROPOSED | EXISTING |
|--|-----------|
| ○ → Traffic Signal Head | ● → N/A |
| ○ → Modified Signal Head | ○ → N/A |
| ⊥ Sign | ⊥ N/A |
| ⊥ Pedestrian Signal Head With Push Button & Sign | ⊥ N/A |
| ○ → Signal Pole with Guy | ○ → N/A |
| ○ → Signal Pole with Sidewalk Guy | ○ → N/A |
| ⊠ Inductive Loop Detector | ⊠ N/A |
| □ Controller & Cabinet | □ N/A |
| □ Junction Box | □ N/A |
| --- 2-in Underground Conduit | --- N/A |
| → Right of Way | → N/A |
| → Directional Arrow | → N/A |
| ▬ Video Detection Area | ▬ N/A |
| ▬ Construction Zone | ▬ N/A |
| ● ● ● Drums | ● ● ● N/A |

Signal Upgrade Temporary Design 1 - TMP Phase I

<p>Stantec Consulting Services Inc. 801 Jones Franklin Road-Suite 300 Raleigh, NC 27606 Tel. (919) 851-6866 Fax. (919) 851-7024 www.stantec.com License No. F-0672</p>		<p>US 401 Business (Raeford Road) at Brighton Road/ Fred Anderson Nissan</p>	
		<p>Division 6 Cumberland County Fayetteville</p> <p>PLAN DATE: March 2018 REVIEWED BY: E D Harris</p> <p>PREPARED BY: R M Muncey REVIEWED BY: B L Watson</p>	<p>3/29/2018</p> <p>DATE</p>

3/29/2018 10:45:00 AM
 User: rfmuncey
 Path: \\fs1\projects\2018\03\Signal\Design\Temporary_Signal_Design\Phase 1\U-4405.sig.dwg
 User: rfmuncey


DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

E. D. Harris
 3/29/2018
 DATE
 SIG. INVENTORY NO. 06-032811

ECONOLITE ASC/3-2070 OVERLAP PROGRAMMING DETAIL

(program controller as shown)

1. From Main Menu select 2. CONTROLLER
2. From CONTROLLER Submenu select 2. VEHICLE OVERLAPS



ALTERNATE PHASING ACTIVATION DETAIL

TO RUN ALT. PHASING DURING FREE RUN - PROGRAM CHANGES (SHOWN BELOW) IN A TIME BASED ACTION PLAN. SCHEDULE A DAY PLAN THAT INCLUDES THE ACTION PLAN PROGRAMMED TO SELECT VEH DET PLAN 2 AND ENABLE SF BITS 1, and 5.

TO RUN ALT. PHASING DURING COORDINATION - SELECT THE TIME BASED ACTION PLAN THAT IS PROGRAMMED TO SELECT VEH DET PLAN 2 AND ENABLE SF BITS 1, and 5.

PHASING	VEH DET PLAN	SF BITS ENABLED
ACTIONS REQUIRED TO RUN <u>DEFAULT PHASING</u>	1	NONE
ACTIONS REQUIRED TO RUN <u>ALTERNATE PHASING</u>	2	1, 5

IMPORTANT: IF ALT. PHASING IS USED DURING FREE RUN AND COORDINATION, DO NOT OPERATE TIME OF DAY EVENTS CONCURRENTLY WITH COORDINATION PLAN EVENTS IN THE EVENT SCHEDULER. (EX. FREE RUN EVENT SHOULD END BEFORE COORDINATION PLAN EVENT STARTS AND VICE-VERSA).

ALTERNATE PHASING CHANGE SUMMARY

THE FOLLOWING IS A SUMMARY OF WHAT TAKES PLACE WHEN SF BITS 1, AND 5 AND VEH DET PLAN 2 ACTIVATE TO CALL THE "ALTERNATE PHASING":

- SF BITS 1,5: Modifies overlap parent phases for heads 11, and 51 to run protected turns only.
- VEH DET PLAN 2: Disables phase 6 call on loop 1A and reduces delay time for phase 1 call on loop 1A to 3 seconds.

Disables phase 2 call on loop 5A and reduces delay time for phase 5 call on loop 5A to 3 seconds.

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-0328T1
DESIGNED: March 2018
SEALED: 03-29-2018
REVISED: N/A

Temporary Design 1 - TMP Phase I
Electrical Detail - Sheet 2 of 3

DOCUMENT NOT CONSIDERED FINAL
UNLESS ALL SIGNATURES COMPLETED

 Stantec Consulting Services Inc. 801 Jones Franklin Road-Suite 300 Raleigh, NC 27606 Tel. (919) 851-6866 Fax. (919) 851-7024 www.stantec.com License No. F-0672	ELECTRICAL AND PROGRAMMING DETAILS FOR: Prepared in the Offices of: STATE OF NORTH CAROLINA DEPARTMENT OF TRANSPORTATION DIVISION OF SIGNALS MANAGEMENT 750 N. Greenfield Pkwy, Garner, NC 27529	US 401 Business (Raeford Road) at Brighton Road/ Fred Anderson Nissan Division 6 Cumberland County Fayetteville	SEAL NORTH CAROLINA PROFESSIONAL ENGINEER SEAL 045933 LAWRENCE E. OVERN
	PLAN DATE: March 2018 REVIEWED BY: L Overn PREPARED BY: R M Muncey REVIEWED BY:		REVISIONS INIT. DATE _____ _____ _____

DATE: 3/29/2018
SIG. INVENTORY NO. 06-0328T1

ECONOLITE ASC/3-2070 VEHICLE DETECTOR SETUP

PROGRAMMING DETAIL FOR ALTERNATE PHASING

IMPORTANT!

LOOPS 1A, 5A

(program controller as shown)

Program detectors per the input file connection and programming chart shown on sheet 1 before proceeding.

- From Main Menu select **8. UTILITIES**
- From UTILITIES Submenu select **1. COPY/CLEAR**
- Copy from DETECTOR PLAN "1" to DETECTOR PLAN "2".

```

COPY / CLEAR UTILITY
FROM          TO
PHASE TIMING... > PHASE TIMING...
TIMING PLAN... > TIMING PLAN...
PH DET OPT PLAN. > PH DET OPT PLAN.
DETECTOR PLAN... 1 > DETECTOR PLAN... 2
TOGGLE TO SELECT A "FROM" AND A "TO"
THEN PRESS ENTER
  
```

- From Main Menu select **6. DETECTORS**
- From DETECTOR Submenu select **2. VEHICLE DETECTOR SETUP**
- Place cursor in VEH DET PLAN [] position and enter "2".

- Place cursor in VEH DETECTOR [] position and enter "1".
- Set delay time to "3.0".

```

VEH DETECTOR [ 1]  VEH DET PLAN [ 2]
TYPE: S-STANDARD
TS2 DETECTOR..... ECPI LOG..... NO
DET PH - 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
1 1
EXTEND TIME... 0.0 DELAY TIME... 3.0
USE ADDED INITIAL . CROSS SWITCH PH.. 0
LOCK IN..... NONE NTCIP VOL . OR OCC .
PMT QUEUE DELAY. NO
  
```

- Place cursor in VEH DETECTOR [] position and enter "26".
- Set assigned phase to "0".

```

VEH DETECTOR [26]  VEH DET PLAN [ 2]
TYPE: G-GREEN EXTENSION/DELAY
TS2 DETECTOR..... ECPI LOG..... NO
DET PH - 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
26 0
EXTEND TIME... 0.0 DELAY TIME... 3.0
USE ADDED INITIAL . CROSS SWITCH PH.. 0
LOCK IN..... NONE NTCIP VOL . OR OCC .
PMT QUEUE DELAY. NO
  
```

- Place cursor in VEH DETECTOR [] position and enter "5".
- Set delay time to "3.0".

```

VEH DETECTOR [ 5]  VEH DET PLAN [ 2]
TYPE: S-STANDARD
TS2 DETECTOR..... ECPI LOG..... NO
DET PH - 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
5 5
EXTEND TIME... 0.0 DELAY TIME... 3.0
USE ADDED INITIAL . CROSS SWITCH PH.. 0
LOCK IN..... NONE NTCIP VOL . OR OCC .
PMT QUEUE DELAY. NO
  
```

- Place cursor in VEH DETECTOR [] position and enter "22".
- Set assigned phase to "0".

```

VEH DETECTOR [22]  VEH DET PLAN [ 2]
TYPE: G-GREEN EXTENSION/DELAY
TS2 DETECTOR..... ECPI LOG..... NO
DET PH - 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
22 0
EXTEND TIME... 0.0 DELAY TIME... 3.0
USE ADDED INITIAL . CROSS SWITCH PH.. 0
LOCK IN..... NONE NTCIP VOL . OR OCC .
PMT QUEUE DELAY. NO
  
```

END PROGRAMMING

ECONOLITE ASC/3-2070 ACTION PLAN

PROGRAMMING DETAIL

- From Main Menu select **5. TIME BASE**
- From TIME BASE Submenu select **2. ACTION PLAN**

```


ACTION PLAN... [ 1]
PATTERN.....AUTO  SYS OVERRIDE.... NO
TIMING PLAN..... 0  SEQUENCE..... 0
VEH DETECTOR PLAN.. 2  DET LOG.....NONE
FLASH..... --  RED REST..... NO
VEH DET DIAG PLN... 0  PED DET DIAG PLN..0
DIMMING ENABLE.. NO  PRIORITY RETURN. NO
PED PR RETURN.. NO  QUEUE DELAY.... NO
PMT COND DELAY  NO
  PHASE  1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
PED RCL . . . . .
WALK 2 . . . . .
VEX 2 . . . . .
VEH RCL . . . . .
MAX RCL . . . . .
MAX 2 . . . . .
  PHASE  1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
MAX 3 . . . . .
CS INH . . . . .
OMIT . . . . .
SPC FCT X . . . X . . . (1-8)
AUX FCT . . . (1-3)
  1 2 3 4 5 6 7 8 9 0 1 2 3 4 5
LP 1-15 . . . . .
LP 16-30 . . . . .
LP 31-45 . . . . .
LP 46-60 . . . . .
LP 61-75 . . . . .
LP 76-90 . . . . .
LP 91-100 . . . . .
  
```

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0328T1
 DESIGNED: March 2018
 SEALED: 03-29-2018
 REVISED: N/A

Temporary Design 1 - TMP Phase I
Electrical Detail - Sheet 3 of 3


DATE: U:\Traffic\Signal\Signal\Temp\Signal\Phase 1\U-4405.sig.ele.06-0328T1.dgn User: rlmuncy

<p>Stantec Consulting Services Inc. 801 Jones Franklin Road-Suite 300 Raleigh, NC 27606 Tel. (919) 851-6866 Fax. (919) 851-7024 www.stantec.com License No. F-0672</p>		ELECTRICAL AND PROGRAMMING DETAILS FOR:		US 401 Business (Raeford Road) at Brighton Road/ Fred Anderson Nissan		SEAL NORTH CAROLINA PROFESSIONAL ENGINEER LAWRENCE E. OVERN 045933 3/29/2018	
		Prepared in the Offices of:		Division 6 Cumberland County Fayetteville			
PLAN DATE: March 2018		REVIEWED BY: L Overn		PREPARED BY: R M Muncey		REVIEWED BY:	
REVISIONS		INIT.		DATE		DATE	
750 N. Greenfield Pkwy, Garner, NC 27529		DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED		SIG. INVENTORY NO. 06-0328T1		DATE	



DEFAULT TABLE OF OPERATION

SIGNAL FACE	PHASE						FLASH
	01+5	01+6	02+5	02+6	04+8	04+8	
11	←	←	←	←	←	←	Y
21,22,23	R	R	G	G	R	Y	
41,42	R	R	R	R	G	R	
51	←	←	←	←	←	←	Y
61,62	R	G	R	G	R	Y	
81,82	R	R	R	R	G	R	



ALTERNATE TABLE OF OPERATION

SIGNAL FACE	PHASE						FLASH
	01+5	01+6	02+5	02+6	04+8	04+8	
11	←	←	←	←	←	←	Y
21,22,23	R	R	G	G	R	Y	
41,42	R	R	R	R	G	R	
51	←	←	←	←	←	←	Y
61,62	R	G	R	G	R	Y	
81,82	R	R	R	R	G	R	




ASC/3 DETECTOR INSTALLATION CHART

LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PROGRAMMING						
					PHASE	CALLING	EXTEND TIME	DELAY TIME	USE ADDED INITIAL	SYSTEM LOOP TYPE	NEW CARD
1A	6X40	0	*	-	1	Yes	-	15★	-	S	-
2A	6X6	300	*	-	2	Yes	-	-	-	N	-
2B	6X6	300	*	-	2	Yes	-	-	-	N	-
2C	6X6	300	*	-	2	Yes	-	-	-	N	-
2D	6X40	0	*	-	2	Yes	2.0	5	-	G	-
2E	6X40	0	*	-	2	Yes	2.0	5	-	G	-
2F	6X40	0	*	-	2	Yes	2.0	5	-	G	-
4A	6X40	0	*	-	4	Yes	-	3	-	S	-
4B	6X40	0	*	-	4	Yes	-	10	-	S	-
5A	6X40	0	*	-	5	Yes	-	15★	-	S	-
6A	6X6	300	*	-	6	Yes	-	-	-	N	-
6B	6X6	300	*	-	6	Yes	-	-	-	N	-
6C	6X40	0	*	-	6	Yes	2.0	5	-	G	-
6D	6X40	0	*	-	6	Yes	2.0	5	-	G	-
8A	6X40	0	*	-	8	Yes	-	3	-	S	-
8B	6X40	0	*	-	8	Yes	-	10	-	S	-

5 Phase Fully Actuated Fayetteville Signal System

NOTES

1. Refer to "Roadway Standard Drawings NCDOT" dated January 2018 and "Standard Specifications for Roads and Structures" dated January 2018.
2. Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
3. Phase 1 and/or phase 5 may be lagged.
4. Set all detector units to presence mode.
5. The Division (City) Traffic Engineer will determine the hours of use for each phasing plan.
6. Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.




* Video Detection Area. Camera locations should be confirmed in the field by the contractor in order to provide detection of the areas indicated.
 # Disable Phase(s) calling during Alternate Phasing Operation.
 ★ Reduce delay to 3 secs during Alternate Phasing Operation.

ASC/3 TIMING CHART

FEATURE	PHASE					
	1	2	4	5	6	8
Min Green *	7	12	7	7	12	7
Walk *	-	-	-	-	-	-
Ped Clear	-	-	-	-	-	-
Veh. Extension *	2.0	6.0	2.0	2.0	6.0	2.0
Max 1 *	15	90	25	15	90	25
Yellow	3.0	4.5	3.2	3.0	4.5	3.2
Red Clear	2.6	1.1	2.9	2.4	1.1	2.2
Red Revert	-	-	-	-	-	-
Actuations B4 Add *	-	-	-	-	-	-
Seconds / Actuation *	-	-	-	-	-	-
Max Initial *	-	-	-	-	-	-
Time Before Reduction *	-	15	-	-	15	-
Time To Reduce *	-	45	-	-	45	-
Minimum Gap	-	3.0	-	-	3.0	-
Locking Detector	-	-	-	-	-	-
Recall Position	-	VEH. RECALL	-	-	VEH. RECALL	-
Dual Entry	-	-	X	-	-	X
Simultaneous Gap	X	X	X	X	X	X

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.



Signal Upgrade Temporary Design 2 - TMP Phase II

Stantec
 Stantec Consulting Services Inc.
 801 Jones Franklin Road-Suite 300
 Raleigh, NC 27606
 Tel. (919) 851-6866
 Fax. (919) 851-7024
 www.stantec.com
 License No. F-0672

Prepared For the Offices of:

 750 N. Greenfield Pkwy, Garner, NC 27526
 SCALE: 0 40
 1" = 40'

US 401 Business (Raeford Road) at Brighton Road/ Fred Anderson Nissan
 Division 6 Cumberland County Fayetteville
 PLAN DATE: March 2018 REVIEWED BY: E D Harris
 PREPARED BY: R M Muncey REVIEWED BY: B L Watson

Professional Engineer Seal
 SEAL 29449
 B L WATSON
 3/29/2018
 SIG. INVENTORY NO. 06-032812

3/29/2018 10:45:11 AM
 User: rlmuncey
 C:\Users\rlmuncey\Documents\Signal Design\Temporary_Signal_Design\Phase_2\U-4405_Sig.dwg
 User: rlmuncey