

# INDEX OF X-SECTION SHEETS

INDEX OF X-SECTION SHEETS	X-1
EARTHWORK QUANTITIES	X-2 THRU X-3
-11-	X-4 THRU X-27
-12-	X-28 THRU X-96
Y1	X-97
Y2	X-98
Y3	X-99
Y4	X-100
Y5	X-101 THRU X-103
Y6	X-104
Y7	X-105
Y8	X-106
Y9	X-107, X-108
Y10	X-109, X-110
Y11	X-111, X-112
Y11A	X-113, X-114
Y12	X-115, X-116
Y13	X-117 THRU X-121
DR1	X-122, X-123
DR2	X-124, X-125
DR3	X-126 THRU X-128
DR4	X-129
DR5	X-130
DFT1	X-131 THRU X-134
DFT2	X-135 THRU X-139