


EDI MODEL 2010ECL CONFLICT MONITOR

PROGRAMMING DETAIL



- NOTES:
- CARD IS PROVIDED WITH ALL DIODE JUMPERS IN PLACE. REMOVAL OF ANY JUMPER ALLOWS ITS CHANNELS TO RUN CONCURRENTLY.
 - MAKE SURE JUMPERS SEL1-SEL5 ARE PRESENT ON THE MONITOR BOARD.

NOTES

- TO PREVENT "FLASH-CONFLICT" PROBLEMS, INSERT RED FLASH PROGRAM BLOCKS FOR ALL UNUSED VEHICLE LOAD SWITCHES IN OUTPUT FILE. THE INSTALLER SHALL VERIFY THAT SIGNAL HEADS FLASH IN ACCORDANCE WITH THE SIGNAL PLANS.
- ENSURE THAT RED ENABLE IS ACTIVE AT ALL TIMES DURING NORMAL OPERATION. TO PREVENT RED FAILURES ON UNUSED MONITOR CHANNELS, TIE UNUSED RED MONITOR INPUTS 1,3,7, 8,9,10,11,12,13,14,15 & 16 TO LOAD SWITCH AC+ PER THE CABINET MANUFACTURER'S INSTRUCTIONS.
- THE CONTROLLER SHALL BE PROGRAMMED TO START UP IN PHASES 2 AND 6 GREEN.
- POWER-UP FLASH TIME SHALL BE SET TO 10 SECONDS AND IMPLEMENTED WITHIN THE CONTROLLER PROGRAMMING.
- ENABLE SIMULTANEOUS GAP-OUT FEATURE, ON CONTROLLER UNIT, FOR ALL PHASES.
- THE CABINET AND CONTROLLER ARE A PART OF THE DURHAM SIGNAL SYSTEM.

FIELD CONNECTION HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S2P	S3	S4	S4P	S5	S6	S6P	S7	S8	S8P
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED
SIGNAL HEAD NO.	NU	21,22	NU	NU	41,42	NU	21	61,62	NU	NU	NU	NU
GREEN		130			103			136				
YELLOW		129			102			135				
RED		128			101		*	134				
RED ARROW												
YELLOW ARROW							132					
GREEN ARROW							133					


NU = NOT USED
 * DENOTES INSTALL LOAD RESISTOR. SEE LOAD RESISTOR INSTALLATION DETAIL THIS PAGE.

EQUIPMENT INFORMATION

CONTROLLER.....CONTRACTOR SUPPLIED 170E
 CABINET.....CONTRACTOR SUPPLIED 332
 SOFTWARE.....BI TRANS 233NC 2.9
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...12
 LOAD SWITCHES USED.....S2,S4,S5,S6
 PHASES USED.....2,4,5,6
 OVERLAPS.....NONE

INPUT FILE POSITION LAYOUT

(front view)



EX.: 1A, 2A, ETC. = LOOP NO.'S
 FS = FLASH SENSE
 ST = STOP TIME


INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT	DETECTOR NO.	PIN NO.	ATTRIBUTES	NEMA PHASE
2A	TB2-5,6	I2U	1	39	5 7	2
4A	TB4-9,10	I6U	2	41	5 7	4
4B	TB4-11,12	I6L	3	45	5 7	4
4C	TB6-1,2	I7U	4	65	5 7	4
5A	TB3-1,2	J1U	5	55	5 7	2
6A	TB3-5,6	J2U	7	40	5 7	6
6B	TB3-7,8	J2L	8	44	5 7	6

NOTE: PROGRAM DETECTOR DELAY AND CARRYOVER TIMES AS SPECIFIED ON SIGNAL DESIGN PLANS.

- INPUT FILE POSITION LEGEND: J2L
 FILE J
 SLOT 2
 LOWER
- DETECTOR ATTRIBUTES LEGEND:
 1-FULL TIME DELAY
 2-PED CALL
 3-RESERVED
 4-COUNTING
 5-EXTENSION
 6-TYPE 3
 7-CALLING
 8-ALTERNATE

LOAD RESISTOR INSTALLATION DETAIL



NOTE: THE PURPOSE OF THIS RESISTOR IS TO LOAD THE CHANNEL RED MONITOR INPUT IN ORDER FOR THE SIGNAL SEQUENCE MONITOR TO USE THE FULL SIGNAL SEQUENCE MONITORING CAPABILITY ON CHANNELS THAT DO NOT USE THE RED DISPLAY IN THE FIELD.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 05-2251T AND 05-2251
 DESIGNED: 08-15-04
 SEALED: 09-03-04
 REVISED:

SIGNAL UPGRADE - TEMPORARY AND FINAL

ELECTRICAL AND PROGRAMMING DETAILS FOR:

Prepared in the Offices of:
 NORTH CAROLINA PROFESSIONAL ENGINEERS AND SURVEYORS
 STATE OF NORTH CAROLINA
 122 N. McDowell St., Raleigh, NC 27603

US 15-501 BYP NB RAMPS AT NC 751 (CAMERON BOULEVARD)

DIVISION 05 DURHAM COUNTY DURHAM, NC

PLAN DATE: AUGUST 2004 REVIEWED BY: *R. H. Brown*

PREPARED BY: JAMES PETERSON REVIEWED BY:

REVISIONS: _____ INIT. DATE

Signature: *George C. Brown* 10/7/04
 SEAL: 022013
 SIGNATURE DATE

SIG. INVENTORY NO. 05-2251