

Appendix F
High Level Bent Calculations

TABLE OF CONTENTS

1.0 High Level Bent Model #129	F.1
1.1 Loads	F.1-1
1.2 Model	F.1-9
1.3 Columns	F.1-18
1.4 Pier Cap	F.1-82
1.5 Pile Cap	F.1-88
2.0 High Level Bent Model #137	F.2
2.1 Loads	F.2-1
2.2 Model	F.2-8
2.3 Columns	F.2-15
2.4 Pier Cap/Struts.....	F.2-111
2.5 Pile Cap	F.2-123
3.0 High Level Bent Model #142	F.3
3.1 Loads	F.3-1
3.2 Model	F.3-8
3.3 Columns	F.3-17
3.4 Pier Cap/Struts.....	F.3-145
3.5 Pile Cap	F.3-163
4.0 High Level Bent Model #143	F.4
4.1 Loads	F.4-1
4.2 Model	F.4-10
4.3 Columns	F.4-20
4.4 Pier Cap/Struts.....	F.4-148
4.5 Pile Cap	F.4-166
5.0 High Level Bent Model #145	F.5
5.1 Loads	F.5-1
5.2 Model	F.5-8
5.3 Columns	F.5-17
5.4 Pier Cap/Struts.....	F.5-145
5.5 Pile Cap	F.5-163
6.0 High Level Bent Model #160	F.6
6.1 Loads	F.6-1
6.2 Model	F.6-8
6.3 Columns	F.6-14
6.4 Pier Cap	F.6-78
6.5 Pile Cap	F.6-84