



STATE OF NORTH CAROLINA
DIVISION OF HIGHWAYS


HARNETT COUNTY

**LOCATION: US 401 IN LILLINGTON FROM NORTH
OF MATTHEWS RD (SR 1436) TO NC 210**

TYPE OF WORK: SIGNALS



Project: R-5185



Refer to "Roadway Standard Drawings NCDOT" dated July 2006 and "Standard Specifications for Roads and Structures" dated July 2006.

Sheet #	Reference #	Index of Plans Location/Description
Sig. 1	N/A	Title Sheet
Sig. 2-4	06-1315	US 401 at Brightwater/McKinney Pkwy
Sig. 5-16	06-1317	US 401 at Pine State Street
Sig. 17-26	06-0129	US 401-421/NC 27-210 (N Main Street) at US 401/US 421-NC 27
Sig. 27-29	N/A	Wireless Communication Plans
Sig. 30-35	N/A	Metal Pole Plans
Sig. 36-38	N/A	Loop Details

INTELLIGENT TRANSPORTATION AND SIGNALS UNIT

Contacts:

Jason P. Galloway, PE - East Region Signals Project Engineer
George Brown, PE - Signal Equipment Design Engineer
Greg Fuller, PE - State ITS & Signals Engineer


Prepared in the Office of:
**DIVISION OF HIGHWAYS
TRANSPORTATION MOBILITY AND SAFETY
DIVISION**

750 N. Greenfield Parkway, Garner, NC 27529

09-MAR-2011 14:49
D:\Prof\Fic\Signals\Design\Signals\A-R-5185\Proj\RES\Proj\RES\sig_teh.dgn

EDI MODEL 2010ECL-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Make sure jumpers SEL2-SEL5 are present on the monitor board.


INPUT FILE POSITION LAYOUT

(front view)

FILE "I"	1	2	3	4	5	6	7	8	9	10	11	12	13	14
	∅ 1 1A	∅ 1 1B	S TOP	S TOP	S TOP	∅ 4 4A	S TOP	S TOP	SYS. DET. S15	S TOP	S TOP	∅ 2 PED ISOLATOR	∅ 6 PED ISOLATOR	FS
	NOT USED	∅ 2 2A,2B	Y TOP	Y TOP	Y TOP	NOT USED	Y TOP	Y TOP	SYS. DET. S16	Y TOP	Y TOP	∅ 4 PED ISOLATOR	∅ 8 PED ISOLATOR	ST
FILE "J"														
	S TOP	∅ 5 5A	∅ 5 5C	W TOP	S TOP	∅ 7 7A	∅ 8 8A	S TOP	S TOP	S TOP	S TOP	S TOP	S TOP	S TOP
	Y TOP	∅ 5 5B	∅ 6 6A,6B	Y TOP	Y TOP	∅ 7 7B	∅ 8 8B	Y TOP	Y TOP	Y TOP	Y TOP	Y TOP	Y TOP	Y TOP

EX.: 1A, 2A, ETC. = LOOP NO.'S
 FS = FLASH SENSE
 ST = STOP TIME

LOAD RESISTOR INSTALLATION DETAIL



NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Ensure that Red Enable is active at all times during normal operation. To prevent Red Failures on unused monitor channels, tie unused red monitor inputs 3,11, 12,13,14,15 & 16 to load switch AC+ per the cabinet manufacturer's instructions.
- Program phase 4 for Dual Entry.
- Enable Simultaneous Gap-Out for all phases.
- Program phases 2 and 6 for Start Up In Green.
- Program phases 2, 4, 6 and 8 for 'STARTUP PED CALL'.
- Program phases 2 and 6 for Yellow Flash, and overlaps 1 and 2 as Wag Overlaps.
- The cabinet and controller are part of the US 401-421/ NC 27-210 Closed Loop System.


EQUIPMENT INFORMATION

CONTROLLER.....2070L
 CABINET.....332 W/ AUX
 SOFTWARE.....ECONOLITE OASIS
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S2P,S4,S4P,S5,S6,S6P,S7,S8,S8P,S9,S10
 PHASES USED.....1,2,2 PED,4,4 PED,5,6,6 PED,7,8,8 PED
 OVERLAP "A".....1+2
 OVERLAP "B".....4
 OVERLAP "C".....NOT USED
 OVERLAP "D".....NOT USED

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
1A ¹	TB2-1,2	I1U	56	18	1	1	Y	Y			15
		J4U	48	10	26	6	Y	Y			
1B	TB2-5,6	I2U	39	1	2	1	Y	Y			15
2A,2B	TB2-7,8	I2L	43	5	12	2	Y	Y			
4A	TB4-9,10	I6U	41	3	4	4	Y	Y			
5A	TB3-5,6	J2U	40	2	6	5	Y	Y			
5B	TB3-7,8	J2L	44	6	16	5	Y	Y			
5C	TB3-9,10	J3U	64	26	36	5	Y	Y			15
6A,6B	TB3-11,12	J3L	77	39	46	6	Y	Y			
7A	TB5-9,10	J6U	42	4	8	7	Y	Y			3
7B	TB5-11,12	J6L	46	8	18	7	Y	Y			
8A	TB7-1,2	J7U	66	28	38	8	Y	Y			3
8B	TB7-3,4	J7L	79	41	48	8	Y	Y			
* S15	TB6-9,10	I9U	60	22	11	SYS					
* S16	TB6-11,12	I9L	62	24	13	SYS					
PED PUSH BUTTONS											
P21,P22	TB8-4,6	I12U	67	29	PED 2	2 PED					
P41,P42	TB8-5,6	I12L	69	31	PED 4	4 PED					
P61,P62	TB8-7,9	I13U	68	30	PED 6	6 PED					
P81,P82	TB8-8,9	I13L	70	32	PED 8	8 PED					

¹Add jumper from I1-W to J4-W, on rear of input file.
 * System detector only. Remove the vehicle phase assigned to this detector in the default programming.




SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S2P	S3	S4	S4P	S5	S6	S6P	S7	S8	S8P	S9	S10	S11	S12	S13	S14				
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE				
SIGNAL HEAD NO.	11★	83	21,22	P21, P22	NU	41,42	P41, P42	42	51,52	61,62	P61, P62	62	71,72	82,83	P81, P82	11★	81★	NU	NU	NU	NU	
RED	*	128			101				134					107								
YELLOW		129			102				135					108								
GREEN		130			103				136					109								
RED ARROW									131				122						A121	A124		
YELLOW ARROW		126							132	132			123	123					A122	A125		
FLASHING YELLOW ARROW																			A123	A126		
GREEN ARROW	127	127							133	133			124	124								
Hand									113													
Person									115													

NU = Not Used
 * Denotes install load resistor. See load resistor installation detail this sheet.
 ★ See pictorial of head wiring in detail below.

3 & 4 SECTION FYA SIGNAL WIRING DETAIL

(wire signal heads as shown)



NOTE

The sequence display for signal head 11 requires special logic programming. See sheet 2 of 2 for programming instructions.

COUNTDOWN PEDESTRIAN SIGNAL OPERATION

Countdown Ped Signals are required to display timing only during Ped Clearance Interval. Consult Ped Signal Module user's manual for instructions on selecting this feature.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1315
 DESIGNED: October 2010
 SEALED: 11/22/10
 REVISED: N/A

New Installation - Sheet 1 of 2

ELECTRICAL AND PROGRAMMING DETAILS FOR:

Prepared In the Offices of:

US 401 at Brightwater Dr/McKinney Pkwy

Division 6 Harnett County Lillington

PLAN DATE: November 2010 REVIEWED BY: T. Joyce

PREPARED BY: S. Armstrong REVIEWED BY:

REVISIONS INIT. DATE

Signature: George C. Brown, 12/20/10


SIG. INVENTORY NO. 06-1315

13-DEC-2010 08:44 S:\TSA\SM\TSS\Signal\sw\kgr\cupa\sig_mon\kgr\trng\061315_sml.e...xxx.dgn

LOGICAL I/O PROCESSOR PROGRAMMING DETAIL TO PRODUCE SPECIAL FYA-PPLT SIGNAL SEQUENCE

(program controller as shown below)

- FROM MAIN MENU PRESS '2' (PHASE CONTROL), THEN '1' (PHASE CONTROL FUNCTIONS). SCROLL TO THE BOTTOM OF THE MENU AND ENABLE ACT LOGIC COMMANDS 1, 2, AND 3.
- FROM MAIN MENU PRESS '6' (OUTPUTS), THEN '3' (LOGICAL I/O PROCESSOR).



LOGIC I/O PROCESSOR PROGRAMMING COMPLETE

OUTPUT REFERENCE SCHEDULE
OUTPUT 50 = Overlap A Red
OUTPUT 51 = Overlap A Yellow
OUTPUT 52 = Overlap A Green

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1315
DESIGNED: October 2010
SEALED: 11/22/10
REVISED: N/A

OVERLAP PROGRAMMING DETAIL

(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS), THEN '1' (VEHICLE OVERLAP SETTINGS).

```

PAGE 1: VEHICLE OVERLAP 'A' SETTINGS
PHASE:           |12345678910111213141516
VEH OVL PARENTS:|XX
VEH OVL NOT VEH:|
VEH OVL NOT PED:|
VEH OVL GRN EXT:|
STARTUP COLOR:  _ RED _ YELLOW _ GREEN
FLASH COLORS:   _ RED _ YELLOW X GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC)...0.0
YELLOW CLEAR (0=PARENT,3-25.5 SEC)..0.0
RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)...0
    
```

← NOTICE GREEN FLASH

PRESS '+' ONCE

```

PAGE 1: VEHICLE OVERLAP 'B' SETTINGS
PHASE:           |12345678910111213141516
VEH OVL PARENTS:| X
VEH OVL NOT VEH:|
VEH OVL NOT PED:|
VEH OVL GRN EXT:|
STARTUP COLOR:  _ RED _ YELLOW _ GREEN
FLASH COLORS:   _ RED _ YELLOW X GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...N
GREEN EXTENSION (0-255 SEC)...0.0
YELLOW CLEAR (0=PARENT,3-25.5 SEC)..0.0
RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)...0
    
```

← NOTICE GREEN FLASH

OVERLAP PROGRAMMING COMPLETE

FLASHER CIRCUIT MODIFICATION DETAIL

IN ORDER TO INSURE THAT SIGNALS FLASH CONCURRENTLY ON THE SAME APPROACH, MAKE THE FOLLOWING FLASHER CIRCUIT CHANGES:

- ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-4 AND TERMINATE ON T2-2.
- ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-5 AND TERMINATE ON T2-3.
- REMOVE FLASHER UNIT 2.


THE CHANGES LISTED ABOVE TIES ALL PHASES AND OVERLAPS TO FLASHER UNIT 1.

13-DEC-2010 08:45 S:\ITS\ASU\ITS\Sig\061315\work\groups\Sig\Mon\armstrong\061315.sm.dwg...xxx.dgn

New Installation - Sheet 2 of 2

<p style="font-size: x-small;">ELECTRICAL AND PROGRAMMING DETAILS FOR:</p> <p style="font-size: x-small;">Prepared In the Office of:</p> <p style="font-size: x-small;">750 N. Greenfield Pkwy, Garner, NC 27529</p>	<p>US 401 at Brightwater Dr/McKinney Pkwy</p> <p style="font-size: x-small;">Division 6 Harnett County Lillington</p> <p style="font-size: x-small;">PLAN DATE: November 2010 REVIEWED BY: <i>T. Siga</i></p> <p style="font-size: x-small;">PREPARED BY: S. Armstrong REVIEWED BY:</p> <table border="1" style="width: 100%; font-size: x-small;"> <tr> <th>REVISIONS</th> <th>INIT.</th> <th>DATE</th> </tr> <tr> <td> </td> <td> </td> <td> </td> </tr> </table>	REVISIONS	INIT.	DATE				<p style="font-size: x-small;">SEAL</p> <p style="font-size: x-small;">SEAL 022013 ENGINEER GEORGE C. BROWN</p> <p style="font-size: x-small;"><i>George C. Brown</i> 12/20/10 SIGNATURE DATE</p> <p style="font-size: x-small;">SIG. INVENTORY NO. 06-1315</p>
REVISIONS	INIT.	DATE						

PHASING DIAGRAM




PHASING DIAGRAM DETECTION LEGEND

- ←● DETECTED MOVEMENT
- ←○ UNDETECTED MOVEMENT (OVERLAP)
- ←--- UNSIGNALIZED MOVEMENT
- ←--- PEDESTRIAN MOVEMENT

TABLE OF OPERATION

SIGNAL FACE	PHASE					
	01+5	01+6	02+5	02+6	04+8	FLASHER
11	←	←	←	←	←	←
21,22	R	R	G	G	R	Y
41,42	R	R	R	R	G	R
51	←	←	←	←	←	←
61,62	R	G	R	G	R	Y
81,82	R	R	R	R	G	R

STANDARD SIGNAL FACE CLEARANCES FOR FLASHING LEFT TURN SIGNAL



OASIS 2070L LOOP & DETECTOR INSTALLATION CHART



LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	DETECTOR PROGRAMMING				SYSTEM LOOP	NEW CARD	
					PHASE	CALLING	EXTENSION	FULL TIME DELAY			
1A	6X40	+5	2-4-2	Y	1	Y	Y	-	15	-	Y
2A	6X6	70	4	Y	2	Y	Y	-	-	-	Y
4A	6X40	0	2-4-2	Y	4	Y	Y	-	-	5	Y
5A	6X40	+5	2-4-2	Y	5	Y	Y	-	15	-	Y
6A	6X6	70	4	Y	6	Y	Y	-	-	-	Y
8A	6X40	0	2-4-2	Y	8	Y	Y	-	-	3	Y
8B	6X40	0	2-4-2	Y	8	Y	Y	-	-	5	Y

3 Phase Fully Actuated Isolated

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated July 2006 and "Standard Specifications for Roads and Structures" dated July 2006.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 1 and/or 5 may be lagged.
- Set all detector units to presence mode.
- Locate new cabinet so as not to obstruct sight distance of vehicles turning right on red.

SIGNAL FACE I.D.



OASIS 2070L TIMING CHART

FEATURE	PHASE					
	1	2	4	5	6	8
Min Green 1*	7	10	7	7	10	7
Extension 1*	2.0	3.0	2.0	2.0	3.0	2.0
Max Green 1*	15	60	20	15	60	20
Yellow Clearance	3.0	4.0	3.9	3.0	4.0	3.1
Red Clearance	2.3	1.9	1.5	2.4	1.9	2.2
Walk 1*	-	-	-	-	-	-
Don't Walk 1	-	-	-	-	-	-
Seconds Per Actuation*	-	-	-	-	-	-
Max Variable Initial*	-	-	-	-	-	-
Time Before Reduction*	-	-	-	-	-	-
Time To Reduce*	-	-	-	-	-	-
Minimum Gap	-	-	-	-	-	-
Recall Mode	-	MIN RECALL	-	-	MIN RECALL	-
Vehicle Call Memory	-	YELLOW	-	-	YELLOW	-
Dual Entry	-	-	ON	-	-	ON
Simultaneous Gap	ON	ON	ON	ON	ON	ON

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND

PROPOSED	EXISTING
○→ Traffic Signal Head	●→
○→ Modified Signal Head	N/A
⊥ Sign	⊥
⊥ Pedestrian Signal Head With Push Button & Sign	⊥
○→ Signal Pole with Guy	●→
○→ Signal Pole with Sidewalk Guy	●→
⊠ Metal Strain Pole	⊠
⊠ Inductive Loop Detector	⊠
⊠ Controller & Cabinet	⊠
⊠ Junction Box	⊠
--- 2-in Underground Conduit	---
⊠ Wheel Chair Ramp	N/A
N/A Right of Way	---
→ Directional Arrow	→
Construction Zone	Construction Zone

New Installation / Temp 1


Prepared in the Offices of:

US 401 at Pine State St
 Division 6 Harnett County Lillington
 PLAN DATE: October 2010 REVIEWED BY: JPG
 PREPARED BY: EM Minshew REVIEWED BY:
 SCALE: 1"=30'
 REVISIONS: INIT. DATE
 SIGNATURE: DATE: 11/22/10
 SIG. INVENTORY NO. 06-1317T1

25-JAN-2011 11:17:37
 R:\MTC\offices\signal\sig\06-1317\061317_s10-temp_1.2010mddi.dgn
 Total Alloway

EDI MODEL 2010ECL-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Make sure jumpers SEL2-SEL5 are present on the monitor board.


INPUT FILE POSITION LAYOUT (front view)

FILE "I"	1	2	3	4	5	6	7	8	9	10	11	12	13	14	FILE "J"
U	∅ 1	∅ 2	S	S	S	∅ 4	S	S	S	S	S	S	S	S	FS
L	1A	2A	←	←	←	4A	←	←	←	←	←	←	←	←	DC ISOLATOR
	NOT USED	NOT USED	←	←	←	NOT USED	←	←	←	←	←	←	←	←	ST
			←	←	←		←	←	←	←	←	←	←	←	DC ISOLATOR
U	∅ 5	∅ 6	S	S	S	∅ 8	S	S	S	S	S	S	S	S	
L	5A	6A	←	←	←	8A	←	←	←	←	←	←	←	←	
	NOT USED	NOT USED	←	←	←	∅ 8	←	←	←	←	←	←	←	←	

EX.: 1A, 2A, ETC. = LOOP NO.'S
 FS = FLASH SENSE
 ST = STOP TIME

⊗ Wired Input - Do not populate slot with detector card

LOAD RESISTOR INSTALLATION DETAIL (install resistors as shown below)



VALUE (ohms)	WATTAGE
1.5K - 1.9K	25W (min)
2.0K - 3.0K	10W (min)

NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Ensure that Red Enable is active at all times during normal operation. To prevent Red Failures on unused monitor channels, tie unused red monitor inputs 1,3,5,7,10,12,13,14,15 & 16 to load switch AC+ per the cabinet manufacturer's instructions.
- Program phases 4 and 8 for Dual Entry.
- Enable Simultaneous Gap-Out for all phases.
- Program phases 2 and 6 for Start Up In Green.
- Program phases 2 and 6 for Yellow Flash, and overlap 1 as Wag Overlaps.

EQUIPMENT INFORMATION


CONTROLLER.....2070L
 CABINET.....332 W/ AUX
 SOFTWARE.....ECONOLITE OASIS
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S4,S5,S6,S8,S9,S12
 PHASES USED.....1,2,4,5,6,8
 OVERLAP "A".....1+2
 OVERLAP "B".....NOT USED
 OVERLAP "C".....5+6
 OVERLAP "D".....NOT USED

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
1A ¹	TB2-1,2	I1U	56	18	1	1	Y	Y			15
	-	J4U	48	10	26	6	Y	Y			
2A	TB2-5,6	I2U	39	1	2	2	Y	Y			
4A	TB4-9,10	I6U	41	3	4	4	Y	Y			5
5A ²	TB3-1,2	J1U	55	17	5	5	Y	Y			15
	-	I4U	47	9	22	2	Y	Y			
6A	TB3-5,6	J2U	40	2	6	6	Y	Y			
8A	TB5-9,10	J6U	42	4	8	8	Y	Y			3
8B	TB5-11,12	J6L	46	8	18	8	Y	Y			5

- Add jumper from I1-W to J4-W, on rear of input file.
- Add jumper from J1-W to I4-W, on rear of input file.

INPUT FILE POSITION LEGEND: J2L



SIGNAL HEAD HOOK-UP CHART


LOAD SWITCH NO.	S1	S2	S2P	S3	S4	S4P	S5	S6	S6P	S7	S8	S8P	S9	S10	S11	S12	S13	S14
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	11*	21,22	NU	NU	41,42	NU	51*	61,62	NU	NU	81,82	NU	11*	NU	NU	51*	NU	NU
RED	128			101			134				107							
YELLOW	*	129		102			*	135			108							
GREEN		130		103			136				109							
RED ARROW													A121			A114		
YELLOW ARROW													A122			A115		
FLASHING YELLOW ARROW													A123			A116		
GREEN ARROW	127						133											

NU = Not Used

* Denotes install load resistor. See load resistor installation detail this sheet.

★ See pictorial of head wiring in detail below.

4 SECTION FYA PPLT SIGNAL WIRING DETAIL (wire signal heads as shown)



NOTE

The sequence display for signal heads 11 and 51 requires special logic programming. See sheet 2 of 2 for programming instructions.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-131711
 DESIGNED: October 2010
 SEALED: 11/22/10
 REVISED: N/A

New Installation (Temp 1) - Sheet 1 of 2


ELECTRICAL AND PROGRAMMING DETAILS FOR: Prepared In the Offices of: TRANSPORTATION MOBILITY AND SAFETY SOLUTIONS, INC. 750 N. Greenfield Pkwy, Garner, NC 27529	US 401 at Pine State Street		SEAL SEAL 022013 ENGINEER GEORGE C. BROWN
	Division 6 PLAN DATE: December 2010 PREPARED BY: S. Armstrong	Harnett County Lillington REVIEWED BY: T. J... REVIEWED BY:	
SIGNATURE: <i>[Signature]</i> DATE: 1/5/11			SIG. INVENTORY NO. 06-131711

C:\Users\jwagner\Documents\06-131711_Sig.e.le.xxx.dgn
 05-Jan-2011 12:22
 05-Jan-2011 12:22
 05-Jan-2011 12:22
 05-Jan-2011 12:22
 05-Jan-2011 12:22


LOGICAL I/O PROCESSOR PROGRAMMING DETAIL TO PRODUCE SPECIAL FYA-PPLT SIGNAL SEQUENCE

(program controller as shown below)


1. FROM MAIN MENU PRESS '2' (PHASE CONTROL), THEN '1' (PHASE CONTROL FUNCTIONS). SCROLL TO THE BOTTOM OF THE MENU AND ENABLE ACT LOGIC COMMANDS 1, 2, 3, 4, 5 AND 6.
2. FROM MAIN MENU PRESS '6' (OUTPUTS), THEN '3' (LOGICAL I/O PROCESSOR).




NOTE: LOGIC FOR PHASE 1 RED CLEAR WHEN TRANSITIONING FROM PHASE 1 TO PHASE 2 (HEAD 11).




NOTE: LOGIC FOR SWITCHING FLASHING YELLOW ARROW "OFF" DURING PHASE 1 (HEAD 11).




NOTE: LOGIC FOR YELLOW ARROW CLEARANCE FROM PHASE 1 (HEAD 11).



NOTE: LOGIC FOR PHASE 5 RED CLEAR WHEN TRANSITIONING FROM PHASE 5 TO PHASE 6 (HEAD 51).



NOTE: LOGIC FOR SWITCHING FLASHING YELLOW ARROW "OFF" DURING PHASE 5 (HEAD 51).



NOTE: LOGIC FOR YELLOW ARROW CLEARANCE FROM PHASE 5 (HEAD 51).

LOGIC I/O PROCESSOR PROGRAMMING COMPLETE

OUTPUT REFERENCE SCHEDULE

- OUTPUT 42 = Overlap C Red
- OUTPUT 43 = Overlap C Yellow
- OUTPUT 44 = Overlap C Green
- OUTPUT 50 = Overlap A Red
- OUTPUT 51 = Overlap A Yellow
- OUTPUT 52 = Overlap A Green

OVERLAP PROGRAMMING DETAIL

(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS), THEN '1' (VEHICLE OVERLAP SETTINGS).

```

    PAGE 1: VEHICLE OVERLAP 'A' SETTINGS
    PHASE: 12345678910111213141516
    VEH OVL PARENTS: XX
    VEH OVL NOT VEH:
    VEH OVL NOT PED:
    VEH OVL GRN EXT:
    STARTUP COLOR: _ RED _ YELLOW _ GREEN
    FLASH COLORS: _ RED _ YELLOW X GREEN
    SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
    FLASH YELLOW IN CONTROLLER FLASH?...Y
    GREEN EXTENSION (0-255 SEC)...0.0
    YELLOW CLEAR (0=PARENT,3-25.5 SEC)...0.0
    RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
    OUTPUT AS PHASE # (0=NONE, 1-16)...0
  
```

← NOTICE GREEN FLASH

PRESS '+' TWICE

```

    PAGE 1: VEHICLE OVERLAP 'C' SETTINGS
    PHASE: 12345678910111213141516
    VEH OVL PARENTS: XX
    VEH OVL NOT VEH:
    VEH OVL NOT PED:
    VEH OVL GRN EXT:
    STARTUP COLOR: _ RED _ YELLOW _ GREEN
    FLASH COLORS: _ RED _ YELLOW X GREEN
    SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
    FLASH YELLOW IN CONTROLLER FLASH?...Y
    GREEN EXTENSION (0-255 SEC)...0.0
    YELLOW CLEAR (0=PARENT,3-25.5 SEC)...0.0
    RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
    OUTPUT AS PHASE # (0=NONE, 1-16)...0
  
```




← NOTICE GREEN FLASH

OVERLAP PROGRAMMING COMPLETE


THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-1317T1
DESIGNED: October 2010
SEALED: 11/22/10
REVISED: N/A

05-JAN-2011 12:20
C:\p1\sig\work\groups\sig_mon\mstron\ong\061317T1_sml.ele.xxx.dgn
sarmstrong

New Installation (Temp 1) - Sheet 2 of 2

Prepared In the Office of:  750 N. Greenfield Pkwy, Garner, NC 27529	US 401 at Pine State Street	SEAL  SEAL 022013 ENGINEER GEORGE C. BROWN
Division 6 Harnett County Lillington		
PLAN DATE: December 2010 REVIEWED BY: T. J. G.		
PREPARED BY: S. Armstrong REVIEWED BY:		
REVISIONS	INIT.	DATE
 SIGNATURE		DATE 1/5/11
SIG. INVENTORY NO. 06-1317T1		

PHASING DIAGRAM




PHASING DIAGRAM DETECTION LEGEND

- DETECTED MOVEMENT
- ◄ UNDETECTED MOVEMENT (OVERLAP)
- ⋯ UNSIGNALIZED MOVEMENT
- ↔ PEDESTRIAN MOVEMENT

TABLE OF OPERATION

SIGNAL FACE	PHASE					
	Ø 1+5	Ø 1+6	Ø 2+5	Ø 2+6	Ø 4+8	F
11	←	←	←	←	←	←
21,22	R	R	G	G	R	Y
41,42	R	R	R	R	G	Y
51	←	←	←	←	←	←
61,62	R	G	R	G	R	Y
81,82	R	R	R	R	G	R

STANDARD SIGNAL FACE CLEARANCES FOR FLASHING LEFT TURN SIGNAL



F = Flashing Yellow Arrow

OASIS 2070L LOOP & DETECTOR INSTALLATION CHART

LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	DETECTOR PROGRAMMING							
					PHASE	CALLING	EXTENSION	FULL TIME DELAY	STRETCH TIME	DELAY TIME	SYSTEM LOOP	NEW CARD
1A	6X40	+5	2-4-2	-	1	Y	Y	-	-	15	-	-
					6	Y	Y	-	-	-	-	-
2A	6X6	70	4	Y	2	Y	Y	-	-	-	-	
4A	6X40	0	2-4-2	-	4	Y	Y	-	-	5	-	
5A	6X40	+5	2-4-2	Y	5	Y	Y	-	-	15	-	-
					2	Y	Y	-	-	-	-	-
6A	6X6	70	4	-	6	Y	Y	-	-	-	-	
8A	6X40	0	2-4-2	Y	8	Y	Y	-	-	3	-	
8B	6X40	0	2-4-2	Y	8	Y	Y	-	-	10	-	



5 Phase Fully Actuated Isolated

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated July 2006 and "Standard Specifications for Roads and Structures" dated July 2006.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 1 and/or phase 5 may be lagged.
- Reposition existing signal heads numbered 21, 22, and 51.
- Set all detector units to presence mode.

SIGNAL FACE I.D.

All Heads L.E.D.



OASIS 2070L TIMING CHART

FEATURE	PHASE						
	1	2	4	5	6	8	
Min Green 1 *	7	10	7	7	10	7	
Extension 1 *	2.0	3.0	2.0	2.0	3.0	2.0	
Max Green 1 *	15	60	20	15	60	20	
Yellow Clearance	3.0	4.0	3.9	3.0	4.0	3.1	
Red Clearance	3.1	2.3	2.2	3.1	2.3	3.1	
Walk 1 *	-	-	-	-	-	-	
Don't Walk 1	-	-	-	-	-	-	
Seconds Per Actuation *	-	-	-	-	-	-	
Max Variable Initial *	-	-	-	-	-	-	
Time Before Reduction *	-	-	-	-	-	-	
Time To Reduce *	-	-	-	-	-	-	
Minimum Gap	-	-	-	-	-	-	
Recall Mode	-	MIN RECALL	-	-	MIN RECALL	-	
Vehicle Call Memory	-	YELLOW	-	-	YELLOW	-	
Dual Entry	-	-	ON	-	-	ON	
Simultaneous Gap	ON	ON	ON	ON	ON	ON	

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND

- | PROPOSED | EXISTING |
|--|--|
| ○ → Traffic Signal Head | ● → Traffic Signal Head |
| ● → Modified Signal Head | N/A |
| ⊥ Sign | ⊥ Sign |
| ⊥ Pedestrian Signal Head With Push Button & Sign | ⊥ Pedestrian Signal Head With Push Button & Sign |
| ⊥ Signal Pole with Guy | ⊥ Signal Pole with Guy |
| ⊥ Signal Pole with Sidewalk Guy | ⊥ Signal Pole with Sidewalk Guy |
| ⊠ Metal Strain Pole | ⊠ Metal Strain Pole |
| ⊠ Inductive Loop Detector Controller & Cabinet | ⊠ Inductive Loop Detector Controller & Cabinet |
| ⊠ Junction Box | ⊠ Junction Box |
| --- 2-in Underground Conduit | --- 2-in Underground Conduit |
| ↗ Wheel Chair Ramp | N/A |
| N/A Right of Way | --- Right of Way |
| → Directional Arrow | → Directional Arrow |
| ▭ Construction Zone | ▭ Construction Zone |


New Installation / Temp 2

	US 401 at Pine State St	
	Division 6 Harnett County Lillington	Division 6 Harnett County Lillington
	PLAN DATE: October 2010	REVIEWED BY:
	PREPARED BY: EM Minshew	REVIEWED BY:
	REVISIONS	INIT. DATE
		11/22/10
		SIG. INVENTORY NO. 06-131772

25-JAN-2011 11:35
 R:\p06171\p06171\sig\061317_51_0_1temp2_2010mod.dgn
 Local Lowy

EDI MODEL 2010ECL-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



REMOVE DIODE JUMPERS 1-5, 1-6, 1-9, 1-II, 2-5, 2-6, 2-9, 2-II, 4-8, 5-9, 5-II, 6-9, 6-II, and 9-II.

REMOVE JUMPERS AS SHOWN

- NOTES:
- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
 - Make sure jumpers SEL2-SEL5 are present on the monitor board.

■ = DENOTES POSITION OF SWITCH

NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Ensure that Red Enable is active at all times during normal operation. To prevent Red Failures on unused monitor channels, tie unused red monitor inputs 1,3, 5,7,10,12,13,14,15 & 16 to load switch AC+ per the cabinet manufacturer's instructions.
- Program phases 4 and 8 for Dual Entry.
- Enable Simultaneous Gap-Out for all phases.
- Program phases 2 and 6 for Start Up In Green.
- Program phases 2 and 6 for Yellow Flash, and overlap 1 as Wag Overlaps.

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S2P	S3	S4	S4P	S5	S6	S6P	S7	S8	S8P	S9	S10	S11	S12	S13	S14
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	11*	21,22	NU	NU	41,42	NU	51*	61,62	NU	NU	81,82	NU	11*	NU	NU	51*	NU	NU
RED		128			101			134			107							
YELLOW	*	129			102		*	135			108							
GREEN		130			103			136			109							
RED ARROW													A121			A114		
YELLOW ARROW													A122			A115		
FLASHING YELLOW ARROW													A123			A116		
GREEN ARROW	127							133										

NU = Not Used
 * Denotes install load resistor. See load resistor installation detail this sheet.
 ★ See pictorial of head wiring in detail below.

EQUIPMENT INFORMATION

CONTROLLER.....2070L
 CABINET.....332 W/ AUX
 SOFTWARE.....ECONOLITE OASIS
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S4,S5,S6,S8,S9,S12
 PHASES USED.....1,2,4,5,6,8
 OVERLAP "A".....1+2
 OVERLAP "B".....NOT USED
 OVERLAP "C".....5+6
 OVERLAP "D".....NOT USED

INPUT FILE POSITION LAYOUT

(front view)

FILE	U	1	2	3	4	5	6	7	8	9	10	11	12	13	14	FS
"I"	U	∅ 1	∅ 2	∅ 3	∅ 4	∅ 5	∅ 6	∅ 7	∅ 8	∅ 9	∅ 10	∅ 11	∅ 12	∅ 13	∅ 14	DC ISOLATOR
	L	NOT USED	NOT USED	W	W	W	W	W	W	W	W	W	W	W	W	ST
"J"	U	∅ 5	∅ 6	∅ 7	∅ 8	∅ 9	∅ 10	∅ 11	∅ 12	∅ 13	∅ 14	∅ 15	∅ 16	∅ 17	∅ 18	DC ISOLATOR
	L	NOT USED	NOT USED	W	W	W	W	W	W	W	W	W	W	W	W	DC ISOLATOR

EX.: 1A, 2A, ETC. = LOOP NO.'S
 FS = FLASH SENSE
 ST = STOP TIME


⊗ Wired Input - Do not populate slot with detector card

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
1A ¹	TB2-1,2	I1U	56	18	1	1	Y	Y			15
	-	J4U	48	10	26	6	Y	Y			
2A	TB2-5,6	I2U	39	1	2	2	Y	Y			
4A	TB4-9,10	I6U	41	3	4	4	Y	Y			5
5A ²	TB3-1,2	J1U	55	17	5	5	Y	Y			15
	-	I4U	47	9	22	2	Y	Y			
6A	TB3-5,6	J2U	40	2	6	6	Y	Y			
8A	TB5-9,10	J6U	42	4	8	8	Y	Y			3
8B	TB5-11,12	J6L	46	8	18	8	Y	Y			10

- Make sure a jumper is installed from I1-W to J4-W on rear of input file.
- Make sure a jumper is installed from J1-W to I4-W on rear of input file.


INPUT FILE POSITION LEGEND: J2L



LOAD RESISTOR INSTALLATION DETAIL


(install resistors as shown below)

VALUE (ohms)	WATTAGE
1.5K - 1.9K	25W (min)
2.0K - 3.0K	10W (min)



4 SECTION FYA PPLT SIGNAL WIRING DETAIL

(wire signal heads as shown)



NOTE

The sequence display for signal heads 11 and 51 requires special logic programming. See sheet 2 of 2 for programming instructions.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1317T2
 DESIGNED: October 2010
 SEALED: 11/22/10
 REVISED: N/A


New Installation (Temp 2) - Sheet 1 of 2

ELECTRICAL AND PROGRAMMING DETAILS FOR: Prepared In the Offices of: TRANSPORTATION MOBILITY AND SAFETY GROUP, INC. 750 N. Greenfield Pkwy, Corner, NC 27529	US 401 at Pine State Street		SEAL GEORGE C. BROWN ENGINEER
	Division 6 PLAN DATE: December 2010 PREPARED BY: S. Armstrong	Harnett County Lillington REVIEWED BY: T. J. J... REVIEWED BY:	

LOGICAL I/O PROCESSOR PROGRAMMING DETAIL TO PRODUCE SPECIAL FYA-PPLT SIGNAL SEQUENCE

(program controller as shown below)

1. FROM MAIN MENU PRESS '2' (PHASE CONTROL), THEN '1' (PHASE CONTROL FUNCTIONS). SCROLL TO THE BOTTOM OF THE MENU AND ENABLE ACT LOGIC COMMANDS 1, 2, 3, 4, 5 AND 6.
2. FROM MAIN MENU PRESS '6' (OUTPUTS), THEN '3' (LOGICAL I/O PROCESSOR).



OUTPUT REFERENCE SCHEDULE	
OUTPUT 42 =	Overlap C Red
OUTPUT 43 =	Overlap C Yellow
OUTPUT 44 =	Overlap C Green
OUTPUT 50 =	Overlap A Red
OUTPUT 51 =	Overlap A Yellow
OUTPUT 52 =	Overlap A Green

OVERLAP PROGRAMMING DETAIL

(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS), THEN '1' (VEHICLE OVERLAP SETTINGS).

```

PAGE 1: VEHICLE OVERLAP 'A' SETTINGS
PHASE:      |12345678910111213141516
VEH OVL PARENTS: |XX
VEH OVL NOT VEH: |
VEH OVL NOT PED: |
VEH OVL GRN EXT: |
STARTUP COLOR:  | - RED - YELLOW - GREEN
FLASH COLORS:   | - RED - YELLOW X GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC)...0.0
YELLOW CLEAR (0=PARENT,3-25.5 SEC)...0.0
RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)...0
    
```

← NOTICE GREEN FLASH

PRESS '+' TWICE

```

PAGE 1: VEHICLE OVERLAP 'C' SETTINGS
PHASE:      |12345678910111213141516
VEH OVL PARENTS: |XX
VEH OVL NOT VEH: |
VEH OVL NOT PED: |
VEH OVL GRN EXT: |
STARTUP COLOR:  | - RED - YELLOW - GREEN
FLASH COLORS:   | - RED - YELLOW X GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC)...0.0
YELLOW CLEAR (0=PARENT,3-25.5 SEC)...0.0
RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)...0
    
```

← NOTICE GREEN FLASH

OVERLAP PROGRAMMING COMPLETE


THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1317T2
DESIGNED: October 2010
SEALED: 11/22/10
REVISED: N/A

New Installation (Temp 2) - Sheet 2 of 2

	US 401 at Pine State Street		SEAL NORTH CAROLINA PROFESSIONAL ENGINEER GEORGE C. BROWN 022013
	Prepared In the Office of:	Division 6	
750 N. Greenfield Pkwy, Garner, NC 27529	PLAN DATE: December 2010	REVIEWED BY: <i>T. J. J...</i>	Lillington
	PREPARED BY: S. Armstrong	REVIEWED BY:	
	REVISIONS	INIT.	DATE
			SIGNATURE: <i>George C. Brown</i> / 11/5/11 DATE
			SIG. INVENTORY NO. 06-1317T2

06-1317T2-10-25
S:\Signal\workgroups\sig_maintenance\061317T2_sml_e_ie_xxx.dgn
sarmstrong

PHASING DIAGRAM




PHASING DIAGRAM DETECTION LEGEND

- DETECTED MOVEMENT
- UNDETECTED MOVEMENT (OVERLAP)
- ⊖ UNSIGNALIZED MOVEMENT
- ⊕ PEDESTRIAN MOVEMENT

TABLE OF OPERATION

SIGNAL FACE	PHASE					
	01+5	01+6	02+5	02+6	04+8	F L
11	←	←	←	←	←	←
21,22	R	R	G	G	R	Y
41,42	R	R	R	R	G	R
51	←	←	←	←	←	←
61,62	R	G	R	G	R	Y
81,82	R	R	R	R	G	R

SIGNAL FACE I.D.
All Heads L.E.D.



STANDARD SIGNAL FACE CLEARANCES FOR FLASHING LEFT TURN SIGNAL

FROM	TO					
	1	2	1	2	1	2
←	←	←	←	←	←	←
→	→	→	→	→	→	→
↔	↔	↔	↔	↔	↔	↔
↔	↔	↔	↔	↔	↔	↔

↔ = Flashing Yellow Arrow


OASIS 2070L LOOP & DETECTOR INSTALLATION CHART

LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	DETECTOR PROGRAMMING								
				NEW LOOP	PHASE	CALLING	EXTENSION	FULL TIME DELAY	STRETCH TIME	DELAY TIME	SYSTEM LOOP	NEW CARD
1A	6X40	0	2-4-2	Y	1	Y	Y	-	-	15	-	-
2A	6X6	70	4	-	2	Y	Y	-	-	-	-	-
4A	6X40	0	2-4-2	-	4	Y	Y	-	-	5	-	-
5A	6X40	+5	2-4-2	-	5	Y	Y	-	-	15	-	-
6A	6X6	70	4	Y	6	Y	Y	-	-	-	-	-
8A	6X40	0	2-4-2	-	8	Y	Y	-	-	3	-	-
8B	6X40	0	2-4-2	-	8	Y	Y	-	-	10	-	-

5 Phase Fully Actuated Isolated

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated July 2006 and "Standard Specifications for Roads and Structures" dated July 2006.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 1 and/or phase 5 may be lagged.
- Reposition existing signal heads numbered 11, 61, and 62.
- Set all detector units to presence mode.



OASIS 2070L TIMING CHART

FEATURE	PHASE					
	1	2	4	5	6	8
Min Green 1*	7	10	7	7	10	7
Extension 1*	2.0	3.0	2.0	2.0	3.0	2.0
Max Green 1*	15	60	20	15	60	20
Yellow Clearance	3.0	4.0	3.9	3.0	4.0	3.1
Red Clearance	2.8	2.0	2.2	2.8	2.0	2.7
Walk 1*	-	-	-	-	-	-
Don't Walk 1	-	-	-	-	-	-
Seconds Per Actuation*	-	-	-	-	-	-
Max Variable Initial*	-	-	-	-	-	-
Time Before Reduction*	-	-	-	-	-	-
Time To Reduce*	-	-	-	-	-	-
Minimum Gap	-	-	-	-	-	-
Recall Mode	-	MIN RECALL	-	-	MIN RECALL	-
Vehicle Call Memory	-	YELLOW	-	-	YELLOW	-
Dual Entry	-	-	ON	-	-	ON
Simultaneous Gap	ON	ON	ON	ON	ON	ON

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND

PROPOSED	EXISTING
○ Traffic Signal Head	● Traffic Signal Head
○ Modified Signal Head	N/A
⊖ Sign	⊖ Sign
⊕ Pedestrian Signal Head With Push Button & Sign	⊕ Pedestrian Signal Head With Push Button & Sign
○ Signal Pole with Guy	○ Signal Pole with Guy
○ Signal Pole with Sidewalk Guy	○ Signal Pole with Sidewalk Guy
□ Metal Strain Pole	□ Metal Strain Pole
⊗ Inductive Loop Detector	⊗ Inductive Loop Detector
⊠ Controller & Cabinet	⊠ Controller & Cabinet
□ Junction Box	□ Junction Box
⊖ 2-in Underground Conduit	⊖ 2-in Underground Conduit
⊕ Wheel Chair Ramp	N/A
⊖ Right of Way	⊖ Right of Way
→ Directional Arrow	→ Directional Arrow
▨ Construction Zone	▨ Construction Zone

New Installation/ Temp 3


Prepared In the Offices of:

US 401 at Pine State St
 Division 6 Harnett County Lillington
 PLAN DATE: October 2010 REVIEWED BY: JPG
 PREPARED BY: EM Minshew REVIEWED BY:
 SCALE: 1"=30'
 REVISIONS: INIT. DATE
 SIGNATURE: DATE: 11/22/10
 SIG. INVENTORY NO. 06-131773

25-JAN-2011 11:35
 R:\AT\OFFICE\GMS\gms\1317\06\1317_519-temp3_2010madd.dgn
 Jgal Lowry

EDI MODEL 2010ECL-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Make sure jumpers SEL2-SEL5 are present on the monitor board.

NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Ensure that Red Enable is active at all times during normal operation. To prevent Red Failures on unused monitor channels, tie unused red monitor inputs 1,3,5,7,10,12,13,14,15 & 16 to load switch AC+ per the cabinet manufacturer's instructions.
- Program phases 4 and 8 for Dual Entry.
- Enable Simultaneous Gap-Out for all phases.
- Program phases 2 and 6 for Start Up In Green.
- Program phases 2 and 6 for Yellow Flash, and overlap 1 as Wag Overlaps.

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S2P	S3	S4	S4P	S5	S6	S6P	S7	S8	S8P	S9	S10	S11	S12	S13	S14
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	9	10	11	12	13	14
SIGNAL HEAD NO.	11	21,22	NU	NU	41,42	NU	51	61,62	NU	NU	81,82	NU	11	NU	NU	51	NU	NU
RED	128				101			134			107							
YELLOW	*	129			102		*	135			108							
GREEN		130			103			136			109							
RED ARROW																A121		A114
YELLOW ARROW																A122		A115
FLASHING YELLOW ARROW																A123		A116
GREEN ARROW	127							133										
⚠																		
🚶																		

NU = Not Used
 * Denotes install load resistor. See load resistor installation detail this sheet.
 ★ See pictorial of head wiring in detail below.

EQUIPMENT INFORMATION


CONTROLLER.....2070L
 CABINET.....332 W/ AUX
 SOFTWARE.....ECONOLITE OASIS
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S4,S5,S6,S8,S9,S12
 PHASES USED.....1,2,4,5,6,8
 OVERLAP "A".....1+2
 OVERLAP "B".....NOT USED
 OVERLAP "C".....5+6
 OVERLAP "D".....NOT USED

INPUT FILE POSITION LAYOUT


(front view)

FILE "I"	1	2	3	4	5	6	7	8	9	10	11	12	13	14
U	∅ 1	∅ 2	S	S	S	∅ 4	S	S	S	S	S	S	S	FS
L	1A	2A	→	→	→	4A	→	→	→	→	→	→	→	DC ISOLATOR
	NOT USED	NOT USED	→	→	→	NOT USED	→	→	→	→	→	→	→	ST
			→	→	→		→	→	→	→	→	→	→	DC ISOLATOR
U	∅ 5	∅ 6	S	S	S	∅ 8	S	S	S	S	S	S	S	
L	5A	6A	→	→	→	8A	→	→	→	→	→	→	→	
	NOT USED	NOT USED	→	→	→	8B	→	→	→	→	→	→	→	

EX.: 1A, 2A, ETC. = LOOP NO.'S
 FS = FLASH SENSE
 ST = STOP TIME



4 SECTION FYA PPLT SIGNAL WIRING DETAIL



NOTE
 The sequence display for signal heads 11 and 51 requires special logic programming. See sheet 2 of 2 for programming instructions.

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
1A ¹	TB2-1,2	I1U	56	18	1	1	Y	Y			15
	-	J4U	48	10	26	6	Y	Y			
2A	TB2-5,6	I2U	39	1	2	2	Y	Y			
4A	TB4-9,10	I6U	41	3	4	4	Y	Y			5
5A ²	TB3-1,2	J1U	55	17	5	5	Y	Y			15
	-	I4U	47	9	22	2	Y	Y			
6A	TB3-5,6	J2U	40	2	6	6	Y	Y			
8A	TB5-9,10	J6U	42	4	8	8	Y	Y			3
8B	TB5-11,12	J6L	46	8	18	8	Y	Y			10

- Make sure a jumper is installed from I1-W to J4-W on rear of input file.
- Make sure a jumper is installed from J1-W to I4-W on rear of input file.

INPUT FILE POSITION LEGEND: J2L



THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-131773
 DESIGNED: October 2010
 SEALED: 11/22/10
 REVISED: N/A

New Installation (Temp 3) - Sheet 1 of 2

	US 401 at Pine State Street	
	Division 6 PLAN DATE: December 2010 PREPARED BY: S. Armstrong	Harnett County Lillington REVIEWED BY: T. W. J. A. REVIEWED BY:
REVISIONS INIT. DATE	DATE	SIGNATURE: George C. Brown DATE:

SIG. INVENTORY NO. 06-131773

05-ANK-2011-11-06
 C:\MSD\SIG\15-Signal\swkr\cupa\sig\15-Signal\strong\06131773_sig_elec_xxx.dgn
 somstrong

**LOGICAL I/O PROCESSOR PROGRAMMING DETAIL
TO PRODUCE SPECIAL FYA-PPLT SIGNAL SEQUENCE**

(program controller as shown below)

- FROM MAIN MENU PRESS '2' (PHASE CONTROL), THEN '1' (PHASE CONTROL FUNCTIONS). SCROLL TO THE BOTTOM OF THE MENU AND ENABLE ACT LOGIC COMMANDS 1, 2, 3, 4, 5 AND 6.
- FROM MAIN MENU PRESS '6' (OUTPUTS), THEN '3' (LOGICAL I/O PROCESSOR).

LOGICAL I/O COMMAND #1 (+/-COMMAND#)
IF ACTIVE PHASE #1 IS ON
AND RED CLEAR ON PHASE #1 IS ON

↓

SCROLL DOWN

THEN:
SET OUTPUT ASSIGNMENT #50 ON
SET OUTPUT ASSIGNMENT #51 OFF

PRESS '+'

NOTE: LOGIC FOR PHASE 1 RED CLEAR WHEN TRANSITIONING FROM PHASE 1 TO PHASE 2 (HEAD 11).

LOGICAL I/O COMMAND #2 (+/-COMMAND#)
IF ACTIVE PHASE #1 IS ON

↓

SCROLL DOWN

THEN:
SET OUTPUT ASSIGNMENT #52 OFF

PRESS '+'

NOTE: LOGIC FOR SWITCHING FLASHING YELLOW ARROW "OFF" DURING PHASE 1 (HEAD 11).

LOGICAL I/O COMMAND #3 (+/-COMMAND#)
IF YELLOW ON PHASE #1 IS ON

↓

SCROLL DOWN

THEN:
SET OUTPUT ASSIGNMENT #51 ON

PRESS '+'

NOTE: LOGIC FOR YELLOW ARROW CLEARANCE FROM PHASE 1 (HEAD 11).

LOGICAL I/O COMMAND #4 (+/-COMMAND#)
IF ACTIVE PHASE #5 IS ON
AND RED CLEAR ON PHASE #5 IS ON

↓

SCROLL DOWN

THEN:
SET OUTPUT ASSIGNMENT #42 ON
SET OUTPUT ASSIGNMENT #43 OFF

PRESS '+'

NOTE: LOGIC FOR PHASE 5 RED CLEAR WHEN TRANSITIONING FROM PHASE 5 TO PHASE 6 (HEAD 51).

LOGICAL I/O COMMAND #5 (+/-COMMAND#)
IF ACTIVE PHASE #5 IS ON

↓

SCROLL DOWN

THEN:
SET OUTPUT ASSIGNMENT #44 OFF

PRESS '+'

NOTE: LOGIC FOR SWITCHING FLASHING YELLOW ARROW "OFF" DURING PHASE 5 (HEAD 51).

LOGICAL I/O COMMAND #6 (+/-COMMAND#)
IF YELLOW ON PHASE #5 IS ON

↓

SCROLL DOWN

THEN:
SET OUTPUT ASSIGNMENT #43 ON

PRESS '+'

NOTE: LOGIC FOR YELLOW ARROW CLEARANCE FROM PHASE 5 (HEAD 51).

LOGIC I/O PROCESSOR PROGRAMMING COMPLETE

OUTPUT REFERENCE SCHEDULE

- OUTPUT 42 = Overlap C Red
- OUTPUT 43 = Overlap C Yellow
- OUTPUT 44 = Overlap C Green
- OUTPUT 50 = Overlap A Red
- OUTPUT 51 = Overlap A Yellow
- OUTPUT 52 = Overlap A Green

OVERLAP PROGRAMMING DETAIL

(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS), THEN '1' (VEHICLE OVERLAP SETTINGS).

PAGE 1: VEHICLE OVERLAP 'A' SETTINGS
PHASE: 12345678910111213141516
VEH OVL PARENTS: XX
VEH OVL NOT VEH:
VEH OVL NOT PED:
VEH OVL GRN EXT:
STARTUP COLOR: - RED - YELLOW - GREEN
FLASH COLORS: - RED - YELLOW X GREEN

SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC)...0.0
YELLOW CLEAR (0=PARENT.3-25.5 SEC)...0.0
RED CLEAR (0=PARENT.0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)...0

← NOTICE GREEN FLASH

PRESS '+' TWICE

PAGE 1: VEHICLE OVERLAP 'C' SETTINGS
PHASE: 12345678910111213141516
VEH OVL PARENTS: XX
VEH OVL NOT VEH:
VEH OVL NOT PED:
VEH OVL GRN EXT:
STARTUP COLOR: - RED - YELLOW - GREEN
FLASH COLORS: - RED - YELLOW X GREEN

SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC)...0.0
YELLOW CLEAR (0=PARENT.3-25.5 SEC)...0.0
RED CLEAR (0=PARENT.0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)...0



← NOTICE GREEN FLASH

OVERLAP PROGRAMMING COMPLETE


THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1317T3
DESIGNED: October 2010
SEALED: 11/22/10
REVISED: N/A

05-JAN-2011 13:06 C:\p1\work\krc\groups\sig\mon\mstron\061317T3_sig.ele.xxx.dgn sarmstrong

New Installation (Temp 3) - Sheet 2 of 2

 <p>750 N. Greenfield Pkwy, Garner, NC 27529</p>	<p>US 401 at Pine State Street</p>		<p>SEAL</p> 					
	<p>Division 6 Harnett County Lillington</p> <p>PLAN DATE: December 2010 REVIEWED BY: <i>T. Lloyd</i></p> <p>PREPARED BY: S. Armstrong REVIEWED BY:</p>	<p>REVISIONS</p> <table border="1"> <tr> <th>REVISIONS</th> <th>INIT.</th> <th>DATE</th> </tr> <tr> <td> </td> <td> </td> <td> </td> </tr> </table>		REVISIONS	INIT.	DATE		
REVISIONS	INIT.	DATE						

PHASING DIAGRAM



PHASING DIAGRAM DETECTION LEGEND


- DETECTED MOVEMENT
- UNDETECTED MOVEMENT (OVERLAP)
- UNSIGNALIZED MOVEMENT
- ↔ PEDESTRIAN MOVEMENT

SIGNAL FACE	PHASE				
	01+5	01+6	02+5	02+6	04+8
11	←	←	←	←	←
21,22	R	R	G	G	R
41,42	R	R	R	R	G
51	←	←	←	←	←
61,62	R	G	R	G	R
81,82	R	R	R	R	G
P21,P22	DW	DW	W	W	DRK
P41,P42	DW	DW	DW	DW	DRK
P61,P62	DW	W	DW	W	DRK
P81,P82	DW	DW	DW	DW	DRK


W-Walk
DW-Don't Walk
DRK-Dark

SIGNAL FACE I.D.

All Heads L.E.D.



STANDARD SIGNAL FACE CLEARANCES FOR FLASHING LEFT TURN SIGNAL



F=Flashing Yellow Arrow


OASIS 2070L LOOP & DETECTOR INSTALLATION CHART

LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	DETECTOR PROGRAMMING			
					PHASE	CALLING EXTENSION	STRETCH TIME DELAY	DELAY TIME
1A	6X40	0	2-4-2	Y	1	Y	Y	15
2A,2B	6X6	70	4	Y	2	Y	Y	-
4A	6X40	0	2-4-2	Y	4	Y	Y	5
5A	6X40	0	2-4-2	Y	5	Y	Y	15
6A,6B	6X6	70	4	Y	6	Y	Y	-
8A	6X40	0	2-4-2	Y	8	Y	Y	3
8B	6X40	0	2-4-2	Y	8	Y	Y	10
S17	6X6	+115	3	Y	-	-	-	Y
S18	6X6	+115	3	Y	-	-	-	Y

5 Phase Fully Actuated
US 401-421/NC 27-210 Closed Loop System

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated July 2006 and "Standard Specifications for Roads and Structures" dated July 2006.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 1 and/or phase 5 may be lagged.
- Set all detector units to presence mode.
- Omit "WALK" and flashing "DON'T WALK" with no pedestrian calls.
- Program pedestrian heads to countdown the flashing "Don't Walk" time only.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Closed loop system data: Controller Asset 1317.



FEATURE	PHASE					
	1	2	4	5	6	8
Min Green 1*	7	10	7	7	10	7
Extension 1*	2.0	3.0	2.0	2.0	3.0	2.0
Max Green 1*	15	60	20	15	60	20
Yellow Clearance	3.0	4.0	3.9	3.0	4.0	3.1
Red Clearance	2.9	2.2	2.3	2.8	2.2	3.1
Walk 1*	-	7	7	-	7	7
Don't Walk 1	-	17	23	-	19	24
Seconds Per Actuation*	-	-	-	-	-	-
Max Variable Initial*	-	-	-	-	-	-
Time Before Reduction*	-	-	-	-	-	-
Time To Reduce*	-	-	-	-	-	-
Minimum Gap	-	-	-	-	-	-
Recall Mode	-	MIN RECALL	-	-	MIN RECALL	-
Vehicle Call Memory	-	YELLOW	-	-	YELLOW	-
Dual Entry	-	-	ON	-	-	ON
Simultaneous Gap	ON	ON	ON	ON	ON	ON

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND

- | | |
|---------------------------------|-----------------|
| PROPOSED | EXISTING |
| ○ Traffic Signal Head | ● N/A |
| ○ Modified Signal Head | ○ N/A |
| ○ Sign | ○ N/A |
| ○ Pedestrian Signal Head | ○ N/A |
| ○ Pedestrian Pushbutton | ○ N/A |
| ○ Signal Pole with Guy | ○ N/A |
| ○ Signal Pole with Sidewalk Guy | ○ N/A |
| ○ Metal Strain Pole | ○ N/A |
| ○ Inductive Loop Detector | ○ N/A |
| ○ Controller & Cabinet | ○ N/A |
| ○ Junction Box | ○ N/A |
| ○ 2-in Underground Conduit | ○ N/A |
| ○ Wheel Chair Ramp | ○ N/A |
| ○ Right of Way | ○ N/A |
| ○ Directional Arrow | ○ N/A |

New Installation - Final

Prepared in the Offices of:

US 401 at Pine State St

Division 6 - Harnett County - Lillington

PLAN DATE: October 2010 REVIEWED BY: JPG

PREPARED BY: EN Minschew REVIEWED BY:

SCALE: 1"=30'


DATE: 11/22/10

SIG. INVENTORY NO. 06-1317


25-AUG-2011 11:33:37
 C:\pwork\421-210\signal\sheet\signal\06-1317-new\06-1317_5.dwg - 2010mads.dgn
 Local Work

EDI MODEL 2010ECL-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)




REMOVE DIODE JUMPERS 1-5, 1-6, 1-9, 1-11, 1-15, 2-5, 2-6, 2-9, 2-11, 2-13, 2-15, 4-8, 4-14, 4-16, 5-9, 5-11, 5-13, 6-9, 6-11, 6-13, 6-15, 8-14, 8-16, 9-11, 9-13, 9-15, 11-13, 11-15, 13-15, and 14-16.



REMOVE JUMPERS AS SHOWN

NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Make sure jumpers SEL2-SEL5 are present on the monitor board.



■ = DENOTES POSITION OF SWITCH

INPUT FILE POSITION LAYOUT

(front view)

FILE "I"	1	2	3	4	5	6	7	8	9	10	11	12	13	14
	∅ 1 1A	∅ 2 2A,2B	∅ 3 3A	∅ 4 4A	∅ 5 5A	∅ 6 6A,6B	∅ 7 7A	∅ 8 8A	∅ 9 9A	∅ 10 10A	∅ 11 11A	∅ 12 12A	∅ 13 13A	∅ 14 14A
FILE "J"	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED

EX.: 1A, 2A, ETC. = LOOP NO.'S


⊗ Wired Input - Do not populate slot with detector card

FS = FLASH SENSE
ST = STOP TIME

LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown below)

VALUE (ohms)	WATTAGE
1.5K - 1.9K	25W (min)
2.0K - 3.0K	10W (min)



NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Ensure that Red Enable is active at all times during normal operation. To prevent Red Failures on unused monitor channels, tie unused red monitor inputs 1,3, 5,7,10,12,13,14,15 & 16 to load switch AC+ per the cabinet manufacturer's instructions.
- Program phases 4 and 8 for Dual Entry.
- Enable Simultaneous Gap-Out for all phases.
- Program phases 2 and 6 for Start Up In Green.
- Program phases 2, 4, 6 and 8 for 'STARTUP PED CALL'.
- Program phases 2 and 6 for Yellow Flash, and overlap 1 as Wag Overlaps.
- The cabinet and controller are part of the US 401-421/ NC 27-210 Closed Loop System.

EQUIPMENT INFORMATION

CONTROLLER.....2070L
 CABINET.....332 W/ AUX
 SOFTWARE.....ECONOLITE OASIS
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S1,S2,S2P,S4,S4P,S5,S6,S6P,S8,S8P,S9,S12
 PHASES USED.....1,2,2 PED,4,4 PED,5,6,6 PED,8,8 PED
 OVERLAP "A".....1+2
 OVERLAP "B".....NOT USED
 OVERLAP "C".....5+6
 OVERLAP "D".....NOT USED


INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
1A ¹	TB2-1,2	I1U	56	18	1	1	Y	Y			15
2A,2B	TB2-5,6	I2U	39	10	26	6	Y	Y			
4A	TB4-9,10	I6U	41	3	4	4	Y	Y			5
5A ²	TB3-1,2	J1U	55	17	5	5	Y	Y			15
6A,6B	TB3-5,6	J2U	40	2	6	6	Y	Y			
8A	TB5-9,10	J6U	42	4	8	8	Y	Y			3
8B	TB5-11,12	J6L	46	8	18	8	Y	Y			10
* S17	TB6-9,10	I9U	60	22	11	SYS					
* S18	TB6-11,12	I9L	62	24	13	SYS					
PED PUSH BUTTONS											
P21,P22	TB8-4,6	I12U	67	29	PED 2	2 PED					
P41,P42	TB8-5,6	I12L	69	31	PED 4	4 PED					
P61,P62	TB8-7,9	I13U	68	30	PED 6	6 PED					
P81,P82	TB8-8,9	I13L	70	32	PED 8	8 PED					

NOTE:
 INSTALL DC ISOLATORS IN INPUT FILE SLOTS 112 AND 113.

- Make sure a jumper is installed from I1-W to J4-W on rear of input file.
 - Make sure a jumper is installed from J1-W to I4-W on rear of input file.
- * System detector only. Remove the vehicle phase assigned to this detector in the default programming.

INPUT FILE POSITION LEGEND: J2L



SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S2P	S3	S4	S4P	S5	S6	S6P	S7	S8	S8P	S9	S10	S11	S12	S13	S14
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	9	10	11	12	13	14
SIGNAL HEAD NO.	11	21,22	P21, P22	NU	41,42	P41, P42	51	61,62	P61, P62	NU	81,82	P81, P82	11	NU	NU	51	NU	NU
RED	128				101			134			107							
YELLOW	*	129			102		*	135			108							
GREEN	130				103			136			109							
RED ARROW																A121		A114
YELLOW ARROW																A122		A115
FLASHING YELLOW ARROW																A123		A116
GREEN ARROW	127							133										
⤴							113		104		119		110					
⤵							115		106		121		112					


NU = Not Used

* Denotes install load resistor. See load resistor installation detail this sheet.

★ See pictorial of head wiring in detail below.

4 SECTION FYA PPLT SIGNAL WIRING DETAIL

(wire signal heads as shown)



NOTE

The sequence display for signal heads 11 and 51 requires special logic programming. See sheet 2 of 2 for programming instructions.

COUNTDOWN PEDESTRIAN SIGNAL OPERATION

Countdown Ped Signals are required to display timing only during Ped Clearance Interval. Consult Ped Signal Module user's manual for instructions on selecting this feature.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1317
 DESIGNED: October 2010
 SEALED: 11/22/10
 REVISED: N/A


New Installation (Final) - Sheet 1 of 2

	DETAILS FOR:		US 401 at Pine State Street		SEAL
	Division 6	Harnett County	Lillington		
PLAN DATE: December 2010	REVIEWED BY: T. J. J.	PREPARED BY: S. Armstrong		REVIEWED BY:	DATE: 1/5/11
REVISIONS	INIT.	DATE	SIGNATURE: <i>S. Armstrong</i>		DATE: 1/5/11
750 N. Greenfield Pkwy, Garner, NC 27529					SIG. INVENTORY NO. 06-1317


LOGICAL I/O PROCESSOR PROGRAMMING DETAIL TO PRODUCE SPECIAL FYA-PPLT SIGNAL SEQUENCE

(program controller as shown below)


- FROM MAIN MENU PRESS '2' (PHASE CONTROL), THEN '1' (PHASE CONTROL FUNCTIONS). SCROLL TO THE BOTTOM OF THE MENU AND ENABLE ACT LOGIC COMMANDS 1, 2, 3, 4, 5 AND 6.
- FROM MAIN MENU PRESS '6' (OUTPUTS), THEN '3' (LOGICAL I/O PROCESSOR).




NOTE: LOGIC FOR PHASE 1 RED CLEAR WHEN TRANSITIONING FROM PHASE 1 TO PHASE 2 (HEAD 11).




NOTE: LOGIC FOR SWITCHING FLASHING YELLOW ARROW "OFF" DURING PHASE 1 (HEAD 11).




NOTE: LOGIC FOR YELLOW ARROW CLEARANCE FROM PHASE 1 (HEAD 11).



NOTE: LOGIC FOR PHASE 5 RED CLEAR WHEN TRANSITIONING FROM PHASE 5 TO PHASE 6 (HEAD 51).



NOTE: LOGIC FOR SWITCHING FLASHING YELLOW ARROW "OFF" DURING PHASE 5 (HEAD 51).



NOTE: LOGIC FOR YELLOW ARROW CLEARANCE FROM PHASE 5 (HEAD 51).

LOGIC I/O PROCESSOR PROGRAMMING COMPLETE

OUTPUT REFERENCE SCHEDULE

OUTPUT 42 = Overlap C Red
 OUTPUT 43 = Overlap C Yellow
 OUTPUT 44 = Overlap C Green
 OUTPUT 50 = Overlap A Red
 OUTPUT 51 = Overlap A Yellow
 OUTPUT 52 = Overlap A Green

OVERLAP PROGRAMMING DETAIL

(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS), THEN '1' (VEHICLE OVERLAP SETTINGS).

PAGE 1: VEHICLE OVERLAP 'A' SETTINGS
 PHASE: :12345678910111213141516
 VEH OVL PARENTS: :XX
 VEH OVL NOT VEH: :
 VEH OVL NOT PED: :
 VEH OVL GRN EXT: :
 STARTUP COLOR: - RED - YELLOW - GREEN
 FLASH COLORS: - RED - YELLOW X GREEN

SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
 FLASH YELLOW IN CONTROLLER FLASH?...Y
 GREEN EXTENSION (0-255 SEC)...0
 YELLOW CLEAR (0=PARENT.3-25.5 SEC)...0.0
 RED CLEAR (0=PARENT.0.1-25.5 SEC)...0.0
 OUTPUT AS PHASE # (0=NONE, 1-16)...0

← NOTICE GREEN FLASH

PRESS '+' TWICE

PAGE 1: VEHICLE OVERLAP 'C' SETTINGS
 PHASE: :12345678910111213141516
 VEH OVL PARENTS: : XX
 VEH OVL NOT VEH: :
 VEH OVL NOT PED: :
 VEH OVL GRN EXT: :
 STARTUP COLOR: - RED - YELLOW - GREEN
 FLASH COLORS: - RED - YELLOW X GREEN

SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
 FLASH YELLOW IN CONTROLLER FLASH?...Y
 GREEN EXTENSION (0-255 SEC)...0
 YELLOW CLEAR (0=PARENT.3-25.5 SEC)...0.0
 RED CLEAR (0=PARENT.0.1-25.5 SEC)...0.0
 OUTPUT AS PHASE # (0=NONE, 1-16)...0



← NOTICE GREEN FLASH

OVERLAP PROGRAMMING COMPLETE


THIS ELECTRICAL DETAIL IS FOR
 THE SIGNAL DESIGN: 06-1317
 DESIGNED: October 2010
 SEALED: 11/22/10
 REVISED: N/A

03-JAN-2011 14:03 S:\TSS\UHTS\Sig\pals\workgroups\Sig Mon\Armstrong\061317_sm_ele_...xxx.dgn

New Installation (Final) - Sheet 2 of 2

	US 401 at Pine State Street		
	Division 6 Harnett County Lillington	PLAN DATE: December 2010 REVIEWED BY: T. V. H.	
REVISIONS		INIT. DATE	SIGNATURE: <i>George C. Brown</i> DATE: 11/11
			SIG. INVENTORY NO. 06-1317

PHASING DIAGRAM




PHASING DIAGRAM DETECTION LEGEND

- ← ● DETECTED MOVEMENT
- ← ○ UNDETECTED MOVEMENT (OVERLAP)
- UNSIGNALIZED MOVEMENT
- ← - - - PEDESTRIAN MOVEMENT

SIGNAL FACE	PHASE							
	01+5	02+5	03+5	04+5	01+6	02+6	03+6	04+6
11,12	←	←	←	←	←	←	←	←
21,22	R	R	G	G	R	R	R	Y
31	←	←	←	←	←	←	←	←
41,42	R	R	R	R	R	G	G	R
51	←	←	←	←	←	←	←	←
61,62	R	G	G	R	R	R	R	Y
71	←	←	←	←	←	←	←	←
81	R	R	R	R	R	G	G	R
82	R	R	R	R	G	R	R	R

SIGNAL FACE I.D.

All Heads L.E.D.




OASIS 2070L LOOP & DETECTOR INSTALLATION CHART											
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	DETECTOR PROGRAMMING						
					PHASE	CALLING	EXTENSION	FULL TIME DELAY	STRETCH TIME	DELAY TIME	SYSTEM LOOP
1A	6X60	0	2-4-2	-	1	Y	Y	-	-	-	Y
1B	6X60	0	2-4-2	-	1	Y	Y	-	-	-	Y
1C	6X60	+5	2-4-2	-	1	Y	Y	-	-	15	Y
2A	6X40	0	*	-	2	Y	Y	-	-	-	Y
2B	6X40	0	*	-	2	Y	Y	-	-	-	Y
3A	6X60	0	2-4-2	-	3	Y	Y	-	-	-	Y
4A	6X40	0	*	-	4	Y	Y	-	-	-	Y
4B	6X40	0	*	-	4	Y	Y	-	-	10	Y
5A	6X40	0	*	-	5	Y	Y	-	-	-	Y
6A,6B	6X6	70	5	-	6	Y	Y	-	-	-	Y
7A	6X60	0	*	-	7	Y	Y	-	-	-	Y
8A	6X60	0	2-4-2	-	8	Y	Y	-	-	-	Y

* Video Detection Zone

8 Phase Fully Actuated US 401-421/NC 27-210 Closed Loop System

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated July 2006 and "Standard Specifications for Roads and Structures" dated July 2006.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 1 and/or phase 5 may be lagged.
- Phase 3 and/or phase 7 may be lagged.
- Set all detector units to presence mode.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Closed loop system data: Controller Asset #0129.



OASIS 2070L TIMING CHART

FEATURE	PHASE							
	1	2	3	4	5	6	7	8
Min Green 1 *	7	10	7	7	7	10	7	7
Extension 1 *	1.0	2.0	1.0	2.0	2.0	3.0	2.0	1.0
Max Green 1 *	20	120	20	45	20	120	20	45
Yellow Clearance	3.0	3.8	3.0	4.0	3.0	3.8	3.0	3.7
Red Clearance	3.4	1.9	2.8	1.8	3.3	1.9	2.4	2.1
Walk 1 *	-	-	-	-	-	-	-	-
Don't Walk 1	-	-	-	-	-	-	-	-
Seconds Per Actuation *	-	-	-	-	-	-	-	-
Max Variable Initial *	-	-	-	-	-	-	-	-
Time Before Reduction *	-	-	-	-	-	-	-	-
Time To Reduce *	-	-	-	-	-	-	-	-
Minimum Gap	-	-	-	-	-	-	-	-
Recall Mode	-	MIN RECALL	-	-	-	MIN RECALL	-	-
Vehicle Call Memory	-	YELLOW	-	-	-	YELLOW	-	-
Dual Entry	-	-	-	-	-	-	-	-
Simultaneous Gap	ON	ON	ON	ON	ON	ON	ON	ON

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND

- | PROPOSED | EXISTING |
|--|--|
| ○ → Traffic Signal Head | ● → Traffic Signal Head |
| ● → Modified Signal Head | N/A |
| □ → Pedestrian Signal Head With Push Button & Sign | □ → Pedestrian Signal Head With Push Button & Sign |
| □ → Signal Pole with Guy | □ → Signal Pole with Guy |
| □ → Signal Pole with Sidewalk Guy | □ → Signal Pole with Sidewalk Guy |
| □ → Metal Strain Pole | □ → Metal Strain Pole |
| □ → Inductive Loop Detector | □ → Inductive Loop Detector |
| □ → Video Detection Area | □ → Video Detection Area |
| □ → Controller & Cabinet | □ → Controller & Cabinet |
| □ → Junction Box | □ → Junction Box |
| □ → Wheel Chair Ramp | N/A |
| □ → 2-in Underground Conduit | □ → 2-in Underground Conduit |
| N/A → Right of Way | --- → Right of Way |
| → → Directional Arrow | → → Directional Arrow |
| □ → Construction Zone | □ → Construction Zone |
| Ⓐ → Right Arrow "ONLY" Sign (R3-5R) | Ⓐ → Right Arrow "ONLY" Sign (R3-5R) |

Signal Upgrade/Temp 1

Prepared In the Offices of:

US 401-421/NC 27-210 (N Main St) at US 401/US 421-NC 27

Division 06 Harnett County Lillington

PLAN DATE: November 2010 REVIEWED BY: JPG

PREPARED BY: EM Minshew REVIEWED BY:

REVISIONS: INIT. DATE


SCALE: 0 30 1"=30'

SIG. INVENTORY NO. 06-0129T1

12/10/10

EDI MODEL 2010ECL-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Make sure jumpers SEL2-SEL5 are present on the monitor board.

NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Ensure that Red Enable is active at all times during normal operation. To prevent Red Failures on unused monitor channels, tie unused red monitor inputs 9,10, 11,12,13,14,15 & 16 to load switch AC+ per the cabinet manufacturer's instructions.
- Enable Simultaneous Gap-Out for all phases.
- Program phases 2 and 6 for Start Up In Green.
- Program phases 2 and 6 for Yellow Flash.
- The cabinet and controller are part of the US 401-421/ NC 27-210 Closed Loop System.

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S2P	S3	S4	S4P	S5	S6	S6P	S7	S8	S8P	S9	S10	S11	S12	S13	S14
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	11,12	82	21,22	NU	31	41,42	NU	51	61,62	NU	71	81,82	NU	NU	NU	NU	NU	NU
RED			128		101			134			107							
YELLOW			129		102			135			108							
GREEN			130		103			136			109							
RED ARROW	125				116			131			122							
YELLOW ARROW	126	126			117			132			123							
GREEN ARROW	127	127			118			133			124							
Hand icon																		
Person icon																		


NU = Not Used

EQUIPMENT INFORMATION

CONTROLLER.....2070L
 CABINET.....332 W/ AUXILIARY OUTPUT FILE
 SOFTWARE.....ECONOLITE OASIS
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 (12-STD, 6-AUX)
 LOAD SWITCHES USED.....S1,S2,S3,S4,S5,S6,S7,S8
 PHASES USED.....1,2,3,4,5,6,7,8
 OVERLAPS.....NONE

INPUT FILE POSITION LAYOUT

(front view)




EX. : 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
 ST = STOP TIME

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
1A	TB2-1,2	I1U	56	18	1	1	Y	Y			
1B	TB2-5,6	I2U	39	1	2	1	Y	Y			
1C	TB2-7,8	I2L	43	5	12	1	Y	Y			15
3A	TB4-5,6	I5U	58	20	3	3	Y	Y			
6A,6B	TB3-5,6	J2U	40	2	6	6	Y	Y			
8A	TB5-9,10	J6U	42	4	8	8	Y	Y			

INPUT FILE POSITION LEGEND: J2L



SPECIAL DETECTOR NOTE

Install a video detection system for vehicle detection in video detection zones 2A, 2B, 4A, 4B, 5A, and 7A shown on the Signal Design plans. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the detection schemes shown on the Signal Design plans.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0129T1
 DESIGNED: November 2010
 SEALED: 12/10/10
 REVISED: N/A

Signal Upgrade - Temp 1

ELECTRICAL AND PROGRAMMING DETAILS FOR: US 401-421/NC 27-210 (N Main St) at US 401/US 421-NC 27

Division 6 Harnett County Lillington

PLANNED BY: December 2010 REVIEWED BY: T. Joyce

PREPARED BY: S. Armstrong REVIEWED BY:

REVISIONS INIT. DATE


750 N. Grandfield Hwy, Garner, NC 27529

SEAL NORTH CAROLINA PROFESSIONAL ENGINEER SEAL 022013 GEORGE C. BROWN ENGINEER

Signature: George C. Brown 12/15/10

SIG. INVENTORY NO. 06-0129T1

PHASING DIAGRAM




PHASING DIAGRAM DETECTION LEGEND

- ←●→ DETECTED MOVEMENT
- ←○→ UNDETECTED MOVEMENT (OVERLAP)
- UNSIGNALIZED MOVEMENT
- PEDESTRIAN MOVEMENT

TABLE OF OPERATION

SIGNAL FACE	PHASE								
	01+5	01+6	02+5	02+6	03+7	03+8	04+7	04+8	FLASH
11,12	←	←	←	←	←	←	←	←	←
21,22	R	R	G	G	R	R	R	R	Y
31	←	←	←	←	←	←	←	←	←
41,42	R	R	R	R	R	R	G	G	R
51	←	←	←	←	←	←	←	←	←
61,62	R	G	R	G	R	R	R	R	Y
71	←	←	←	←	←	←	←	←	←
81	R	R	R	R	R	G	R	G	R
82	R	R	R	R	R	G	R	R	R

SIGNAL FACE I.D.




OASIS 2070L LOOP & DETECTOR INSTALLATION CHART

LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	DETECTOR PROGRAMMING				SYSTEM LOOP	NEW CARD
					PHASE	CALLING EXTENSION	STRETCH TIME	DELAY TIME		
1A	6X60	0	2-4-2	-	1	Y	Y	-	-	-
1B	6X60	0	2-4-2	-	1	Y	Y	-	-	-
1C	6X60	+5	2-4-2	-	1	Y	Y	-	15	-
2A	6X40	0	*	-	2	Y	Y	-	-	-
2B	6X40	0	*	-	2	Y	Y	-	-	-
3A	6X60	0	2-4-2	-	3	Y	Y	-	-	-
4A	6X40	0	*	-	4	Y	Y	-	-	-
4B	6X40	0	*	-	4	Y	Y	-	10	-
5A	6X40	0	*	-	5	Y	Y	-	-	-
6A,6B	6X6	70	5	-	6	Y	Y	-	-	-
7A	6X60	0	*	-	7	Y	Y	-	-	-
8A	6X60	0	2-4-2	-	8	Y	Y	-	-	-

8 Phase Fully Actuated US 401-421/NC 27-210 Closed Loop System

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated July 2006 and "Standard Specifications for Roads and Structures" dated July 2006.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 1 and/or phase 5 may be lagged.
- Phase 3 and/or phase 7 may be lagged.
- Set all detector units to presence mode.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Closed loop system data: Controller Asset #0129.



OASIS 2070L TIMING CHART

FEATURE	PHASE							
	1	2	3	4	5	6	7	8
Min Green 1*	7	10	7	7	7	10	7	7
Extension 1*	1.0	2.0	1.0	2.0	2.0	3.0	2.0	1.0
Max Green 1*	20	120	20	45	20	120	20	45
Yellow Clearance	3.0	3.8	3.0	4.0	3.0	3.8	3.0	3.7
Red Clearance	3.4	1.9	2.8	1.8	3.3	1.9	2.4	2.1
Walk 1*	-	-	-	-	-	-	-	-
Don't Walk 1	-	-	-	-	-	-	-	-
Seconds Per Actuation*	-	-	-	-	-	-	-	-
Max Variable Initial*	-	-	-	-	-	-	-	-
Time Before Reduction*	-	-	-	-	-	-	-	-
Time To Reduce*	-	-	-	-	-	-	-	-
Minimum Gap	-	-	-	-	-	-	-	-
Recall Mode	-	MIN RECALL	-	-	-	MIN RECALL	-	-
Vehicle Call Memory	-	YELLOW	-	-	-	YELLOW	-	-
Dual Entry	-	-	-	-	-	-	-	-
Simultaneous Gap	ON	ON	ON	ON	ON	ON	ON	ON

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND

PROPOSED	EXISTING
○→ Traffic Signal Head	●→ Traffic Signal Head
○→ Modified Signal Head	N/A
○→ Sign	N/A
○→ Pedestrian Signal Head With Push Button & Sign	○→ Pedestrian Signal Head
○→ Signal Pole with Guy	○→ Signal Pole with Guy
○→ Signal Pole with Sidewalk Guy	○→ Signal Pole with Sidewalk Guy
○→ Metal Strain Pole	○→ Metal Strain Pole
○→ Inductive Loop Detector	○→ Inductive Loop Detector
○→ Video Detection Area	○→ Video Detection Area
○→ Controller & Cabinet	○→ Controller & Cabinet
○→ Junction Box	○→ Junction Box
○→ Wheel Chair Ramp	N/A
○→ 2-in Underground Conduit	○→ 2-in Underground Conduit
N/A	○→ Right of Way
○→ Directional Arrow	○→ Directional Arrow
○→ Construction Zone	○→ Construction Zone
(A) Right Arrow "ONLY" Sign (R3-5R)	(A) Right Arrow "ONLY" Sign (R3-5R)
(B) "YIELD" Sign (R1-2)	(B) "YIELD" Sign (R1-2)

Signal Upgrade/Temp 2


Prepared in the Offices of:

US 401-421/NC 27-210 (N Main St) at US 401/US 421-NC 27
 Division 06 Harnett County Lillington
 PLAN DATE: November 2010 REVIEWED BY: JPG
 PREPARED BY: EM Minshew REVIEWED BY:
 SCALE: 1"=30'
 REVISIONS: _____ INIT. DATE
 SIGNATURE: _____ DATE: 12/10/10
 SIG. INVENTORY NO. 06-012972

10-DEC-2010 15:20
 P:\MTC\106\Signal\060129-210\temp\2_01\0madd.dgn
 J. J. Gallaway


EDI MODEL 2010ECL-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Make sure jumpers SEL2-SEL5 are present on the monitor board.



NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Ensure that Red Enable is active at all times during normal operation. To prevent Red Failures on unused monitor channels, tie unused red monitor inputs 9,10, 11,12,13,14,15 & 16 to load switch AC+ per the cabinet manufacturer's instructions.
- Enable Simultaneous Gap-Out for all phases.
- Program phases 2 and 6 for Start Up In Green.
- Program phases 2 and 6 for Yellow Flash.
- The cabinet and controller are part of the US 401-421/ NC 27-210 Closed Loop System.

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S2P	S3	S4	S4P	S5	S6	S6P	S7	S8	S8P	S9	S10	S11	S12	S13	S14
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	11,12	82	21,22	NU	31	41,42	NU	51	61,62	NU	71	81,82	NU	NU	NU	NU	NU	NU
RED			128		101			134			107							
YELLOW			129		102			135			108							
GREEN			130		103			136			109							
RED ARROW	125				116			131			122							
YELLOW ARROW	126	126			117			132			123							
GREEN ARROW	127	127			118			133			124							
Hand icon																		
Person icon																		


NU = Not Used

EQUIPMENT INFORMATION

CONTROLLER.....2070L
 CABINET.....332 W/ AUXILIARY OUTPUT FILE
 SOFTWARE.....ECONOLITE OASIS
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 (12-STD, 6-AUX)
 LOAD SWITCHES USED.....S1,S2,S3,S4,S5,S6,S7,S8
 PHASES USED.....1,2,3,4,5,6,7,8
 OVERLAPS.....NONE

INPUT FILE POSITION LAYOUT

(front view)




EX. : 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
 ST = STOP TIME

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
1A	TB2-1,2	I1U	56	18	1	1	Y	Y			
1B	TB2-5,6	I2U	39	1	2	1	Y	Y			
1C	TB2-7,8	I2L	43	5	12	1	Y	Y			15
3A	TB4-5,6	I5U	58	20	3	3	Y	Y			
6A,6B	TB3-5,6	J2U	40	2	6	6	Y	Y			
8A	TB5-9,10	J6U	42	4	8	8	Y	Y			

INPUT FILE POSITION LEGEND: J2L



THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0129T2
 DESIGNED: November 2010
 SEALED: 12/10/10
 REVISED: N/A

SPECIAL DETECTOR NOTE

Install a video detection system for vehicle detection in video detection zones 2A, 2B, 4A, 4B, 5A, and 7A shown on the Signal Design plans. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the detection schemes shown on the Signal Design plans.

Signal Upgrade - Temp 2

ELECTRICAL AND PROGRAMMING DETAILS FOR: **US 401-421/NC 27-210 (N Main St) at US 401/US 421-NC 27**

Prepared In the Office of:

Division 6 Harnett County Lillington

PLAN DATE: December 2010 REVIEWED BY: *T. J. J.*


PREPARED BY: S. Armstrong REVIEWED BY:

REVISIONS: INIT. DATE


Signature: *George C. Brown* 12/15/10
 SEAL: NORTH CAROLINA PROFESSIONAL ENGINEER SEAL 022013 GEORGE C. BROWN

SIG. INVENTORY NO. 06-0129T2

PHASING DIAGRAM




PHASING DIAGRAM DETECTION LEGEND



SIGNAL FACE	PHASE								
	01+5	01+6	02+5	02+6	03+7	03+8	04+7	04+8	FLASH
11,12	-	-	-	-	-	-	-	-	-
21,22	R	R	G	G	R	R	R	R	Y
23,24	R	R	-	-	-	-	-	-	Y
31	-	-	-	-	-	-	-	-	-
41,42	R	R	R	R	R	R	G	G	R
51	-	-	-	-	-	-	-	-	-
61,62	R	G	R	G	R	R	R	R	Y
71	-	-	-	-	-	-	-	-	-
81	R	R	R	R	R	G	R	G	R
82	R	R	R	R	R	G	R	R	R

SIGNAL FACE I.D.

All Heads L.E.D.




LOOP	SIZE (FT)	INDUCTIVE LOOPS		DETECTOR PROGRAMMING					SYSTEM LOOP	NEW CARD
		DISTANCE FROM STOPBAR (FT)	TURNS	PHASE	CALLING	EXTENSION	STRETCH TIME	DELAY TIME		
1A	6X60	0	2-4-2	-	1	Y	Y	-	-	-
1B	6X60	0	2-4-2	-	1	Y	Y	-	-	-
1C	6X60	+5	2-4-2	-	1	Y	Y	-	-	15
2A	6X40	0	*	-	2	Y	Y	-	-	-
3A	6X60	0	2-4-2	-	3	Y	Y	-	-	-
4A	6X40	0	*	-	4	Y	Y	-	-	-
4B	6X40	0	*	-	4	Y	Y	-	-	10
5A	6X40	0	*	-	5	Y	Y	-	-	-
6A,6B	6X6	70	5	-	6	Y	Y	-	-	-
7A	6X60	0	*	-	7	Y	Y	-	-	-
8A	6X60	0	2-4-2	-	8	Y	Y	-	-	-

* Video Detection Zone

8 Phase Fully Actuated US 401-421/NC 27-210 Closed Loop System

NOTES


- Refer to "Roadway Standard Drawings NCDOT" dated July 2006 and "Standard Specifications for Roads and Structures" dated July 2006.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 1 and/or phase 5 may be lagged.
- Phase 3 and/or phase 7 may be lagged.
- Set all detector units to presence mode.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Closed loop system data: Controller Asset #0129.



FEATURE	OASIS 2070L TIMING CHART							
	PHASE							
	1	2	3	4	5	6	7	8
Min Green 1*	7	10	7	7	7	10	7	7
Extension 1*	1.0	2.0	1.0	2.0	2.0	3.0	2.0	1.0
Max Green 1*	30	60	20	40	20	60	20	40
Yellow Clearance	3.0	3.8	3.0	4.0	3.0	3.8	3.0	3.7
Red Clearance	3.7	2.4	2.9	2.3	3.6	2.1	2.4	2.1
Walk 1*	-	-	-	-	-	-	-	-
Don't Walk 1	-	-	-	-	-	-	-	-
Seconds Per Actuation *	-	-	-	-	-	-	-	-
Max Variable Initial *	-	-	-	-	-	-	-	-
Time Before Reduction *	-	-	-	-	-	-	-	-
Time To Reduce *	-	-	-	-	-	-	-	-
Minimum Gap	-	-	-	-	-	-	-	-
Recall Mode	-	MIN RECALL	-	-	-	MIN RECALL	-	-
Vehicle Call Memory	-	YELLOW	-	-	-	YELLOW	-	-
Dual Entry	-	-	-	-	-	-	-	-
Simultaneous Gap	ON	ON	ON	ON	ON	ON	ON	ON

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND




Signal Upgrade/Temp 3

	Prepared in the Offices of: US 401-421/NC 27-210 (N Main St) at US 401/US 421-NC 27		SEAL 29904 JASON P. GALINSKY ENGINEER STATE OF NORTH CAROLINA License No. 29904	
	Division 06 Harnett County Lillington PREPARED BY: EM Minshew REVIEWED BY: JPG	PREPARED BY: EM Minshew REVIEWED BY: JPG		PREPARED BY: EM Minshew REVIEWED BY: JPG
	SCALE 0 30 1"=30'			


EDI MODEL 2010ECL-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Make sure jumpers SEL2-SEL5 are present on the monitor board.



NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Ensure that Red Enable is active at all times during normal operation. To prevent Red Failures on unused monitor channels, tie unused red monitor inputs 9,10, 12,13,14,15 & 16 to load switch AC+ per the cabinet manufacturer's instructions.
- Enable Simultaneous Gap-Out for all phases.
- Program phases 2 and 6 for Start Up In Green.
- Program phases 2 and 6 for Yellow Flash.
- The cabinet and controller are part of the US 401-421/ NC 27-210 Closed Loop System.

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S2P	S3	S4	S4P	S5	S6	S6P	S7	S8	S8P	S9	S10	S11	S12	S13	S14
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	11,12	82	21,22	NU	31	41,42	NU	51	61,62	NU	71	81,82	NU	NU	NU	23,24	NU	NU
RED		128			101			134			107					A114		
YELLOW			129		102			135			108							
GREEN			130		103			136			109							
RED ARROW	125				116			131			122							
YELLOW ARROW	126	126			117			132			123					A115		
GREEN ARROW	127	127			118			133			124					A116		
Hand icon																		
Person icon																		

NU = Not Used

EQUIPMENT INFORMATION

CONTROLLER.....2070L
 CABINET.....332 W/ AUXILIARY OUTPUT FILE
 SOFTWARE.....ECONOLITE OASIS
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 (12-STD, 6-AUX)
 LOAD SWITCHES USED.....S1,S2,S3,S4,S5,S6,S7,S8,S12
 PHASES USED.....1,2,3,4,5,6,7,8
 OVERLAP C.....2+3

OVERLAP PROGRAMMING DETAIL

(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS), THEN '1' (VEHICLE OVERLAP SETTINGS).


PRESS '+' TWICE

PAGE 1: VEHICLE OVERLAP 'C' SETTINGS
 PHASE: 12345678910111213141516
 VEH OVL PARENTS: XX
 VEH OVL NOT VEH:
 VEH OVL NOT PED:
 VEH OVL GRN EXT:
 STARTUP COLOR: _ RED _ YELLOW _ GREEN
 FLASH COLORS: _ RED _ YELLOW _ GREEN
 SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
 FLASH YELLOW IN CONTROLLER FLASH?...Y
 GREEN EXTENSION (0-255 SEC)...0
 YELLOW CLEAR (0=PARENT,3-25.5 SEC)...0.0
 RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
 OUTPUT AS PHASE # (0=NONE, 1-16)...0

OVERLAP PROGRAMMING COMPLETE

INPUT FILE POSITION LAYOUT

(front view)




EX.: 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
 ST = STOP TIME

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
1A	TB2-1,2	I1U	56	18	1	1	Y	Y			
1B	TB2-5,6	I2U	39	1	2	1	Y	Y			
1C	TB2-7,8	I2L	43	5	12	1	Y	Y			15
3A	TB4-5,6	I5U	58	20	3	3	Y	Y			
6A,6B	TB3-5,6	J2U	40	2	6	6	Y	Y			
8A	TB5-9,10	J6U	42	4	8	8	Y	Y			

INPUT FILE POSITION LEGEND: J2L



SPECIAL DETECTOR NOTE

Install a video detection system for vehicle detection in video detection zones 2A, 4A, 4B, 5A, and 7A shown on the Signal Design plans. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the detection schemes shown on the Signal Design plans.

Signal Upgrade - Temp 3

ELECTRICAL AND PROGRAMMING DETAILS FOR: US 401-421/NC 27-210 (N Main St) at US 401/US 421-NC 27

Division 6 Harnett County Lillington

PLAN DATE: December 2010 REVIEWED BY: T. J. J. J.

PREPARED BY: S. Armstrong REVIEWED BY:

REVISIONS INIT. DATE


750 N. Greenfield Pkwy, Garner, NC 27529

Signature: George C. Brown 12/15/10

SIG. INVENTORY NO. 06-0129T3

13-DEC-2010 08:48 S:\TSS\SM\TSS\Sig\01\sm\work\c\c\sig\060129T3.sm.ele.xxx.dgn

PHASING DIAGRAM




PHASING DIAGRAM DETECTION LEGEND

- ← ● → DETECTED MOVEMENT
- ← ○ → UNDETECTED MOVEMENT (OVERLAP)
- UNSIGNALIZED MOVEMENT
- ← ○ → PEDESTRIAN MOVEMENT

TABLE OF OPERATION

SIGNAL FACE	PHASE							
	01+5	02+6	03+7	04+8	01+6	02+5	03+8	04+7
11,12	←	←	←	←	←	←	←	←
21,22	R	R	G	G	R	R	R	Y
23,24	R	R	←	←	←	←	←	←
31	←	←	←	←	←	←	←	←
41,42	R	R	R	R	R	R	G	G
51	←	←	←	←	←	←	←	←
61,62	R	G	R	G	R	R	R	Y
71	←	←	←	←	←	←	←	←
81	R	R	R	R	R	G	R	G
82	←	←	←	←	←	←	←	←

SIGNAL FACE I.D.



OASIS 2070L LOOP & DETECTOR INSTALLATION CHART


LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	DETECTOR PROGRAMMING						
					PHASE	CALLING	EXTENSION	STRETCH TIME	DELAY TIME	SYSTEM LOOP	NEW CARD
1A	6X60	0	2-4-2	-	1	Y	Y	-	-	-	-
1B	6X60	0	2-4-2	-	1	Y	Y	-	-	-	-
1C	6X60	+5	2-4-2	-	1	Y	Y	-	15	-	-
2A	6X40	0	*	-	2	Y	Y	-	-	-	-
2B	6X40	0	*	-	2	Y	Y	-	-	-	-
3A	6X60	0	2-4-2	-	3	Y	Y	-	-	-	-
4A	6X40	0	*	-	4	Y	Y	-	-	-	-
4B	6X40	0	*	-	4	Y	Y	-	10	-	-
5A	6X40	0	*	-	5	Y	Y	-	-	-	-
6A,6B	6X6	70	5	-	6	Y	Y	-	-	-	-
7A	6X60	0	*	-	7	Y	Y	-	-	-	-
8A	6X60	0	2-4-2	-	8	Y	Y	-	-	-	-

* Video Detection Zone

8 Phase Fully Actuated US 401-421/NC 27-210 Closed Loop System

NOTES

- Refer to "Roadway Standard Drawings NCDOT" dated July 2006 and "Standard Specifications for Roads and Structures" dated July 2006.
- Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- Phase 1 and/or phase 5 may be lagged.
- Phase 3 and/or phase 7 may be lagged.
- Set all detector units to presence mode.
- Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- Closed loop system data: Controller Asset #0129.



OASIS 2070L TIMING CHART

FEATURE	PHASE							
	1	2	3	4	5	6	7	8
Min Green 1 *	7	10	7	7	7	10	7	7
Extension 1 *	1.0	2.0	1.0	2.0	2.0	3.0	2.0	1.0
Max Green 1 *	20	120	20	45	20	120	20	45
Yellow Clearance	3.0	3.8	3.0	4.0	3.0	3.8	3.0	3.7
Red Clearance	3.7	2.4	2.9	2.3	3.6	2.1	2.4	2.1
Walk 1 *	-	-	-	-	-	-	-	-
Don't Walk 1	-	-	-	-	-	-	-	-
Seconds Per Actuation *	-	-	-	-	-	-	-	-
Max Variable Initial *	-	-	-	-	-	-	-	-
Time Before Reduction *	-	-	-	-	-	-	-	-
Time To Reduce *	-	-	-	-	-	-	-	-
Minimum Gap	-	-	-	-	-	-	-	-
Recall Mode	-	MIN RECALL	-	-	-	MIN RECALL	-	-
Vehicle Call Memory	-	YELLOW	-	-	-	YELLOW	-	-
Dual Entry	-	-	-	-	-	-	-	-
Simultaneous Gap	ON	ON	ON	ON	ON	ON	ON	ON

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

LEGEND

- | PROPOSED | EXISTING |
|--|--|
| ○ → Traffic Signal Head | ● → Traffic Signal Head |
| ● → Modified Signal Head | N/A |
| ○ → Sign | ○ → Sign |
| ○ → Pedestrian Signal Head With Push Button & Sign | ○ → Pedestrian Signal Head With Push Button & Sign |
| ○ → Signal Pole with Guy | ○ → Signal Pole with Guy |
| ○ → Signal Pole with Sidewalk Guy | ○ → Signal Pole with Sidewalk Guy |
| ○ → Metal Strain Pole | ○ → Metal Strain Pole |
| ○ → Inductive Loop Detector | ○ → Inductive Loop Detector |
| ○ → Video Detection Area | ○ → Video Detection Area |
| ○ → Controller & Cabinet | ○ → Controller & Cabinet |
| ○ → Junction Box | ○ → Junction Box |
| ○ → Wheel Chair Ramp | N/A |
| ○ → 2-in Underground Conduit | ○ → 2-in Underground Conduit |
| N/A | ○ → Right of Way |
| ○ → Directional Arrow | ○ → Directional Arrow |
| ○ → Construction Zone | ○ → Construction Zone |
| ○ → Right Arrow "ONLY" Sign (R3-5R) | ○ → Right Arrow "ONLY" Sign (R3-5R) |
| ○ → "U-TURN YIELD TO RIGHT TURN" Sign (R10-16) | ○ → "U-TURN YIELD TO RIGHT TURN" Sign (R10-16) |

Signal Upgrade/Temp 4

US 401-421/NC 27-210 (N Main St) at US 401/US 421-NC 27

Division 06 Harnett County Lillington

Prepared In the Offices of:

 750 N. Greenfield Pkwy, Garner, NC 27529


PREPARED BY: EM Winshew
 REVISIONS: _____
 SCALE: 0 30
 1"=30'

SEAL
 NORTH CAROLINA
 PROFESSIONAL ENGINEER
 J. GALLAWAY
 12/10/10
 DATE

08-MAR-2011 13:50:13 P:\GIS\Projects\GIS\06-0129\060129-01\temp_4_2010.mxd-dgn

EDI MODEL 2010ECL-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



- REMOVE DIODE JUMPERS 1-5, 1-6, 2-5, 2-6, 2-II, 3-7, 3-8, 3-II, 4-7, 4-8, 5-II, 6-II, 7-II, and 8-II.
- REMOVE JUMPERS AS SHOWN
- NOTES:
- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
 - Make sure jumpers SEL2-SEL5 are present on the monitor board.



NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Ensure that Red Enable is active at all times during normal operation. To prevent Red Failures on unused monitor channels, tie unused red monitor inputs 9,10, 12,13,14,15 & 16 to load switch AC+ per the cabinet manufacturer's instructions.
- Enable Simultaneous Gap-Out for all phases.
- Program phases 2 and 6 for Start Up In Green.
- Program phases 2 and 6 for Yellow Flash.
- The cabinet and controller are part of the US 401-421/ NC 27-210 Closed Loop System.

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S2P	S3	S4	S4P	S5	S6	S6P	S7	S8	S8P	S9	S10	S11	S12	S13	S14
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	11,12	82	21,22	NU	31	41,42	NU	51	61,62	NU	71	81,82	NU	NU	NU	23,24	NU	NU
RED		128			101			134			107					A114		
YELLOW			129		102			135			108							
GREEN			130		103			136			109							
RED ARROW	125				116			131			122							
YELLOW ARROW	126	126			117			132			123					A115		
GREEN ARROW	127	127			118			133			124					A116		
Hand icon																		
Person icon																		

NU = Not Used

EQUIPMENT INFORMATION

CONTROLLER.....2070L
 CABINET.....332 W/ AUXILIARY OUTPUT FILE
 SOFTWARE.....ECONOLITE OASIS
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 (12-STD, 6-AUX)
 LOAD SWITCHES USED.....S1,S2,S3,S4,S5,S6,S7,S8,S12
 PHASES USED.....1,2,3,4,5,6,7,8
 OVERLAP C.....2+3

OVERLAP PROGRAMMING DETAIL


(program controller as shown below)
 FROM MAIN MENU PRESS '8' (OVERLAPS), THEN '1' (VEHICLE OVERLAP SETTINGS).
 PRESS '+' TWICE

PAGE 1: VEHICLE OVERLAP 'C' SETTINGS
 PHASE: 12345678910111213141516
 VEH OVL PARENTS: XX
 VEH OVL NOT VEH: :
 VEH OVL NOT PED: :
 VEH OVL GRN EXT: :
 STARTUP COLOR: - RED - YELLOW - GREEN
 FLASH COLORS: - RED - YELLOW - GREEN
 SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
 FLASH YELLOW IN CONTROLLER FLASH?...Y
 GREEN EXTENSION (0-255 SEC).....0
 YELLOW CLEAR (0=PARENT,3-25.5 SEC)...0.0
 RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
 OUTPUT AS PHASE # (0=NONE, 1-16)....0

OVERLAP PROGRAMMING COMPLETE

INPUT FILE POSITION LAYOUT


(front view)



EX.: 1A, 2A, ETC. = LOOP NO.'S
 FS = FLASH SENSE
 ST = STOP TIME

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
1A	TB2-1,2	I1U	56	18	1	1	Y	Y			
1B	TB2-5,6	I2U	39	1	2	1	Y	Y			
1C	TB2-7,8	I2L	43	5	12	1	Y	Y			15
3A	TB4-5,6	I5U	58	20	3	3	Y	Y			
6A,6B	TB3-5,6	J2U	40	2	6	6	Y	Y			
8A	TB5-9,10	J6U	42	4	8	8	Y	Y			



SPECIAL DETECTOR NOTE

Install a video detection system for vehicle detection in video detection zones 2A, 2B, 4A, 4B, 5A, 7A and 7A shown on the Signal Design plans. Perform installation according to manufacturer's directions and NCDOT engineer-approved mounting locations to accomplish the detection schemes shown on the Signal Design plans.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0129T4
 DESIGNED: November 2010
 SEALED: 12/10/10
 REVISED: N/A

Signal Upgrade - Temp 4

ELECTRICAL AND PROGRAMMING DETAILS FOR: US 401-421/NC 27-210 (N Main St) at US 401/US 421-NC 27

Division 6 Harnett County Lillington

PLAN DATE: December 2010 REVIEWED BY: T. J. J.

PREPARED BY: S. Armstrong REVIEWED BY:

REVISIONS: INIT. DATE

750 N. Greenfield Pkwy, Garner, NC 27529



SEAL NORTH CAROLINA PROFESSIONAL ENGINEER SEAL 022013 GEORGE C. BROWN

Signature: [Signature] DATE: 12/15/10

SIG. INVENTORY NO. 06-0129T4

13-DEC-2010 08:50 S:\TSS\JMT\TSS\SIGNAL\WORK\KGR\060129T4.sm.ele...xxx.dgn


PHASING DIAGRAM



SIGNAL FACE	PHASE							
	01+5	01+6	02+5	02+6	03+7	03+8	04+7	04+8
11,12	←	←	←	←	←	←	←	←
21,22	R	R	G	G	R	R	R	Y
23,24	R	R	→	→	→	→	→	→
31	←	←	←	←	←	←	←	←
41,42	R	R	R	R	R	R	G	G
51	←	←	←	←	←	←	←	←
61,62	R	G	R	G	R	R	R	Y
71	←	←	←	←	←	←	←	←
81	R	R	R	R	R	G	R	R
82	R	R	R	R	R	G	R	R
P41,P42	DW	DW	DW	DW	DW	W	W	DRK
P61,P62	DW	W	DW	W	DW	DW	DW	DRK

W- Walk
DW- Don't Walk
DRK- Dark

SIGNAL FACE I.D.
All Heads L.E.D.




OASIS 2070L LOOP & DETECTOR INSTALLATION CHART												
INDUCTIVE LOOPS					DETECTOR PROGRAMMING							
LOOP	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	PHASE	CALLING	EXTENSION	FULL TIME DELAY	STRETCH TIME	DELAY TIME	SYSTEM LOOP	NEW CARD
1A	6X40	0	2-4-2	Y	1	Y	Y	-	-	-	-	-
1B	6X40	0	2-4-2	Y	1	Y	Y	-	-	-	-	-
1C	6X40	0	2-4-2	Y	1	Y	Y	-	-	10	-	-
2A,2B	6X6	70	3	Y	2	Y	Y	-	-	-	-	Y
3A	6X40	0	2-4-2	Y	3	Y	Y	-	-	-	-	-
4A	6X40	0	2-4-2	Y	4	Y	Y	-	-	-	-	Y
4B	6X40	0	2-4-2	Y	4	Y	Y	-	-	10	-	Y
5A	6X40	0	2-4-2	Y	5	Y	Y	-	-	-	-	Y
6A,6B	6X6	70	5	Y	6	Y	Y	-	-	-	-	-
7A	6X40	0	2-4-2	Y	7	Y	Y	-	-	-	-	Y
8A	6X40	0	2-4-2	Y	8	Y	Y	-	-	-	-	Y
S11	6X6	+210	3	-	-	-	-	-	-	-	-	Y
S12	6X6	+210	3	-	-	-	-	-	-	-	-	Y
S19	6X6	+180	4	-	-	-	-	-	-	-	-	Y
S20	6X6	+180	4	-	-	-	-	-	-	-	-	Y

8 Phase Fully Actuated US 401-421/NC 27-210 Closed Loop System

NOTES


1. Refer to "Roadway Standard Drawings NCDOT" dated July 2006 and "Standard Specifications for Roads and Structures" dated July 2006.
2. Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
3. Phase 1 and/or phase 5 may be lagged.
4. Phase 3 and/or phase 7 may be lagged.
5. Set all detector units to presence mode.
6. Omit "WALK" and flashing "DON'T WALK" with no pedestrian calls.
7. Program pedestrian heads to countdown the flashing "Don't Walk" time only.
8. Reposition head 51.
9. Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
10. Closed loop system data: Controller Asset #0129.



OASIS 2070L TIMING CHART

FEATURE	PHASE							
	1	2	3	4	5	6	7	8
Min Green 1 *	7	10	7	7	7	10	7	7
Extension 1 *	1.0	3.0	1.0	1.0	1.0	3.0	1.0	1.0
Max Green 1 *	20	120	20	45	20	120	20	45
Yellow Clearance	3.0	3.8	3.0	4.0	3.0	3.8	3.0	3.7
Red Clearance	3.8	2.6	2.4	2.5	3.6	2.7	3.1	2.4
Walk 1 *	-	-	-	7	-	7	-	-
Don't Walk 1	-	-	-	33	-	26	-	-
Seconds Per Actuation *	-	-	-	-	-	-	-	-
Max Variable Initial *	-	-	-	-	-	-	-	-
Time Before Reduction *	-	-	-	-	-	-	-	-
Time To Reduce *	-	-	-	-	-	-	-	-
Minimum Gap	-	-	-	-	-	-	-	-
Recall Mode	-	MIN RECALL	-	-	-	MIN RECALL	-	-
Vehicle Call Memory	-	YELLOW	-	-	-	YELLOW	-	-
Dual Entry	-	-	-	-	-	-	-	-
Simultaneous Gap	ON	ON	ON	ON	ON	ON	ON	ON

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.



Signal Upgrade

Prepared in the Offices of:

US 401-421/NC 27-210 (N Main St) at US 401/US 421-NC 27

Division 06 Harnett County Lillington

PLAN DATE: November 2010 REVIEWED BY: JPG

PREPARED BY: EM Winshew REVIEWED BY:

REVISIONS: _____ INIT. DATE

SCALE: 1"=30'

DATE: 12/10/10

SIG. INVENTORY NO. 06-0129


10-DEC-2010 16:11:03 \\s:\projects\10129\10129.dwg User: jg... 2010mstda.dgn

EDI MODEL 2010ECL-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)




REMOVE DIODE JUMPERS 1-5, 1-6, 1-15, 2-5, 2-6, 2-11, 2-15, 3-7, 3-8, 3-11, 4-7, 4-8, 4-14, 5-11, 6-11, 6-15, 7-11, 7-14, 8-11, 8-14, and 11-15.



REMOVE JUMPERS AS SHOWN

NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Make sure jumpers SEL2-SEL5 are present on the monitor board.



NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Ensure that Red Enable is active at all times during normal operation. To prevent Red Failures on unused monitor channels, tie unused red monitor inputs 9,10, 12,13,14,15 & 16 to load switch AC+ per the cabinet manufacturer's instructions.
- Enable Simultaneous Gap-Out for all phases.
- Program phases 2 and 6 for Start Up In Green.
- Program phases 4 and 6 for 'STARTUP PED CALL'.
- Program phases 2 and 6 for Yellow Flash.
- The cabinet and controller are part of the US 401-421/ NC 27-210 Closed Loop System.

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S2P	S3	S4	S4P	S5	S6	S6P	S7	S8	S8P	S9	S10	S11	S12	S13	S14
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE
SIGNAL HEAD NO.	11,12	82	21,22	NU	31	41,42	P41, P42	51	61,62	P61, P62	71	81,82	NU	NU	NU	23,24	NU	NU
RED		128			101			134			107							
YELLOW		129			102			135			108							
GREEN		130			103			136			109							
RED ARROW	125				116			131			122						A114	
YELLOW ARROW	126	126			117			132			123						A115	
GREEN ARROW	127	127			118			133			124						A116	
Hand icon							104			119								
Person icon							106			121								

NU = Not Used

EQUIPMENT INFORMATION

CONTROLLER.....2070L
 CABINET.....332 W/ AUXILIARY OUTPUT FILE
 SOFTWARE.....ECONOLITE OASIS
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 (12-STD, 6-AUX)
 LOAD SWITCHES USED.....S1,S2,S3,S4,S4P,S5,S6,S6P,S7,S8,S12
 PHASES USED.....1,2,3,4,4 PED,5,6,6 PED,7,8
 OVERLAP C.....2+3

OVERLAP PROGRAMMING DETAIL

(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS), THEN '1' (VEHICLE OVERLAP SETTINGS).

PRESS '+' TWICE

PAGE 1: VEHICLE OVERLAP 'C' SETTINGS
 PHASE: 12345678910111213141516
 VEH OVL PARENTS: XX
 VEH OVL NOT VEH:
 VEH OVL NOT PED:
 VEH OVL GRN EXT:
 STARTUP COLOR: _ RED _ YELLOW _ GREEN
 FLASH COLORS: _ RED _ YELLOW _ GREEN
 SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
 FLASH YELLOW IN CONTROLLER FLASH?...Y
 GREEN EXTENSION (0-255 SEC)...0.0
 YELLOW CLEAR (0=PARENT,3-25.5 SEC)...0.0
 RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
 OUTPUT AS PHASE # (0=NONE, 1-16)...0

OVERLAP PROGRAMMING COMPLETE

INPUT FILE POSITION LAYOUT

(front view)

FILE "I"	1	2	3	4	5	6	7	8	9	10	11	12	13	14
U	∅ 1 1A	∅ 1 1B	∅ 2 2A,2B	S T	∅ 3 3A	∅ 4 4A	S T	S T	SYS. DET. S11	S T	S T	NOT USED	∅ 6 PED DC ISOLATOR	FS DC ISOLATOR
L	NOT USED	∅ 1 1C	NOT USED	Y T	NOT USED	∅ 4 4B	Y T	Y T	SYS. DET. S12	Y T	Y T	∅ 4 PED DC ISOLATOR	NOT USED	ST DC ISOLATOR
U	∅ 5 5A	∅ 6 6A,6B	S T	S T	∅ 7 7A	∅ 8 8A	S T	S T	SYS. DET. S19	S T	S T	S T	S T	S T
L	NOT USED	NOT USED	Y T	Y T	NOT USED	NOT USED	Y T	Y T	SYS. DET. S20	Y T	Y T	Y T	Y T	Y T

EX.: 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
 ST = STOP TIME

INPUT FILE CONNECTION & PROGRAMMING CHART


LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
1A	TB2-1,2	I1U	56	18	1	1	Y	Y			
1B	TB2-5,6	I2U	39	1	2	1	Y	Y			
1C	TB2-7,8	I2L	43	5	12	1	Y	Y			10
2A,2B	TB2-9,10	I3U	63	25	32	2	Y	Y			
3A	TB4-5,6	I5U	58	20	3	3	Y	Y			
4A	TB4-9,10	I6U	41	3	4	4	Y	Y			
4B	TB4-11,12	I6L	45	7	14	4	Y	Y			10
5A	TB3-1,2	J1U	55	17	5	5	Y	Y			
6A,6B	TB3-5,6	J2U	40	2	6	6	Y	Y			
7A	TB5-5,6	J5U	57	19	7	7	Y	Y			
8A	TB5-9,10	J6U	42	4	8	8	Y	Y			
* S11	TB6-9,10	I9U	60	22	11	SYS					
* S12	TB6-11,12	I9L	62	24	13	SYS					
* S19	TB7-9,10	J9U	59	21	15	SYS					
* S20	TB7-11,12	J9L	61	23	17	SYS					
PED PUSH BUTTONS											
P41,P42	TB8-5,6	I12L	69	31	PED 4	4 PED					
P61,P62	TB8-7,9	I13U	68	30	PED 6	6 PED					

NOTE:

INSTALL DC ISOLATORS IN INPUT FILE SLOTS 112 AND 113.

* System detector only. Remove the vehicle phase assigned to this detector in the default programming.

INPUT FILE POSITION LEGEND: J2L



COUNTDOWN PEDESTRIAN SIGNAL OPERATION

Countdown Ped Signals are required to display timing only during Ped Clearance Interval. Consult Ped Signal Module user's manual for instructions on selecting this feature.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0129
 DESIGNED: November 2010
 SEALED: 12/10/10
 REVISED: N/A

Signal Upgrade

ELECTRICAL AND PROGRAMMING DETAILS FOR: US 401-421/NC 27-210 (N Main St)

at US 401/US 421-NC 27

Division 6 Harnett County Lillington

PLAN DATE: December 2010 REVIEWED BY: T. J. J.
















PREPARED BY: S. Armstrong REVIEWED BY:


REVISIONS INIT. DATE

750 N. Greenfield Pkwy, Garner, NC 27529



SEAL
 NORTH CAROLINA PROFESSIONAL ENGINEER
 SEAL 022013
 GEORGE C. BROWN
 SIGNATURE DATE 12/15/10
 SIG. INVENTORY NO. 06-0129

LEGEND

	YAGI ANTENNA (DOUBLE) FOR REPEATER OPERATION
	YAGI ANTENNA (SINGLE)
	OMNI ANTENNA
	EXISTING CONTROLLER AND CABINET
	EXISTING MASTER CONTROLLER AND CABINET
	SIGNAL INVENTORY NUMBER
	NEW METAL POLE W/MAST ARM
	EXISTING WOOD POLE
	NEW METAL POLE
	SIGNAL POLE
	EXISTING METAL POLE
	NEW OVERSIZED JUNCTION BOX
	EXISTING OVERSIZED JUNCTION BOX
	EXISTING CONDUIT
	EXISTING COMMUNICATIONS CABLE



- NOTES FOR WIRELESS COMMUNICATIONS:**
- INSTALL COAXIAL CABLE:
 - ON WOOD POLES, REQUIRING A NEW RISER, INSTALL A 2" RISER WITH WEATHERHEAD TO ROUTE THE COAXIAL CABLE TO THE ANTENNA. ON POLES WITH EXISTING RISERS WITH WEATHERHEADS REUSE THE RISER ASSEMBLY.
 - ON METAL POLES, RUN COAXIAL CABLE UP THROUGH THE POLE AND OUT THE MAST ARM; FIELD DRILL 1/2" HOLE WITH GROMMET THROUGH BOTTOM OF MAST ARM FOR INSTALLATION OF THE COAXIAL CABLE TO THE ANTENNA.
 - ON METAL STRAIN POLES, RUN COAXIAL CABLE UP THROUGH THE POLE AND REPLACE THE WEATHERHEAD WITH HEAT SHRINK TUBING AND ROUTE THE COAXIAL CABLE TO THE ANTENNA.
 - BETWEEN THE POINT OF EXITING THE METAL POLE OR MAST ARM AND THE ANTENNA, SECURE THE COAXIAL CABLE TO THE STRUCTURE USING 3/4" STAINLESS STEEL STRAPS EVERY 12".
 - IF EXISTING SPARE RISER IS AVAILABLE, REMOVE WEATHERHEAD AND INSTALL COAXIAL CABLES. RESEAL WITH HEAT SHRINK TUBING.
 - INSTALL WIRELESS ANTENNA ON POLE WITH RF WARNING SIGN AND AIM TOWARDS MASTER. (NOTE: RF WARNING SIGN NOT REQUIRED WHEN ANTENNA IS INSTALLED ON AN NCDOT-OWNED POLE.)
 - MAINTAIN PROPER CLEARANCE FROM ALL UTILITIES PER THE NATIONAL ELECTRICAL SAFETY CODE.
 - INSTALL WIRELESS SERIAL RADIO MODEM WITH EXTERIOR DISCONNECT SWITCH LOCATED ON CABINET. (NOTE: RF ANTENNA DISCONNECT SWITCH AND DECAL ARE NOT REQUIRED WHEN THE ANTENNA IS INSTALLED ON AN NCDOT-OWNED POLE.)
 - REFERENCE "WIRELESS RADIO ANTENNA TYPICAL DETAILS."

	WIRELESS COMMUNICATIONS PLAN US 401 IN LILLINGTON FROM NORTH OF MATTHEWS ROAD TO NC HWY 210		
	DIVISION 6 HARNETT COUNTY LILLINGTON	REVIEWED BY: I. N. AVERY REVIEWED BY: G.A. FULLER, PE	
PLAN DATE: JANUARY 2011 PREPARED BY: P. C. LOUDER	REVISIONS _____ _____	INIT. _____ _____	DATE _____ _____
250 N. Greenfield Pkwy., Garner, NC 27529 	SCALE 0 _____	SIGNATURE: <i>Gregory A. Fuller</i> 1-13-11 DATE	

DECAL


POLE MOUNTED SIGN

SIGN NUMBER: SPO5224
 TYPE: DECAL
 QUANTITY:

SYMBOL	X	Y	WID	HT

 SIGN WIDTH: 0'-9"
 HEIGHT: 0'-6"
 TOTAL AREA: 0.4 Sq.Ft.
 BORDER TYPE: FLUSH
 RECESS: 0"
 WIDTH: 0.25"
 RADII: 1"
 NO. Z BARS:
 LENGTH:
 BACKG COLOR: Yellow
 COPY COLOR: Black
 MAT'L: 0.063" (1.6 mm) ALUMINUM

DESIGN BY: S PIOTROWSKI DATE: Jul 18,2005 CHECKED BY: SUSAN B. KUNZ
 PROJECT ID: ID DIV: INTELLIGENT TRANSPORTATION SYSTEM



NOTE:
 THIS
 SIGN
 SHALL
 BE
 PRODUCED
 AS
 A
 DECAL

- USE NOTES: 2, 4
- Legend and border shall be direct applied Type III reflective sheeting.
 - Legend and border shall be direct applied non-reflective sheeting.
 - Shields shall be Type III reflective sheeting on 0.032" (0.8mm) aluminum and demountable.
 - Background shall be Type III reflective sheeting.
 - Background shall be Type I reflective sheeting.
 - Center arrow(s) vertically on sign.
 - Bottom panel shall be yellow Type III sheeting. Legend shall be direct applied black non-reflective sheeting. Yellow panel is:

LETTER POSITIONS

Letter spacings are to start of next letter

	R	F	A	N	T	E	N	N	A		Series/Size	
0.9	0.8	0.5	1	0.8	0.7	0.7	0.7	0.8	0.7	0.6	0.9	C1
												7.2
	D	I	S	C	O	N	N	E	C	T		C1
1.2	0.8	0.3	0.7	0.7	0.8	0.8	0.8	0.7	0.7	0.5	1.2	6.7
	S	W	I	T	C	H						C1
2.6	0.7	0.9	0.3	0.7	0.7	0.5	2.6					3.9


Spacing Factor is 1 unless specified otherwise

SIGN NUMBER: SPO5223
 TYPE: D
 QUANTITY:

SYMBOL	X	Y	WID	HT
BAR	0.2	8.2	8.6	1.0

 SIGN WIDTH: 0'-9"
 HEIGHT: 1'-0"
 TOTAL AREA: 0.8 Sq.Ft.
 BORDER TYPE: FLUSH
 RECESS: 0"
 WIDTH: 0.2"
 RADII: 1"
 NO. Z BARS:
 LENGTH:
 BACKG COLOR: Yellow
 COPY COLOR: Black
 MAT'L: 0.063" (1.6 mm) ALUMINUM

DESIGN BY: S PIOTROWSKI DATE: Jul 18,2005 CHECKED BY: SUSAN KUNZ
 PROJECT ID: DIV: INTELLIGENT TRANSPORTATION SYSTEMS



- USE NOTES: 2, 4
- Legend and border shall be direct applied Type III reflective sheeting.
 - Legend and border shall be direct applied non-reflective sheeting.
 - Shields shall be Type III reflective sheeting on 0.032" (0.8mm) aluminum and demountable.
 - Background shall be Type III reflective sheeting.
 - Background shall be Type I reflective sheeting.
 - Center arrow(s) vertically on sign.
 - Bottom panel shall be yellow Type III sheeting. Legend shall be direct applied black non-reflective sheeting. Yellow panel is:

LETTER POSITIONS

Letter spacings are to start of next letter

	C	A	U	T	I	O	N	:		Series/Size			
2.3	0.6	0.7	0.6	0.6	0.3	0.7	0.7	0.1	2.3	C1			
											4.4		
	R	F	A	N	T	E	N	N	A		C1		
1.1	0.7	0.5	1	0.7	0.6	0.6	0.6	0.7	0.6	0.6	1.1	6.7	
	I	F	W	O	R	K	I	N	G			C1	
1.4	0.3	0.5	1	0.8	0.7	0.7	0.6	0.3	0.7	0.5	1.4	6.1	
	W	I	T	H	I	N	2	F	T			C1	
1.1	0.9	0.2	0.6	0.7	0.3	0.5	1	0.5	1	0.6	0.5	1.1	6.8
	D	I	S	C	O	N	N	E	C	T		C1	
1.5	0.7	0.3	0.6	0.6	0.7	0.7	0.7	0.6	0.6	0.5	1.5	6	
	A	T	T	R	A	F	F	I	C			C1	
1.4	0.7	0.5	1	0.6	0.6	0.7	0.6	0.6	0.3	0.6	1.4	6.2	
	S	I	G	N	A	L						C1	
0.5	0.7	0.3	0.7	0.6	0.7	0.5	5					3.5	
	C	A	B	I	N	E	T					C1	
4.5	0.6	0.7	0.7	0.3	0.7	0.6	0.5	0.5				4	

Spacing Factor is 1 unless specified otherwise

Prepared in the Offices of:

122 N. McDowell St., Raleigh, NC 27603

SCALE: 0

WIRELESS RADIO ANTENNA TYPICAL DETAILS


PLAN DATE: JULY 2005 REVIEWED BY: I. N. AVERY
 PREPARED BY: A. CREECH REVIEWED BY: A. T. FAULKNER

REVISIONS: _____ INIT. DATE

SEAL: 023919 ENGINEER GREGORY A. FULLER

SIGNATURE: _____ DATE: 11-12-10



CADD Filename: _____



NOTES

1. WOOD POLE — BOND # 6 AWG SOLID BARE COPPER WIRE TO ANTENNA SUPPORT USING LISTED PIPE CLAMP. BOND OTHER END OF # 6 AWG SOLID BARE COPPER WIRE TO THE POLE GROUND USING A SPLIT BOLT CONNECTOR. BOND SHIELD OF COAXIAL CABLE WITH AN APPROVED GROUNDING SYSTEM (USING #6 AWG STRANDED COPPER WIRE) BONDED TO THE POLE GROUND. WEATHERPROOF THE CONNECTION ONCE THE GROUNDING SYSTEM IS INSTALLED. ENSURE "POLE GROUND" IS IN PLACE.

METAL POLE — BOND # 6 AWG SOLID BARE COPPER WIRE TO ANTENNA SUPPORT USING LISTED PIPE CLAMP. BOND OTHER END OF # 6 AWG SOLID BARE COPPER WIRE TO THE POLE OR EXISTING SYSTEM GROUND USING A METHOD APPROVED BY THE ENGINEER. BOND SHIELD OF COAXIAL CABLE WITH AN APPROVED GROUNDING SYSTEM (USING #6 AWG STRANDED COPPER WIRE) BONDED TO THE POLE BY A METHOD APPROVED BY THE ENGINEER. WEATHERPROOF THE CONNECTION ONCE THE GROUNDING SYSTEM IS INSTALLED. ENSURE "SYSTEM GROUND" IS IN PLACE.
2. YAGI ANTENNA SHOWN IN VERTICAL POLARIZATION POSITION FOR CLARIFICATION. TYPICALLY INSTALL ANTENNA IN HORIZONTAL POLARIZATION POSITION.
3. TO CONSERVE VERTICAL SPACING ON THE POLE (JOINT-USE OR SIGNAL POLE) WITH REGARDS TO THE SURROUNDING UTILITIES, INSTALL THE ANTENNA MOUNTING HARDWARE USING ONE OF THE TWO METHODS LISTED BELOW: (ENSURE THAT THE MOUNTING METHOD DOES NOT DEGRADE THE ANTENNA'S SIGNAL INTEGRITY)
 - A) ROTATE THE VERTICAL SUPPORT ARM 90 DEGREES SUCH THAT THE ANTENNA IS AT THE SAME HEIGHT AS THE HORIZONTAL SUPPORT ARM.
 - B) ELIMINATE THE VERTICAL SUPPORT ARM AND MOUNT THE ANTENNA TO THE HORIZONTAL SUPPORT ARM.
 - C) ANTENNA, ANTENNA SUPPORT ARM, AND SIGN TO MAINTAIN A 40" SEPARATION FROM NEUTRAL /POWER AND 12" FROM OTHER UTILITIES.
4. INSTALL AN END CAP TO SEAL THE EXPOSED END OF THE MOUNTING PIPE.




	WIRELESS RADIO ANTENNA TYPICAL DETAILS	
	PLAN DATE: JULY 2005 PREPARED BY: A. CREECH	REVIEWED BY: I. N. AVERY REVIEWED BY: A. T. FAULKNER
SCALE: 0	REVISIONS: UPDATE GROUNDING - COAXIAL CABLE SHIELD	INIT. DATE DATE
Prepared in the Offices of: 122 N. McDowell St., Raleigh, NC 27603		SIGNATURE: <i>Gregory A. Faulkner</i> 11-12-10 DATE:

**STATE OF NORTH CAROLINA
DIVISION OF HIGHWAYS**

STATE	PROJECT NO.	SHEET NO.
N.C.	R-5185	Sig. 30
F.A. PROJ. NO.		M 1
PROJECT ID. NO.		

STANDARD DRAWINGS FOR METAL POLES




WIND ZONE LEGEND

WIND ZONE 1 (140 mph) Special Wind Zone	
WIND ZONE 2 (130 mph) Coastal Region	
WIND ZONE 3 (110 mph) Eastern Region	
WIND ZONE 4 (90 mph) Central & Mtn. Region	
WIND ZONE 5 (120 mph) Special Wind Zone	

<http://www.ncdot.org/doh/preconstruct/traffic/ITSS/ws/mpoles/poles.html>

Prepared In the Offices of:



750 N. Greenfield Pkwy, Garner, NC 27529

Designed in conformance with the 2002 Interim to the 4th Edition 2001

AASHTO

Standard Specifications for Structural Supports for Highway Signs, Luminaires, and Traffic Signals

INDEX OF PLANS


DRAWING NUMBER	DESCRIPTION
M 1	Title Sheet
M 2	Fabrication Details - All Poles
M 3	Fabrication Details - Strain Poles
M 4,5	Fabrication Details - Mast Arm Poles
M 6	Construction Details - Strain Poles
M 7	Construction Details - Foundations
M 8	Standard Strain Poles

NCDOT CONTACTS:


MOBILITY AND SAFETY DIVISION - ITS and SIGNALS UNIT

- G. A. Fuller, P.E. - State ITS and Signals Engineer
- G. G. Murr, Jr., P.E. - State Signals Engineer
- D. C. Sarkar, P.E. - ITS and Signals Senior Structural Engineer
- C. F. Andrews, Jr. - ITS and Signals Structural Project Engineer
- M. Aslam - ITS and Signals Structural Project Engineer
- N. Biting, P.E. - ITS and Signals Structural Project Engineer

SEAL





D. C. Sarkar 7.26.2009
SIGNATURE DATE




Section C-C Note: Unless otherwise specified, locate Terminal Compartment 1 foot above the pole base plate at 180 degrees on the pole's radial index.

Terminal Compartment Detail



Anchor Bolt Detail



MFG _____ MFG. DATE: MM/YY

SHAFT D/T/L/Y _____

ARM-A D/T/L/Y _____

ARM-B D/T/L/Y _____

A.B. DIA./B.C./L/Y _____

NCDOT STANDARD _____

MFG _____ MFG. DATE: MM/YY

SECTION D/T/L/Y _____

NCDOT STANDARD _____

Arm I.D. Tag (Provide on each section of a multi-section mast arm)

Shaft I.D. Tag (Provide on Strain Poles and Mast Arm Poles)

- Notes:
- 1) D= Diameter, T= Thickness, L= Length, Y= Yield Strength
 - 2) A.B. = Anchor Bolt
 - 3) B.C. = Bolt Circle of Anchor Bolts
 - 4) If Custom Design, use "NCDOT STANDARD" line for plan pole I.D.
 - 5) See drawing M4 for mounting positions of I.D. tags.

Identification Tag Details

Prepared in the Office of:

122 N. McDowell St., Raleigh, NC 27603

SCALE: 0 NA NONE

Typical Fabrication Details Common To All Metal Poles

PLAN DATE: May 2005 REVIEWED BY: C.F. Andrews

PREPARED BY: P.L. Alexander REVIEWED BY: A.M. Esposito


REVISIONS	INIT.	DATE

SIGNATURE: D. Sarker 9.22.2005 DATE


SIG. INVENTORY NO.

Fabrication Details - All Poles

01-SEP-2005 18:22 D:\2004_Metrol_Pole_Standards\04_m2 thru m5.dgn




Cable Entrances at Top of Pole




**Section B-B
(See drawing M2)
Pole Base Plate**


2 Cable Clamps designed for variable attachment heights from 1'-6" to 10' below the top of the pole.




**Monotube Strain Pole
(.14"/Foot Taper)**



**Radial Orientation for Factory Installed
Accessories at Top of Pole**




Socket Connection Weld Detail



Fabrication Details - Strain Poles


01-SEP-2005 14:07
w:\poc\ee-unit\work\poc\ee2004_metal_pole_standards\ee2004_m3.dgn
pa alexander

<p>Prepared in the Office of Traffic, State of North Carolina Department of Transportation 122 N. McDowell St., Raleigh, NC 27603</p>	Typical Fabrication Details For Strain Poles		
	PLAN DATE: May 2005 PREPARED BY: P.L. Alexander	REVIEWED BY: C.F. Andrews REVIEWED BY: A.M. Esposito	
SCALE 0 NA NONE	REVISIONS _____ _____	INLT. DATE _____ _____	SIGNATURE _____ DATE
			SIG. INVENTORY NO.




Note: Strap all signal cables to the side of the pole with 3/4" stainless steel straps when the distance between the spanwire attachment clamp and the weatherheads exceeds 36"

Strain Pole Attachments



Attachment of Cable to Intermediate Metal Pole




Metal Pole Grounding Detail

Construction Details - Strain Poles

01-SEP-2005 16:33 \\n11\work\grcupse2004\metal pole standard\sig33.m6.dgn


	Construction Details Strain Poles		
	PLAN DATE: May 2005 PREPARED BY: C.F. ANDREWS	REVIEWED BY: P.L. ALEXANDER REVIEWED BY: D.C. SARKAR	
SCALE: NA NONE	REVISIONS: _____ INIT. DATE	DATE: 9-1-05 SIGNATURE: <i>P.L. Alexander</i>	SIG. INVENTORY NO.

Reinforcing Steel Bars



REINFORCING STEEL TABLE FOR STANDARD DRILL PIER SHAFT (42" & 48" DIAMETER)						
Shaft Dia (in.)	Conc. Volume (cu. yds.)	Bar Name	No.	Size	Type	Length
42"	.356 x L	V1	9	#8	STR.	**
		C	*	#4	CIR.	10'-9"
48"	.465 x L	V1	12	#8	STR.	**
		C	*	#4	CIR.	12'-6"

* See Note No. 1
** See Note No. 3



Typical "C" Bars

REINFORCING STEEL TABLE FOR STANDARD 42" and 48" DRILL PIER SHAFT WITH TYPE 1 AND TYPE 2 WING WALLS						
Wing Wall Type	Drill Pier Shaft Dia. (in.)	Reinforcing Steel				
		Bar Name	No.	Size	Type	Length
TYPE 1	42"	V1	9	#8	STR.	**
		V2	12	#4	STR.	2'-6"
		H	8	#4	STR.	6'-0"
		C	*	#4	CIR.	10'-9"
TYPE 2	42"	V1	9	#8	STR.	**
		V2	16	#4	STR.	4'-6"
		H	12	#4	STR.	9'-0"
		C	*	#4	CIR.	10'-9"
TYPE 2	48"	V1	12	#8	STR.	**
		V2	16	#4	STR.	4'-6"
		H	12	#4	STR.	9'-6"
		C	*	#4	CIR.	12'-6"


* See Note No. 1
** See Note No. 3

WING WALL DETAILS				
Wing Wall Type	Wing Wall Length (Ft.)	Wing Wall Width (Ft.)	Wing Wall Depth (Ft.)	Concrete Volume (Cu. Yds.)
TYPE 1	1'-6"	1'-0"	3'-0"	.4
TYPE 2	3'-0"	1'-0"	5'-0"	1.2


See Note No. 4

Typical Foundation Anchor Bolt Details

(Reinforcing Cage Not Shown for Clarity)



Typical Foundation Conduit Details



Notes

- The number of C-bars is based on foundation depth. For standard foundations, see sheet M 8.
- Circular tie reinforcing rings may be vertically adjusted by +/- 3" at a depth between 2'-0" and 3'-0" to facilitate the installation of electrical conduit entering in the cage.
- The length of V1-bars is based on foundation depth. For standard foundations, see sheet M 8.
- The quantities for steel and concrete shown in the Wing Wall Details Chart reflect the amount of material for 1 pair of wing walls (2 wing walls per drilled pier shaft.)

Construction Details - Foundations

01-SEP-2005 11:48 w:\p\p\105-un\11\w\w\groups\2004\mat01\pote\standard\sig34\m7.dgn

	Construction Details Foundations		
	PLAN DATE: May 2005 PREPARED BY: C.F. ANDREWS	REVIEWED BY: P.L. ALEXANDER REVIEWED BY: A.M. ESPOSITO	

		STANDARD STRAIN POLES				STANDARD FOUNDATIONS 42" Diameter Drilled Pier Length (L) - Feet						
		Case No.	Pole Height (Ft.)	Base Plate BC (In.)	Moment at the Pole Base (ft-kp)	Clay				Sand		
						Medium N-Value 4-8	Stiff N-Value 9-15	Very Stiff N-Value 16-30	Hard N-Value >30	Loose N-Value 4-10	Medium N-Value 11-30	Dense N-Value >30
WIND ZONE 1	LIGHT	S26L3	26	25	280	20.5	14.0	11.5	9.5	18.0	16.0	14.0
		S30L3	30	25	310	21.0	14.5	11.5	9.5	18.5	16.5	14.5
		S35L3	35	25	350	22.5	15.0	12.0	10.0	19.5	17.5	15.5
	HEAVY	S30H3	30	29	450	25.5	16.5	13.0	11.0	21.0	18.5	16.5
		S35H3	35	29	540	26.0	17.0	13.5	11.5	22.0	19.5	17.0
WIND ZONE 2	LIGHT	S26L2	26	23	250	19.5	13.5	11.0	9.0	18.0	15.5	14.0
		S30L2	30	23	290	20.0	14.0	11.5	9.5	18.5	16.0	14.0
		S35L2	35	23	315	21.0	14.5	11.5	9.5	19.0	16.5	14.5
	HEAVY	S30H2	30	29	415	24.5	16.0	13.0	10.5	21.0	18.5	16.0
		S35H2	35	29	485	25.5	16.5	13.5	11.0	21.5	19.0	16.5
WIND ZONE 3	LIGHT	S26L2	26	23	250	18.5	13.0	10.5	9.0	17.5	15.0	13.5
		S30L2	30	23	290	19.5	13.5	11.0	9.0	18.0	15.5	14.0
		S35L2	35	23	315	20.0	14.0	11.5	9.5	18.5	16.0	14.5
	HEAVY	S30H2	30	29	415	23.0	15.5	12.5	10.0	20.5	17.5	16.0
		S35H2	35	29	485	24.0	16.0	13.0	10.5	21.0	18.0	16.5
WIND ZONE 4	LIGHT	S26L1	26	22	195	18.0	13.0	10.5	9.0	16.5	14.5	13.0
		S30L1	30	22	225	18.5	13.0	10.5	9.0	17.0	15.0	13.5
		S35L1	35	22	255	19.0	13.5	11.0	9.0	17.5	15.5	14.0
	HEAVY	S30H1	30	25	330	22.0	15.0	12.0	9.5	19.5	17.0	15.0
		S35H1	35	25	385	23.0	15.5	12.5	10.0	20.0	17.5	15.5
WIND ZONE 5	LIGHT	S26L2	26	23	250	19.0	13.5	10.5	9.0	17.5	15.5	13.5
		S30L2	30	23	290	20.0	14.0	11.0	9.5	18.0	16.0	14.0
		S35L2	35	23	315	21.0	14.5	11.5	10.0	19.0	16.5	14.5
	HEAVY	S30H2	30	29	415	23.5	15.5	12.5	10.5	21.0	18.0	16.0
		S35H2	35	29	485	25.0	16.5	13.0	11.0	21.5	18.5	16.5

Concrete Volume (cubic yards) = .356 X L

Fabrication Design Notes:



- Values shown in "Moment at the Pole Base" column represents the minimum acceptable capacity allowable for design using a design CSR of 1.
- Base plate thickness (T) is 2.0 inches.

Foundation Selection:

- Perform a standard penetration test at each proposed foundation site to determine "N" value.
- Select the appropriate wind zone from sheet M 1.
- Select the soil type (Clay or Sand) that best describes the soil characteristics.
- Get the appropriate pole case load number from the plans or from the Engineer.
- Select the appropriate column in the chart based on soil type and "N" value. Select the appropriate row based on the pole load case. The foundation depth is the value where the column and the row intersect.

Standard Strain Poles

02-SEP-2005 12:42 \\unit1\pwr\krcupae2004\metal pole standard\std004.mxd std strain pole.dgn pal Alexander

	Standard Strain Poles and Standard Foundations		
	PLAN DATE: May 2005 PREPARED BY: P.L. Alexander	REVIEWED BY: C.F. Andrews REVIEWED BY: A.W. Esposito	
SCALE: 0 NA None		SIGNATURE: <i>D. Sarker</i> DATE: 9.2.2005	

STATE OF NORTH CAROLINA
DEPT. OF TRANSPORTATION
DIVISION OF HIGHWAYS
RALEIGH, N.C.


11-08

ENGLISH DETAIL DRAWING FOR
INDUCTIVE DETECTION LOOPS

SHEET 1 OF 3
1725D01


SAW SLOT DEPTH CHART

DEPTH (IN)	NO. OF WIRE TURNS				
	2	3	4	5	6
CONCRETE	2.0	2.0	2.5	2.5	3.0
ASPHALT	2.0	2.5	3.0	3.0	3.0




CONVENTIONAL 4-SIDED LOOP


SAW CUT OPTIONS



LOOP WINDING METHOD



LOOP WIRE TWISTING METHOD




NOTES


1. OVERLAP SAW CUTS AT CORNERS AND INTERSECTION POINTS TO ENSURE UNIFORM SAW SLOT DEPTH.
2. MAINTAIN 12" SPACING BETWEEN LOOP WIRE TAIL SECTIONS.
3. WIRE LOOPS CONNECTED TO THE SAME DETECTOR CHANNEL IN SERIES.
4. LOCATE LOOPS IN CENTER OF LANES UNLESS OTHERWISE SHOWN ON PLANS OR APPROVED BY ENGINEER.

QUADRUPOLE LOOP

SAW CUT OPTIONS



LOOP WINDING METHOD



DEPTH IS 2.5" FOR CONCRETE AND 3.0" FOR ASPHALT

STATE OF NORTH CAROLINA
DEPT. OF TRANSPORTATION
DIVISION OF HIGHWAYS
RALEIGH, N.C.

11-08

ENGLISH DETAIL DRAWING FOR
INDUCTIVE DETECTION LOOPS

SHEET 1 OF 3
1725D01

See Plate for Title

Prepared in the Offices of:

750 N. Greenfield Parkway
Garner, NC 27529

SEAL

Milton Dean 11/24/08
SIGNATURE DATE

24-Nov-2008 09:28
d:\work_files\1725D01_1725D01.mxd
zmlittle

STATE OF NORTH CAROLINA
DEPT. OF TRANSPORTATION
DIVISION OF HIGHWAYS
RALEIGH, N.C.


11-08

ENGLISH DETAIL DRAWING FOR
INDUCTIVE DETECTION LOOPS
LOOP WIRE DETAILS


SHEET 2 OF 3
1725D01

LOOP WIRE SPLICE POINT DETAILS

LOOP WIRE AT JUNCTION BOX



LOOP WIRE AT POLE




NOTE


SPLICE ALL LOOP WIRE TAIL SECTIONS/LEAD-IN CABLE IN JUNCTION BOXES OR APPROVED CONDULETS.

LOOP WIRE PAVEMENT EDGE DETAILS

LOOP WIRE AT CURB & GUTTER SECTION



LOOP WIRE AT PAVEMENT SECTION



NOTES

- DO NOT EXCAVATE UNDER CURB AND GUTTER SECTIONS FOR CONDUIT INSTALLATION.
- TWIST LOOP WIRE TAIL SECTIONS FROM WHERE LOOP WIRE TAIL LEAVES SAW CUT TO JUNCTION BOX, INCLUDING THROUGH CONDUIT.
- BEFORE SEALING LOOPS, INSTALL DUCT SEAL WHERE LOOP WIRE TAIL SECTION LEAVES SAW CUT IN PAVEMENT AND AT ENTRANCE OF CONDUIT TO JUNCTION BOX.

STATE OF NORTH CAROLINA
DEPT. OF TRANSPORTATION
DIVISION OF HIGHWAYS
RALEIGH, N.C.

11-08


ENGLISH DETAIL DRAWING FOR
INDUCTIVE DETECTION LOOPS
LOOP WIRE DETAILS

SHEET 2 OF 3
1725D01

See Plate for Title



750 N. Greenfield Parkway
Garner, NC 27529



Milton J. Dean 11/24/08
SIGNATURE DATE


STATE OF NORTH CAROLINA
DEPT. OF TRANSPORTATION
DIVISION OF HIGHWAYS
RALEIGH, N.C.

11-08


ENGLISH DETAIL DRAWING FOR
INDUCTIVE DETECTION LOOPS
SPlicing FOR LEAD-IN CABLE AND LOOP WIRE

SHEET 3 OF 3
1725D01

STEP 1. STRIP LOOP WIRE AND LEAD-IN CABLE




STEP 2. CONNECT AND SOLDER




BOND SHIELD DRAIN WIRE AT SPLICE SECTIONS (DO NOT GROUND)


LOOP WIRE AND LEAD-IN CABLE CONNECTION DETAILS



STEP 3. INSULATE EACH SOLDER JOINT SEPARATELY



STEP 4. ENVIRONMENTALLY PROTECT SPLICE



STATE OF NORTH CAROLINA
DEPT. OF TRANSPORTATION
DIVISION OF HIGHWAYS
RALEIGH, N.C.

11-08

ENGLISH DETAIL DRAWING FOR
INDUCTIVE DETECTION LOOPS
SPlicing FOR LEAD-IN CABLE AND LOOP WIRE

SHEET 3 OF 3
1725D01

See Plate for Title

Prepared in the Offices of:

750 N. Greenfield Parkway
Garner, NC 27529

SEAL

Milton Dean 11/24/08
SIGNATURE DATE

24-Nov-2008 09:36
d:\work_files\standard plate sheets\17250103_moy2307.dgn
zml title