



STATE OF NORTH CAROLINA
DIVISION OF HIGHWAYS

WAYNE COUNTY

**LOCATION: ROYALL AVENUE TO SOUTH DRIVE
GOLDSBORO, NC**

TYPE OF WORK: TRAFFIC SIGNAL

Project: BERKELEY BOULEVARD WIDENING



Refer to "Roadway Standard Drawings NCDOT" dated January 2012 and "Standard Specifications for Roads and Structures" dated January 2012.

Index of Plans		Location/Description
Sheet #	Reference #	
Sig. 1		Title Sheet
Sig. 2-4	04-0556	US 13 (Berkeley Blvd.) at SR 1560 (Royall Ave.) & SR 1709 (Central Hts. Rd.)
Sig. 5-7	04-1173	US 13 (Berkeley Boulevard) at Lowe's Drive/Goldsboro Crossing Drive
Sig. 8-11	04-0367	US 13 (Berkeley Boulevard) at SR 1003 (New Hope Road)
Sig. 12-17	N/A	Metal Strain Poles Typicals

INTELLIGENT TRANSPORTATION AND SIGNALS UNIT

Contacts:

Pamela L. Alexander, PE - Eastern Region Signals Engineer
John T. Rowe Jr., PE - Signal Equipment Design Engineer


Prepared in the Office of:
DIVISION OF HIGHWAYS
TRANSPORTATION MOBILITY AND SAFETY DIVISION

750 N. Greenfield Parkway, Garner, NC 27529

03-MAY-2012 11:20 S:\TSS&S\NTIS\Signals\Signal Design Section\Eastern Region\Div-04\U-3609A\Signals\Design\Titlesheet\U3609A_rdy_tsh.dgn

EDI MODEL 2010ECL-NC CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Make sure jumpers SEL2-SEL5 are present on the monitor board.

NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Ensure that Red Enable is active at all times during normal operation. To prevent Red Failures on unused monitor channels, tie unused red monitor inputs 9,10,11,12,13,14,15 & 16 to load switch AC+ per the cabinet manufacturer's instructions.
- Program phases 2 and 6, on the controller unit, for Start Up In Green.
- Program phases 2 and 6, on the controller unit, for Yellow Flash.
- Enable Simultaneous Gap-Out, on the controller unit, for all phases.
- The cabinet and controller are part of the Goldsboro City System.

EQUIPMENT INFORMATION

CONTROLLER.....CONTRACTOR SUPPLIED 2070L
 CABINET.....CONTRACTOR SUPPLIED 332
 SOFTWARE.....ECONOLITE OASIS 3.02.77
 OR LATEST APPROVED VERSION
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...12
 LOAD SWITCHES USED.....S1,S2,S3,S4,S5,S6,S7,S8
 PHASES USED.....1,2,3,4,5,6,*7
 OVERLAP E.....4+7
 OVERLAP P.....1+2+3+4+5+6
 *USED ONLY DURING PREEMPTION

SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S2P	S3	S4	S4P	S5	S6	S6P	S7	S8	S8P
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	OLE	8 PED
SIGNAL HEAD NO.	11	21,22	NU	31, 32,33	41, 42,43	NU	51	61,62	NU	31,41	62	NU
RED		128		116	101			134		*	*	
YELLOW		129		117	102			135				
GREEN		130		118	103			136				
RED ARROW	125							131				
YELLOW ARROW	126							132		123	108	
GREEN ARROW	127							133		124	109	

NU = Not Used
 * Denotes install load resistor. See load resistor installation detail this sheet.

PREEMPT ONLY PHASE OMIT NOTE

(program controller as shown below)

From Main Menu press '2' (Phase Control). Then '1' (Phase Control Functions). Program Phase 7 for 'Omit Phase' and Phases 1, 2, 3, 4, 5 and 6 for 'Startup Calls'. This is to prevent Phase 7 from being served when not in Preempt.

INPUT FILE POSITION LAYOUT

(front view)

FILE U	1	2	3	4	5	6	7	8	9	10	11	12	13	14
U	φ 1	φ 2	S	S	S	φ 4	φ 3	S	S	S	S	S	S	FS
L	1A	2A,2B	NOT USED	NOT USED	NOT USED	4A	3A	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	DC ISOLATOR
U	φ 5	φ 6	S	S	S	φ 4	φ 3	S	S	S	S	S	S	PRE1
L	5A	6A,6B	NOT USED	NOT USED	NOT USED	4B	3B	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	AC ISOLATOR


EX.: 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
 ST = STOP TIME
 PRE1 = RR PREEMPT

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
1A	TB2-1,2	I1U	56	18	1	1	Y	Y			3
2A,2B	TB2-5,6	I2U	39	1	2	2	Y	Y			
3A	TB6-1,2	I7U	65	27	34	3	Y	Y			3
3B	TB6-3,4	I7L	78	40	44	3	Y	Y			
4A	TB4-9,10	I6U	41	3	4	4	Y	Y			3
4B	TB4-11,12	I6L	45	7	14	4	Y	Y			
5A	TB3-1,2	J1U	55	17	5	5	Y	Y			3
6A,6B	TB3-5,6	J2U	40	2	6	6	Y	Y			

INPUT FILE POSITION LEGEND: J2L



OVERLAP 'P' PROGRAMMING DETAIL

(program controller as shown below)

From Main Menu press '8' (Overlaps), then '1' (Vehicle Overlap Settings).

PRESS '+' FOUR TIMES

```
PAGE 1: VEHICLE OVERLAP 'E' SETTINGS
PHASE: :12345678910111213141516
VEH OVL PARENTS: : X X
VEH OVL NOT VEH: :
VEH OVL NOT PED: :
VEH OVL GRN EXT: :
STARTUP COLOR: - RED - YELLOW - GREEN
FLASH COLORS: - RED - YELLOW - GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...N
GREEN EXTENSION (0-255 SEC)...0
YELLOW CLEAR (0=PARENT,3-25.5 SEC)...0.0
RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)...8
```

PRESS '-' FIVE TIMES


```
PAGE 1: VEHICLE OVERLAP 'P' SETTINGS
PHASE: :12345678910111213141516
VEH OVL PARENTS: :XXXXXX
VEH OVL NOT VEH: :
VEH OVL NOT PED: :
VEH OVL GRN EXT: :
STARTUP COLOR: - RED - YELLOW - GREEN
FLASH COLORS: - RED - YELLOW - GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...N
GREEN EXTENSION (0-255 SEC)...0
YELLOW CLEAR (0=PARENT,3-25.5 SEC)...0.0
RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)...0
```

OVERLAP PROGRAMMING COMPLETE

The utilization of overlap P ensures consistent clearance timing during transition to preemption


LOAD RESISTOR INSTALLATION DETAIL

ACCEPTABLE VALUES	VALUE (ohms)	WATTAGE
1.5K - 1.9K	25W (min)	
2.0K - 3.0K	10W (min)	



NOTE: The purpose of this resistor is to load the channel red monitor input in order for the Signal Sequence Monitor to use the full signal sequence monitoring capability on channels that do not use the red display in the field.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 04-0556
 DESIGNED: March 2012
 SEALED: 4/11/12
 REVISED: N/A



Signal Upgrade - Sheet 1 of 2

Electrical and Programming Details For: **US 13 (Berkeley Blvd.) at SR 1560 (Royall Ave.) & SR 1709 (Central Hts. Rd.)**

Division 4 Wayne County Goldsboro
 PLAN DATE: January 2009 REVIEWED BY: T. Joyce
 PREPARED BY: C. Strickland REVIEWED BY:

REVISIONS: [Table with columns for REVISIONS, INIT., and DATE]

Signature: *JTK* DATE: 4-11-12

Not a certified document as to the original document but only as to the revisions. This document originally issued and sealed by George C. Brown, #022013, on 2/17/09. This document is only certified as to the revisions.

SIG. INVENTORY NO. 04-0556

RAILROAD PREEMPTION PROGRAMMING DETAIL

(program controller as shown below)


From Main Menu press 'A' (Preemption), then '1' (Standard Preemptions).

PREEMPTION #1	SETTINGS (NEXT:1-10)
INTERVAL/TIMING	CLEAR/DWELL PHASES
GRN YEL RED	12345678910111213141516
1 0 0.0 0.0	
2 255 0.0 0.0	X
3 0 0.0 0.0	
4 0 0.0 0.0	
5 1 0.0 0.0	X X

EXIT CALLS	OPTIONS
PRIORITY (Y/N TO SELECT)	HIGH
DELAY TIMER (0-255 SEC)	0
MIN GREEN BEFORE PRE (0= DEFAULT)...	1
PED CLEAR BEFORE PRE (0= DEFAULT)...	0
YELLOW CLEAR BEFORE PRE (0= DEFAULT)...	0
RED CLEAR BEFORE PRE (0= DEFAULT)...	0
DWELL MIN TIMER (0-255 SEC)	7
DWELL MAX TIMER (0=OFF,1-255MIN)	0
DWELL HOLD-OVER TIMER (0-255)	0
LATCH CALL?	N
LINK TO NEXT PREEMPT?	N
ENABLE BACKUP PROTECTION?	N
HOLD CLEAR 1 PHASES DURING DELAY? ...	N
FAST GREEN FLASH DWELL PHASES?	N
PED CLEARANCE THROUGH YELLOW?	N
INHIBIT OVERLAP GREEN EXTENSION? ...	N
SERVICE DURING SOFTWARE FLASH?	N
REST IN RED DURING DWELL INTERVAL? ..	N
FLASH DWELL INTERVAL?	N
ALLOW PEDS IN DWELL INTERVAL?	N
RE-TIME DWELL INTERVAL?	N
OVERLAPS:	ABCDEFGHIJKLMN
DWELL INT FLASH YELLOW	
OMIT OVERLAPS:	X

RAILROAD PREEMPTION WIRING DETAIL


(wire as shown below)



NOTES


- Relay K1 is shown in the energized (Preempt not active) normal operation state.
- Relay K1 is a DPDT with 120VAC coil. Potter & Brumfield KRP11AG with octal base or approved equivalent.
- Relay SSR1 is a SPST (normally open) Solid State Relay with AC input and AC (25 amp) output. Crydom TA1225 or approved equivalent.
- AC Isolator Card shall activate preemption upon removal of AC+ from the input (as shown above). To accomplish this set invert dip switch on AC Isolator Card.
- Resistor is valued at 2K ohm, 12 watt. Clarostat part no. VPR10F-2K or approved equivalent.
- RC network is valued at .1 microfarad, 100 ohm.
- If replacement movs are needed, GE part no. V150LA20A may be used.
- Preemption and Blankout Sign Control Box is a Control Technologies part no. 2299-101 or approved equivalent.
- IMPORTANT!! A jumper must be added between input file terminals J14-E and J14-K if not already present. Also, terminal TB9-12 (on input panel) shall be connected to AC neutral (jumper may have to be added).

FRONT VIEW



PREEMPT 1 AC ISOLATOR (MODEL 252) OUTPUT PROGRAMMING DETAIL

(set DIP switches as shown below)



NOTE: IF ANOTHER MANUFACTURER TYPE OF AC ISOLATOR IS USED, OUTPUT PROGRAMMING IS LIKELY NOT TO EQUATE TO THAT SHOWN ABOVE.

PHASE SEQUENCE PROGRAMMING DETAIL

(program controller as shown below)

FROM DAVIS LOCAL CONTROLLER MAIN MENU
SELECT: 4 PHASE SEQUENCE

PHASE SEQUENCE: PAGE 1	NEXT: PAGES)					
RNG:LEAD	BARRIER 1	X-LAG:LEAD	BARRIER 2	X-LAG:LEAD	BARRIER 3	X-LAG
1 :1	2 0	0 :3	4 0	0 :7	0 0	0 0
2 :0	6 0	0 :0	0 0	0 :0	0 0	0 0
3 :0	0 0	0 :0	0 0	0 :0	0 0	0 0
4 :0	0 0	0 :0	0 0	0 :0	0 0	0 0

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 04-0556
DESIGNED: March 2012
SEALED: 4/11/12
REVISED: N/A

Signal Upgrade - Sheet 2 of 2

	US 13 (Berkeley Blvd.) at SR 1560 (Royall Ave.) & SR 1709 (Central Hts. Rd.)		
	Division 4 PLAN DATE: January 2009 PREPARED BY: C. Strickland	Wayne County REVIEWED BY: T. Joyce REVIEWED BY:	Goldsboro on 2/17/09. This document is only certified as to the revisions.
	REVISIONS Added right turn over lap head 62 and created over lap. Et changed loops and revised input file. (WSA)	INIT. DATE JTK 4-11-12	SIGNATURE DATE JTK 4-11-12
	SIG. INVENTORY NO. 04-0556		SEAL

11-APR-2012 09:10 S:\MITSASU\1151\proj\15\wkr\krc\040556_sml.e...xxx.dgn

LOGICAL I/O PROCESSOR PROGRAMMING DETAIL TO PRODUCE SPECIAL FYA-PPLT SIGNAL SEQUENCE

(program controller as shown below)

- FROM MAIN MENU PRESS '2' (PHASE CONTROL), THEN '1' (PHASE CONTROL FUNCTIONS), SCROLL TO THE BOTTOM OF THE MENU AND ENABLE ACT LOGIC COMMANDS 1, 2, 3, 4, 5 AND 6.
- FROM MAIN MENU PRESS '6' (OUTPUTS), THEN '3' (LOGICAL I/O PROCESSOR).

LOGICAL I/O COMMAND #1 (+/-COMMAND#)
IF ACTIVE PHASE #1 IS ON
AND RED CLEAR ON PHASE #1 IS ON

↓
SCROLL DOWN

THEN:
SET OUTPUT ASSIGNMENT #50 ON
SET OUTPUT ASSIGNMENT #51 OFF

PRESS '+'

NOTE: LOGIC FOR PHASE 1 RED CLEAR WHEN TRANSITIONING FROM PHASE 1 TO PHASE 2 (HEAD 11).

LOGICAL I/O COMMAND #2 (+/-COMMAND#)
IF ACTIVE PHASE #1 IS ON

↓
SCROLL DOWN

THEN:
SET OUTPUT ASSIGNMENT #52 OFF

PRESS '+'

NOTE: LOGIC FOR SWITCHING FLASHING YELLOW ARROW "OFF" DURING PHASE 1 (HEAD 11).

LOGICAL I/O COMMAND #3 (+/-COMMAND#)
IF YELLOW ON PHASE #1 IS ON

↓
SCROLL DOWN

THEN:
SET OUTPUT ASSIGNMENT #51 ON

PRESS '+'

NOTE: LOGIC FOR YELLOW ARROW CLEARANCE FROM PHASE 1 (HEAD 11).

LOGICAL I/O COMMAND #4 (+/-COMMAND#)
IF ACTIVE PHASE #5 IS ON
AND RED CLEAR ON PHASE #5 IS ON

↓
SCROLL DOWN

THEN:
SET OUTPUT ASSIGNMENT #42 ON
SET OUTPUT ASSIGNMENT #43 OFF

PRESS '+'

NOTE: LOGIC FOR PHASE 5 RED CLEAR WHEN TRANSITIONING FROM PHASE 5 TO PHASE 6 (HEAD 51).

LOGICAL I/O COMMAND #5 (+/-COMMAND#)
IF ACTIVE PHASE #5 IS ON

↓
SCROLL DOWN

THEN:
SET OUTPUT ASSIGNMENT #44 OFF

PRESS '+'

NOTE: LOGIC FOR SWITCHING FLASHING YELLOW ARROW "OFF" DURING PHASE 5 (HEAD 51).

LOGICAL I/O COMMAND #6 (+/-COMMAND#)
IF YELLOW ON PHASE #5 IS ON

↓
SCROLL DOWN

THEN:
SET OUTPUT ASSIGNMENT #43 ON

PRESS '+'

NOTE: LOGIC FOR YELLOW ARROW CLEARANCE FROM PHASE 5 (HEAD 51).

LOGIC I/O PROCESSOR PROGRAMMING COMPLETE

OUTPUT REFERENCE SCHEDULE

OUTPUT 42 = Overlap C Red
OUTPUT 43 = Overlap C Yellow
OUTPUT 44 = Overlap C Green
OUTPUT 50 = Overlap A Red
OUTPUT 51 = Overlap A Yellow
OUTPUT 52 = Overlap A Green

OVERLAP PROGRAMMING DETAIL

(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS), THEN '1' (VEHICLE OVERLAP SETTINGS).

PAGE 1: VEHICLE OVERLAP 'A' SETTINGS
PHASE: 12345678910111213141516
VEH OVL PARENTS: XX
VEH OVL NOT VEH:
VEH OVL NOT PED:
VEH OVL GRN EXT:
STARTUP COLOR: _ RED _ YELLOW _ GREEN
FLASH COLORS: _ RED _ YELLOW X GREEN

SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC)...0.0
YELLOW CLEAR (0=PARENT.3-25.5 SEC)...0.0
RED CLEAR (0=PARENT.0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)...0

← NOTICE GREEN FLASH

PRESS '+' TWICE

PAGE 1: VEHICLE OVERLAP 'C' SETTINGS
PHASE: 12345678910111213141516
VEH OVL PARENTS: XX
VEH OVL NOT VEH:
VEH OVL NOT PED:
VEH OVL GRN EXT:
STARTUP COLOR: _ RED _ YELLOW _ GREEN
FLASH COLORS: _ RED _ YELLOW X GREEN



SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC)...0.0
YELLOW CLEAR (0=PARENT.3-25.5 SEC)...0.0
RED CLEAR (0=PARENT.0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)...0

← NOTICE GREEN FLASH

OVERLAP PROGRAMMING COMPLETE

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 04-1173
DESIGNED: February 2012
SEALED: 4/10/12
REVISED: N/A


Signal Upgrade (Final) - Sheet 2 of 2

	ELECTRICAL AND PROGRAMMING DETAILS FOR:		US 13 (Berkeley Boulevard) at Lowe's Drive/ Goldsboro Crossing Drive		
	Prepared In the Offices of:		Division 4 Wayne County Goldsboro		
PLAN DATE: April 2012		REVIEWED BY: JTR		PREPARED BY: S. Armstrong	
REVISIONS		REVIEWED BY:		SIGNATURE: <i>John T. Rowe</i> DATE: 4-10-12	
750 N. Greenfield Pkwy, Garner, NC 27529		SIG. INVENTORY NO. 04-1173		SEAL	

EDI MODEL 2018ECL-NC CONFLICT MONITOR

PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



NOTES:

1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
3. Ensure that Red Enable is active at all times during normal operation.
4. Connect serial cable from conflict monitor to comm. port 1 of 2070 controller. Ensure conflict monitor communicates with 2070.

NOTES

1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
2. Enable Simultaneous Gap-Out for all phases.
3. Program phases 2 and 6 for Variable Initial and Gap Reduction.
4. Program phases 2 and 6 for Start Up In Green.
5. Program phases 2 and 6 for Yellow Flash.
6. The cabinet and controller are part of the Goldsboro City System.

EQUIPMENT INFORMATION

CONTROLLER.....2070L
 CABINET.....332
 SOFTWARE.....ECONOLITE OASIS
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...12
 LOAD SWITCHES USED.....S1,S2,S4,S5,S7,S8
 PHASES USED.....1,2,3,4,5,6
 OVERLAPS.....NONE


SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12			
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16			
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED			
SIGNAL HEAD NO.	11	21,22	NU	22	31	32	41	42	NU	51	61,62	NU	NU	NU	NU
RED		128		116	116	101	101			134					
YELLOW		129		117	117	102	102			135					
GREEN		130		118	118	103	103			136					
RED ARROW	125									131					
YELLOW ARROW	126			117						132					
GREEN ARROW	127			118	118	103				133					
Hand icon															
Person icon															

NU = Not Used

INPUT FILE POSITION LAYOUT

(front view)




EX.: 1A, 2A, ETC. = LOOP NO.'S

FS = FLASH SENSE
 ST = STOP TIME

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
1A	TB2-1,2	I1U	56	18	1	1	Y	Y			3
2A	TB2-5,6	I2U	39	1	2	2	Y	Y			
2B	TB2-7,8	I2L	43	5	12	2	Y	Y			
3A	TB4-9,10	I6U	41	3	4	3	Y	Y			3
3B	TB4-11,12	I6L	45	7	14	3	Y	Y			3
4A	TB6-1,2	I7U	65	27	34	4	Y	Y			3
4B	TB6-3,4	I7L	78	40	44	4	Y	Y			3
5A	TB3-1,2	J1U	55	17	5	5	Y	Y			3
6A	TB3-5,6	J2U	40	2	6	6	Y	Y			

INPUT FILE POSITION LEGEND: J2L



THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 04-0367T
 DESIGNED: March 2012
 SEALED: 5/3/12
 REVISED: N/A

Signal Upgrade (Temporary Signal - Phase I)

ELECTRICAL AND PROGRAMMING DETAILS FOR: **US 13 (Berkeley Boulevard) at SR 1003 (New Hope Road)**

Prepared In the Offices of: **Wayne County Department of Transportation Signal Management System**

Division 4 Wayne County Goldsboro

PLAN DATE: **May 2012** REVIEWED BY: **JTR**



PREPARED BY: **S. Armstrong** REVIEWED BY:

REVISIONS: INIT. DATE

Signature: **John T. Rowland** 5-4-12
 SEAL: NORTH CAROLINA PROFESSIONAL ENGINEER 008453
 SIG. INVENTORY NO. 04-0367T

**EDI MODEL 2018ECL-NC CONFLICT MONITOR
PROGRAMMING DETAIL**

(remove jumpers and set switches as shown)



- NOTES:**
1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
 2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
 3. Ensure that Red Enable is active at all times during normal operation.
 4. Connect serial cable from conflict monitor to comm. port 1 of 2070 controller. Ensure conflict monitor communicates with 2070.

NOTES

1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
2. Enable Simultaneous Gap-Out for all phases.
3. Program phases 2 and 6 for Variable Initial and Gap Reduction.
4. Program phases 2 and 6 for Start Up In Green.
5. Program phases 2 and 6 for Yellow Flash.
6. The cabinet and controller are part of the Goldsboro City System.

EQUIPMENT INFORMATION

CONTROLLER.....2070L
 CABINET.....332
 SOFTWARE.....ECONOLITE OASIS
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...12
 LOAD SWITCHES USED.....S1,S2,S4,S5,S7,S8
 PHASES USED.....1,2,3,4,5,6
 OVERLAPS.....NONE


SIGNAL HEAD HOOK-UP CHART

LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12			
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16			
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED			
SIGNAL HEAD NO.	11	21,22	NU	22	31	32	41	42	NU	51	61,62	NU	NU	NU	NU
RED		128		116	116	101	101			134					
YELLOW		129		117	117	102	102			135					
GREEN		130		118	118	103	103			136					
RED ARROW	125									131					
YELLOW ARROW	126			117						132					
GREEN ARROW	127			118	118	103				133					

NU = Not Used

INPUT FILE POSITION LAYOUT

(front view)




EX.: 1A, 2A, ETC. = LOOP NO.'S
 FS = FLASH SENSE
 ST = STOP TIME

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT ASSIGNMENT NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND	FULL TIME DELAY	STRETCH TIME	DELAY TIME
1A	TB2-1,2	I1U	56	18	1	1	Y	Y			3
2A	TB2-5,6	I2U	39	1	2	2	Y	Y			3
3A	TB4-9,10	I6U	41	3	4	3	Y	Y			3
3B	TB4-11,12	I6L	45	7	14	3	Y	Y			3
4A	TB6-1,2	I7U	65	27	34	4	Y	Y			3
4B	TB6-3,4	I7L	78	40	44	4	Y	Y			3
5A	TB3-1,2	J1U	55	17	5	5	Y	Y			3
6A	TB3-5,6	J2U	40	2	6	6	Y	Y			
*S01	TB6-9,10	I9U	60	22	11	SYS					
*S02	TB6-11,12	I9L	62	24	13	SYS					

* System detector only. Remove the vehicle phase assigned to this detector in the default programming.

INPUT FILE POSITION LEGEND: J2L



THIS ELECTRICAL DETAIL SUPERSEDES THE DETAIL SEALED ON 4-11-12.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 04-0367
 DESIGNED: March 2012
 SEALED: 4/11/12
 REVISED: N/A

Signal Upgrade - Final

ELECTRICAL AND PROGRAMMING DETAILS FOR: **US 13 (Berkeley Boulevard) at SR 1003 (New Hope Road)**

Prepared In the Offices of: **John T. Rowley, PE**

Division 4 Wayne County Goldsboro

PLAN DATE: **May 2012** REVIEWED BY: **JTR**

PREPARED BY: **S. Armstrong** REVIEWED BY:

REVISIONS INIT. DATE


Signature: **John T. Rowley** 5-4-12
 SEAL: NORTH CAROLINA PROFESSIONAL ENGINEER 008453
 SIG. INVENTORY NO. 04-0367

04-MAY-2012 09:10 S:\ITS\SUM\ITS S\proj\sm\trng\groups\sig Mon\Armstrong\040367_sm_elec_001.dgn

STATE OF NORTH CAROLINA DIVISION OF HIGHWAYS

STATE	PROJECT NO.	SHEET NO.
N.C.	U-3605A	Sig. 12
F. A. PROJ. NO.		M 1
PROJECT ID. NO.		

STANDARD DRAWINGS FOR METAL POLES



WIND ZONE LEGEND

WIND ZONE 1 (140 mph) Special Wind Zone	
WIND ZONE 2 (130 mph) Coastal Region	
WIND ZONE 3 (110 mph) Eastern Region	
WIND ZONE 4 (90 mph) Central & Mtn. Region	
WIND ZONE 5 (120 mph) Special Wind Zone	

<http://www.ncdot.org/doh/preconstruct/traffic/ITSS/ws/mpoles/poles.html>

Prepared In the Offices of:



750 N. Greenfield Pkwy, Garner, NC 27529

Designed in conformance
with the
2002 Interim to the
4th Edition 2001

AASHTO

Standard Specifications for
Structural Supports for
Highway Signs, Luminaires,
and Traffic Signals

INDEX OF PLANS


DRAWING NUMBER	DESCRIPTION
M 1	Title Sheet
M 2	Fabrication Details - All Poles
M 3	Fabrication Details - Strain Poles
M 4,5	Fabrication Details - Mast Arm Poles
M 6	Construction Details - Strain Poles
M 7	Construction Details - Foundations
M 8	Standard Strain Poles

NCDOT CONTACTS:


MOBILITY AND SAFETY DIVISION - ITS and SIGNALS UNIT

- G. A. Fuller, P.E. - State ITS and Signals Engineer
- G. G. Murr, Jr., P.E. - State Signals Engineer
- D. C. Sarkar, P.E. - ITS and Signals Senior Structural Engineer
- C. F. Andrews, Jr. - ITS and Signals Structural Project Engineer
- M. Aslam - ITS and Signals Structural Project Engineer
- N. Bitting, P.E. - ITS and Signals Structural Project Engineer

SEAL




D. Sarkar 7.21.2003
SIGNATURE DATE



Note: Unless otherwise specified, locate Terminal Compartment 1 foot above the pole base plate at 180 degrees on the pole's radial index.

Terminal Compartment Detail



Construct Templates and Plates from 1/4" min. thick Steel. Galvanizing is not required.
Base Plate Template and Anchor Bolt Lock Plate Details

MFG _____ MFG. DATE: MM/YY
 SHAFT D/T/L/Y _____
 ARM-A D/T/L/Y _____
 ARM-B D/T/L/Y _____
 A.B. DIA./B.C./L/Y _____
 NCDOT STANDARD _____


MFG _____ MFG. DATE: MM/YY
 SECTION D/T/L/Y _____
 NCDOT STANDARD _____

Arm I.D. Tag
 (Provide on each section of a multi-section mast arm)


Shaft I.D. Tag
 (Provide on Strain Poles and Mast Arm Poles)

- Notes:
- 1) D= Diameter, T= Thickness, L= Length, Y= Yield Strength
 - 2) A.B. = Anchor Bolt
 - 3) B.C. = Bolt Circle of Anchor Bolts
 - 4) If Custom Design, use "NCDOT STANDARD" line for plan pole I.D.
 - 5) See drawing M4 for mounting positions of I.D. tags.

Identification Tag Details



Anchor Bolt Detail




Prepared in the Office of:


 Typical Fabrication Details Common To All Metal Poles
 PLAN DATE: May 2005 REVIEWED BY: C.F. Andrews
 PREPARED BY: P.L. Alexander REVIEWED BY: A.W. Esposito
 SCALE: 0 NA NONE
 SIGNATURE: D. Sarker 22.2005
 DATE: 22.2005
 SEAL: NORTH CAROLINA PROFESSIONAL ENGINEER SEAL 028094 DEBESH C. SARKAR
 SIG. INVENTORY NO.

Fabrication Details - All Poles

01-SEP-2005 18:22 D:\2004_Metrol_Pole_Standards\04_mf thru mf.dgn




Cable Entrances at Top of Pole




Section B-B
(See drawing M2)
Pole Base Plate

2 Cable Clamps designed for variable attachment heights from 1'-6" to 10' below the top of the pole.




Monotube Strain Pole
(.14"/Foot Taper)



Section A-A

Radial Orientation for Factory Installed Accessories at Top of Pole




Section C-C

Socket Connection Weld Detail

	<p>Typical Fabrication Details For Strain Poles</p>		
	<p>PLAN DATE: May 2005</p>	<p>REVIEWED BY: C.F. Andrews</p>	
<p>222 N. McDowell St., Raleigh, NC 27603</p>	<p>PREPARED BY: P.L. Alexander</p>	<p>REVIEWED BY: A.M. Esposito</p>	<p>Signature: P. L. Alexander Date: 9.2.2005</p>
<p>REVISIONS</p>	<p>INIT.</p>	<p>DATE</p>	<p>STG. INVENTORY NO.</p>


01-SEP-2005 14:07 C:\P\2005\unit\new\p\p\0505004 metal pole standard\05004 ns.dgn

Construction Details - Strain Poles




Note: Strap all signal cables to the side of the pole with $\frac{3}{4}$ " stainless steel straps when the distance between the spanwire attachment clamp and the weatherheads exceeds 36"

Strain Pole Attachments



Attachment of Cable to Intermediate Metal Pole




Metal Pole Grounding Detail

01-SEP-2005 16:33
w:\peop\lee-un11\work\groups\2004 metal pole standard\2004 mb.dgn
p1\text\mb

	Construction Details Strain Poles		
	PLAN DATE: May 2005 PREPARED BY: C.F. ANDREWS	REVIEWED BY: P.L. ALEXANDER REVIEWED BY: D.C. SARKAR	
SCALE: 0 NA NONE	REVISIONS:	INT. DATE:	SIG. INVENTORY NO.:


Reinforcing Steel Bars



REINFORCING STEEL TABLE FOR STANDARD DRILL PIER SHAFT (42" & 48" DIAMETER)

Shaft Dia. (in.)	Conc. Volume (cu. yds.)	Bar Name	No.	Size	Type	Length
42"	.356 x L	V1	9	#8	STR.	**
		C	*	#4	CIR.	10'-9"
48"	.465 x L	V1	12	#8	STR.	**
		C	*	#4	CIR.	12'-6"

* See Note No. 1
** See Note No. 3



Typical "C" Bars

REINFORCING STEEL TABLE FOR STANDARD 42" and 48" DRILL PIER SHAFT WITH TYPE 1 AND TYPE 2 WING WALLS

Wing Wall Type	Drill Pier Shaft Dia. (in.)	Reinforcing Steel					
		Bar Name	No.	Size	Type	Length	
TYPE 1	42"	V1	9	#8	STR.	**	
		V2	12	#4	STR.	2'-6"	
		H	8	#4	STR.	6'-0"	
		C	*	#4	CIR.	10'-9"	
TYPE 2	42"	V1	9	#8	STR.	**	
		V2	16	#4	STR.	4'-6"	
		H	12	#4	STR.	9'-0"	
		C	*	#4	CIR.	10'-9"	
TYPE 2	48"	V1	12	#8	STR.	**	
		V2	16	#4	STR.	4'-6"	
		H	12	#4	STR.	9'-6"	
		C	*	#4	CIR.	12'-6"	

* See Note No. 1
** See Note No. 3


WING WALL DETAILS

Wing Wall Type	Wing Wall Length (ft.)	Wing Wall Width (ft.)	Wing Wall Depth (ft.)	Concrete Volume (Cu. Yds.)
TYPE 1	1'-6"	1'-0"	3'-0"	.4
TYPE 2	3'-0"	1'-0"	5'-0"	1.2


See Note No. 4

Typical Foundation Anchor Bolt Details

(Reinforcing Cage Not Shown for Clarity)



Typical Foundation Conduit Details



Notes

- The number of C-bars is based on foundation depth. For standard foundations, see sheet M 8.
- Circular tie reinforcing rings may be vertically adjusted by +/- 3" at a depth between 2'-0" and 3'-0" to facilitate the installation of electrical conduit entering in the cage.
- The length of V1-bars is based on foundation depth. For standard foundations, see sheet M 8.
- The quantities for steel and concrete shown in the Wing Wall Details Chart reflect the amount of material for 1 pair of wing walls (2 wing walls per drilled pier shaft.)

Construction Details - Foundations

Prepared in the Office of:

Construction Details Foundations

PLAN DATE: May 2005 REVIEWED BY: P. L. ALEXANDER
 PREPARED BY: C. F. ANDREWS REVIEWED BY: A. M. ESPOSITO

SCALE: 0 NA NONE

REVISIONS: _____ INIT. DATE _____

SIGNATURE: *D. Saarkar* 9.2.2005 DATE
 SIG. INVENTORY NO. _____

